

## Product Specifications

Model Name	FS22GA FS22TA
Width x Depth x Height (mm) (Max.)	715 x 426 x 947
Weight (kg)	6.7

### ⚠ CAUTION


- This stand is designed exclusively for TVs manufactured by LG Electronics Inc. For compatible TV series, please refer to the below table.
- Using it with other equipment may render it unstable and cause injury.

## Precautions before Installation

- The floor stand does not include a power strip. To power the TV and use connected devices with the floor stand, buy and use a power strip of an appropriate length (2.5 m or longer is recommended).
- The maximum weight that can be placed on the rear bracket of the floor stand is 1.5 kg.
- If you place a wireless router on the rear bracket of the floor stand, the TV's artificial intelligence remote control may not operate properly due to frequency interference that occurs when the wireless antenna inside the TV and the wireless router are close to each other.
- If you place a set-top box on the rear bracket of the floor stand, it can block the remote control reception unit of the set-top box, making it difficult to receive remote control signals. (If this remote control operation problem continues, you can use an IR repeater extender (remote control signal extension cable) to solve the problem.)

## IR Repeater Mounting Guide

- For the positions of installation, please refer to **A** - **C** of Figure 10 in the installation manual.

<b>A</b> Reception unit	Lower part Attach with  facing forwards.
<b>B</b> Transmission unit	Reception unit of the set-top box
<b>C</b> Power connection unit	USB terminal of the TV or the set-top box

## Models Compatible with the Floor Stand

### Compatible Model Released in 2020

Product Group	Inches	Series
OLED	48	CX

### Compatible Model Released in 2021


Product Group	Inches	Series
OLED	48	A1 C1

### Compatible Model Released in 2022

Product Group	Inches	Series
OLED	42	C2
	48	A2 C2




## How to Prevent TV from Falling



- 1 Fix the brackets on the rear part of the product and on the wall as shown in the picture. Secure the product brackets and wall brackets at the same height.
- 2 Verify that the product brackets and wall brackets are firmly fastened.
- 3 Using a strong cord, tie and connect the product brackets to the wall brackets. When moving a product installed in this way, please untie the cord first.
  - Install the TV in the horizontal position only.
  - It is safe to install the product according to the installation method to prevent the damage to the product or personal injury even if the product is pulled forward.
  - Install the TV near a wall to prevent falls when pushed.
  - The brackets, screws, and cords must be purchased separately as they are not provided with the product.

## How to Adjust the Height on Both Sides of the TV on Floor Stand



- Loosen the screw halfway by using a Phillips screwdriver, adjust the height on both sides of the TV as illustrated, and tighten the screw.

### CAUTION

- Do not place an object or step on the floor stand.
- Do not pull or push the floor stand.