



## SIMPLE MANUAL

# Mini Hi-Fi Audio

ENGLISH

Please read this manual carefully before operating your set and retain it for future reference.

To view the instructions of advanced features, visit <http://www.lg.com> and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL

ON66



MFL71664369

2004\_Rev02

[www.lg.com](http://www.lg.com)

Copyright © 2021-2022 LG Electronics Inc. All Rights Reserved.



## Top panel

- 
- 1** (Standby)  
Turns the power on or off.
- 2** **DEMO**  
In power off status, if you press **DEMO**, show demo mode.
- 3** USB 1 Port  
You can play sound files by connecting the USB device.
- 4** Display window
- 5** USB 2 Port  
You can play sound files by connecting the USB device.
- 6** **F** (Function)  
Selects the function and input source.
- 7** **LIGHTING**  
Selects the lighting mode.
- 8** **TWIN**  
Connects two units for TWIN mode in WIRELESS PARTY LINK.
- 9** (Skip/Search)  
- Skips backward or forward.  
- Searches for a section within a track/file.  
- Selects the radio stations.
- (Play/Pause)  
- Starts or pauses playback.  
- Selects stereo/mono.  
- **Bluetooth** connection lock (BT LOCK): Select the **Bluetooth** function by pressing **F** repeatedly. And long press to limit **Bluetooth** connection to only BT and LG TV.
- 10** (Auto Music Play)  
Plays the audio currently playing by tagging the mobile (with "LG XBOOM" App) to this unit. (Android Only)
- 11** **VOICE CANCELLER**  
You can reduce the vocal tones during music playback from various input sources.
- (Open/Close)  
Opens and closes the disc tray.
- 12** **CLUB, DRUM, USER** (DJ PAD)  
Selects CLUB, DRUM or USER sound effect to mix.  
(If you want to use USER, you have to register a source with "LG XBOOM" app. (Android Only))
- 1, 2, 3** (DJ PAD)  
Press a desired sound pad.
- 13** **MIC** (Microphone) **ECHO**  
Selects ECHO mode.
- VOCAL EFFECTS**  
Selects various vocal effects mode.
- KEY CHANGER** () **#**  
Changes the key to suit your vocal range.
- 14** Remote sensor
- 15** **SPECIAL EQ / BASS BLAST** (or **BASS BLAST+**)  
- Chooses special equalizer.  
- Press and hold to select **BASS** (or **BASS+**) effect directly.

(Stop)

Stops playback or cancels DELETE function.

**VOL** (Volume) **-/+**

Adjusts speaker volume.

**MIC** (Microphone) / **GUITAR** **-/+**

Adjusts Microphone volume or Guitar volume.

**10** (Auto Music Play)

Plays the audio currently playing by tagging the mobile (with "LG XBOOM" App) to this unit. (Android Only)

**11** **VOICE CANCELLER**

You can reduce the vocal tones during music playback from various input sources.

(Open/Close)

Opens and closes the disc tray.

**12** **CLUB, DRUM, USER** (DJ PAD)

Selects CLUB, DRUM or USER sound effect to mix.

(If you want to use USER, you have to register a source with "LG XBOOM" app. (Android Only))

**1, 2, 3** (DJ PAD)

Press a desired sound pad.

**13** **MIC** (Microphone) **ECHO**

Selects ECHO mode.

**VOCAL EFFECTS**

Selects various vocal effects mode.

**KEY CHANGER** () **#**

Changes the key to suit your vocal range.

**14** Remote sensor

**15** **SPECIAL EQ / BASS BLAST** (or **BASS BLAST+**)

- Chooses special equalizer.

- Press and hold to select **BASS** (or **BASS+**) effect directly.

**SEARCH**

Moves to folder or file in selection mode.

**OK**

Selects a folder when searching a file.

**USER EQ**

Selects the equalizer created by your own.


**Multi jog**

- Searches a folder or a file.


- Turns clockwise or counterclockwise to control the USER EQ level.

- Chooses special equalizer.

## Front panel / Rear panel



- 1** Disc tray
- 2** Lighting
- 3** Remote sensor



- 4** GUITAR IN: Connect a guitar.
- 5** MIC (Microphone) IN: Connect a microphone.
- 6** ANTENNA (FM)
- 7** AC IN socket

### Controller App



Android



iOS

Download the **LG XBOOM** App to your device.


### LG Sound Sync (Wireless)



For more information, download the online owner's manual. <http://www.lg.com>

## Additional Information

### Specifications

|                        |  |
|------------------------|--|
| Power Requirements     | Refer to the main label on the unit.   |
| Power Consumption      | Refer to the main label on the unit.   |
|                        | Networked standby : 0.5 W<br>(If all network ports are activated.)                           |
| Dimensions (W x H x D) | Approx. 330.0 mm x 685.0 mm x 344.0 mm   |
| Bus Power Supply (USB) | 5 V  500 mA |

Design and specifications are subject to change without notice.

### Caution

- Connect the power cord to wall outlet directly if possible. Or when you use an extension cable, it is highly recommended to use an extension cable of 110 V / 15 A or 230 V / 15 A, otherwise the unit may not operate properly because of the lack of power supply.
- Do not overload the extension cord with excessive electrical load.


### Note

- Do not look directly at the light emitting part when the LIGHTING is turned on.
- If the illumination brightness is glaring, switch on the room lights or turn off the LIGHTING of the unit.

### How to disconnect the wireless network connection or the wireless device

Turn off the unit by pressing the power button for more than 5 seconds.

### Replacement of battery



### Declaration of Conformity



Hereby, LG Electronics declares that the radio equipment type MINI HI-FI AUDIO is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<http://www.lg.com/global/support/cedoc/cedoc#>

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.



-----

-----

-----

-----

-----

-----

-----

-----

-----

-----



-----

-----

-----

-----

-----

-----

-----

-----

-----

-----



-----

-----

-----

-----

-----

-----

-----

-----

-----

-----



#### **Российская Федерация**

Импортер ООО "ЛГ Электроникс Рус"

Адрес импортера: 143160, Российская Федерация, Московская область, Рузский городской округ, территория Минское шоссе, километр 86-й, дом 9

Адрес производителя : ЛГ Электроникс (Хужоу) Инк., завод Хатаи  
516006, Китай, пров. ГуанДонг, г. Хужоу, Промышленная зона  
Жонгкай, Индустриальный парк Хутай, ХуФенг Донг Уи Роуд, 13.

**Сделано в Китае**

#### **Україна**

Вироблено в : ЛГ Електронікс (Хужоу) Інк., завод Хатай  
516006, Китай, пров. ГуанДонг, м. Хужоу, Промислова зона Жонгкай,  
Індустріальний парк Хутай, ХуФенг Донг Уі Роуд, 13.

#### **Қазақстан Республикасы**

Импорттаушы АҚ "ЭЛ Джи Электроникс Алматы Қазақстан", 050061, Алматы қ., Көкорай көшесі, 2А/9

Өндірушінің мекенжайы: LG Electronics(Huizhou) Inc. Huitai Factory  
516006, Қытай, ГуанДонг ауданы, Хужоу қаласы,  
Жонгкай өнеркәсіптік аймағы, Хутай Индустриялық саябағы,  
ХуФенг Донг Уи Роуд, 13.

Қазақстан Республикасы территориясында тұтынушылардан келіп түскен талаптар мен ұсыныстарды қарайтын және тауарды жөндеу мен техникалық қызмет көрсететін ұжым:

АҚ «Эл Джи Электроникс Алматы Қазақстан», 050061, Қазақстан Республикасы, Алматы қ., Көкорай көшесі, 2А/9. Басқа сервис орталықтары жайында мағлұматты "Тұтынушыға қызмет көрсету орталығына" телефон шалу арқылы білуге болады.

**Қытайда жасалған**