



Network 3D Blu-ray Disc™/DVD Player

BP420

ENGLISH | SIMPLE MANUAL

To view the instructions of advanced features, visit <http://www.lg.com> and then download Owner's Manual. Some of the content in this manual may differ from your unit.

DEUTSCH | KURZANLEITUNG

Anleitungen zu den erweiterten Funktionen finden in der Bedienungsanleitung, die Sie unter <http://www.lg.com> herunterladen können. Bestimmte Inhalte in dieser Bedienungsanleitung unterscheiden sich unter Umständen von Ihrem Gerät.

FRANÇAIS | MANUEL Simplifié


Pour connaître les instructions des fonctionnalités avancées, visitez le site <http://www.lg.com> et téléchargez le manuel d'utilisation. Il est possible qu'une partie du contenu de ce manuel diffère de votre lecteur.

ESPAÑOL | MANUAL SIMPLE

Para ver las instrucciones de las funciones avanzadas, visite <http://www.lg.com> y descargue el manual del propietario. Cierta contenido en este manual puede ser diferente del de su unidad.


ITALIANO | MANUALE SEMPLIFICATO

Per visualizzare le istruzioni delle caratteristiche avanzate, visita il sito <http://www.lg.com> e scarica il manuale del proprietario. Alcuni dei contenuti di questo manuale possono essere diversi da quelli del tuo lettore.




Audio/Video cables


TV Connection (HDMI OUT) / TV-Verbindung (HDMI OUT) / Raccordement télé (HDMI OUT) / Conexión de TV (HDMI OUT) / Collegamento TV (HDMI OUT)




TV Connection (VIDEO OUT) / TV-Verbindung (VIDEO OUT) / Raccordement télé (VIDEO OUT) / Conexión de TV (VIDEO OUT) / Collegamento TV (VIDEO OUT)




Wired Network Connection / Kabel-Netzwerkverbindung / Connexion à un réseau filaire / Conexión a red por cable / Connessione di rete cablata



Safety Information / Sicherheitshinweise / Consignes de sécurité / Información de seguridad / Informazioni di sicurezza



Software Update / Software-Update / Mise à jour du logiciel / Actualización del software / Aggiornamento del software



Customer Support

You can update the Player using the latest software to enhance the products operation and/or add new features. To obtain the latest software for this player (if updates have been made), proceed the software updates as above or visit <http://www.lg.com> or contact LG Electronics customer care centre.

Kundendienst

Die Software des Players kann auf die neueste Version aktualisiert werden, um den Funktionsumfang zu erweitern und/oder neue Funktionen hinzuzufügen. Um die neueste Software-Version für diesen Player zu erhalten (falls Updates durchgeführt wurden), führen Sie wie oben beschrieben einen Software-Update durch, gehen Sie auf <http://www.lg.com> oder kontaktieren Sie das Kundendienst-Center von LG Electronics.

Support client

Vous pouvez mettre à jour le lecteur avec les logiciels les plus récents afin d'améliorer son fonctionnement et/ou d'ajouter de nouvelles fonctionnalités. Pour obtenir le logiciel le plus récent de ce lecteur (si les mises à jour ont été effectuées), faites les mises à jour du logiciel comme indiqué ci-dessus ou visitez <http://www.lg.com> ou contactez le service clientèle de LG Electronics.


Asistencia al cliente

Es posible actualizar el reproductor con el software más reciente para mejorar el funcionamiento de los productos o agregar nuevas funciones. Para conseguir el software más reciente para este reproductor (en caso de que se hayan hecho actualizaciones), realice las actualizaciones de software como se muestra anteriormente, entre en <http://www.lg.com> o póngase en contacto con el centro de atención al cliente de LG Electronics.


Assistenza clienti

Potete aggiornare il lettore usando il software più recente per migliorare il funzionamento del prodotto e/o aggiungere nuove funzionalità. Per ottenere il software più recente per il player (se sono stati fatti gli aggiornamenti), effettuare gli aggiornamenti software come sopra o visitare il sito o contattare il centro assistenza clienti LG Electronics a <http://www.lg.com>.

Disc Playback / Disk-Wiedergabe / Lecteur de disque / Reproducción de discos / Riproduzione disco





Data Playback / Datenwiedergabe / Lecteur de données / Reproducción de datos / Riproduzione dati






Using HOME menu / Verwendung HOME-Menü / Utilisant le menu ACCUEIL / Uso del menú HOME / Utilizzo menù HOME




[Music] - Plays audio contents.
[Musik] - Wiedergabe von Musik.
[Musique] - Lit le contenu audio.
[Música] - Reproduce contenidos de audio.
[Musica] - Visualizza i contenuti di audio.



[Movie] - Plays video contents.
[Spielfilm] - Wiedergabe von Videos.
[Film] - Lit le contenu vidéo.
[Película] - Reproduce contenidos de video.
[Video] - Visualizza i contenuti di video.



[Photo] - Plays photo contents.
[Foto] - Wiedergabe von Fotos.
[Photo] - Lit le contenu photo.
[Foto] - Reproduce contenidos de foto.
[Foto] - Visualizza i contenuti di foto.



[Premium] - Displays the Premium Home screen.
[Premium] - Premium-Startbildschirm aufrufen.
[Premium] - Permet d'afficher l'écran d'accueil Premium.
[Premium] - Muestra la pantalla de inicio Premium.
[Premium] - Visualizza la schermata Home Premium.






[Setup] - Adjusts the system settings.
[Setup] - Systemeinstellungen aufrufen.
[Config.] - Donne accès à la configuration du système.
[Config.] - Ajusta la configuración del sistema.
[Impostaz.] - Regola le impostazioni del sistema.



[LG Apps] - Displays the [LG Apps] screen.
[LG-Apps] - Anzeige des [LG-Apps]-Bildschirms.
[LG Apps] - Affiche l'écran [LG Apps].
[LG Apps] - Muestra la pantalla de las aplicaciones para TV [LG Apps].
[LG Apps] - Visualizza la schermata [LG Apps].



On-Screen Display / On Screen-Anzeige / Affichage sur écran / Presentación en pantalla / On-Screen Display



Disc	Title / Titel / Titre / Título / Titolo
Chapter	Chapter / Kapitel / Chapitre / Capítulo / Capitolo
Time	Time / Zeit / Heure / Tiempo / Tempo
Audio	Audio / Audio / Audio / Audio / Audio
Subtitle	Subtitle / Untertitel / Sous-titrage / Subtítulo / Sottotitolo
Angle	Angle / Winkel / Angle / Angulo / Angolo
TV Aspect Ratio	TV Aspect Ratio / Bildformat / Format d'image / Aspecto TV / Aspetto TV
Picture Mode	Picture Mode / Bildmodus / Mode image / Modo de imagen / Mod. immagine



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING: TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

WARNING: Do not install this equipment in a confined space such as a book case or similar unit.

CAUTION: Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock.

CAUTION: No naked flame sources, such as lighted candles, should be placed on the apparatus.

CAUTION: Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings shall be never be blocked by placing the product on a bed, sofa, rug or other similar surface.

This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.

CAUTION concerning the Power Cord
To disconnect power from the mains, pull out the mains cord plug. When installing the product, ensure that the plug is easily accessible.

CAUTION: The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.

This device is equipped with a portable battery or accumulator.

Safety way to remove the battery or the battery from the equipment: Remove the old battery or battery pack, follow the steps in reverse order than the assembly. To prevent contamination of the environment and bring on possible threat to human and animal health, the old battery or the battery put it in the appropriate container at designated collection points. Do not dispose of batteries or battery together with other waste. It is recommended that you use local, free reimbursement systems batteries and accumulators. The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

Disposal of your old appliance

1. This crossed-out wheeled bin symbol indicates that waste electrical and electronic products (WEEE) should be disposed of separately from the municipal waste stream.
2. Old electrical products can contain hazardous substances so correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health. Your old appliance may contain reusable parts that could be used to repair other products, and other valuable materials that can be recycled to conserve limited resources.
3. You can take your appliance either to the shop where you purchased the product, or contact your local government waste office for details of your nearest authorised WEEE collection point. For the most up to date information for your country please see www.lg.com/global/recycling




Disposal of waste batteries/accumulators

1. This symbol may be combined with chemical symbols for mercury (Hg), cadmium (Cd) or lead (Pb) if the battery contains more than 0.0005% of mercury, 0.002% of cadmium or 0.004% of lead.
2. All batteries/accumulators should be disposed separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
3. The correct disposal of your old batteries/accumulators will help to prevent potential negative consequences for the environment, animal and human health.




4. For more detailed information about disposal of your old batteries/accumulators, please contact your city office, waste disposal service or the shop where you purchased the product. (<http://www.lg.com/global/sustainability/environment/take-back-recycling/global-network-europe>)



Network Playback / Netzwerkwiedergabe / Lecteur en réseau / Reproducción en red / Riproduzione rete



On Line Content / Online-Inhalte / Contenus en ligne / Contenidos en línea / Contenuti on-line



Specification / Technische Daten / Spécifications / Especificaciones / Specifiche

ENGLISH

Power requirements	200-240 V ~, 50-60 Hz
Power consumption	12 W
Dimensions (W x H x D)	Approx. 430 x 41 x 188 mm
Net Weight (Approx.)	1.6 Kg
Bus Power Supply (USB)	5 V $\overline{\text{---}}$ 500 mA

Design and specifications are subject to change without notice.

DEUTSCH

Stromversorgung	200-240 V ~, 50-60 Hz
Leistungsaufnahme	12 W
Abmessungen (B x H x T)	Ca. 430 x 41 x 188 mm
Gesamtgewicht (ca.)	1,6 Kg
Stromversorgung über Bus (USB)	5 V $\overline{\text{---}}$ 500 mA

Änderungen der Ausführung und der technischen Daten ohne vorherige Ankündigung vorbehalten.

FRANÇAIS

Alimentation	200-240 V ~, 50-60 Hz
Consommation électrique	12 W
Dimensions (L x H x P)	Approximativement 430 x 41 x 188 mm
Poids net (approx.)	1,6 Kg
Bus Power Supply (USB)	5 V $\overline{\text{---}}$ 500 mA

La conception et les spécifications sont sujettes à modification sans préavis.

ESPAÑOL

Requisitos de alimentación	200-240 V ~, 50-60 Hz
Consumo de energía	12 W
Dimensiones (A x Alt x F)	Aprox. 430 x 41 x 188 mm
Peso neto (aprox.)	1,6 Kg
Alimentación bus (USB)	5 V $\overline{\text{---}}$ 500 mA


El diseño y las especificaciones están sujetas a cambio sin previo aviso.

ITALIANO

Requisiti di alimentazione	200-240 V ~, 50-60 Hz
Assorbimento energetico	12 W
DIMENSIONI (L x A x P)	Approx. 430 x 41 x 188 mm
Peso netto (approssimativo)	1,6 Kg
Alimentazione tensione bus (USB)	5 V $\overline{\text{---}}$ 500 mA

Il design e le specifiche tecniche sono soggette a cambiamento senza preavviso.

Replacement of battery / Auswechseln der Batterie / Remplacement de la pile / Sustitución de la pila / Sostituzione della batteria



Open source software notice

To obtain the corresponding source code under GPL, LGPL and other open source licenses, please visit <http://opensource.lge.com>. All referred license terms, warranty disclaimers and copyright notices are available to download with the source code.

Hinweise zu Open Source-Software

Eine Kopie der GPL, LGPL- und anderer Open Source-Genehmigungen finden Sie unter <http://opensource.lge.com>.
Alle angegebene Lizenzbedingungen, Haftungsausschlüsse und Hinweise zum Urheberrecht stehen als Quellcode zum Download bereit.

Avis concernant les logiciels open source

Pour connaître le code source correspondant de GPL, LGPL et d'autres licences open source, rendez-vous sur <http://opensource.lge.com>. Les conditions de licence, les dénis de responsabilités et les avis concernant les droits d'auteur sont disponibles en téléchargement avec le code source.

Aviso sobre el software de código abierto

Para obtener el correspondiente código bajo la licencia de GPL, LGPL y otras licencias de código abierto, visite <http://opensource.lge.com>. Todos los terminos referidos, la exclusion de garantía y los avisos de copyright pueden descargarse con código abierto.

Nota di software di libera circolazione

Per ottenere il corrispondente codice di software di libera circolazione in base alle licenze GPL, LGPL e altre, visitate il sito <http://opensource.lge.com>. Tutti i termini relativi a licenza, rivendicazioni di garanzia e note di copyright sono disponibili per lo scaricamento con il codice di sorgente.

