



SIMPLE MANUAL

Mini Hi-Fi System

- ENGLISH
- МАКЕДОНСКИ
- MAGYAR
- POLSKI
- ČESKY
- ROMÂNĂ
- HRVATSKI
- РУССКИЙ
- SRPSKI
- LATVIEŠU
- SLOVENČINA
- ЛИТОВИŪ К.
- БЪЛГАРСКИ
- EESTI

To view the instructions of advanced features,
visit <http://www.lg.com> and then download Owner's Manual.
Some of the content in this manual may differ from your unit.


MODEL
CM4460



www.lg.com




Front Panel



- 1 Display window
- 2 USB1/USB2 : Plays the audio files by connecting the USB device.
- 3 **USB REC.** : Records to USB.
- 4 **⏻/⏹ (Power)** : Switches the unit ON or OFF.
- 5 **⏸ (Stop)** : Stops playback or recording.
- 6 **AUTO DJ** : Selects the AUTO DJ mode.
- 7 **⏮ (Skip/Search)** : Searches backward. / Skips to the previous track/file.
- 8 **DEMO / RDS** : Shows demo mode. / RDS (Radio Data System)
- 9 **PORT. IN**
- 10 Disc tray
- 11 **F / WIRELESS BOOM** : Selects the function and input source. / Press and hold for 3 seconds to select Wireless X-Boom Plus mode.
- 12 **⏪** : Starts or pauses playback. / Selects Stereo/Mono.
- 13 **REGION EQ** : Chooses region equalizer.
- 14 **⏭ (Skip/Search)** : Searches forward. / Skips to the next track/file.
- 15 **BASS BLAST** : Selects BASS effect directly.
- 16 **MASTER VOLUME** : Adjusts volume of speaker.
- 17 **⏴ (Open/Close)** : Opens or closes the disc tray.

Rear Panel



- 1 POWER IN
- 2 AUX IN (L/R) connectors
- 3 ANTENNA (FM)
- 4 SPEAKERS terminal

Controller App




Download the **Music Flow Bluetooth** App to your device.

LG Sound Sync (Wireless)



For more information, download the online owner's manual. <http://www.lg.com>


Speaker Connection



How to disconnect the wireless network connection or the wireless device

Turn off the unit by pressing the power button for more than 5 seconds.

Replacement of battery



Additional Information

Specifications

Power Requirements	Refer to the main label on the unit.
Power Consumption	Refer to the main label on the unit. Networked standby : 0.5 W (If all network ports are activated.)
Dimensions (W x H x D)	Approx. 206 mm x 308 mm x 284 mm
Net Weight	Approx. 3 kg
Bus Power Supply (USB)	5 V 500 mA
Amplifier (Total RMS output power)	460 W

Design and specifications are subject to change without notice.

Declaration of Conformity

CE 0197

Hereby, LG Electronics European Shared Service Center BV, declares that this MINI HI-FI SYSTEM is compliant with the essential requirements and other relevant provisions of Directive 1999/5/EC. The complete Declaration of Conformity may be requested through the following postal address:

LG Electronics European Shared Service Center BV.
Krijgsman 1
1186 DM Amstelveen
The Netherlands

or can be requested at our dedicated DoC website:
<http://www.lg.com/global/support/cedoc/cedoc#>

This device is a 2.4 GHz wideband transmission system, intended for use in all EU member states and EFTA countries.

