






*NANO91SPA




1-A
75NANO91*

















1-B
86NANO91*





2



3





5s



9



1s



型號		86NANO91SPA	75NANO91SPA
尺寸 (寬 x 高 x 深)	含底座 (公釐)	1,925 x 1,177 x 452	1,673 x 1,035 x 405
	不含底座 (公釐)	1,925 x 1,105 x 46.1	1,673 x 963 x 44.9
重量	含底座 (公斤)	59.1	41.6
	不含底座 (公斤)	55.3	38.2
電源需求		AC 110 V ~ 60 Hz	AC 110 V ~ 60 Hz



- 簡易設定指南
- 操作電視機之前，請先詳細閱讀本手冊，並妥善保管手冊以供日後參考。
- 請閱讀安全與相關資訊

⊕：視型號而定