


Additional Information

Specifications

Power Requirements	Refer to the main label on the unit.
Power Consumption	Refer to the main label on the unit.
Dimensions (W x H x D)	Approx. 451.5 mm x 311.0 mm x 302.5 mm
Bus Power Supply (USB)	5 V  500 mA
Amplifier (Total RMS output power)	220 W RMS

Design and specifications are subject to change without notice.

Replacement of battery



ENGLISH

SIMPLE MANUAL

Portable X Boom Cube

Please read this manual carefully before operating your set and retain it for future reference.
To view the instructions of advanced features, visit <http://www.lg.com> and then download Owner's Manual. Some of the content in this manual may differ from your unit.


MODEL
OK45



www.lg.com
Copyright © 2018 LG Electronics Inc. All Rights Reserved.
1807_Rev02



Front panel



1 (Standby)

Turns the power on or off.

MIC (Microphone) -/+

Adjust microphone volume.

2 **F** (Function)

- Selects the function and input source.
- Press and hold to select the PARTY LINK.

VOCAL EFFECTS

Selects VOCAL EFFECTS mode.

MIC ECHO / DEMO

- Selects ECHO mode.
- In power off status, if you press **MIC ECHO / DEMO**, show demo mode.

LIGHTING

Selects the lighting mode.

3 **MIC** (Microphone) jack

4 Disc tray

5 Display window

6 (Open/Close)

Opens and closes the disc tray.

7 (Remote sensor)

8 USB Port

You can play sound files by connecting the USB device.

9 (Skip/Search)

- Skips forward.
- Searches for a section within a track/file.
- Selects the radio stations.

(Stop)

Stops playback or cancels DELETE function.

(Skip/Search)

- Skips backward.
- Searches for a section within a track/file.
- Selects the radio stations.

(Play/Pause)

Starts or pauses playback.


10 **VOL** (Volume) -/+

Adjusts speaker volume.

WIRELESS LINK

- Selects MAIN or OTHER on WIRELESS PARTY LINK mode.
- Enable or disable WIRELESS PARTY LINK mode

Rear panel



1 Power cord

2 **ANTENNA** (FM)

3 **AUX IN** (L/R) **AUX OUT** (L/R)

Controller App



Download the **Music Flow Bluetooth** App to your device. (Android only)

LG Sound Sync (Wireless)



For more information, download the online owner's manual. <http://www.lg.com>