




Quick Start Guide



www.lg.com

Image may vary depending on models

Unpacking

Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item.

⊕ : Depending on model
Depending on country



English

- Read **Safety and Reference**.
- For the power supply and power consumption, refer to the label attached to the product.


.




CAUTION

Image shown may differ from your TV.
When attaching the stand to the TV set,
place the screen facing down on a
cushioned table or flat surface to protect
the screen from scratches.


1




2




3




4




5





6










HDMI IN/ARC




HDMI IN



USB IN




PCMCIA CARD SLOT





NOTE

Image shown may vary depending on model.
All connection cables & devices shown in the picture are not included
along with the TV set.




ANTENNA /
CABLE IN




Satellite IN





HDMI IN



RS-232C IN
(CONTROL&SERVICE)





LAN








NOTE

Image shown may vary depending on model.
All connection cables & devices shown in the picture are not included
along with the TV set.




NOTE

Image shown may vary depending on model.
All connection cables & devices shown in the picture are not included
along with the TV set.



NOTE

Image shown may vary depending on model.



	A	B	C	D	E	F	F - G
	(mm)					(kg)	
43UT640S0TA	973	623	216	572	85.0	8.1	8.0
Power requirement					AC 100-240 V ~ 50 / 60 Hz		