








43UP7700PSB 43UP8050PSB
43UP7750PSB





OPTICAL DIGITAL
AUDIO OUT



LAN




+

HDMI IN



+

USB IN



USB IN



HDMI IN




HDMI IN

eARC/ARC



ANTENNA /

CABLE IN





5s



9

1s



MODELS	A		B		C		D		E		F		F - G		Power consumption	
MODELOS	(mm)														(kg)	Consumo de potencia
43UP7700PSB 43UP7750PSB 43UP8050PSB	967	967	622	622	216	216	564	564	57.1	57,1	8.9	8,9	8.8	8,8	110 W	
Power requirement / Alimentación requerida										AC 100 V - 240V - 50 / 60 Hz						



ENGLISH Read **Safety and Reference**.
Due to environmental government regulations about imports and battery destruction in Colombia, TVs will not include the batteries for the remote control.

ESPAÑOL Leer **Seguridad y Consultas**.
Por regulaciones de tipo ambiental respecto a la importación y destrucción de baterías en Colombia; los televisores no van a traer incluidas las pilas del control remoto.

ENGLISH
Easy Setup Guide
Please read this manual carefully before operating your set and retain it for future reference.

ESPAÑOL
Guía Rápida de Configuración
Lea atentamente este manual antes de poner en marcha el equipo y consérvelo para futuras consultas.

+ : Depending upon model / Según el modelo