ENGLISH

Specification

Power requirements

- Refer to the main label.

Power consumption

- Refer to the main label.

Receiver Dimensions (W x H x D): Approx. 430.0 mm x 62.5 mm x 307.8 mm

Speaker Dimensions (W x H x D): Approx. 233.0 mm x 998.0 mm x 310.0 mm

Bus Power Supply (USB): 5 V ⎓ 500 mA

Amplifier (Total RMS Output power): 1,000 W RMS

POWER: This unit operates on a mains supply of 200 - 240 V ~ 50 / 60 Hz.

Wiring: This unit is supplied with a BS 1363 approved main plug. When replacing the fuse, always use a fuse of the same rating and approved to BS 1362. Never use this plug with the fuse cover omitted. To obtain a replacement fuse cover contact your dealer. If the type of plug supplied is not suitable for the mains sockets in your home, then the plug should be removed and a suitable type fitted. Please refer to the wiring instructions below:

Warning: A mains plug removsed from the mains lead of this unit must be destroyed. A mains plug with bared wires is hazardous if inserted in a mains socket. Do not connect either wire to the earth pin, marked with the letter E or with the earth symbol ⏚ or coloured green or green and yellow. If any other plug is fitted, use same rating of fuse in the plug.

Important: The wires in this mains lead are coloured in accordance with the following codes:

- BLUE: NEUTRAL, BROWN: LIVE - As the colours of the wires in the mains lead of this unit may not correspond with the coloured marking identifying the terminals in your plug, proceed as follows: The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black. The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

HDMI™

LG

SIMPLE MANUAL


High Power Multimedia Receiver


MR7

COV32056501
2602_Rev01


www.lg.com

Copyright © 2026 LG Electronics Inc.
All Rights Reserved.





Replacement of Battery



ENGLISH

Installing and Using the Product

Please read this manual carefully before operating your set and retain it for future reference.
To view the instructions of advanced features, visit http://www.lg.com or scan QR code and then download Owner's Manual. Some of the content in this manual may differ from your product.

Ⓐ Receiver
Ⓑ Remote Control Receiver / Status Display
Ⓒ External Device - (Blu-ray player, game console, etc.)
Ⓓ Front and Surround (Rear) speaker with built in subwoofer

1 Connecting the receiver with speakers

① Match each wire's coloured band and a woofer cord to the same coloured connection terminal on the rear of the receiver. When connecting a woofer cord to the receiver, insert the connector until it clicks.
② Connect the black striped cable to the negative terminal and the other cable to the positive terminal.

2 Connecting the supplied FM antenna

3 Connecting the receiver to your TV via an optical cable or an HDMI cable

① Press the **Power** button to turn on the receiver.
② Press the **Function** button repeatedly until "**OPT/HDMI ARC**" appears on the status display.
③ On your TV's settings, set the output speaker to [HDMI ARC], [Optical], or [External Speaker].
④ When the TV is properly connected to the product, "**OPT**", "**ARC**" will appear on the status display.

4 If you are using an external device (ex. Blu-ray player, game console, etc.), connect it to the receiver via an HDMI cable.

5 Playing Music from the USB

① Press the **Power** button to turn on the receiver.
② Plug the USB storage device into the USB terminal.
③ Press the **Function** button repeatedly until "**USB**" appears on the status display.
④ Press the **Play/Pause** button to enjoy the music.

6 Connecting a Portable Device

① Press the **Power** button to turn on the receiver.
② Connect the external device to the AUX terminal via a 3.5 mm stereo cable. Product will automatically recognised when connecting a stereo cable. "**AUX**" will appear on the status display.
③ Turn the external device on and start playing.

7 Connecting the product to your smartphone via Bluetooth

① Press the **Power** button to turn on the receiver.
② Tap the **Settings** button on your smartphone and select **Bluetooth**. Turn on the **Bluetooth** function. (Off > On)
③ Press the **Bluetooth pair** button on the remote control. After a moment, you will see "**BT READY**" on the status display.
④ Find and tap the product on your smartphone. The product appears as "LG-MR7(XX)".
⑤ When the product is connected to your smartphone via **Bluetooth**, you can see the status display change from "**PAIRED**" → "**Connected Bluetooth device name**" → "**BT**".

8 Connecting the LG XBOOM App

① Find the **LG XBOOM** app on the Google Play or App Store and install it on your smartphone.
② Run the **LG XBOOM** app and use more features.

- Actual features, functionality, and other product specifications may differ and are subject to change without notice.
- Google Play is a trademark of Google LLC.