




# Quick Start Guide

LED TV  
LH51\*\*



+: Image may vary depending on model.

+: Depending on model

## Unpacking

Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item.




[www.lg.com](http://www.lg.com)

P/No: T 031 JI I FF ÁÍ EGUOXEE

English

- Read **Safety and Reference**.
- For the power supply and power consumption, refer to the label attached to the product.





### CAUTION

Image shown may differ from your TV.


When attaching the stand to the TV set, place the screen facing down on a cushioned table or flat surface to protect the screen from scratches.



ANTENNA/  
CABLE IN



HDMI IN



USB IN




**NOTE**

- Image shown may vary depending on model.
- All connection cables & devices shown in the picture are not included along with the TV set.



**NOTE**


Connect the USB storage device such as a USB flash memory, external hard drive, or a USB memory card reader to the TV and access the Smart Share menu to use various multimedia files.





### NOTE


- Image shown may vary depending on model.
- All connection cables & devices shown in the picture are not included along with the TV set.

### COMPONENT IN



### AUDIO OUT













### NOTE


- Image shown may vary depending on model.
- All connection cables & devices shown in the picture are not included along with the TV set.

### AV IN













+: Image may vary depending on model.




**NOTE**

\*Image may vary depending on model.




### NOTE

\*Image may vary depending on model.



+: Depending on model



	<b>A</b> (mm)	<b>B</b> (mm)	<b>C</b> (mm)	<b>D</b> (mm)	<b>E</b> (mm)	<b>F</b> (kg)	<b>F</b> - ( <b>G</b> <sub>1</sub> + <b>G</b> <sub>2</sub> ) (kg)
32LH510A-TA 32LH512A-TC 32LH516A-TA 32LH517A-TC	734	474	172	438	71	4.7	4.5
43LH511A-TE 43LH516A-TE	976	621	208.7	583	81.5	8.5	8.2
49LH511A-TE 49LH516A-TE	1108	696	208.7	657	81.5	10.9	10.6



### NOTE

\*Image may vary depending on model.



	Power requirement
32LH510A-TA 32LH512A-TC	19 V --- 1.6 A
32LH516A-TA 32LH517A-TC	19 V --- 1.8 A
43LH511A-TE 43LH516A-TE	19 V --- 2.5 A
49LH511A-TE	19 V --- 3.2 A
49LH516A-TE	AC 100-240 V ~ 50 / 60 Hz





MFL69446117

IN020222