



OWNER'S MANUAL

AIR CONDITIONER



Read this owner's manual thoroughly before operating the appliance and keep it handy for reference at all times.

ENGLISH

Ceiling Cassette

ARNU24GTPA4 ARNU28GTPA4 ARNU30GTPA4
ARNU36GTNA4 ARNU42GTMA4 ARNU48GTMA4

TABLE OF CONTENTS

This manual may contain images or content that may be different from the model you purchased.

This manual is subject to revision by the manufacturer.

SAFETY PRECAUTIONS

Safety Precautions	3
Safety Precautions	3
WARNING	3
Installation	3
Operation	5
CAUTION.....	6
Installation	6
Operation	7

PRIOR TO OPERATION

Prior to Operation	9
Preparing for Operation.....	9
Cleaning and Maintenance	9
Service	9
Usage	9

MAINTENANCE

Maintenance and Service	10
Ceiling Cassette - 4Way	10
When the air conditioner is not going to be used for a long time	11
Operation Tips	11
Before you call for service.....	11

SAFETY PRECAUTIONS

Safety Precautions

Safety Precautions

To prevent injury to the user or other people and property damage, the following instructions must be followed.

Incorrect operation due to ignoring instruction will cause harm or damage. The seriousness is classified by the following indications.

WARNING

- This symbol indicates the possibility of death or serious injury.

CAUTION

- This symbol indicates the possibility of injury or damage to properties only.

Meanings of symbols used in this manual are as shown below.

	Be sure not to do.
	Be sure to follow the instruction.

WARNING

Installation

- Do not use a defective or underrated circuit breaker. Use this appliance on a dedicated circuit.
 - There is risk of fire or electric shock.
- For electrical work, contact the dealer, seller, a qualified electrician, or an Authorized Service Center.
 - Do not disassemble or repair the product. There is risk of fire or electric shock.
- Always ground the product.

- There is risk of fire or electric shock.
- Install the panel and the cover of control box securely.
 - There is risk of fire or electric shock.
- Always install a dedicated circuit and breaker.
 - Improper wiring or installation may cause fire or electric shock.
- Use the correctly rated breaker or fuse.
 - There is risk of fire or electric shock.
- Do not modify or extend the power cable.
 - There is risk of fire or electric shock.
- Do not install, remove, or reinstall the unit by yourself (customer).
 - There is risk of fire, electric shock, explosion, or injury.
- Be cautious when unpacking and installing the product.
 - Sharp edges could cause injury. Be especially careful of the case edges and the fins on the condenser and evaporator.
- For installation, always contact the dealer or an Authorized Service Center.
 - There is risk of fire, electric shock, explosion, or injury.
- Do not install the product on a defective installation stand.
 - It may cause injury, accident, or damage to the product.
- Do not turn on the breaker or power under condition that front panel, cabinet, top cover, control box cover are removed or opened.
 - Otherwise, it may cause fire, electric shock, explosion or death.
- Be sure the installation area does not deteriorate with age.
 - If the base collapses, the air conditioner could fall with it, causing property damage, product failure, and personal injury.
- Use a vacuum pump or Inert (nitrogen) gas when doing leakage test or air purge. Do not compress air or Oxygen and Do not use Flammable gases. Otherwise, it may cause fire or explosion.
 - There is the risk of death, injury, fire or explosion.

Operation

- Take care to ensure that power cable could not be pulled out or damaged during operation.
 - There is risk of fire or electric shock.
- Do not place anything on the power cable.
 - There is risk of fire or electric shock.
- Do not touch(operate) the product with wet hands.
 - There is risk of fire or electrical shock.
- Do not place a heater or other appliances near the power cable.
 - There is risk of fire and electric shock.
- Do not allow water to run into electric parts.
 - It may cause risk of fire, failure of the product, or electric shock.
- Do not store or use flammable gas or combustibles near the product.
 - There is risk of fire or failure of product.
- Do not use the product in a tightly closed space for a long time.
 - Oxygen deficiency could occur.
- When flammable gas leaks, turn off the gas and open a window for ventilation before turn the product on.
 - Do not use the telephone or turn switches on or off. There is risk of explosion or fire.
- If strange sounds, smell or smoke comes from product. Turn the breaker off or disconnect the power supply cable.
 - There is risk of electric shock or fire.
- Stop operation and close the window in storm or hurricane. If possible, remove the product from the window before the hurricane arrives.
 - There is risk of property damage, failure of product, or electric shock.
- Do not open the inlet grill of the product during operation. (Do not touch the electrostatic filter, if the unit is so equipped.)
 - There is risk of physical injury, electric shock, or product failure.

- When the product is soaked (flooded or submerged), contact an Authorized Service Center.
 - There is risk of fire or electric shock.
- Be cautious that water could not enter the product.
 - There is risk of fire, electric shock, or product damage.
- Ventilate the product from time to time when operating it together with a stove, etc.
 - There is risk of fire or electric shock.
- Turn the main power off when cleaning or maintaining the product.
 - There is risk of electric shock.
- Take care to ensure that nobody could step on or fall onto the outdoor unit.
 - This could result in personal injury and product damage.
- Do not let the air conditioner run for a long time when the humidity is very high and a door or a window is left open.
 - Moisture may condense and wet or damage furniture.
- Do not turn on the breaker or power under condition that front panel, cabinet, top cover, control box cover are removed or opened.
 - Otherwise, it may cause fire, electric shock, explosion or death.

CAUTION

Installation

- Always check for gas (refrigerant) leakage after installation or repair of product.
 - Low refrigerant levels may cause failure of product.
- Install the drain hose to ensure that water is drained away properly.
 - A bad connection may cause water leakage.
- Keep level even when installing the product.
 - To avoid vibration or water leakage.
- Use two or more people to lift and transport the product.

- Avoid personal injury.
- Contact the authorized service technician for repair or maintenance of this unit.
- Contact the installer for installation of this unit.
- When the power cord is to be replaced, replacement work shall be performed by authorized personnel only using only genuine replacement parts.
- Installation work must be performed in accordance with the National Electric Code by qualified and authorized personnel only.
- The air conditioner should be used only for the applications for which it has been designed : the indoor unit is not suitable to be installed in areas used for laundry.
- If anyone other than a licensed professional installs, repairs, or alters LG Electronics air conditioning products, the warranty is voided.
 - All costs associated with repair are then the full responsibility of the owner.
- Do not install the unit in potentially explosive atmospheres.

Operation

- Do not expose the skin directly to cool air for long periods of time. (Don't sit in the draft.)
 - This could harm to your health.
- Do not use the product for special purposes, such as preserving foods, works of art, etc. It is a consumer air conditioner, not a precision refrigeration system.
 - There is risk of damage or loss of property.
- Do not block the inlet or outlet of air flow.
 - It may cause product failure.
- Use a soft cloth to clean. Do not use harsh detergents, solvents, etc.
 - There is risk of fire, electric shock, or damage to the plastic parts of the product.
- Do not touch the metal parts of the product when removing the air filter. They are very sharp!

- There is risk of personal injury.
- Do not step on or put anything on the product.(outdoor units)
 - There is risk of personal injury and failure of product.
- Always insert the filter securely. Clean the filter every two weeks or more often if necessary.
 - A dirty filter reduces the efficiency of the air conditioner and could cause product malfunction or damage.
- Do not insert hands or other objects through the air inlet or outlet while the product is operated.
 - There are sharp and moving parts that could cause personal injury.
- Do not drink the water drained from the product.
 - It is not sanitary and could cause serious health issues.
- Use a firm stool or ladder when cleaning or maintaining the product.
 - Be careful and avoid personal injury.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
 - Children should be supervised to ensure that they do not play with the appliance.

PRIOR TO OPERATION

Prior to Operation

Preparing for Operation

- 1) Contact an installation specialist for installation.
- 2) Use a dedicated circuit.

Cleaning and Maintenance

- 1) Do not touch the metal parts of the unit when removing the filter. Injuries can occur when handling sharp metal edges.
- 2) Do not use water to clean inside the air conditioner. Exposure to water can destroy the insulation, leading to possible electric shock.
- 3) When cleaning the unit, first make sure that the power and breaker are turned off. The fan rotates at a very high speed during operation. There is a possibility of injury if the unit's power is accidentally triggered on while cleaning inner parts of the unit.

Service

For repair and maintenance, contact your authorized service dealer.

Usage

- 1) Being exposed to direct airflow for an extended period of time could be hazardous to your health. Do not expose occupants, pets, or plants to direct airflow for extended periods of time.
- 2) Due to the possibility of oxygen deficiency, ventilate the room when used together with stoves or other heating devices.
- 3) Do not use this air conditioner for non-specified special purposes (e.g. preserving precision devices, food, pets, plants, and art objects). Such usage could damage the items.

MAINTENANCE

Maintenance and Service


Ceiling Cassette - 4Way

⚠ CAUTION

- Before performing any maintenance, turn off the main power to the system.

Grille, Case, and Remote Control

- Turn the system off before cleaning. To clean, wipe with a soft, dry cloth. Do not use bleach or abrasives.




- ① Air Outlet
- ② Air Intake
- ③ Air Filter
- ④ Wired Remote Controller (Optional)

NOTE

- Supply power must be disconnected before cleaning the indoor unit.

Air Filters

The air filters behind the front grille should be checked and cleaned once every 2 weeks or more often if necessary.



- ① Rack
- ② Air Filter

- Never use any of the followings:
 - Water hotter than 40°C. Could cause deformation and/or discoloration.
 - Volatile substances. Could damage the surfaces of the air conditioner.



1 Remove the Air filters

- Take hold of the tab and pull slightly forward to remove the filter.

⚠ CAUTION

- When the air filter is to be removed, do not touch the metal parts of the indoor unit. It may cause an injury.

- 2 Clean dirt from the air filter using a vacuum cleaner or washing with water.

- If dirt is conspicuous, wash with a neutral detergent in lukewarm water.
- If hot water (40°C or more) is used, it may be deformed.

3 After washing with water, dry well in the shade.

- Do not expose the air filter to direct sunlight or heat from a fire when drying it.

4 Install the air filter.

When the air conditioner is not going to be used for a long time

When it is not going to be used for a long time.

1 Operate the air conditioner at the following settings for 2 to 3 hours.

- Type of operation: Fan operation mode.
- This will dry out the internal mechanisms.

2 Turn off the breaker.

CAUTION

- Turn off the breaker when the air conditioner is not going to be used for a long time.
 - Dirt may collect and may cause a fire.

Helpful information

The air filters and your electric bill.

If the air filters become clogged with dust, the cooling capacity will drop, and 6 % of the electricity used to operate the air conditioner will be wasted.

When the air conditioner is to be used again

1 Clean the air filter and install it in the indoor unit.

2 Check that the air inlet and outlet of the indoor/outdoor unit are not blocked.

3 Check that the ground wire is connected correctly. It may be connect to the indoor unit side.

Operation Tips

- Do not overcool the room.
 - This is not good for the health and wastes electricity.
- Keep blinds or curtains closed.
 - Do not let direct sunshine enter the room when the air conditioner is in operation.
- Keep the room temperature uniform.
 - Adjust the vertical and horizontal airflow direction to ensure a uniform temperature in the room.
- Make sure that the doors and windows are shut tight.
 - Avoid opening doors and windows as much as possible to keep the cool air in the room.
- Clean the air filter regularly.
 - Blockages in the air filter reduce the airflow and lower cooling and dehumidifying effects. Clean at least once every two weeks.
- Ventilate the room occasionally.
 - Since windows are kept closed, it is a good idea to open them and ventilate the room now and then.

Before you call for service...

Troubleshooting Tips! Save time and money!

Check the following points before requesting repairs or service.... If the malfunction persist, please contact your dealer.

- The air conditioner does not operate.
 - Have you made a mistake in timer operation?

12 MAINTENANCE

- Has the fuse blown or has the circuit breaker been tripped?
- The room has a peculiar odor.
 - Check that this is not a damp smell exuded by the walls, carpet, furniture or cloth items in the room.
- It seems that condensation is leaking from the air conditioner.
 - Condensation occurs when the airflow from the air conditioner cools the warm room air.
- Air conditioner does not operate for about 3 minutes when restart.
 - This is the protector of the mechanism.
 - Wait about three minutes and operation will begin.
- Does not cool or heat effectively.
 - Is the air filter dirty? See air filter cleaning instructions.
 - The room may have been very hot when the room air conditioner was first turned on. Allow time for it to cool down.
 - Has the temperature been set incorrectly?
 - Are the indoor unit's air inlet or outlet vents obstructed?
- The air conditioner operation is noisy.
 - For a noise that sounds like water flowing.
This is the sound of freon flowing inside the air conditioner unit.
 - For a noise that sounds like the compressed air releasing into atmosphere.
This is the sound of the dehumidifying water being processed inside the air conditioning unit.
- Crack sound is heard.
 - This sound is generated by the expansion/constriction of the front panel, etc. due to changes of temperature.
- Remote control display is faint, or no display at all.
 - Are the batteries depleted?
 - Are the batteries inserted in the opposite (+) and (-) directions?
- The air conditioner changes generated airflow during operation.

- When the air conditioner reaches the desired temperature, the airflow rate reduces in order to avoid generating cool airflow during heating, or to minimize energy consumption and indoor humidity change during cooling.
This symptom is normal.

NOTE

- Water resistant: The outdoor side of this appliance is WATER RESISTANT. The indoor side is not water resistant and should not be exposed to excess water.
 - Some functions may not be supported, depending on the model.
-

Only for INDIA

LG CUSTOMER CARE



1800-180-3575 (Toll Free)
9 x 7 (9:00 AM - 6:00 PM)



www.lg.com/in/support
cac.service@lgepartner.com

To know more about LG, visit www.lg.com
For Corporate/Insttutional enquiries,
please write to enquiries@lgindia.com

Regd. Office : LG Electronics India Ltd., A-24/6 Mohan Cooperative Industrial Estate, Mathura Road, New Delhi-110044

Memo



BUKU PETUNJUK

PENDINGIN

RUANGAN



Baca buku panduan pemilik ini secara menyeluruh sebelum mengoperasikan alat dan simpan dengan baik untuk digunakan sebagai referensi setiap saat.

BAHASA INDONESIA

Kaset Plafon

ARNU24GTPA4 ARNU28GTPA4 ARNU30GTPA4
ARNU36GTNA4 ARNU42GTMA4 ARNU48GTMA4

DAFTAR ISI

Panduan ini dapat berisi gambar atau isi yang berbeda dari model yang Anda beli. Buku panduan ini dapat diubah oleh pabrik.

TINDAKAN KESELAMATAN

Tindakan Pencegahan demi Keselamatan.....	3
Tindakan Pencegahan demi Keselamatan.....	3
PERINGATAN	3
Pemasangan	3
Pengoperasian.....	5
PERHATIAN	7
Pemasangan	7
Pengoperasian.....	8

SEBELUM MENGOPERASIKAN

Sebelum Pengoperasian	10
Persiapan Pengoperasian	10
Pembersihan dan Perawatan	10
Layanan	10
Pemakaian.....	10

PEMELIHARAAN

Pemeliharaan dan Servis.....	11
Kaset Langit-Langit - 4 Arah.....	11
Saat pendingin ruangan tidak akan digunakan untuk waktu yang lama...12	
Kiat Pengoperasian	12
Before Anda menghubungi petugas servis... ..	13

TINDAKAN KESELAMATAN

Tindakan Pencegahan demi Keselamatan

Tindakan Pencegahan demi Keselamatan

Untuk mencegah cedera terhadap pengguna atau orang lain dan mencegah kerusakan properti, petunjuk berikut ini harus diikuti. Pengoperasian yang tidak benar karena mengabaikan petunjuk akan menyebabkan cedera atau kerusakan. Tingkat keseriusannya diklasifikasikan berdasarkan indikasi berikut.

PERINGATAN

- Simbol ini menunjukkan kemungkinan kematian atau cedera serius.

PERHATIAN

- Simbol ini menunjukkan kemungkinan luka atau kerusakan.

Arti simbol-simbol yang digunakan dalam panduan ini adalah sebagai berikut.

	Pastikan anda tidak melakukannya.
	Pastikan anda mengikuti petunjuknya.

PERINGATAN

Pemasangan

- Jangan menggunakan pemutus sirkuit yang rusak atau dengan rating yang rendah. Gunakan alat ini pada sirkuit khusus.
 - Berisiko kebakaran atau kejutan listrik.
- Untuk pekerjaan listrik, hubungi dealer, penjual, teknisi listrik yang memenuhi syarat, atau Pusat Layanan Resmi.

- Jangan membongkar atau memperbaiki produk. Ada risiko kebakaran atau sengatan listrik.
- Selalu pasang arde ke produk.
 - Berisiko kebakaran atau kejutan listrik.
- Pasang panel dan tutup kotak kontrol dengan erat.
 - Berisiko kebakaran atau kejutan listrik.
- Selalu pasang dengan rangkaian dan pemutus arus listrik terpisah.
 - Pemasangan kabel atau produk yang tidak tepat dapat menyebabkan kebakaran atau kejutan listrik.
- Gunakan pemutus atau sekering dengan rating yang sesuai.
 - Berisiko kebakaran atau kejutan listrik.
- Jangan mengubah atau memperpanjang kabel daya.
 - Berisiko kebakaran atau kejutan listrik.
- Jangan memasang, melepas, atau memasang kembali unit sendiri (pelanggan).
 - Berisiko kebakaran, kejutan listrik, meledak, atau cedera.
- Berhati-hatilah saat mengeluarkan dan memasang produk.
 - Tepi yang tajam dapat menyebabkan cedera. Terutama berhati-hatilah dengan tepi kotak dan sirip pada kondensor dan evaporator.
- Untuk pemasangan, selalu hubungi dealer atau Pusat Layanan Resmi.
 - Berisiko kebakaran, kejutan listrik, meledak, atau cedera.
- Jangan memasang produk pada penyangga yang rusak.
 - Tindakan ini dapat menyebabkan cedera, kecelakaan, atau kerusakan produk.
- Jangan menyalakan pemutus arus listrik atau daya dengan kondisi panel depan, kabinet, penutup atas, penutup kotak kontrol dalam keadaan dilepas atau terbuka.
 - Jika tidak, itu dapat menyebabkan kebakaran, sengatan listrik, ledakan atau kematian.
- Pastikan area pemasangan tidak rusak karena termakan usia.

- Jika dasarnya runtuh, pendingin ruangan dapat jatuh bersamanya, menyebabkan kerusakan properti, kerusakan produk, dan cedera pribadi.
- Gunakan pompa vakum atau Gas inert (nitrogen) saat melakukan uji kebocoran atau pembersihan udara. Jangan memampatkan udara atau Oksigen dan jangan menggunakan Gas yang mudah terbakar. Jika tidak, itu dapat menyebabkan kebakaran atau ledakan.
- Ada risiko kematian, cedera, kebakaran, atau ledakan.

Pengoperasian

- Berhati-hatilah jangan sampai kabel listrik tertarik atau rusak selama pengoperasian.
 - Berisiko kebakaran atau kejutan listrik.
- Jangan meletakkan apa pun di atas kabel daya.
 - Berisiko kebakaran atau kejutan listrik.
- Jangan menyentuh (mengoperasikan) produk dengan tangan basah.
 - Berisiko kebakaran atau kejutan listrik.
- Jangan meletakkan pemanas atau alat lainnya di dekat kabel daya.
 - Ada risiko kebakaran dan sengatan listrik.
- Jangan biarkan air mengalir ke komponen listrik.
 - Ada risiko kebakaran, kerusakan produk, atau sengatan listrik.
- Jangan menyimpan atau menggunakan gas yang mudah menyala atau terbakar di dekat produk.
 - Berisiko kebakaran atau kerusakan produk.
- Jangan menggunakan produk di ruangan yang tertutup rapat untuk waktu yang lama.
 - Kekurangan oksigen dapat terjadi.
- Saat terjadi kebocoran gas yang mudah terbakar, matikan gas dan buka jendela untuk ventilasi sebelum menyalakan produk.
 - Jangan menggunakan telepon atau menyalakan atau mematikan sakelar. Ada risiko ledakan atau kebakaran.

- Jika ada bunyi yang aneh, bau atau asap keluar dari produk. Matikan pemutus arus listrik atau cabut kabel daya.
 - Ada risiko sengatan listrik atau kebakaran.
- Hentikan pengoperasian dan tutup jendela jika terjadi badai atau angin topan. Jika memungkinkan, lepaskan produk dari jendela sebelum angin topan datang.
 - Ada risiko kerusakan properti, kerusakan produk, atau sengatan listrik.
- Jangan membuka kisi-kisi saluran masuk selama pengoperasian. (Jangan menyentuh filter elektrostatik, jika unit dilengkapi dengan filter tersebut.)
 - Berisiko cedera badan, kejutan listrik, atau kerusakan produk.
- Jika produk terendam (kebanjiran atau tenggelam), hubungi Pusat Servis Resmi.
 - Berisiko kebakaran atau kejutan listrik.
- Berhati-hatilah jangan sampai air masuk ke dalam produk.
 - Berisiko kebakaran, kejutan listrik atau kerusakan produk.
- Alirkan udara ke produk dari waktu ke waktu saat alat dioperasikan bersamaan dengan kompor, dsb.
 - Berisiko kebakaran atau kejutan listrik.
- Cabut daya utama saat membersihkan atau melakukan pemeliharaan produk.
 - Ada risiko sengatan listrik.
- Hati-hati dan pastikan tidak ada seorang pun yang menginjak atau jatuh menimpa unit luar-ruangan.
 - Ini dapat menyebabkan cedera badan dan kerusakan mesin.
- Jangan biarkan pendingin ruangan menyala untuk waktu yang lama saat kelembapannya sangat tinggi dan pintu atau jendela dibiarkan terbuka.
 - Udara yang lembap dapat mengembun dan membasahi atau merusak perabotan.