





## Language Setting




With power on, press and hold the  (power) button and **LEVEL** button for approx 3 seconds each time you change function. (Cantonese → English → Chinese)

## Change cleansing time




With power off, press and hold the  (power) button until you hear the voice guide. (Approx. 5 seconds) (70 seconds ↔ 120 seconds)

## How to cleanse the face curve



Please cleanse face curve such as corner of nose and between eyebrows with edge of silicone brush head.

## Set voice guide function



With power on, press and hold the **LEVEL** button for approx 5 seconds each time you change function. (Voice guide → Sound effect guide → Turn off guide (mute))

### Precautions for use

- Recommend using the product once a day. (Using more than twice a day may make skin more sensitive.)
  - If you are undergoing skin treatment or cosmetic surgery, it is recommended that you use it in normal your skin condition. (After more than 1 month)
  - Who are pregnant or lactating are not recommended to use this device.
  - Who are wearing a cardiac pacemaker or device implantation are not recommended to use this device.
  - Who have acne, contact dermatitis, allergies or other intractable skin disease are not recommended to use this device.
- ⓘ Please refer to the full text of safety skin information in owner's manual.

## How to hold the device






Please hold the unit naturally without blocking speaker as shown image.



MBM67219235

1912\_Rev01

How to use  Use unit once a day  Use bubble foam cleansing



1 Wet your face or brush head of unit with tepid water.



2 Put cleansing product for your skin type on your face.


ⓘ Making sufficient amount of bubble before cleansing is recommended.



3 Press the  (Power) button to turn on.



4 Press the **LEVEL** button and choose cleansing vibration speed and level.  
(1 → 2 → 3)




5 Cleanse the face by gently moving the brush in a small circle, avoiding around the eyes in the below order.

(Default setting: 70 seconds / Setting method : Refer to first page.)

**70 seconds** ① Left cheek (10's) → ② Right cheek (10's) → ③ Nose (20's) → ④ Chin (10's) → ⑤ Forehead (20's) → Power off

**120 seconds** ① Left cheek (20's) → ② Right cheek (20's) → ③ Nose (30's) → ④ Chin (20's) → ⑤ Forehead (30's) → Power off



6 Rinse your face sufficiently with tepid water after cleansing.