



SIMPLE MANUAL

MINI HI-FI AUDIO

ENGLISH

Please read this manual carefully before operating your set and retain it for future reference.

To view the instructions of advanced features, visit <http://www.lg.com> and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL

ON77DK



MFL71664368


2102_Rev01

www.lg.com

Copyright © 2021-2022 LG Electronics Inc. All Rights Reserved.



Top panel



1 (Standby)

Turns the power on or off.

2 DEMO

In power off status, if you press **DEMO**, show demo mode.

3 USB 1 Port

You can play sound files by connecting the USB device.

4 Display window

5 USB 2 Port

You can play sound files by connecting the USB device.

6 F (Function)

Selects the function and input source.

7 LIGHTING

Selects the lighting mode.

8 TWIN

Connects two units for TWIN mode in WIRELESS PARTY LINK.

9 KK/DK (Skip/Search)

- Skips backward or forward.
- Searches for a section within a track/file/chapter.
- Selects the radio stations.

DK (Play/Pause)

- Starts or pauses playback.
- Selects stereo/mono.

- **Bluetooth** connection lock (BT LOCK): Select the **Bluetooth** function by pressing **F** repeatedly. And long press **DK** to limit **Bluetooth** connection to only BT and LG TV.

□ (Stop)

Stops playback or cancels DELETE function.

VOL (Volume) -/+

Adjusts speaker volume.

MIC (Microphone) -/+

Adjust microphone volume.

10 (Auto Music Play)

Plays the audio currently playing by tagging the mobile (with "LG XBOOM" App) to this unit. (Android Only)

11 VOICE CANCELLER

You can reduce the vocal tones during music playback from various input sources.

△ (Open/Close)

Opens and closes the disc tray.

12 CLUB, DRUM, USER (DJ PAD)

Selects CLUB, DRUM or USER sound effect to mix.

(If you want to use USER, you have to register a source with "LG XBOOM" app. (Android Only))

1, 2, 3 (DJ PAD)

Press a desired sound pad.

13 MIC (Microphone) ECHO

Selects ECHO mode.

VOCAL EFFECTS

Selects various vocal effects mode.

KEY CHANGER (b/#)

Changes the key to suit your vocal range.

14 Remote sensor

15 SPECIAL EQ / BASS BLAST (or BASS BLAST+)

- Chooses special equalizer.
- Press and hold to select BASS (or BASS+) effect directly.

SEARCH

Moves to folder or file in selection mode. (USB only)

OK

Selects a folder when searching a file.


USER EQ

Selects the equalizer created by your own.


Multi jog

- Searches a folder or a file. (USB only)
- Turns clockwise or counterclockwise to control the USER EQ level.
- Chooses special equalizer.

Front panel / Rear panel



- 1** Disc tray
- 2** Lighting
- 3** Remote sensor



- 4** MIC (Microphone) IN 1/2
Connect a microphone.
- 5** ANTENNA (FM)
- 6** HDMI OUT TO TV
Connect to TV.
- 7** SERVICE ONLY
S/W download connector.
- 8** AC IN socket

Controller App



Android



iOS

Download the **LG XBOOM** App to your device.

LG Sound Sync (Wireless)



For more information, download the online owner's manual. <http://www.lg.com>


1

TV Connection

HDMI Connection :

Connect with the Player and TV using HDMI .

- 1 Connect the Player to the TV using HDMI cable.
- 2 Set the input selector to HDMI on the TV.
- 3 Follow the instructions on the TV screen using remote control.



2

Home Menu

Home menu appears on the TV screen. Enjoy various functions on the player.



Home menu only appears on DVD/CD function.

Additional Information

Specifications

Power Requirements	Refer to the main label on the unit.
	Refer to the main label on the unit.
Power Consumption	Networked standby : 0.5 W (If all network ports are activated.)
Dimensions (W x H x D)	Approx. 330.0 mm x 685.0 mm x 344.0 mm
Bus Power Supply (USB)	5 V 500 mA

Design and specifications are subject to change without notice.

Caution

- Connect the power cord to wall outlet directly if possible. Or when you use an extension cable, it is highly recommended to use an extension cable of 110 V / 15 A or 230 V / 15 A, otherwise the unit may not operate properly because of the lack of power supply.
- Do not overload the extension cord with excessive electrical load.


Note

- Do not look directly at the light emitting part when the LIGHTING is turned on.
- If the illumination brightness is glaring, switch on the room lights or turn off the LIGHTING of the unit.

How to disconnect the wireless network connection or the wireless device

Turn off the unit by pressing the power button for more than 5 seconds.

Replacement of battery



Declaration of Conformity



Hereby, LG Electronics declares that the radio equipment type MINI HI-FI AUDIOfs is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<http://www.lg.com/global/support/cedoc/cedoc#>

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

HDMI™
HIGH-DEFINITION MULTIMEDIA INTERFACE



Российская Федерация

Импортер ООО “ЛГ Электроникс Рус”

Адрес импортера: 143160, Российская Федерация, Московская область, Рузский городской округ, территория Минское шоссе, километр 86-й, дом 9

Адрес производителя : ЛГ Электроникс (Хужоу) Инк., завод Хатай

516006, Китай, пров. Гуандонг, г. Хужоу, Промышленная зона Жонгкай, Индустриальный парк Хутай, ХуФенг Донг Уи Роуд, 13.

Сделано в Китае

Україна

Вироблено в : ЛГ Електронікс (Хужоу) Інк., завод Хатай

516006, Китай, пров. Гуандонг, м. Хужоу, Промислова зона Жонгкай, Індустриальний парк Хутай, ХуФенг Донг Уи Роуд, 13.

Қазақстан Республикасы

Импорттаушы АҚ “Эл Джи Электроникс Алматы Қазақстан”, 050061, Алматы қ., Қекорай көшесі, 2А/9

Өндірушінің мекенжайы: LG Electronics(Huizhou) Inc. Huitai Factory

516006, Қытай, Гуандонг ауданы, Хужоу қаласы, Жонгкай өнеркәсіптік аймағы, Хутай Индустріялық саябағы, ХуФенг Донг Уи Роуд, 13.

Қазақстан Республикасы территориясында тұтынушылардан келіп түсken талаптар мен ұсыныстарды қарайтын және тауарды жөндеу мен техникалық қызмет көрсететін үхым:

АҚ «Эл Джи Электроникс Алматы Қазақстан», 050061, Қазақстан Республикасы, Алматы қ., Қекорай көшесі, 2А/9. Басқа сервис орталықтары жайында мәглұмматты “Тұтынушыға қызмет көрсету орталығына” телефон шалу арқылы білуге болады.

Қытайда жасалған