




+ : Depending on model

Unpacking

Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item.

*Image may vary depending on models







www.lg.com



English


- Read **Safety and Reference**.
- For the power supply and power consumption, refer to the label attached to the product.





CAUTION

Image shown may differ from your TV.



When attaching the stand to the TV set, place the screen facing down on a cushioned table or flat surface to protect the screen from scratches.



ANTENNA/
CABLE IN



HDMI IN



USB IN




H/P OUT





NOTE



Image shown may vary depending on model.
All connection cables & devices shown in the picture are not included
along with the TV set.



COMPONENT IN



AV IN







! NOTE

Image shown may vary depending on model.
All connection cables & devices shown in the picture are not included
along with the TV set.




+












NOTE


Image shown may vary depending on model.



NOTE


Image shown may vary depending on model.





NOTE

Image shown may vary depending on model.



	A (mm)	B (mm)	C (mm)	D (mm)	E (mm)	F (kg)	F - (G ₁ + G ₂) (kg)
32LJ510D-TB 32LJ510U-TA 32LJ510Z-TA 32LJ514D-TB 32LJ519D-TA	739	472	168	441	84	4.90	4.85
Power requirement	19 V $\overline{\text{---}}$ 2.0 A						

MEL69446164

