


























OLED83C2PSA






MODELS	A	B	C	D	E	F	F-G	Power consumption							
MODELOS	(mm)				(kg)				Consumo de potencia						
OLED83C2PSA	1851	1851	1092	1092	279	279	1062	1062	55.3	55.3	41.6	41.6	32.3	32.3	802 W
Power requirement / Alimentación requerida						AC 100-240 V ~ 50/60 Hz									



A	B	C x D (mm)	E
LSW440B	OLED83C2*	400 x 400	M6



A	B	C x D (mm)
WB21EB	OLED83C2*	180 x 55



ENGLISH Read **Safety and Reference**.
Due to environmental government regulations about imports and battery destruction in Colombia, TVs will not include the batteries for the remote control.

ESPAÑOL Leer **Seguridad y Consultas**.
Por regulaciones de tipo ambiental respecto a la importación y destrucción de baterías en Colombia; los televisores no van a traer incluidas las pilas del control remoto.

ENGLISH
Easy Setup Guide
Please read this manual carefully before operating your set and retain it for future reference.

ESPAÑOL
Guía Rápida de Configuración
Lea atentamente este manual antes de poner en marcha el equipo y consérvelo para futuras consultas.

+ : Depending upon model / Según el modelo