

# SIMPLE MANUAL

## Sound Bar

Please read this manual carefully before operating your set and retain it for future reference. To view the instructions of advanced features, visit <http://www.lg.com> and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL  
SK1D



[www.lg.com](http://www.lg.com)


Copyright © 2020 LG Electronics Inc. All Rights Reserved.

1806\_Rev01

ENGLISH



### Front Panel




phi/I ..... Standby/ON

F ..... Selects Function.

- / + ..... Adjusts Volume.

### Rear Panel




PORT.IN ..... Connect to a Portable device

OPTICAL IN ..... Connect to an Optical device

USB ..... Connect to a USB device


### TV Connection

- 1 Connect the sound bar to the TV using Optical cable.
- 2 Set up [External Speaker (Optical)] on your TV setting menu.




### Additional Device Connection

- 1 Connect to the external device as follows.



- 2 Set the input source by pressing F on the remote control or unit repeatedly.

### Remote control




**ASC/BASS BLAST/CINEMA:** Selects the sound effect.

**NIGHT ON/OFF:** Turns down the volume at night.

**DRC ON/OFF:** Dynamic Range Control optimizes the volume level of compatible Dolby Digital content.

**AUTO POWER ON/OFF:** Automatically turns on by an input source.

### Replacement of battery



### Additional Information


#### Specification

Power requirements	Refer to the main label.
Power consumption	Refer to the main label.
Dimensions (W x H x D)	Approx. 950 mm x 71 mm x 47 mm
Bus Power Supply (USB)	5 V 500 mA
Amplifier (Total RMS Output power)	100 W RMS

Design and specifications are subject to change without notice.




### Panel frontal



- Off ..... Modo de espera/Encendido
- F ..... Selecciona la Función
- / + ..... Ajusta el volumen


### Panel trasero



- PORT.IN ..... Conectar a un dispositivo Portátil
- OPTICAL IN ..... Conectar a un dispositivo Óptico
- USB ..... Conectar a un dispositivo USB


### Conexión del TV

- 1 Conecte el dispositivo a la Barra de sonido y a la TV utilizando un cable Óptico.
- 2 Establezca [Altavoz Externo (Óptico)] en el menú de ajuste de su TV.




### Conexión de un dispositivo externo

- 1 Conecte el dispositivo externo como sigue.



- 2 Seleccione la fuente de entrada pulsando F repetidamente en el mando a distancia o la unidad.

### Mando a distancia




**ASC/BASS BLAST/CINEMA** : Seleccione el efecto de sonido.

**NIGHT ON/OFF**: Baja el volumen durante la noche.

**DRC ON/OFF**: Dynamic Range Control optimiza el nivel del volumen del contenido Dolby Digital compatible.

**AUTO POWER ON/OFF**: Esta unidad se enciende automáticamente con una fuente de entrada.

### Reemplazo de batería



### Información adicional

#### Especificación

Requisitos de alimentación	Consulte la etiqueta principal del aparato.
Consumo de energía	Consulte la etiqueta principal del aparato.
Dimensiones (L x A x F)	Aprox. 950 mm x 71 mm x 47 mm
Suministro de Alimentación de Bus (USB)	5 V 500 mA
Amplificador (potencia de salida RMS total)	100 W Eficaz

El diseño y las especificaciones están sujetos a cambios sin previo aviso.

# MANUAL DE USUARIO

## Barra de sonido

Lea este manual detenidamente antes de utilizar el aparato y guárdelo como referencia para el futuro.

Lea atentamente este manual antes de operar su producto. Para ver las instrucciones de las funciones avanzadas, visite <http://www.lg.com> y descargue el Manual del Propietario. Puede que algunos de los contenidos de este manual no se ajusten exactamente a su unidad.

MODELO  
SK1D



MFL71698874

[www.lg.com](http://www.lg.com)

Copyright © 2020 LG Electronics Inc. Todos los derechos reservados.

1806\_Rev01