


ENGLISH Installing and Using the Product

Please read this manual carefully before operating your set and retain it for future reference. To view the instructions of advanced features, visit <http://www.lg.com> or scan QR code and then download Owner's Manual. Some of the content in this manual may differ from your product.



- (A) Sound bar
- (B) Remote Control Receiver
- (C) Status LED (①②③)
- (D) Rear Speakers / Wireless Receiver (Sold separately, SPQ8-S)

- (E) Wireless Subwoofer - Install it close to the sound bar
- (F) External Device - (Blu-ray player, game console, etc.)

○: On / ●: Off / ○: Blink						
Red blinking	White blinking	White	Blue blinking	Blue	White	White
Power on Power off	Wi-Fi ready	Wi-Fi	Bluetooth ready	Bluetooth	OPTICAL / HDMI ARC	HDMI IN

1 Connect the sound bar to your TV via an optical cable or an HDMI cable.

- 2 If you are using an external device (ex. Set-top box, Blu-ray player, game console, etc), connect it to the sound bar or to the TV via an HDMI cable.

① If necessary, purchase HDMI cables, or an optical cable to connect the sound bar.

- 3 If you purchased the rear speakers and wireless receiver separately, connect the rear speakers to the wireless receiver via a speaker cable. When connecting the rear speakers to the wireless receiver, connect the black striped cable to the negative terminal of each speaker and the remaining cable to the positive terminal of each speaker.

- 4 Connect to power in the following order: wireless subwoofer → wireless receiver → sound bar. Then, turn on the sound bar. When the connection is automatically established with the sound bar, the LEDs on the wireless subwoofer and the wireless receiver will light up green.

- 5 Using the product with your TV

- ① Press the **Function** (●) button repeatedly until LED1 and LED2 light up white. If you are using an external device that is connected to HDMI™ IN on the sound bar, press the **Function** (●) button repeatedly until LED1 and LED3 light up white.

- ② On your TV's settings, set the output speaker to [HDMI ARC], [Optical], or [External Speaker].

- ③ You can enjoy the sound by connecting LG WOCAST (Sold separately, WTP3) to the sound bar wirelessly.

- 6 Connecting the product to your smartphone via Wi-Fi

- ① Connect your smartphone to Wi-Fi.
- ② Install the **LG Sound Bar** app on Google Play or the App Store.

- ③ Run the **LG Sound Bar** app and follow the instructions.
- ④ The product will connect to your smartphone and you can control the product with **LG Sound Bar** app.


- 7 Connecting the product to your smartphone via Bluetooth

- ① Tap the **Settings** (●) button on your smartphone and select **Bluetooth**. Turn on the **Bluetooth** function. (● Off > ● On)

- ② Press the **Bluetooth pair** (●) button. After a moment, LED2 blinks blue.

- ③ Find and tap "LG_Speaker_SC9S_XXXX" or the name you registered on the Google Home app.

- ④ When the product is connected to your smartphone via **Bluetooth**, all LEDs light up blue.



- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.

Google Play is a trademark of Google LLC.




- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.




- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.




- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.



- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.




- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.



- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.



- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.



- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.
- يخص تصميم المراصقات للتغيير دون اشعار مسيقى.

