



SIMPLE MANUAL

Mini Hi-Fi Audio

ENGLISH

Please read this manual carefully before operating your set and retain it for future reference.

To view the instructions of advanced features, visit <http://www.lg.com> and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL

ON44DK



MFL71714726


2005_Rev01

www.lg.com

Copyright © 2020-2022 LG Electronics Inc. All Rights Reserved.



Top panel



1 (Standby)

Turns the power on or off.

2 USB Port

You can play MP3 files by connecting the USB device.

3 Display window

4 (Function)

Selects the function and input source.

5 (Open/Close)

Opens and closes the disc tray.

(Skip/Scan)

- Skips backward or forward.
- Scans for a section within a track/file/chapter.
- Selects the radio stations.

(Stop)

Stops playback.

VOL (Volume) -/+

Adjusts speaker volume.

(Play/Pause)

Starts or pauses playback.

6 **MIC VOL** (Microphone volume) -/+

Adjust microphone volume.

MIC (Microphone) **ECHO** -/+

Adjusts microphone echo level.


BASS -/+

Adjusts bass level.


EQ

Chooses sound impressions.

Front panel / Rear panel



- 1** Remote sensor
- 2** Disc tray




- 3** Power cord
- 4** **SERVICE ONLY:** S/W download connector
- 5** **HDMI OUT TO TV:** Connect to TV.
- 6** **ANTENNA FM**
- 7** **AUX IN (L/R):** Connect an auxiliary device.
- 8** **MIC (Microphone) 1/2:** Connect a microphone.

1 TV Connection

HDMI Connection :

Connect with the Unit and TV using HDMI.

- 1** Connect the Unit to the TV using HDMI cable.
- 2** Set the input selector to HDMI on the TV.
- 3** Follow the instructions on the TV screen using remote control.



2 Home Menu

Home menu appears on the TV screen. Enjoy various functions on the player.



! Home menu only appears on DVD/CD function.

Additional Information

Specifications

Power Requirements	Refer to the main label on the unit.
Power Consumption	Refer to the main label on the unit.
Dimensions (W x H x D)	Approx. 300.0 mm x 390.0 mm x 324.0 mm
Bus Power Supply (USB)	5 V  500 mA

Design and specifications are subject to change without notice.

Declaration of Conformity




Hereby, LG Electronics declares that the radio equipment type Mini Hi-Fi Audio is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<http://www.lg.com/global/support/cedoc/cedoc#>

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

Replacement of battery











Российская Федерация

Импортер ООО "ЛГ Электроникс Рус"

Адрес импортера: 143160, Российская Федерация, Московская область, Рузский городской округ, территория Минское шоссе, километр 86-й, дом 9

Адрес производителя : ПТ ЭМСОНИК ИНДОНЕЗИЯ Кавасан Индастри MM2100, Джи Тимур Блок Е5, 17845 Сибитунг Бекаси, Индонезия.

Сделано в Индонезии

Україна

Вироблено в : ПТ ЕМСОНИК ІНДОНЕЗІЯ Кавасан Індастрі MM2100 ДЖІю Тімур Блок Е5
17845 Сібітанг Бекасі Індонезія

Қазақстан Республикасы

Импорттаушы АҚ "ЭЛ Джи Электроникс Алматы Қазақстан", 050061, Алматы қ., Көкорай көшесі, 2А/9

Өндірушінің мекенжайы: PT EMSONIC INDONESIA Кавасан Индастри MM2100, Джи Тимур
Е5 Блогі, 17845 Сибитунг Бекаси, Индонезия.

Қазақстан Республикасы территориясында тұтынушылардан келіп түскен талаптар мен ұсыныстарды қарайтын және тауарды жөндеу мен техникалық қызмет көрсететін ұжым:

АҚ «Эл Джи Электроникс Алматы Қазақстан», 050061, Қазақстан Республикасы, Алматы қ., Көкорай көшесі, 2А/9. Басқа сервис орталықтары жайында мағлұматты "Тұтынушыға қызмет көрсету орталығына" телефон шалу арқылы білуге болады.

Индонезияда жасалған