

UP75*


Quick Start Guide



Images shown in manual
may vary depending on model


Unpacking

Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item.




1



50/55UP75*



2




3




1


65/70UP75*



2




3




CAUTION

Image shown may differ from your TV
When attaching the stand to the TV set, place the screen facing down on a cushioned table or flat surface to protect the screen from scratches.


1



2




3




4-A

50/55UP75*




4-B


65/70UP75*




5




6








- NOTE**
- Some USB Hubs may not work, if a USB device connected using a USB Hub is not detected, connect it to the USB port on the TV directly
 - Connect the external power source if your USB is needed.
- NOTE**
- Do not look into the optical output ports, looking at the laser beam may damage your vision
 - Audio with ACP (Audio Copy Protection) function may block digital audio output.



- ARC (Audio Return Channel)**
An external audio device that supports SIMPLINK and ARC must be connected using HDMI IN eARC/ARC port
- When connected with a high-speed HDMI cable, the external audio device that supports ARC outputs, SPDIF audio without additional audio cable and supports the SIMPLINK function
- NOTE**
- Some USB Hubs may not work, if a USB device connected using a USB Hub is not detected, connect it to the USB port on the TV directly
 - Connect the external power source if your USB is needed.



	A	B	C	D	E	F	F - G
	(mm)					(kg)	
50UP7500PTC 50UP7550PTC 50UP7500PTZ 50UP7550PTZ	1130	722	231	663	86.3	11.5	11.3
50UP7500PVG 50UP7550PVG	1130	719	235	663	86.3	11.4	11.3
55UP7500PTC 55UP7550PTC 55UP7500PTZ 55UP7550PTZ	1244	786	231	726	87.1	14.5	14.3
55UP7500PVG 55UP7550PVG	1244	783	235	726	87.1	14.4	14.3
65UP7500PTC 65UP7550PTC 65UP7500PTZ 65UP7550PTZ	1463	914	269	850	87.8	21.6	21.3
65UP7500PVG 65UP7550PVG	1463	910	255	850	87.8	21.5	21.3
70UP7500PTC 70UP7500PTZ 70UP7550PTC 70UP7550PVD	1578	984	299	913	91.1	31.4	30.7
Power requirement				AC 100-240 V ~ 50 / 60 Hz			



- Read **Safety and Reference**.
- The Analog Gender adapter can be purchased separately at Customer Service.

+ : Depending upon model

