LG
Life's Good

ENGLISH

SIMPLE MANUAL

Sound Bar

To view the instructions of advanced features,
visit http://www.lg.com and then download Owner's Manual.
Some of the content in this manual may differ from your unit.

MODEL
SH2




www.lg.com

SH2_APANLLK_SIM_ENG_0124.indd 1 2016-03-04 10:25:23



Front Panel




F ..... Selects Function

– + ... Adjusts Volume

⏻ ..... Power On/Off

Rear Panel



SUB WOOFER (4Ω) ..... Connect to a Subwoofer


OPT. IN ..... Connect to an Optical device

PORT. IN ..... Connect to a Portable device

1 Subwoofer Connection


Place the subwoofer near the sound bar and follow steps below.

1. Press each plastic finger pad to open subwoofer terminals on the unit.
2. Connect the black stripe wire to the terminal marked - (minus) and the other end to the terminal (red tube) marked + (plus).



2 TV Connection

1. Connect the sound bar to the TV using Optical cable.
2. Set up [External Speaker (Optical)] on your TV setting menu.



Controller App



Download the **Music Flow Bluetooth** App to your device.

LG Sound Sync (Wireless)



For more information, download the online owner's manual. **http://www.lg.com**

Additional Information

Specification

Power requirements	Refer to the main label.
Power consumption	Refer to the main label.
	Networked standby : 0.5 W (If all network ports are activated.)
Dimensions (W x H x D)	Approx. 880 mm x 62 mm x 90 mm
Net Weight	Approx. 1.8 kg
Amplifier (Total RMS Output power)	100 W

Design and specifications are subject to change without notice.

Remote control



ASC CINEMA STANDARD : Selects sound effect.
*ASC : Adaptive Sound Control

DRC ON DRC OFF : Makes comfortable sound at Dolby Digital.


WOOFER LEVEL + WOOFER LEVEL - : Adjusts the volume level of subwoofer.

AUTO POWER ON AUTO POWER OFF : Automatically turns on by an input source : Optical, **Bluetooth**, LG TV

How to disconnect the wireless network connection or the wireless device

Set up the AUTO POWER ON/OFF function to off and turn off the unit.

Replacement of battery





SH2_APANLLK_SIM_ENG_0124.indd 4 2016-03-04 10:25:26