


Pagination & Folding

4 pages



Printing Specifications

Material	Cover	-	Note	FSC logo size:	18 mm x 28.1 mm	RYU HWA YEONG	Description	Manual
	Inner	Recycled 30 % 80 g/m²		Purpose:	Eco-friendly certify			
Coating	Cover	-		Country:	GLOBAL			
	Inner	Uncoated		Application type:	For Product	Prepared		
Color	Cover	-		· Especially, Don't use or contain lead (Pb) and cadmium (Cd) in ink. · It should be printed with inks whose the total Mineral Oil(MOSH and MOAH) content is below 1% applied to the ink weight.		2023-11-14		
	Inner	1 color (Black)				Checked	P/No.	MFL70405658
Size		297 mm x 210 mm (Unfolded) 148 mm x 210 mm (A5 size, Folded size)						
Binding Method		Folding (4 pages)				Approved	Ver.	1.0
Book Binding		Center folding once						
Completed total pages		4						

Specification**Power consumption**

- Refer to the main label.

AC adapter

- Model: **DA-50F25**
- Manufacturer: Asian Power Devices Inc.
- Input: 100 - 240 V ~ 50 - 60 Hz
- Output: 25 V $\overline{\text{---}}$ 2 A
- Model: **A650-250200W-M21**
- Manufacturer: Dongguan Aohai Technology Co., Ltd.
- Input: 100 - 240 V ~ 50/60 Hz
- Output: 25 V $\overline{\text{---}}$ 2 A

Dimensions (W x H x D): Approx. 1000.0 mm x 63.0 mm x 105.0 mm

Bus Power Supply (USB): 5 V $\overline{\text{---}}$ 500 mA

Amplifier (Total RMS Output power): 420 W RMS

Open Source Software Notice Information

To obtain the source code that is contained in this product, under GPL, LGPL, MPL, and other open source licenses that have the obligation to disclose source code, and to access all referred license terms, copyright notices and other relevant documents, please visit <https://opensource.lge.com>.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com.

This offer is valid to anyone in receipt of this information for a period of three years after our last shipment of this product.



SIMPLE MANUAL

WIRELESS SOUND BAR

S65Q




MFL70405658

2310_Rev02


www.lg.com

Copyright © 2022-2023 LG Electronics Inc. All Rights Reserved.



ENGLISH Installing and Using the Product

Please read this manual carefully before operating your set and retain it for future reference.
To view the instructions of advanced features, visit <http://www.lg.com> or scan QR code and then download Owner's Manual. Some of the content in this manual may differ from your product.



- (A) Sound bar
(B) Remote Control Receiver / Status Display
(C) Wireless Subwoofer - Install it close to the sound bar.
(D) External Device - (Blu-ray player, game console, etc.)




- 1 Connect the sound bar to your TV via an optical cable or an HDMI cable.
- 2 If you are using an external device (ex. Blu-ray player, game console, etc.), connect it to the sound bar via an HDMI cable.
- 3 Connect to power in the following order: wireless subwoofer → sound bar. Then, turn on the sound bar. When the connection is automatically established with the sound bar, the LED on the wireless subwoofer will light up green.
- 4 Using the product with your TV
 - 1 Press the **Function** (⏏) button repeatedly until "OPT/HDMI ARC" appears on the status display.
 - 2 On your TV's settings, set the output speaker to [HDMI ARC], [Optical], or [External Speaker].
 - 3 When the TV is properly connected to the product, "OPT" or "ARC" appears on the status display with a sound.
- 5 Connecting the product to your smartphone via Bluetooth
 - 1 Tap the **Settings** (⚙) button on your smartphone and select **Bluetooth**. Turn on the **Bluetooth** function. (Off > On)
 - 2 Press the **Bluetooth pair** (🔗) button. After a moment, you will see "BT READY" on the status display.
 - 3 Find and tap the product on your smartphone. The product appears as "LG S65Q (XX)".
 - 4 When the product is connected to your smartphone via **Bluetooth**, you can see the status display change from "PAIRED" → "Connected Bluetooth device name" → "BT".
- 6 Connecting to the LG Sound Bar app
 - 1 Find and install the **LG Sound Bar app** on Google Play or App Store from your smartphone.
 - 2 You can get more information regarding its use by selecting [Help] in [Setting].



If you see a red LED on the front of the wireless subwoofer, it means that the sound bar is not connected to the subwoofer. If this is the case, connect them in the following order.

- 1 Press the **Power** (⏻) button on the sound bar to turn it off.
- 2 Press the **PAIRING** button on the back of the disconnected wireless subwoofer. Check if LED blinks green.
 - If you still see a red LED on the front of the wireless subwoofer, press and hold the button on the back of the subwoofer again.
- 3 Press the **Power** (⏻) button on the sound bar to turn it on.
- 4 When the connection is established, you will see a green LED light on the front of the wireless subwoofer.
- * Keep the sound bar, the subwoofer away from the device (ex. wireless router, microwave oven, etc.) over 1 m to prevent wireless interference.
 - Some speakers may not make sound depend on the input source. Select CINEMA sound mode to listen through all speakers.

- Design and specifications are subject to change without notice.
- Google Play is a trademark of Google LLC.



Replacement of Battery

HDMI™
HIGH-DEFINITION MULTIMEDIA INTERFACE