


















43UQ7500PSF
43UQ7400PSF





MODELS	A		B		C		D		E		F		F-G		Power consumption
MODELOS	(mm)										(kg)				Consumo de potencia
43UQ7500PSF 43UQ7400PSF	973	973	611	611	187	187	572	572	85.0	85,0	8.1	8,1	8.0	8,0	110 W
Power requirement / Alimentación requerida									AC 100 - 240 V~ 50/60 Hz						



A	B	C x D (mm)	E
LSW240B MSW240	43UQ74* 43UQ75*	200 x 200	M6



ENGLISH Read **Safety and Reference**.
Due to environmental government regulations about imports and battery destruction in Colombia, TVs will not include the batteries for the remote control.

ESPAÑOL Leer **Seguridad y Consultas**.
Por regulaciones de tipo ambiental respecto a la importación y destrucción de baterías en Colombia; los televisores no van a traer incluidas las pilas del control remoto.

ENGLISH
Easy Setup Guide
Please read this manual carefully before operating your set and retain it for future reference.

ESPAÑOL
Guía Rápida de Configuración
Lea atentamente este manual antes de poner en marcha el equipo y consérvelo para futuras consultas.

: Depending upon model / Según el modelo