




\*UN8000PWA




55UN80\*


1



2




3




65UN80\*


1




2




3




1




2




3




4-A 55UN80\*




4-B 65UN80\*






5



6





| 型號             |           | 65UN8000PWA        | 55UN8000PWA        |
|----------------|-----------|--------------------|--------------------|
| 尺寸 (寬 x 深 x 高) | 含底座 (公釐)  | 1,453 x 271 x 901  | 1,234 x 232 x 773  |
|                | 不含底座 (公釐) | 1,453 x 84.0 x 840 | 1,234 x 84.0 x 717 |
| 重量             | 含底座 (公斤)  | 23.3               | 16.2               |
|                | 不含底座 (公斤) | 23.0               | 16.0               |
| 電源需求           |           | AC 110 V ~ 60 Hz   |                    |



繁體中文

- 簡易設定指南
- 操作電視機之前，請先詳細閱讀本手冊，並妥善保管手冊以供日後參考。
- 請閱讀安全與相關資訊

⊕：視型號而定