














NAN091*





	A	B	C	D	E	F	F-G
	(mm)					(kg)	
65NANO91TNA 65NANO91VNA	1456	910	324	840	70.5	25.7	24.0
Power requirement / متطلبات الطاقة / Alimentation / Requisito de alimentaao / דרשות חשמל / แรงดันและความถี่ไฟฟ้า / Nguồn điện yêu cầu				AC 100-240 V ~ 50 / 60 Hz تيار متردد 240-100 فولت ~ 60 / 50 هرتز			



English

- Read **Safety and Reference**.
- The Analog Gender adapter can be purchased separately at Customer Service.

Franais

- Lire le document **Scurit et rfrence**.
- L'adaptateur analogique peut tre achet sparment auprs du SAV.

Portugus

- Consulte o manual **Segurana e referncia**.
- O adaptador analgico pode ser comprado em separado no Servio de Apoio ao Cliente da LG.

ภาษาไทย

- โปรดอนคู่มือผู้ใช้**ความปลอดภัยและการอางอิง**
- สายรวมสัญญาณ Component และ AV สามารถซื้อแยกตางหากได้ที่ศูนย์บริการของบริษัท

Ting Vit

- Đọc phần **An ton v Tham kho**.
- Đầu chuyển tín hiệu analog c thể mua ring ti Trung tm chăm sc khch hng của LG.

العربية

- قراءه **الآمان والمرجع**.
- يمكن شراء النوع التناظري بشكل منفصل من دعم عملاء LG.

עברית

- יש לקרוא את **האזהרות בטיחות, הפניות ואיזכורים**.
- כבל לחיבור אנאלוגי ניתן לרכישה במרכז השירות והתמיכה של LG ובחנויות למוצרי חשמל.

+ : Depending on model / حسب الطراز / Selon le modle / Dependendo do modelo / ځړښت ګڼلای / ځړښت ګڼلای / ځړښت ګڼلای