LG
Life's Good

SIMPLE MANUAL

Portable Bluetooth Speaker

MODELS
PH1 / PH1R / PH1L

MFL69561925

www.lg.com

Copyright © 2017 LG Electronics.
All Rights Reserved

Safety Information

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING:

- To prevent fire or electric shock hazard, do not expose this product to rain or moisture.
- Do not install this equipment in a confined space such as a book case or similar unit.
- This unit contains magnets which can be harmful to some kind of object (Ex : Magnetic card, Pacemaker etc..).

H1.AAUSLLK_SIM_ENG_MFL69561925.indd 2 2017-06-09 12:08:17

CAUTION:

- The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- It is recommended that you use the 5 V AC adapter (more than 1.8 A) with this device. If you do not use the recommended adapter, charging is unavailable or charging time may differ.
- To avoid fire or electric shock, do not open the unit. contact to qualified personnel only.
- Do not leave the unit in a place near the heating appliances or subject to direct sunlight, moisture, or mechanical shock.
- To clean the unit, use a soft, dry cloth. If the surfaces are extremely dirty, use a soft cloth lightly moistened with a mild detergent solution. Do not use strong solvents such as alcohol, benzine, or thinner, as these might damage the surface of the unit.
- Do not use volatile liquids such as insecticide spray near the unit. Wiping with strong pressure may damage the surface. Do not leave rubber or plastic products in contact with the unit for a long period of time.
- Do not place the unit over the vehicle's air bag. When the air bag deploys, it may result in injury. Before using in the car, fix the unit.
- Do not use the handsfree function during driving a car.
- Do not leave the unit on an unstable place such as high shelves. it may fall down because of the vibration of the sound.
- Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock.

PH1.AAUSLLK_SIM_ENG_MFL69561925.indd 3 2017-06-09 12:08:17


CAUTION when using this product in environments of low humidity.

- It may cause static electricity in environments of low humidity.
- It is recommended to use this product after touching any metal object which conducts electricity.

NOTICE: For safety marking information including product identification and supply ratings, please refer to the main label on the bottom or the other surface of the product.

- The appliance is not intended for use by young children or infirm persons without supervision.
- Young Children should be supervised to ensure that they do not play with appliance.
- If the appliance is supplied from a cord extension set or an electrical portable outlet device, the cord extension set on electrical portable outlet device must be positioned so that it is not subject to splashing (of water or any form of liquid) or ingress of moisture.

H1.AAUSLLK_SIM_ENG_MFL69561925.indd 4 2017-06-09 12:08:17



Power	Power On / Off	Hold ⏻/I
Bluetooth	To pair your mobile device, select ***LG PH1 (xx)*** from device list. When successfully Paired, **Bluetooth** LED will turn on.	
Playback Controls	Play / Pause	Press >II
	Forward Skip	Press >II X2
	Backward Skip	Press >II X3
Handsfree Function	Receive / Disconnect	Press ✆

PH1.AAUSLLK_SIM_ENG_MFL69561925.indd 5 2017-06-09 12:08:18

Mood LED light Controls

Mood LED light Turn On / Off	Hold
Change Mood LED light mode:	
Various colors → White color → Music-synchronized	Press
ⓘ Music-synchronized option is available only when the speaker is on.	

Important Notice

- Fully charge the device before using for the first time.
- It is recommended that you use the 5 V AC adapter (more than 1.8 A) with this unit.
- Press and hold the ⏻/I button for more than 2 seconds to turn on or off the unit.
- **Bluetooth** connection using the TV, PC or dongle is not supported.
- **Resetting**
  - In case that the unit freezes due to malfunction, press >II and + buttons at the same time.

H1.AAUSLLK_SIM_ENG_MFL69561925.indd 6 2017-06-09 12:08:18

Specification

Power Supply:
- 5 V ⎓ 1.8 A (AC Adapter)
- Built-in rechargeable battery

Power consumption:
- 2.5 W

Dimensions (W x H x D):
Approx. 81 mm X 88 mm X 82 mm

Net Weight: Approx. 0.19 kg

Operating Temperature: 0 °C to 35 °C

Operating Humidity: 5 % to 60 %

Battery Life: Approx. 5 hours
(Varies by volume level and audio content.)

- Design and specifications are subject to change without notice.

For more information, download the online owner's manual. http://www.lg.com

PH1.AAUSLLK_SIM_ENG_MFL69561925.indd 7 2017-06-09 12:08:19



H1.AAUSLLK_SIM_ENG_MFL69561925.indd 8 2017-06-09 12:08:19