LG

LG Pra.L

快速指南

Skin Booster

在操作設備之前，請仔細閱讀本手冊，並保留以備將來參考。

BBS1

本產品不防水。

詳細說明可查閱 LG Electronics 官方網站的線上使用手冊。
你可以使用智能手機掃描二維碼，快速查閱使用手冊。

COV37837505
2409_Rev01

www.lg.com

了解基本功能

採用超聲波滲與電穿孔復合技術，塑肌嫩更水潤

令護膚品的有效成份更加深入地滲透至皮膚內。

※超聲波滲：利用超聲波將護膚品的有效成份傳遞至皮膚內的技術

※電穿孔：利用電脈衝在皮膚表面形成暫時性微孔，將護膚品的有效成份傳遞至皮膚細胞內部的技術

利用經過脈衝的低頻超聲波進行細致的低刺激護理

傳導超聲波與微脈衝，最大程度降低皮膚刺激。

最優化護理頭設計

采用出色的圓角設計，鼻翼、眼周等局部都位也可輕鬆護理。護理頭面積較大，可在短時間內滲透大量有效成份。

Blooming Lighting

利用 Skin Booster 獨有的 Blooming Lighting 功能，可以確認當前使用模式及檔位。


護理頭保護蓋（軟按蓋）

利用護理頭保護蓋保護護理頭，可保持乾淨並妥善保管。

檢查組件



查看產品




5 護理燈
6 電源鍵 ⏻（檔位/模式）鍵
- 開機時：請長按約 1.5 秒以上。
- 關機時：請長按約 2.5 秒以上。
- 更改檔位/模式時：請短按。

7 充電端口（C 型）
8 充電端口蓋
9 電池狀態指示燈
- 50% 以上
- 50-20%
- 20% 以下
- 需要充電

1 超聲波滲護理頭
2 電穿孔護理頭
3 Blooming Lighting（顯示檔位/模式）
4 護理頭保護蓋

電池充電



充電纜配器
（單獨售賣）

開始護理

建議使用原本使用的護膚品或適合皮膚類型的護膚品。



1 清潔面部後，請將護膚品充分塗抹在需要護理的部位。
使用前請打開護理頭保護蓋。



2 請長按電源 ⏻（檔位/模式）鍵1.5 秒以上，開啟產品。
請短按電源 ⏻（檔位/模式）鍵，選擇適合自己的護理強度和模式。



3 如圖所示，請輕輕貼住本儀器使用。



4 如圖所示，在需要的部位慢慢移動導入（促進吸收）護理頭進行護理。

導入模式（3 分鐘，建議每日 1 次）

初次使用時，建議使用第 1 檔 -（共 6 個級別）

●: 亮燈 / ●: 熄滅

功能	電穿孔和超聲促滲（超聲波）的復合功能
Blooming Lighting	● 第 1 檔 ● 第 2 檔 ● 第 5 檔 ● 第 6 檔
護理頭	電穿孔護理頭 超聲促滲護理頭（低刺激護理）
功效	護膚品有效成份導入模式，請使用適合本人的檔位。

- 初次使用時，請以導入模式的 1 檔運行，洗臉使用產品時，將會以上次使用的檔位運行。
- 充電過程中無法使用產品。
- 若護理時間不足，可補充使用。
- 眼周、鼻子等局部部位，請使用圖中標示的護理頭部位進行護理。
- 護理敏感部位（眼周及唇周）時，建議使用低檔位。



強力模式（5 分鐘，建議每周 2~3 次）

●: 亮燈 / ●: 熄滅

功能	只有電穿孔功能
Blooming Lighting	● 第 4 檔 ● 第 5 檔 ● 第 6 檔
護理頭	電穿孔護理頭
功效	請在需要集中護理時使用。

修復模式（3 分鐘，建議每日 1 次）

●: 亮燈 / ●: 熄滅

功能	只有超聲促滲（超聲波）功能
Blooming Lighting	● 第 1 檔 ● 第 2 檔 ● 第 3 檔
護理頭	超聲促滲護理頭（低刺激護理）
功效	修復模式，適合敏感皮膚或皮膚紋理的護理。

產品規格

一般事項	
尺寸（頭 x 高 x 深）	主機：約 73 mm x 97 mm x 32 mm
使用溫度	5℃ - 35℃
使用濕度	0% - 90%
推薦使用次數	每日 1 次 • 充滿電後可在導入模式下以第 6 檔使用約 120 分鐘。（基於本公司內部測試結果） • 使用時間會隨電池的狀態變動，環境溫度或使用條件而異。
完全充電時間	3.5 小時以內

- 5 V ⎓ 2.0 A 充電適配器標準
- 充電時間可能會因充電適配器規格、電池剩餘電量、環境溫度或充電條件而異。

- 設計和規格若有變更，恕不另行通知。
- 本產品為皮膚美容儀，並非醫療儀器，產品功能除了美容效果外，不提供任何醫學功效及效果。

常見問答

Q 應如何進行產品的保養？

A

如果護理後產品或產品的頭部仍留有化妝品等異物，請使用蘸取市販去訊部分，然後用柔軟的乾毛巾或布完全擦拭。



柔軟的乾手帕或布

然後蓋上護理頭保護蓋，並置於通風處保管。

請勿使用強化學產品，如苯、丙酮或甲酚水。



化學物質…
（甲酚水、苯、丙酮等）

使用注意事項

護理皮膚前注意事項

- 本產品為面部專用，不建議用於身體其他部位。
- 使用本產品時，根據個人皮膚狀態，可能出現皮膚泛紅或刺痛等皮膚刺激，若此類刺激持續存在，請立即停止使用，在諮詢皮膚科醫生後再使用。
- 面部有皮膚病或經常患皮炎的使用者，使用前應諮詢專科醫生。
- 若搭配產品使用的護膚品不足，可能會感覺到刺痛等皮膚刺激。
- 若使用頻率高於建議使用週期，可能給皮膚造成刺激。（建議每日 1 次）
- 若按觸皮膚的護理頭部份出現裂痕或破損，請停止使用並聯繫客服中心。
- 護理頭可能存在異物，使用前，請務必將護理頭擦拭幹淨。

安全注意事項

- **有關電源線的注意事項**
  電源插頭是斷電裝置。萬一發生緊急情況，電源插頭必須隨時可用。
- **注意：**充電適配器必須另外購買，並且必須使用認證的充電適配器（5 V ⎓ 2.0 A或更高）。如果使用未經認證的充電器，存在故障和充電時間增加的風險。如果充電不成功，建議嘗試使用另一個認證的充電適配器再次嘗試。
- 給產品充電時，請注意不要讓充電部分沾上水分或化妝品等異物，否則可能會導致產品發熱或引起火災。
- **警告：**禁止在浴缸、淋浴、水槽或其他盛水容器附近使用本設備。



① 安全及注意事項請參考另外的說明書。

LG

LG Pra.L

Quick Guide

Skin Booster

Please read this manual carefully before operating your set and retain it for future reference.

BBS1

This product is not waterproof.

Detailed instructions can be found in the WEB manual from LG Electronics official website. You can quickly access the user manual by scanning the QR code with a smart device.

www.lg.com

Product Features

A technology combining sonophoresis with electroporation for moist skin care

The product makes cosmetic ingredients penetrate deep into the skin.

※ Sonophoresis: A technology which delivers cosmetic ingredients into the skin through ultrasonic waves.

※ Electroporation: A technique which uses electrical pulses to create temporary pores on the skin's surface and enables cosmetic ingredients to penetrate more effectively into skin cells.

Verified low-frequency ultrasound for meticulous and low-irritation care

Ultrasound and micro-vibrations are applied to minimize skin irritation.

Head design optimized for care

The edge design enables easy treatment of targeted areas, such as the sides of the nose and around the eyes, while the large head surface area ensures rapid absorption of active ingredients.

Blooming Lighting

Users can check the current mode and level with Blooming Lighting unique to the Skin Booster.


Head protection cap (soft touch cap)

The head protection cap protects the head part and allows for clean storage and management.

Components




Exploring the Product



1. Sonophoresis head
2. Electroporation head
3. Blooming Lighting (Displays level/mode)
4. Head protection cap
5. Care Lighting
6. Power (Level/Mode) button
   - When turning on: Press and hold for 1.5 seconds or longer.
   - When turning off: Press and hold for 2.5 seconds or longer.
   - When changing the level/mode: Press briefly.
7. Charge port (C type)
8. Charging port cover
9. Battery status indicator
   - 50% or higher
   - 50-20%
   - 20% or less
   - Charging needed

Charging the Battery




Charging adapter (Sold separately)

Starting Care

Use cosmetics that you have been using or those that fit your skin type.



After washing your face, apply cosmetics sufficiently to the parts to be cared for.
Before use, open the head protection cap.



Press and hold the power (level/mode) button for more than 1.5 seconds to turn on the device.

Press the power (level/mode) button briefly to select care intensity and mode suitable for you.



As shown in the image, hold the device gently and naturally to use it.



As shown in the image, move the absorption-boosting head slowly over the desired area.

- The device will start at the first level of Boosting Mode during initial use. When you use the device again, it operates at the level used previously.
- The product cannot be used while charging.
- If the care time is insufficient, you can use for the extended time.
- For localized areas such as around the eyes and nose, use the head area indicated in the illustration.
- When using the device for sensitive areas (around the eyes and mouth), it is recommended to use a lower setting.



Boosting Mode (3 min., Recommended use: Once a day)

It is recommended to start with level 1 for first use. (out of 6 levels)

On / Off

Function	Combined functions of electroporation and sonophoresis (ultrasound)
Blooming Lighting	Level 1 → Level 2 → Level 3 → Level 6
Care Head	Electroporation head Sonophoresis head (low-irritation care)
Effect	Use this mode at the level that suits you to enhance the absorption of active ingredients in cosmetics.

Repair Mode (3 min., Recommended use: Once a day)

On / Off

Function	Sonophoresis (ultrasound)-only function
Blooming Lighting	Fast flashing → Slow flashing → Level 1
Care Head	Sonophoresis head (low-irritation care)
Effect	The repair mode is suitable for sensitive skin or for refining skin texture.

Turbo Mode (5 min., Recommended use: 2-3 times a week)

On / Off

Function	Electroporation-only function
Blooming Lighting	Level 6 → Fast flashing → Slow flashing
Care Head	Electroporation head
Effect	Use on days when intensive care is needed.

Specification

General	
Dimensions (W x H x D)	Main body: Approx. 73 mm x 97 mm x 32 mm
Operating temperature	5°C - 35°C
Operating humidity	0% - 90%
Recommended number of uses	Once a day • When fully charged, the device can be used for approximately 120 minutes on level 6 of Boosting Mode. (Internal test result) • The use duration may vary depending on the battery warranty period, ambient temperature and conditions of use.
Time to full charge	Within 3.5 hours • Based on a 5 V, 2.0 A charging adapter • Charging time may vary depending on charging adapter specifications, battery level, ambient temperature and charging conditions.

- Design and specifications are subject to change without notice.
- This product is a skin care device, not a medical device, and produces no medical effect whatsoever other than the cosmetic effects related to the product function.

Q&A

Q How do I maintain the product? **A**

If there are foreign substances left on the product or product head after the care, wipe off that part with water tissue and wipe again with a soft dry towel or cloth.

Then, close the head protection cap and store it in a well-ventilated place.

Do not use strong chemicals such as thiner, benzene, or acetone.



Soft dry towel or cloth.

Chemical products (thiner, benzene, acetone, etc.)

Precautions for use

Precautions before skin care

- It is not recommended to use the product over other parts of the body except the face.
- When this product is used, there may be skin irritation such as blushing or tingling depending on the user's skin condition. If such irritation persists, stop using it immediately and consult a dermatologist before using it again.
- Those who have a facial skin disease or frequently suffer from facial dermatitis should consult a dermatologist before use.
- If insufficient cosmetics are used with the product, there may be skin irritation such as tingling.
- Using the product more frequently than the recommended use frequency may cause skin irritation. (Recommended use: Once a day)
- If crack or damage occurs on the head part that touches the skin, stop using the product and receive service at the service center.
- There may be foreign substances on the head surface, so make sure to clean the head surface thoroughly before use.

Safety cautions

- **CAUTION concerning the Power Cord**
  The Power Plug is the disconnecting device. In case of an emergency, the Power Plug must remain readily accessible.
- **CAUTION**: The DC Adapter must be purchased separately, and a certified DC adapter (5 V, 2.0 A or higher) must be used. If you use an uncertified charger, there is a risk of breakdown and change in charging time. If charging is unsuccessful, it is recommended to try again with an alternative certified DC adapter.
- When charging the product, be cautious not to get the charging part to be stained with foreign substances such as moisture or cosmetics. Otherwise, it may cause damage to the product or a fire.
- **WARNING:** Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

For safety precautions, refer to the manual provided separately.