
Quick Start Guide

LED TV
UH75**



: Depending on model

Unpacking

Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item.

*Images may vary depending on models.


www.lg.com

P/NO : MFL69446116 (1601-REV00)


English

- Read **Safety and Reference.**
- For the power supply and power consumption, refer to the label attached to the product.

USING THE USER GUIDE




Press the ( ) button
To access home button.





Navigate & Select
User Guide.





Refer User Guide for
Detail information



















⚠ CAUTION

Image shown may differ from your TV.

When attaching the stand to the TV set, place the screen facing down on a cushioned table or flat surface to protect the screen from scratches.









NOTE

Image shown may vary depending on model.
All connection cables & devices shown inthe picture are not included along with the TV set.







⊕ : Depending on model

ARC (Audio Return Channel)

- An external audio device that supports SIMPLINK and ARC must be connected using HDMI IN 2 (ARC) port.
- When connected with a high-speed HDMI cable, the external audio device that supports ARC outputs SPDIF audio without additional audio cable and supports the SIMPLINK function.

NOTE

Image shown may vary depending on model.
All connection cables & devices shown inthe picture are not included along with the TV set.

NOTE

Some USB Hubs may not work. If a USB device connected using a USB Hub is not detected, connect it to the USB port on the TV directly.
Connect the external power source if your USB is needed.


NOTE

- Headphone impedance : 16Ω
- Max audio output of headphone : 0.627 mW to 1.334mW
- Headphone jack size: 0.35 cm

NOTE


- Do not look into the optional output port. Looking at the laser beam may damage your vision.
- Audio with ACP (Audio Copy Protection) function may block digital audio output.






NOTE


Image shown may vary depending on model.
All connection cables & devices shown inthe picture are not included along with the TV set.








NOTE

Image shown may vary depending on model.









	A (mm)	B (mm)	C (mm)	D (mm)	E (mm)	F (kg)	F -(G1 + G2) (kg)
43UH750T-TA 43UH750V-TA 43UH750Y-TA 43UH755T-TC 43UH755V-TC 43UH755Y-TC	971	630	176	577	51.0	12.1	11.7
49UH750T-TA 49UH750V-TA 49UH750Y-TA 49UH755T-TC 49UH755V-TC 49UH755Y-TC	1104	709	218	652	51.0	16.0	15.6

Power requirement	AC 100-240 V ~ 50 / 60 Hz

NOTE

Image may vary depending on model.

	A (mm)	B (mm)	C (mm)	D (mm)	E (mm)	F (kg)	F - (G_1 + G_2) (kg)
55UH750T-TA 55UH750V-TA 55UH750Y-TA 55UH755T-TC 55UH755V-TC 55UH755Y-TC	1239	783	218	726	51.2	19.7	19.3
60UH750T-TA 60UH750V-TA 60UH750Y-TA 60UH755T-TC 60UH755V-TC 60UH755Y-TC	1348	847	252	788	51.9	24.5	23.9
65UH750T-TA 65UH750V-TA 65UH750Y-TA 65UH755T-TC 65UH755V-TC 65UH755Y-TC	1460	909	252	851	52.3	30.6	30.0

Power requirement	AC 100-240 V ~ 50 / 60 Hz



IN020222