English

Product Specifications

Model Name	FS21GB FS22GB
Width x Depth x Height (mm) (Max.)	1159 x 761 x 1061
Weight (kg)	6.0

⚠ CAUTION

- This stand (model name: FS21GB/FS22GB) is designed exclusively for TVs manufactured by LG Electronics Inc. For compatible TV series, please refer to the below table.
- Using it with other equipment may render it unstable and cause injury.

Precautions before Installation

- The Gallery Stand does not include a power strip. In order to connect a TV or other devices on the Gallery Stand, purchase and use a power strip of an appropriate length (2.5 metres or more is recommended).
- The maximum weight mountable on the rear brackets of Gallery Stand is 1.5 kg.
- Mounting a wireless router on the rear brackets of Gallery Stand causes frequency interference due to the proximity of the wireless antenna built into the TV and the wireless router, which may prevent the TV'S artificial intelligence remote control from working properly.
- If you mount a set-top box on the rear brackets of Gallery Stand, the remote control reception unit on the set-top box may be blocked, causing problems with reception to the set-top box. (If problems with the remote control reception continue, the issue may be fixed with the enclosed IR repeater (signal extension cable).)

IR Repeater Mounting Guide

- For the positions of installation, please refer to Ⓐ-Ⓒ of Figure 9 in the installation manual.

Ⓐ Reception unit	Lower end of Gallery Stand Attach with ⬅ facing forwards.
Ⓑ Transmission unit	Reception unit of the set-top box
Ⓒ Power connection unit	USB terminal of the TV or the set-top box

Models Compatible with the Gallery Stand

Compatible Model Released in 2019

Product Group	Inches	Series
OLED	55/65	C9 B9
SUHD	55	SM98 SM96 SM95 SM90
	55/65	SM89 SM86 SM85 SM83 SM82 SM81 SM80

Compatible Model Released in 2020

Product Group	Inches	Series
OLED	55/65	GX CX BX
NANO	55/65	NANO93 NANO91 NANO90 NANO87 NANO86 NANO85 NANO83 NANO81 NANO80
	55	NANO95


Compatible Model Released in 2021

Product Group	Inches	Series
OLED	55/65	G1 C1 B1 A1
NANO	55/65	NANO75 NANO76 NANO77 NANO79 NANO80 NANO81 NANO83 NANO85 NANO86 NANO88
UHD	55/60/65	UP80 UP81 UP82 UP83 UP77 UP78

Compatible Model Released in 2022


Product Group	Inches	Series
OLED	55/65	G2 C2 B2 A2
NANO	55/65	NANO75 NANO80
UHD	55/60/65	UQ80 UQ90

How to Prevent TV from Falling




1 Fix the brackets on the rear part of the product and on the wall as shown in the picture. Secure the product brackets and wall brackets at the same height.
2 Verify that the product brackets and wall brackets are firmly fastened.
3 Use a cord to tie and connect the wall brackets. When moving a product installed in this way, please untie the cord first.

- Install the TV in the horizontal position only.
- It is safe to install the product according to the installation method to prevent the damage to the product or personal injury even if the product is pulled forward.
- Install the TV near a wall to prevent falls when pushed.



Make the knot as in the drawing.

How to Adjust the Height on Both Sides of the TV on Gallery Stand



- Loosen the screw halfway by using a Phillips screwdriver, adjust the height on both sides of the TV as illustrated, and tighten the screw.

MBM67484312
(2203-REV02)

日本語

製品仕様

モデル名	FS21GB FS22GB
幅x奥行きx高さ(mm) (最大)	1159 x 761 x 1061
重量(kg)	6.0

⚠ 注意

- このスタンド(モデル名:FS21GB/FS22GB)は、LG Electronics Inc.が製造したテレビ専用に設計されています。互換性のあるテレビシリーズについては、以下の表を参照してください。
- 他の機器と併用すると、不安定になりけがの原因になります。

取り付け前の注意事項

- ギャラリースタンドには電源タップは付属していません。ギャラリースタンドにテレビやその他のデバイスを接続する場合は、適切な電源タップを購入して使用してください(2.5メートル以上の長さの電源タップをおすすめします)。尚、電源タップを使用する時は、電源タップの取扱説明書をよく読んで使用してください。
- ギャラリースタンドの背面ブラケットに取り付け可能な最大重量は1.5kgです。
- ギャラリースタンドの背面ブラケットにワイヤレスルーターを取り付けると、テレビに組み込まれているワイヤレスアンテナとワイヤレスルーターが近接しているため、周波数干渉が発生し、テレビのインテリジェントリモコンが正常に機能しなくなることがあります。
- ギャラリースタンドの背面ブラケットにセットトップボックスを取り付けると、セットトップボックスのリモコン受信ユニットがブロックされ、セットトップボックスへの受信に問題が発生する場合があります。(リモコンの受信に関連する問題が続く場合は、同梱のIRリピーター(信号延長ケーブル)で問題が解決する場合があります。)

IRリピーター取り付けガイド

- 取り付け位置については、取り付けマニュアルの図9のⒶ-Ⓒを参照してください。

Ⓐ 受信ユニット	ギャラリースタンドの下端 ⬅ 前方を向けて取り付けます。
Ⓑ 送信ユニット	セットトップボックスの受信ユニット
Ⓒ 電源接続ユニット	テレビまたはセットトップボックスのUSB端子

ギャラリースタンド対応モデル

2019年に発売された互換性のあるテレビ

製品グループ	インチ	シリーズ
OLED	55/65	C9 B9
SUHD	55	SM90
	55/65	SM81

2020年に発売された互換性のあるテレビ

製品グループ	インチ	シリーズ
OLED	55/65	GX CX BX
NANO	55	NANO95
	55/65	NANO91


2021年に発売された互換性のあるテレビ


製品グループ	インチ	シリーズ
OLED	55/65	G1 C1 B1 A1
NANO	55/65	NANO76 NANO75
UHD	55/65	UP80

2022年に発売された互換性のあるテレビ

製品グループ	インチ	シリーズ
OLED	55/65	G2 C2 B2 A2
NANO	55/65	NANO75 NANO80
UHD	55/60/65	UQ80 UQ90

テレビの転倒を防ぐ方法






適切なネジを使用して壁に取り付けます。


1 図のように、製品後部と壁にブラケットを固定します。製品ブラケットと壁ブラケットを同じ高さに固定します。
2 製品ブラケットと壁ブラケットがしっかりと固定されていることを確認します。
3 コードを使用して、壁掛けブラケットに結んで接続します。この方法で取り付けた製品を移動させる場合は、まずコードをほどいてください。

- テレビは水平な場所に設置してください。
- いかなる場合でも事故や製品の損傷を避けるために、設置方法に従い安全に設置してください。
- テレビを壁の近くに設置する場合は、壁の揺れなどによる壁との接触でテレビの転倒などにご注意ください。



図のように結びます。

ギャラリースタンドのテレビの両側の高さを調整する方法



- プラスドライバーを使用してネジを半分ほど緩め、図のようにテレビの両側の高さを調整して、ネジを締めます。