



OWNER'S MANUAL

Color Video Camera

Please read this manual carefully before operating your set and retain it for future reference.

MODEL
L5213-BN
L5213-BP
L5213-DN

P/NO : MFL63745108 (A)

Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.





CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK
DO NOT REMOVE COVER (OR BACK)
NO USER-SERVICEABLE PARTS INSIDE
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

- 

This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.
- 

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.




FCC WARNING: This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

REGULATORY INFORMATION: FCC Part 15

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

- A suitable conduit entries, knock-outs or glands shall be provided in the cable entries of this product in the end user.

Accessories

Installation sticker	
Camera mounting bracket	
M3 Fixing screws	

- Caution: Danger of explosion if battery is incorrectly replaced. Replaced only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.
- Holes in metal, through which insulated wires pass, shall have smooth well rounded surfaces or shall be provided with brushings.

This Class A digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

- Warning:** Do not install this equipment in a confined space such as a bookcase or similar unit.
- Warning:** Wiring methods shall be in accordance with the National Electric Code, ANSI/NFPA 70.
- Warning:** This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.
- Warning:** To reduce a risk of fire or electric shock, do not expose this product to rain or moisture.
- Caution:** This installation should be made by a qualified service person and should conform to all local codes.
- Caution:** To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.
- Caution:** The apparatus shall not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, shall be placed on the apparatus.

To disconnect power from mains, pull out the mains cord plug. When installing the product, ensure that the plug is easily accessible.


Specification

Item		L5213-BP	L5213-BN	L5213-DN
Signal System		PAL	NTSC	
Total Pixels		470 000 Pixels	410 000 Pixels	
Effective Pixels		440 000 Pixels	380 000 Pixels	
Image Device		6 mm Super HAD II CCD		
DSP		XDI-S2		
Lens		2.8 mm to 11 mm Vari-focal lens (F1.4)		
Digital Zoom		X8		
Synchronization System		Internal		
Scanning Frequency (H/V)		15.625 kHz / 50 Hz	15.734 kHz / 59.94 Hz	
Horizontal Resolution		620 TV Lines		
S/N Ratio		52 dB		
Minimum Illumination (30 IRE)	Color mode	0.06 lx (Sens-up OFF, F1.4)		
		0.0001 lx (Sens-up Auto, F1.4)		
	B/W mode	0.006 lx (Sens-up OFF, F1.4)		
		0.000 001 lx (Sens-up x128, F1.4)		
Control Method		Inner Key Button		
Video Output Signal		1 Vp-p Composite (75 Ω)		
Day & Night		Day / Night / Auto		
BACKLIGHT		OFF / BLC / HSBLC		
DNR		3D-DNR (Off/Low/Middle/High)		

CE LG Electronics hereby declares that this/these product(s) is/are in compliance with the essential requirements and other relevant provisions of Directive 2004/108/EC, 2006/95/EC, and 2009/125/EC.
European representative :
LG Electronics Service Europe B.V.
Veluwezoom 15, 1327 AE Almere,
The Netherlands (Tel : +31-(0)36-547-8888)


Disposal of your old appliance

- 
1. When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
 2. All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
 3. The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
 4. For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.
- <For Turkey only>
5. EEE Compliance with Directive.
(EEE Yönetmeliğine Uygundur.)




Item	L5213-BP	L5213-BN	L5213-DN
Auto Gain Control	Off / Low / Middle / High		
Electronic Shutter Speed	1/50 to 1/90 000	1/60 to 1/90 000	
Electronic Sensitivity	OFF/Auto		
White Balance	ATW / AWC ➡ PUSH / Manual		
Motion Detection	4 Zones		
Privacy Zone Masking	8 Masks		
Stabilizer(EIS)	On / Off		
User Color Mode	STANDARD/COOL/WARM/VIVID		
Power Source	DC 12 V / AC 24 V		DC 12 V
Power Consumption	2.8 W		2.2 W
Operation Temp.	-10 °C to 50 °C		
Storage Temp.	-20 °C to 60 °C		
Operation Humidity	0 % RH to 80 % RH		
Storage Humidity	0 % RH to 85 % RH		
Weight	323 g		
Dimension (Ø x H)	Ø 140 x 87.3 mm		


Installation Guide




<ITALIANO>	Utilizzando il modello come guida, praticare un foro attraverso il soffitto.
<FRANÇAIS>	En vous servant du modèle comme guide, percez un trou dans le plafond.
<ESPAÑOL>	Usando la plantilla como guía, haga un agujero en el techo.
<PORTUGUÊS>	Usando o molde como um guia, faça um furo no teto.
<PYCCKHŨ>	Используя шаблон как вспомогательный элемент, сделать отверстие в потолке.
<POLSKI>	Używając szablonu wykonać otwór w suficie.
<ČEŠTINA>	Pomocí šablony udělejte díru do stropu.



<ITALIANO>	Installare la staffa per il montaggio della videocamera al soffitto.
<FRANÇAIS>	Fixez le support de montage de la caméra au plafond.
<ESPAÑOL>	Instale el soporte de la cámara en el techo.
<PORTUGUÊS>	Instale o suporte de montagem da câmera no teto.
<PYCCKHŨ>	Прикрепить монтажный кронштейн камеры к потолку.
<POLSKI>	Zainstalować na suficie wspornik montażowy kamery.
<ČEŠTINA>	Instalujte mechanismus pro uchycení kamery na strop.




<ITALIANO>	Collegare i cavi alle prese sul corpo della videocamera.
<FRANÇAIS>	Raccordez les câbles aux prises correspondantes du corps de la caméra.
<ESPAÑOL>	Conecte los cables en los terminales del cuerpo de la cámara.
<PORTUGUÊS>	Conecte os cabos na tomada de cabos do corpo da câmera.
<PYCCKHŨ>	Подключить кабели к разъемам на корпусе камеры.
<POLSKI>	Podłączyć kable do gniazd znajdujących się w obudowie kamery.
<ČEŠTINA>	Zapojte kabely do konektorů těla kamery.




<ITALIANO>	Montare la videocamera e la staffa come illustrato nei passi 1 e 2.
<FRANÇAIS>	Assemblez la caméra et le support de montage comme illustré aux étapes 1 et 2.
<ESPAÑOL>	Monte la cámara y el soporte como se muestra en los pasos 1 y 2.
<PORTUGUÊS>	Monte a câmera e o suporte de montagem conforme mostrado nos passos 1 e 2.
<PYCCKHŨ>	Соединить камеру и монтажный кронштейн, как показано на иллюстрации шага 1 и 2.
<POLSKI>	Zamontować kamerę na wsporniku montażowym tak, jak to pokazano na ilustracji kroku 1 oraz 2.
<ČEŠTINA>	Připevněte kameru a mechanismus pro uchycení jak je vyobrazeno v kroku 1 a 2.


Camera Adjustment




<ITALIANO>	Collegare un monitor portatile alla presa video.
<FRANÇAIS>	Raccordez un moniteur portable à la prise vidéo.
<ESPAÑOL>	Conecte un monitor portátil a la conexión de video.
<PORTUGUÊS>	Conecte o monitor portátil na tomada de vídeo.
<PYCCKHŨ>	Подключить переносной монитор к разъему видео.
<POLSKI>	Podłącz monitor przenośny do złącza video (video jack).
<ČEŠTINA>	Zapojte přenosný monitor ke konektoru videa.



<ITALIANO>	Regolare la posizione Pan/Tilt della videocamera.
<FRANÇAIS>	Réglez la position de panoramique/inclinaison de la caméra.
<ESPAÑOL>	Ajuste la posición de movimiento panorámico/inclinación de la cámara.
<PORTUGUÊS>	Ajuste as posições de Pan/Inclinar da câmera.
<PYCCKHŨ>	Регулировать наклон/поворот камеры.
<POLSKI>	Ustaw panoramę/pochylenie kamery.
<ČEŠTINA>	Nastavte pozici kamery Pan/Tilt.



<ITALIANO>	Regolare l'angolo dell'azimut.
<FRANÇAIS>	Réglez l'angle d'azimut.
<ESPAÑOL>	Ajuste el ángulo de azimut.
<PORTUGUÊS>	Ajuste o ângulo de fundo.
<PYCCKHŨ>	Регулировать угол перекося.
<POLSKI>	Ustaw kąt azymutu.
<ČEŠTINA>	Nastavte azimut.



<ITALIANO>	Regolare lo zoom e la messa a fuoco.
<FRANÇAIS>	Réglez le zoom et la mise au point.
<ESPAÑOL>	Ajuste el zoom y el enfoque.
<PORTUGUÊS>	Ajuste o zoom e o foco..
<PYCCKHŨ>	Регулировать зум и фокус.
<POLSKI>	Ustaw przybliżenie oraz ostrość.
<ČEŠTINA>	Nastavte přiblížení/oddálení a zaostření.