SIMPLE MANUAL

LG Wi-Fi
SOUND BAR

Please read this manual carefully before operating your set and retain it for future reference.
To view the instructions of advanced features, visit http://www.lg.com and then download Owner's Manual.
Some of the content in this manual may differ from your unit.

MODEL
SL7Y

SLOVENŠČINA | ČESKY | ENGLISH
SHQIP | SLOVENČINA | DEUTSCH
BOSANSKI | POLSKI | FRANÇAIS
SVENSKA | ROMÂNĂ | NEDERLANDS
DANSK | LATVIEŠU | ITALIANO
NORSK | HRVATSKI | ESPAÑOL
SUOMI | SRPSKI | ΕΛΛΗΝΙΚΑ
БЪЛГАРСКИ | PORTUGUÊS
МАКЕДОНСКИ | MAGYAR

MFL71399806
1901_Rev01

www.lg.com
Copyright © 2019 LG Electronics Inc. All Rights Reserved.

Front Panel

The buttons are located on the side.

⏻ (Standby) ········ Switches the unit ON or OFF.
F (Function) ······················ Selects function.
━/╋ (Volume) ·················· Adjusts volume.
📶 ·························· Selects Wi-Fi function.

Rear Panel

DC IN

5 V ⎓ 500 mA   OPTICAL IN   HDMI IN   (TV ARC) HDMI OUT

DC IN ······························· AC adapter input.
USB port ··················· Connect to a USB device.
OPTICAL IN ··········· Connect to an optical device.
HDMI IN ·········· Connect to device with HDMI OUT.
(TV ARC) HDMI OUT ··············· Connect to a TV.

> ⚠
> It is recommended that you purchase a USB gender separately for the convenience of USB insertion and extraction.
> (Recommended USB gender type : USB 2.0 extension cable)

Subwoofer Connection

Place the wireless subwoofer near the sound bar and follow steps below.

❶ Connect the power cord of the sound bar and the wireless subwoofer to the outlet.

❷ Turn on the sound bar.
  • The sound bar and wireless subwoofer will be **automatically** connected. The subwoofer's green LED turns on.

Manual Subwoofer Connection

If the subwoofer does not make sound, try to connect manually.

❶ Press **Pairing** on the rear of the wireless subwoofer.
  • The green LED on the rear of the wireless subwoofer blinks quickly.
    (If the green LED does not blink, press and hold the **Pairing**.)

❷ Turn on the sound bar.
  • Pairing is completed. The green LED on the rear of the wireless subwoofer turns on.

> ⚠
> Keep the sound bar and the subwoofer away from the device (ex. wireless router, microwave oven, etc.) over 1 m to prevent wireless interference.
>
>
>
> >1 m

TV Connection

Connect the sound bar and TV using Optical (Ⓐ) or HDMI ARC (Ⓑ).

Ⓐ Optical Connection

❶ Connect the sound bar to the TV using Optical cable.

❷ Set up [External Speaker (Optical)] on your TV setting menu.


Ⓑ HDMI(ARC) Connection

❶ Connect the sound bar to the TV using HDMI cable.

❷ Set up [External Speaker (HDMI ARC)] on your TV setting menu.

> • HDMI connection is unavailable if your TV does not support HDMI ARC.
> • If this unit is connected by OPTICAL and ARC at the same time, the ARC signal is a high priority.

Additional Device Connection

❶ Connect to the external device like as follow.

(Set-top Box, Player etc.)

OR

❷ Set the input source by pressing **F** repeatedly.

Network Connection

❶ Check network condition. A router connected to network should be installed.

❷ Connect your smart device to your home network.

❸ Connect the sound bar to the power supply.

> All devices should be connected to same router.

Download LG Wi-Fi Speaker Application

Download "LG Wi-Fi Speaker" on the App Store or Google Play.

Launch LG Wi-Fi Speaker App

Follow the steps for wireless connection displayed on the screen.

Additional Information

Specification

Power consumption	Refer to the main label.
	Networked standby : 6.0 W (If all network ports are activated.)
AC adapter	• Model : DA-50F25 • Manufacturer : Asian Power Devices Inc. • Input : 100 - 240 V ~ 50 - 60 Hz • Output : 25 V $=$ 2 A
Dimensions (W x H x D)	Approx. 1060.0 mm x 57.0 mm x 85.0 mm With foot
Bus Power Supply (USB)	5 V $=$ 500 mA
Amplifier (Total RMS Output power)	420 W RMS

Design and specifications are subject to change without notice.

Remote control

Replacement of Battery

◁◁/▷▷: Skip

▷‖: Play/Pause

- **Bluetooth connection lock (BT LOCK):** Select the **Bluetooth** function by pressing **F** repeatedly. Long press ▷‖ and press it again to limit Bluetooth connection to only BT and LG TV.

SOUND EFFECT: Selects a sound effect mode.

- **TV remote:** Long press **SOUND EFFECT** and press it again to use TV remote control.

FOLDER ⋀/⋁: Searches a folder

ⓘ: Displays the information of a file, an input source or connected **Bluetooth** device name.

- **Auto Power ON/OFF:** Long press ⓘ and press it again.

🎚: Adjusts sound level of each speaker.

- **Surround sound:** Long press 🎚 and press it again.

REPEAT: Listens to your files repeatedly or randomly.

> ⚠
> ### Rear Speakers Ready
> Ready for surround sound with Rear Speakers Kit sold separately. (SPK8-S)

How to disconnect the wireless network connection or the wireless device

Press and hold the " 📶 " button until you hear the beep sound once.

OPEN SOURCE SOFTWARE NOTICE INFORMATION

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit http://opensource.lge.com.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com.

This offer is valid for a period of three years after our last shipment of this product. This offer is valid to anyone in receipt of this information.

Declaration of Conformity

Hereby, LG Electronics declares that the radio equipment type Wi-Fi Sound Bar is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

http://www.lg.com/global/support/cedoc/cedoc#

The use of the 5150 – 5350 MHz band is restricted to indoor use only. This restriction exists in the countries Belgium (BE), Bulgaria (BG), Czech Republic (CZ), Denmark (DK), Germany (DE), Estonia (EE), Ireland (IE), Greece (EL), Spain (ES), France (FR), Croatia (HR), Italy (IT), Cyprus (CY), Latvia (LV), Lithuania (LT), Luxembourg (LU), Hungary (HU), Malta (MT), Netherlands (NL), Austria (AT), Poland (PL), Portugal (PT), Romania (RO), Slovenia (SI), Slovakia (SK), Finland (FI), Sweden (SE), United Kingdom (UK), Switzerland (CH), Iceland (IS), Liechtenstein (LI) and Norway(NO).

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

Frequency range	Output power (Max.)
2402 to 2480 MHz	10 dBm
2412 to 2472 MHz	16 dBm
5180 to 5240 MHz	20.1 dBm
5730 to 5821 MHz	13 dBm

HIGH-DEFINITION MULTIMEDIA INTERFACE