LG
Life's Good

SIMPLE MANUAL

Wireless Sound Bar

Please read this manual carefully before operating your set and retain it for future reference.
To view the instructions of advanced features, visit http://www.lg.com and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL

SN6Y

MFL71669664
2105_Rev02

Front Panel

The buttons are located on the side.

⏻ (Standby) ··········· Switches the unit ON or OFF.
F (Function) ·························· Selects function.
−/+ (Volume) ······················ Adjusts volume.

Rear Panel

DC IN ···················· Connect to the AC adapter.
USB (Service only) ·········· S/W download connector.
OPTICAL IN ············· Connect to an optical device.
HDMI IN ·········· Connect to device with HDMI OUT.
(TV ARC) HDMI OUT ··············· Connect to a TV.

> ⚠
> • It is recommended that you purchase a USB gender separately for the convenience of USB insertion and extraction. (Recommended USB gender type : USB 2.0 extension cable)
> • Make sure to properly align and connect the optical cable; improper alignment may cause damage to the jack.

Subwoofer Connection

Place the wireless subwoofer near the sound bar and follow steps below.
1 Connect the power cord of the sound bar and the wireless subwoofer to the outlet.
2 Turn on the sound bar.
   • The sound bar and wireless subwoofer will be **automatically** connected. The subwoofer's green LED turns on.

Manual Subwoofer Connection
If the subwoofer does not make sound, try to connect manually.
1 Press **PAIRING** on the rear of the wireless subwoofer.
   • The green LED on the rear of the wireless subwoofer blinks quickly.
   (If the green LED does not blink, press and hold the **PAIRING**.)
2 Turn on the sound bar.
   • Pairing is completed. The green LED on the rear of the wireless subwoofer turns on.

> ⚠
> Keep the sound bar and the subwoofer away from the device (ex. wireless router, microwave oven, etc.) over 1 m to prevent wireless interference.
>
> > 1 m

TV Connection

Connect the sound bar and TV using Optical (Ⓐ) or HDMI ARC (Ⓑ).

Ⓐ **Optical Connection**
1 Connect the sound bar to the TV using Optical cable.
2 Set up [External Speaker (Optical)] on your TV setting menu.

TV	OPTICAL OUT
	OPTICAL IN

Ⓑ **HDMI (ARC) Connection**
1 Connect the sound bar to the TV using HDMI cable.
2 Set up [External Speaker (HDMI ARC)] on your TV setting menu.

TV	HDMI IN (ARC)
	(TV ARC) HDMI OUT

> ⚠
> • HDMI connection is unavailable if your TV does not support HDMI ARC.
> • If this unit is connected by OPTICAL and ARC at the same time, the ARC signal has a higher priority.

Additional Device Connection
1 Connect to the external device like as follow.

(Set-top Box, Player etc.)

HDMI OUT
HDMI IN

TV	OPTICAL OUT		HDMI IN (ARC)
	OPTICAL IN	OR	(TV ARC) HDMI OUT

2 Set the input source by pressing **F** repeatedly.

Remote control

Replacement of Battery

◄◄/►►| : Skip
►|| : Play/Pause
- **Bluetooth connection lock (BT LOCK):** Select the **Bluetooth** function by pressing **F** repeatedly. Long press ►|| and press it again to limit Bluetooth connection to only BT and LG TV.
SOUND EFFECT: Selects a sound effect mode.
- **TV remote:** Long press **SOUND EFFECT** and press it again to use TV remote control.
☽ : Turns on or off the Night time mode.
ⓘ : Displays the information of a file, an input source or connected **Bluetooth** device name.
- **Auto Power ON/OFF:** Long press ⓘ and press it again.
🔊 : Adjusts sound level of each speaker.
- **Surround sound:** Long press 🔊 and press it again.
✱ : This button is not available.

Additional Information

Specification

Power consumption	Refer to the main label.
AC adapter	• Model : DA-50F25 • Manufacturer : Asian Power Devices Inc. • Input : 100 - 240 V ~ 50 - 60 Hz • Output : 25 V ⎓ 2 A • Model : MS-Z2000R250-050D0-P • Manufacturer : MOSO POWER SUPPLY TECHNOLOGY CO, LTD. • Input : 100 - 240 V ~ 50/60 Hz • Output : 25 V ⎓ 2 A
Dimensions (W x H x D)	Approx. 1060.0 mm X 57.0 mm X 85.0 mm With foot
Amplifier (Total RMS Output power)	420 W RMS

Design and specifications are subject to change without notice.

> ⚠
> **Rear Speakers Ready**
> Ready for surround sound with Rear Speakers Kit sold separately. (SPK8-S)

After Sales Service (Egypt Only)
Shelf Life Time : 2 Years
LG is committed to providing all spare parts of this device during the shelf life time.

Open Source Software Notice Information

To obtain the source code under GPL, LGPL, MPL, and other open source licenses that have the obligations to disclose source code, that is contained in this product, and to access all referred license terms, copyright notices and other relevant documents please visit https://opensource.lge.com.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com.

This offer is valid to anyone in receipt of this information for a period of three years after our last shipment of this product.

HDMI™

SN6Y.DEGYLLK_SIM (Sheet)_MFL71669664.indd   1-4   2022-03-29   2:06:31

معلومات إضافية

المواصفات

المواصفات		
استهلاك الطاقة	• الطراز : DA-50F25 • المصنّع : Asian Power Devices Inc. • الدخل : ١٠٠ ~ ٢٤٠ فولت ~ ٥٠ ~ ٦٠ هرتز • الخرج : ٢٥ فولت ⎓ ٢ أمبير	
محوّل التيار المتردد AC	• الطراز : -MS-Z2000R250 050D0-P • المصنّع : MOSO POWER SUPPLY TECHNOLOGY CO., LTD. • الدخل : ١٠٠ ~ ٢٤٠ فولت ~ ٦٠/٥٠ هرتز • الخرج : ٢٥ فولت ⎓ ٢ أمبير	
الأبعاد (العرض × الارتفاع × العمق)	تقريبًا ١٠٦٠٠، مم ٥٧٠، × مم ٨٥٠، مم مع	
مضخم الصوت (إجمالي طاقة خرج RMS)	٤٢٠ وات RMS	

تخضع التصاميم والمواصفات للتغييرات دون إخطار مسبق.

الخلفية السماعات

تتطلب لصوت المحيطي باستخدام مجموعة السماعات
الخلفية والتي تباع بصورة منفصلة. (SPK8-S)

جهاز التحكم عن بعد

استبدال البطارية

- إيقاف/تشغيل :⏻
- تخطي :⏮/⏭
- تشغيل/إيقاف :⏯
- قفل اتصال BLUETOOTH (BT LOCK) :
اختر وظيفة Bluetooth بالضغط على F بشكل متكرر.
اضغط مطولاً على ⏯ ثم اضغط مجددًا لتحديد إتصال
Bluetooth بـ BT أو TV LG.
- SOUND EFFECT: قم باختيار نمط تأثير الصوت
- SOUND التحكم في التأثير: اضغط مطولاً على ⏯ على
EFFECT ثم اضغط مجددًا لاستخدام جهاز التحكم بالتأثيرات.
- ⏻: قم بتشغيل أو إغلاق نمط وقت السماعة.
- ⏹: قم بعرض المعلومات الخاصة بالملف، مصدر إدخال، أو
اسم جهاز Bluetooth متصل.
- التشغيل التلقائي تشغيل/إيقاف: اضغط مطولاً على ⏯ ثم
اضغط مجددًا.
- ⏮/⏭: قم بتعديل مستوى الصوت لكل مكبر الصوت.
- الصوت المعتم: اضغط مطولاً على ⏯ ثم اضغط مجددًا.
- ⏯ : إن إن الزر غير متاح.

توصيل التليفزيون

وصل مكبر الصوت والتلفاز باستخدام Optical (Ⓐ) أو
HDMI ARC (Ⓑ).

Ⓐ التوصيل البصري

1. وصل مكبر الصوت والتلفاز باستخدام الكابل الضوئي.
2. قم بإعداد [(External Speaker (Optical] في قائمة
الضبط بالتليفزيون.

Ⓑ HDMI (ARC) اتصال

1. وصل مكبر الصوت والتلفاز باستخدام كابل HDMI.
2. قم بإعداد [(External Speaker (HDMI ARC] في
قائمة الضبط بالتليفزيون.

> • لن تكون خاصية التوصيل لميكروفون HDMI إذا لم يكن
> بجهاز التلفاز مقبس HDMI ARC.
> • إذا كانت الوحدة متصلة عن طريق OPTICAL و
> ARC في نفس الوقت، فسيكون لإشارة ARC
> الأولوية.

توصيل الجهاز الإضافي

1. وصّله بالجهاز الخارجي كما يلي:

2. قم بضبط مصدر الإدخال بالضغط على F بشكل متكرر.

اللوحة الأمامية

الأزرار موجودة على الجانب.

- ⏻ (استعداد) .... لتشغيل الوحدة أو إيقاف تشغيلها.
- F (الوظيفة) .... يحدد الوظيفة.
- +/− (التحكم بالصوت) .... يضبط مستوى الصوت.

اللوحة الخلفية

- DC IN .... قم بتوصيل محوّل التيار المتردد.
- USB (لعمليات الصيانة فقط) ...... موضع تنزيل البرامج.
- OPTICAL IN .... يُستخدم للتوصيل بجهاز بصري.
- HDMI IN ...... للتوصيل بجهاز به منفذ HDMI OUT.
- HDMI OUT (TV ARC) ..... يُستخدم للتوصيل بجهاز
التلفزيون.

> • من المستحسن أن تقوم بشراء USB gender
> منفصلة لراحة إدخال وإخراج USB. (نوع USB
> الموصى به تحديد ذلك؛ نوع USB 2.0 الـ gender
> • إذا لم تصل الكبل البصري بالاتجاه الصحيح،
> عندها قد يسبب التلف للمقبل البصري.

توصيل مضخم الصوت

ضع مضخم الصوت بالقرب من مكبر الصوت واتبع الخطوات
الواردة أدناه.

1. وصّل سلك الطاقة لمكبر الصوت ومضخم الصوت اللاسلكي
بمأخذ التيار الكهربائي.
2. قم بتشغيل مكبر الصوت.
• سيتم توصيل السماعة اللوحية ومضخم الصوت اللاسلكي
تلقائيًا. يعمل الضوء الأخضر لمكبر الصوت.

توصيل مكبر الصوت يدويًا

إذا لم يعمل صوت مضخم صوت افحد التوصيل يدويًا.
1. اضغط PAIRING على الجزء الخلفي من مضخم الصوت
اللاسلكي.
• يومض المصباح الأخضر على الجانب الخلفي من مكبر
الصوت بالاتصال اللاسلكي بسرعة.
(إذا لم يظهر المؤشر الأخضر، اضغط مطولاً على
PAIRING.)
2. قم بتشغيل مكبر الصوت.
• اكتمل الإقران. يعمل المصباح الأخضر على الجانب
الخلفي من مكبر الصوت بالاتصال اللاسلكي.

> احفظ مكبر الصوت الأفقي و مكبر الصوت بعيدا عن
> الأجهزة (مثل: الراوتر اللاسلكي و فرن الميكروويف
> إلخ) بمسافة ١ متر لعمل الداخل اللاسلكي.
>
> ١ متر >

الدليل البسيط

المكبر الصوتي
اللوحي اللاسلكي

يُرجى قراءة هذا الدليل بعناية قبل تشغيل الجهاز الذي بحوزتك واحتفظ به للرجوع إليه في
المستقبل.

لعرض تعليمات الخصائص المتقدمة، تفضل بزيارة موقع http://www.lg.com وقم بتحميل
دليل المالك. يمكن أن تختلف بعض محتويات هذا الدليل عن المشغل الخاص بك.

الطراز

SN6Y

HDMI™
HIGH-DEFINITION MULTIMEDIA INTERFACE

LG
Life's Good