

USER GUIDE

# LG Watch Urbane™

2<sup>ND</sup> EDITION | *LTE*

LG-W200A

Thank you for choosing LG. Please carefully read this user guide before using the device for the first time to ensure safe and proper use. Visit the LG website at [www.lg.com](http://www.lg.com) to obtain the latest version of this manual.

- Always use genuine LG accessories. The items supplied are designed only for this device and may not be compatible with other devices.
- Due to the touchscreen, this device is not suitable for the visually impaired.
- Descriptions are based on the device's default settings.
- Default apps on the device are subject to updates. Support for these apps may be withdrawn without prior notice. If you have any questions about an app provided with the device, please contact an LG Service Center. For user-installed apps, please contact the relevant service provider.
- Modifying the device's operating system or installing software from unofficial sources may damage the device and lead to data corruption or loss. Such actions will violate your LG license agreement and void your warranty.
- Some content and illustrations may differ from your device depending on the region, service provider, software version, or OS version, and are subject to change without prior notice.
- The apps on your device, and their functions, may vary according to country, region or hardware specifications. LG will not be responsible for any performance issues which arise from using applications developed by providers other than LG.
- LG will not be responsible for performance or incompatibility issues which arise from edited registry settings or modified operating system software.
- Any attempt to customize your operating system may lead to the device or its apps not working correctly.
- Software, audio, wallpaper, images, and other media supplied with your device are licensed for limited use. If you extract and use these materials for commercial or other purposes, you may be infringing copyright laws. As a user, you are entirely responsible for the illegal use of media.
- Additional charges may apply for data services, such as messaging, uploading, downloading, auto-syncing and location services. To avoid additional charges, select a data plan suitable to your needs. Contact your service provider for details.

## Instructional Notices



### **WARNING**

Situations that could cause injury to yourself and others, or damage to the device or other property.



### **NOTE**

Notices or additional information.

# Table of contents

Safety Information.....	5	Managing the Quick Settings .....	39
Basic.....	16	Apps Screen .....	40
Accessories .....	17	Call Forwarding .....	40
Watch Layout .....	18	Call.....	41
Charging the Watch.....	21	Android Pay.....	43
If the Screen Freezes .....	23	Google Fit.....	45
Installing the SIM Card .....	24	Opening the Apps Installed On Your Watch .....	48
Turning the Watch On and Off.....	27	Downloading Other Apps.....	49
Connecting to Another Mobile Device ....	28	<b>Tasks Using Voice Command .....</b>	<b>50</b>
Touch Screen Tips.....	28	Getting help from your Voice Actions on Your Watch.....	51
Wearing the Watch .....	29	Taking or Viewing a Note.....	51
Heart Rate Sensor .....	30	Setting a Reminder .....	52
<b>Connecting the Watch to a Mobile Device .....</b>	<b>32</b>	Seeing Your Step Count.....	52
Setting Up Your Companion Device.....	33	Using the Heart Rate Sensor.....	53
Pairing Your Watch with Your Companion Device.....	34	Sending a Text .....	55
Connecting to Another Companion Device.....	35	Sending and Reading Email.....	56
Setting a Timer.....	57	Using the Stopwatch .....	57
<b>How to Use Your Watch .....</b>	<b>36</b>	Setting an Alarm .....	58
Start on Your Watch Face (Where You See the Time).....	37	Managing Your Alarms.....	58
Quickly Dim the Screen.....	37	<b>Using Apps .....</b>	<b>59</b>
Changing the Watch Face.....	37	Downloading Other Apps.....	60
Notification Cards.....	38	Phone.....	60

Call Forwarding .....	62
Messenger .....	63
LG Health .....	64
Use the Google Fit App.....	65
<b>Settings.....</b>	<b>66</b>
Opening the Settings Menu.....	67
Display.....	67
Sound & notifications.....	67
Apps .....	68
Gestures.....	68
Connectivity .....	68
Accessibility .....	71
Personalization.....	71
System.....	72
<b>More Information.....</b>	<b>73</b>
Open Source Software Notice Information .....	74
Trademarks.....	74
Regulatory information.....	75
How to update your device .....	75

A decorative graphic consisting of several groups of horizontal white lines of varying lengths, arranged in a descending staircase pattern from left to right across the top half of the page.

# **Safety Information**

Before turning on your product, review the basic safety information provided here.

## General Safety & Handling

While using your product, be aware of the following common-sense guidelines.

### Your environment

- **Safe operating temperatures.** Use and store your product in temperatures between 0°C/32°F and 40°C/104°F. Exposing your product to extremely low or high temperatures may result in damage, malfunction, or even explosion.
- **While driving.** When driving a car, driving is your first responsibility. Using a mobile device or accessory for a call or other app while driving may cause distraction. Keep your eyes on the road.
- **Around explosives.** Do not use in areas where sparks from the product might cause a fire or explosion.
- **On airplanes.** Observe all rules and instructions for the use of electronic devices. Most airlines allow the use of electronics only in mid-flight, not during take-off or landing. There are three main types of airport security devices: X-ray machines (used on items placed on conveyor belts), magnetic detectors (used on people walking through security checks), and magnetic wands (hand-held devices used on people or individual items). You can pass this product through airport X-ray machines. Do not send it through airport magnetic detectors or expose it to magnetic wands.
- Always follow any special regulations in the area you are located. Turn your device off in areas where use is forbidden, or when it may cause interference or danger.
- Changing the wrist straps to metallic might cause Bluetooth®/Wi-Fi connectivity issues.

## Safety Tips

### **WARNING**

- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.  
***Wash hands after handling.***
- The charging cable contains strong magnets that may interfere with pacemakers, credit cards, watches, and other magnet-sensitive objects.
- To avoid damaging your product and reduce the risk of fire or electric shock, explosion, or other hazards, observe these common-sense precautions:
  - Always use LG-approved cables, chargers, and other accessories. Using any other types may void any approval or warranty applying to the device and may be dangerous.
  - Available accessories may vary depending on your region, country or service provider.
  - Some content and illustrations may differ from your device depending on the region, service provider, software version, or OS version, and are subject to change without prior notice.
  - Do not drop, strike, or shake your product.
  - Do not damage the power cord by bending, twisting, pulling, heating, or placing heavy items on it.
  - This product is equipped with a USB cable for connecting to a desktop or notebook computer or to the charger. Be sure your computer is properly grounded before connecting the product to the computer. The power supply cords of desktop or notebook computers have an equipment-grounding conductor and a grounding plug. This must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.
  - Do not attempt to repair or modify or re-manufacture the product. It is equipped with an internal rechargeable battery which should be replaced only by LG or an authorized LG repair center.
  - Do not open, disassemble, crush, bend or deform, puncture, or shred the product.
  - Do not insert foreign objects into the product.

- Do not place the product in a microwave oven.
- Do not expose the product to fire, explosion, or other hazards.
- Clean with a soft, damp cloth. Do not use harsh chemicals (such as alcohol, benzene, or thinners) or detergents to clean your product.
- Dispose of your product and battery separately from household waste and in accordance with local regulations.
- Like many electronic devices, this product generates heat during normal operation. Extremely prolonged, direct skin contact in the absence of adequate ventilation may result in discomfort or minor burns. Use care when handling your product during or immediately after operation.
- If a problem arises using this product, stop using it and consult with an authorized LG Electronics customer service center.
- Do not immerse or expose the product to water or other liquids.

## Heart Rate Precautions

- Pedometer, sleep, exercise, and heart rate are not intended to treat or diagnose any medical condition, and should be used for leisure, well-being and fitness purposes only.
- Heart rate readings can be affected by measurement conditions and your surroundings. Make sure you are seated and relaxed before reading your heart rate.
- This product is water and dust-resistant according to the IP67 Rating, which tests submersion in water at up to 1 meter for up to 30 minutes. It is not shockproof. The case must be completely closed.
- Heart rate readings may be affected by skin condition, measurement conditions and your surroundings.
- Never look directly at the light of the heart rate sensor, as this may damage your eyesight.
- If your device becomes hot, remove it until it cools down. Exposing skin to hot surfaces for a long period of time may cause burns.
- The heart rate feature is only intended for measuring your heart rate and must not be used for any other purposes.

## Battery Warnings

- Do not disassemble, open, crush, bend or deform, puncture or shred the device.
- Do not modify or re-manufacture the device, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, or expose to fire, explosion or other hazard.
- Make sure that no sharp-edged items, such as animals' teeth or claws, come into contact with the battery. This could cause a fire.
- Only use the battery for the device for which it is specified.
- Only use the battery with a charging system that has been qualified with the device, per CTIA Certification Requirements for Battery System Compliance to IEEE1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Do not short-circuit a battery or allow metallic conductive objects to contact battery terminals.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard. Only authorized service providers can replace the battery (If the battery is not user-replaceable).
- Battery usage by children should be supervised.
- Avoid dropping the phone or battery. If the phone or battery is dropped, especially on a hard surface, and you suspect damage, take it to a service center for inspection.
- Improper battery use may result in fire, explosion or other hazards.
- Always unplug the charger from the wall socket after the product is fully charged to save unnecessary power consumption.
- There is risk of explosion if the battery is replaced with an incorrect type.
- To dispose of the battery properly, call (800) 822-8837 or visit [www.call2recycle.org](http://www.call2recycle.org).

## Embedded Battery

### **WARNING: Notice for battery replacement**

- For your safety, do not remove the battery inside the product. If you need to replace the battery, take it to the nearest authorized LG Electronics service point or dealer for assistance.
- The Li-Ion Battery is a hazardous component which can cause injury.
- Battery replacement by non-qualified professionals can cause damage to your device.

## Notes on Water-Resistant Properties

This product is water and dust-resistant in compliance with the Ingress Protection rating IP67\*.

\* This IP67 rating means that the product will maintain operability even if it is gently submerged in a tank of tap water at room temperature for about 30 minutes, up to a depth of 1 meter.

Avoid exposing the product to environments with excessive dust or moisture. Do not use the product in the following environments.



Do not immerse the product in any liquid chemicals (soap, etc.) other than water.



Do not immerse the product in salt water, including seawater.



Do not immerse the product in a hot spring.



Do not swim while wearing this product.



Do not use the product underwater.



Do not place the product directly on sand (such as at a beach) or mud.

- Drain the water if the voice activation does not work properly due to water in the microphone.
- Do not use the product in places where it may be sprayed with high-pressure water (e.g. near a faucet or shower head) or submerge it in water for extended periods of time, as the product is not designed to withstand high water pressure.

- This product is not resistant to shock. Do not drop the product or subject it to shock. Doing so might damage or deform the main unit, causing water leakage.

## Pacemakers and Other Medical Devices

Persons with pacemakers should:

- ALWAYS keep the product more than six (6) inches from their pacemaker when the product is turned ON.
- Not carry the product in a breast pocket.
- Use the wrist opposite the pacemaker to minimize the potential for RF interference.
- Turn the product OFF immediately if there is any indication that interference is taking place.

If you use any other personal medical device, consult your physician or the manufacturer of your medical device to determine if it is adequately shielded from external RF energy.

## Tips for Using Bluetooth and Wi-Fi on Your Watch

- When connecting your product to other mobile devices, the devices must be positioned close to each other. Failure to do so may cause abnormal operation or noise, depending on the environment.
- In an open space, the Bluetooth communication range usually spans approximately 32 feet (10 m). This range may vary depending on the environment.
- Do not place obstacles between your product and connected devices. Outgoing/incoming signals may be weakened due to the user's body, walls, corners or obstacles. Make sure there are no obstacles during use.
- When using a Wi-Fi connection, your watch can get notifications from your device even if Bluetooth is unavailable.
- Your watch will search for and connect to the nearest Wi-Fi network based on the Wi-Fi list registered on your phone.

## Tips for the Display Screen

- Do not display non-moving images for an extended period. This may cause image burn-in or stains on the screen.
- Applications that display the same screen for more than 10 minutes are not recommended, since the potential screen damage is not covered by warranty.

## Exposure to Radio Frequency(RF) Energy

In August 1996, the U.S. Federal Communications Commission (FCC), with its action in Report and Order FCC 96-326, adopted an updated safety standard for human exposure to Radio Frequency (RF) electromagnetic energy emitted by FCC-regulated transmitters. The design of this product complies with the FCC guidelines and these international standards.

## Next-to-Mouth and Wrist-Worn Operation

This device was tested for typical body-worn (wrist) operations with the back of the device kept 0 inches (0 cm) between the user's body (wrist) and the back of the device.

This device was also tested for typical next-to-mouth (face) operations with the front of the device kept 0.39 inches (1 cm) between the user's mouth (face) and the front of the device.

To comply with FCC/IC RF exposure requirements, a minimum separation distance of 0.39 inches (1 cm) must be maintained between the user's mouth (face) and the front of the device.

Any accessories containing metallic components may not be used.

## Specific Absorption Rate (SAR) Values

This product transmits and receives radio signals. It is designed and manufactured not to exceed the emission limits for exposure to Radio Frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless products employs a unit of measurement known as the Specific Absorption Rate, or SAR. In the United States and Canada, the SAR limit for wrist watch used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue, or 4.0 watts/kg (W/kg) averaged over ten grams of tissue.

SAR tests are conducted using standard operating positions specified by the FCC, with the product transmitting at its highest certified power level in all tested frequency bands.

Although SAR is determined at the highest certified power level, the actual SAR level of the product during operation can be well below the maximum value.

Because the product is designed to operate at multiple power levels to use only the power required to reach the network, in general, the closer you are to a wireless base station antenna, the lower the power output. The highest SAR value for this product is 0.51 W/kg (1 g) when tested for use at next-to-mouth (face) level and 2.88 W/kg (10 g) for bodyworn (wrist) use.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure.

The FCC has granted an Equipment Authorization for this product with all reported SAR levels evaluated, in compliance with FCC RF emission guidelines.

SAR information on this model product is on file with the FCC and can be found under the Display Grant section of

<http://transition.fcc.gov/oet/ea/fccid/> after searching on FCC ID ZNFW200A.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) website at <http://www.ctia.org/>.

\* Product meets current FCC Radio Frequency Exposure Guidelines  
FCC ID : ZNFW200A

## Part 15.19 Statement General Requirement

This device complies with part 15 of FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

## Part 15.21 Statement

Changes or modifications that are not expressly approved by the manufacturer could void the user's authority to operate the equipment.

## U.S. Declarations of Conformity (Part 15.105 Statement)

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference with radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference or television reception, which can be determined by turning the equipment off and on, you can try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



**Basic**

# Accessories


These accessories are available for use with your device.

- Travel adapter
- Quick Start Guide
- Magnetic charging cable
- SIM card cover opener

## **NOTE**

- Always use genuine LG accessories. The supplied items are designed only for this device and may not be compatible with other devices.
- The items supplied with the device and any available accessories may vary depending on the region or service provider.


# Watch Layout



## NOTE

- The touch screen must not come into contact with any other electrical devices. Electrostatic discharge can result in the touch screen malfunctioning.

<b>Power Key</b>	<p><b>To turn the watch on:</b></p> <ul style="list-style-type: none"><li>· Press and hold to turn the watch on. If it doesn't turn on, press and hold for a few seconds until the LG logo appears.</li></ul> <p><b>When the screen is dimmed:</b></p> <ul style="list-style-type: none"><li>· Press once to wake the screen.</li></ul> <p><b>When the device is idle:</b></p> <ul style="list-style-type: none"><li>· Press to open the apps screen when you are on the watch's Home screen.</li><li>· Press to return to the Home screen when you are on any other screen.</li><li>· Press and hold for one second to get help from your Voice Actions.</li></ul> <p><b>If the screen freezes:</b></p> <ul style="list-style-type: none"><li>· Press and hold for more than 10 seconds until the LG logo appears to restart the watch.</li></ul>
<b>Top Key and Bottom Key</b>	<p><b>When the watch's Home screen is on:</b></p> <ul style="list-style-type: none"><li>· Press the <b>Top Key</b> to launch the <b>Fit Workout</b> app.</li><li>· Press the <b>Bottom Key</b> to launch the <b>Android Pay</b> app.</li></ul> <p><b>During a call:</b></p> <ul style="list-style-type: none"><li>· Press to control the volume.</li></ul>




**⚠ WARNING**

- Do not close or push the hole located at the bottom of the device with a sharp object. Doing so may cause your device to work improperly.
- Any damage to the barometer or microphone resulting from accidents, unreasonable use, tampering or other causes not arising from defects in material or workmanship may void the Limited Warranty.

**⚠ WARNING: Before wearing the strap**

- Excess force on the watch band may lead to breakage.



# Charging the Watch

Before using your watch for the first time, you should charge the battery. Use the charging cable included with the watch to charge the device's battery.

You can also charge the device's battery using a computer. Simply connect the computer to the charging cable using the USB cable included with the watch.

## NOTE

- When battery power is low, the battery icon is displayed as empty. If the battery charge is completely empty, the watch cannot be turned on immediately after connecting the charger. Leave an empty battery to charge for a few minutes before turning the device on. Some features are not available while the battery is charging.

## WARNING: Corrosion of charging terminals

- Exposure to sweat or other foreign material during the use of the product may cause the charging terminals to corrode while charging. To prevent this, wipe the product with a cloth before charging.


- 1 Locate the charging terminals on both the watch and the charging cable.



## NOTE

- The charging cable is designed to only be used with the watch and is not compatible with other devices.


- Place the watch on the charging cable and make sure that the charging terminals are aligned with each other.



- Connect the charging cable to a power outlet and place the watch on it. If your watch is turned off, it will turn on automatically.

 **NOTE**

- Make sure the watch is firmly connected to the charging cable before connecting the cable to a travel adapter or PC.
- After the charging cable is connected to a power outlet, you will see a charging screen, shown as below, while charging. You can check the remaining battery percentage and the time. Swipe right to return to the watch face.



- Once the watch battery is fully charged, disconnect the device from the charging cable.

- 6 The charging cable is equipped with a magnet inside. Do not leave metal objects nearby when separated from the watch. Contact with metal may lead to damage to the travel adapter or PC.

 **NOTE**

- The touch screen may not function if power to the watch is unstable while charging.
- The watch may become warm while charging. This is normal. If the battery becomes hotter than usual, disconnect the charger.

## If the Screen Freezes


If the device freezes up and stops working, press and hold the **Power Key** for over 10 seconds until the device reboots and the LG logo is displayed.

# Installing the SIM Card


## NOTE

- Please power off the device before you insert or remove a SIM card.
- Don't use excessive force when you turn the SIM card cover using the SIM card cover opener.


- 1 Open the SIM card cover using SIM card cover opener as shown in the figure below. Align the SIM card cover opener to the hole located at the bottom of the device and then turn counter-clockwise until the SIM card cover direction indicator reaches the "UNLOCK" position.




- 2 To remove SIM card cover, hold the watch firmly in one hand. Press the outer corner of the SIM card cover after removing the SIM card cover opener, the other side will lift. Then, lift off the SIM card cover with your other hand as shown in the figure below.



- 3** Slide the Nano SIM card into the SIM card slot as shown in the figure. Make sure the gold contact area on the card is facing downward.




- 4** Close the SIM card cover using the SIM card cover opener as shown in the figure below. Align the SIM card cover opener to the hole located at the bottom of the device and then turn clockwise until the SIM card cover direction indicator reaches the "LOCK" position.



## NOTE

- Foreign materials on the SIM card cover sealing pad or SIM card cover may compromise the water resistant function. Make sure to clean or remove any foreign material.



## Unlock the SIM Card


If you insert the SIM card with a PIN lock enabled, you have to enter the unlock code. If the SIM card PIN is disabled, ignore this section.

- 1 After turning the watch on, swipe up from the bottom of your watch screen until the SIM Locked screen appears.
- 2 Tap the SIM Locked screen to enter the unlock code.
- 3 Enter the unlock code.

# Turning the Watch On and Off

## Turning the Watch on

Turn the watch on by pressing and holding the **Power Key** (on the right-hand side of the device) for a few seconds. The screen lights up and the LG logo is displayed.



## Turning the Watch off

- 1 Press the **Power Key** to display the app list.
- 2 Tap **Settings** > **System** > **Power off**.
- 3 When prompted with the message **Power off: Are you sure?**, tap .

# Connecting to Another Mobile Device

If you want to connect your watch to another device, you must reset your device.

## Reset Your Watch

This setting unpairs the watch from your phone, resets your watch's settings to their factory default values, and deletes all of your data.

- 1 Press the **Power Key** to display the app list.
- 2 Tap **Settings** > **System** > **Disconnect & reset**. You are prompted to confirm.
- 3 Tap .
  - Your watch connects to one mobile device at a time.
  - Unpairing with your phone erases all data from your watch's memory. After completion, it is ready to connect to another mobile device.

## Touch Screen Tips

Here are some tips on how to navigate on your watch.

- **Tap or touch** – A single finger tap selects items, links, shortcuts and letters on the on-screen keyboard.
- **Touch and hold** – Touch and hold an item on the screen by tapping it and not lifting your finger until an action occurs.
- **Swipe or slide** – To swipe or slide, quickly move your finger across the surface of the screen, without pausing when you first tap it.



**Tap or touch**



**Touch and hold**



**Swipe or slide**

# Wearing the Watch

## Cautions for Water-Resistance

Your watch has undergone testing in a controlled environment and is proven to be water and dust-resistant in certain circumstances (meets the requirements of classification IP67 as described by the international standard IEC 60529 - Degrees of Protection provided by Enclosures [IP Code]; test conditions: 15° C/59° F ~ 35° C/95° F, 86 - 106 kPa, 1 meter (approximately 3 feet), for 30 minutes). Despite this classification, your device is not fully resistant to water damage.


- The watch must not be immersed in water deeper than 3 feet (approximately 1 meter) and kept submerged for longer than 30 minutes.
- The device must not be exposed to **water at high pressure**, such as ocean waves or a waterfall.
- Should your watch or your hands become wet, dry them thoroughly before handling the device.
- The device must not be exposed to **salt water, ionized water or soapy water**.
- The watch's water and dust-resistant features may be damaged **by dropping or receiving an impact**.
- If the watch gets wet, use a clean, soft cloth to dry it thoroughly.
- The touch screen and other features may not work properly **if the device is used in water or any other liquid**.
- **If the watch has been immersed in water or if the microphone or speaker has gotten wet**, in-call sound quality may be affected. Wipe the microphone or speaker with a dry cloth to ensure it is clean and dry.

## Caution on Product Overheating

Overheating the product to certain temperature will trigger a warning in order to prevent product breakage, skin irritation or damage, battery leakage, etc. Further rise in product temperature will turn off the power. Stop using the device if you feel discomfort due to overheating during use.

## Heart Rate Sensor

Make sure your watch is positioned on your wrist correctly before measuring your heart rate.



### NOTE

- Loose fitting or too much movement may cause inaccurate measurements.
- Never look directly at the heart rate sensor light as this may damage your eyesight.
- Escaping light may lead to inaccurate measurements. Wear the device so it doesn't touch your wrist bone when taking measurements.

## Ensuring Accurate Measurements

Heart rate readings may be inaccurate depending on conditions and surroundings. Follow these steps for more accurate heart rate readings:

- Never measure your heart rate after smoking or drinking alcohol. Smoking and/or alcohol can affect your heart rate.
- Never take heart rate measurements at low temperatures. Keep yourself warm when you measure your heart rate.
- Users with thin wrists may find their heart rate measurements are inaccurate.
- When measuring your pulse for workout purposes, take the measurement while seated and relaxed before exercise, then proceed with your workout.
- If the measurement significantly differs from predicted values, relax and measure again in 30 minutes.
- Confirm your pulse by taking the average of around 5 repeated measurements.
- If you speak, yawn or breathe deeply during the measurement, you may see inaccurate values.
- Light reflection may be uneven depending on your circulation, blood pressure or skin condition, and may lead to inaccurate measurements.
- If light reflection is blocked by body hair or other items, you may obtain inaccurate measurements.
- If the heart rate sensor is dirty, wipe the sensor and try again for a more accurate measurement.



# Connecting the Watch to a Mobile Device

# Setting Up Your Companion Device

Before pairing, follow these steps to set up your companion device that you want to pair with your watch.

- 1 Make sure the companion device is running Android™ 4.3 or iOS 9+ and supports Bluetooth®.
  - If your companion device is not Android 4.3 or iOS 9+, please check with your manufacturer for a possible software update.
- 2 Make sure your companion device supports Android Wear™.
  - To find out, visit <http://g.co/WearCheck> from your companion device.
- 3 Turn on Bluetooth on your companion device if it isn't already on.
- 4 Make sure your companion device is next to your watch.
- 5 On your companion device, download the **Android Wear**  app from the **Play Store** or **App Store** and install it. If **Android Wear**  is already on your companion device, make sure you have the most recent version.

## NOTE

- Depending on the network connection, the setup process might take over 20 minutes.

# Pairing Your Watch with Your Companion Device

## Step 1. Follow these steps on your watch.

- 1 Turn on the watch and tap the screen to begin.
- 2 Tap a language.
- 3 Swipe up and follow the onscreen instructions until the watch name is displayed.

## Step 2. Follow these steps on your companion device.

- 1 Open the **Android Wear**  app on your companion device.
- 2 On your companion device, you'll see a list of nearby devices. Tap your watch's name.
- 3 You'll see a passkey on your companion device and watch. Check that the codes match.
- 4 Tap **PAIR** on your companion device to start pairing.

## Step 3. Follow these steps to pair your watch with your companion device.

- 1 You'll see a confirmation message on your watch once it is paired. This may take a few minutes.
- 2 Follow the onscreen instructions to complete the initial setup.
- 3 When your watch completes the connection with your companion device, you can copy Google accounts on your companion device to your watch.

### **NOTE**

- Copying a Google account to your watch allows you to download new apps using the Play Store.
- Once initial setup is complete, you will see a tutorial notification. Follow the tutorial notices before using your watch.

# Connecting to Another Companion Device

Your watch connects to one companion device at a time. If you want to connect your watch to a different companion device, you must reset your watch using the **Disconnect & reset** setting on your watch.

## Unpairing and Resetting Your Watch

This setting unpairs the watch from your companion device and resets your watch's settings to their factory default values and deletes all of your data.

- 1 Press the **Power Key** to display the apps list.
- 2 Tap **Settings** > **System** > **Disconnect & reset**.
- 3 When prompted, tap  to confirm.
- 4 Connect your watch to another device.

### **WARNING**

- Performing a factory reset erases all data from your watch's memory and all watch data from your companion device. After resetting, your watch is ready to connect to another companion device.



# How to Use Your Watch

# Start on Your Watch Face (Where You See the Time)

Start by waking up your watch. If your watch's screen is dimmed, you can wake up the watch by doing any of the following:

- Touch the screen.
- Turn your wrist so your watch face is upright.
- Press the **Power Key** on the watch.


## Quickly Dim the Screen

- Press your palm onto the screen until it vibrates. This will dim the watch face.

## Changing the Watch Face

You can add more watch faces and personalize your watch to your style.

- 1 From the watch's Home screen, swipe left or right to the last screen and then tap **Add more watch faces** .
- 2 Tap the desired watch face to add it to your favorites.
- 3 Once the watch face has been added to your favorites, you can swipe the screen right or left to browse designs, then tap the one you want to choose.



### **NOTE**

- You can also download watch faces through the Play Store on your watch.

# Notification Cards

Most notifications you see on your companion device will also show up on your watch. These include notifications for missed calls, texts, event reminders, and more.

Notifications are displayed in the form of cards. Card previews appear at the bottom of the watch's Home screen.


- To see a notification card, swipe the watch face upwards.
- To see more cards, keep swiping up from the bottom of the screen.



## Notification cards

Swipe up on the watch face to view notification cards.

Swipe up to view more notifications.



Swipe right or left to dismiss the card.


# Blocking Notifications

If you get notifications on your companion device that you don't want to see on your watch, you can stop specific apps from showing their notifications on your watch.

- 1 On your companion device, open the **Android Wear**  app.
- 2 Tap  > **Block app notifications** > .
- 3 Select the app you want to block.

# Managing the Quick Settings

To open the Quick settings, swipe down on the watch's Home screen. The Quick settings allow you to quickly and easily change commonly used settings.



- **Airplane mode** ✈️ : Tap the **Airplane mode** to disconnect all networks and turn off your device's connectivity on your watch.
- **Sound mode** 🔊 : Tap the **Sound mode** to turn on/off the sound for notifications.
- **Brightness mode** ⚙️ : Tap the **Brightness mode** to set the level of brightness for your watch's display. When **Theater mode** is turn on, your watch's display does not light up and notifications do not appear.
- **Do not disturb** 🚫 : Your watch will not show any notifications and alerts while this setting is turned on.
- **Settings** ⚙️ : Tap the **Settings** to open the Settings app.


## NOTE

- Some content may differ from your companion device depending on the OS version.

# Apps Screen

The Apps screen displays icons for all apps.

- From the watch's Home screen, press the **Power Key** to open to the Apps screen.
- To open an app on the Apps screen, tap an app icon.



# Call Forwarding

This feature allows you to forward calls to your watch when incoming calls are not answered on your mobile phone.

## How to activate call forwarding when paired to a GSM device

- 1 Press the **Power Key** to open the Apps screen, then tap **Settings** .
- 2 From the Settings menu, tap **Connectivity** > **Cellular** > **Call forwarding** > **Turn on call forwarding** > **Request activation**.

### **NOTE**

- You can also use the LG Call forwarding app to activate the feature while paired with a GSM device.
- The call forwarding feature for your watch is not supported by all carriers. Please contact your service provider for supported features.


## WARNING

- Depending on your service provider, you may have to register for call forwarding service in advance.
- This feature may not work depending on network conditions. Please check with your service provider if you have any issues.
- For call forwarding service information, please check with your service provider.

# Call

## To Open the Phone app

Open the Apps screen and then tap **Phone**.



## NOTE

- If you set the 'Play phone voice call on watch' option on in the Bluetooth Device menu in Settings, you will be able to receive call notifications, accept incoming calls, and make outgoing calls on your companion device via your watch (**Settings** > **Connectivity** > **Bluetooth** > **Play phone voice call on watch**).

## Making a Call


### To call from the Contacts view menu

- 1 Open the Apps screen and then tap **Phone**.
- 2 Tap a contact you want to call.
- 3 You can choose to call the contact using the watch or your companion device.




### To call from the Recents view menu

- 1 Open the **Phone** app and swipe left on **Contacts**.
- 2 Tap a call log entry to dial that number.
- 3 You can choose to call the contact using the watch or your companion device.



### To call using the dialpad

- 1 Open the **Phone** app and swipe left until you reach the dialpad.
- 2 Use the dialpad to enter the number you want to call.
- 3 Tap the ☎️ (on the dialpad) to dial the number that you entered.
- 4 You can choose to call the contact using the watch or your companion device.




- To dial an international number, touch and hold 0+ to enter the plus (+) symbol. Then enter the international prefix for the country, followed by the full phone number.

## Answering a Call

You can get an instant alert when your companion device receives an incoming call. The notification shows the caller's number and/or contact information on your watch and lets you accept or decline the call.

- To answer a call, simply tap ☺.
- To end a call, simply tap ☹.



## Android Pay

### Set up Android Pay on Your Watch

**Step 1. Follow these steps on your watch.**

- 1 Open the Apps screen and then tap **Android Pay**.
- 2 If you have your companion device and your card, tap ☞.
- 3 Tap ☺ to add a screen lock.

**Step 2. Follow these steps on your companion device.**

- 1 On the companion device, you go through Android Pay's add card setup.
- 2 Follow the onscreen instructions to complete the add card setup.
- 3 You'll see a confirmation message on your watch and your companion device.

## NOTE

- NFC must be enabled to activate on your watch and set Android Pay as your default payment before using Android Pay on your watch.

## Making Payments


You can make payments on your watch using Android Pay.

- 1 Open the Apps screen and tap **Android Pay**.

**OR**

Press the **Bottom right** button.

- 2 Tap the surface of the touch screen on the credit card readers as shown.



- 3 When the payment is completed, you'll see a confirmation message on your watch.

# Google Fit

Google Fit helps to work out when you're walking, jogging or cycling. Set fitness goals and regularly record and check your progress.

## To Open the Google Fit App

Open the Apps screen and then tap **Fit**.




### NOTE

- If you feel discomfort while using the device, stop using it and remove it from your wrist.
- If your device becomes hot to the touch, please remove it until it cools.

## Using the Google Fit App

### Setting up your goal

- 1 Open the **Fit** app to personalize your goal.
- 2 Swipe up and tap **Add goal**  to set one of the following preset goals or create your own: **Take 10,000 steps a day, Active 30 min a day, Running 3 times a week, Steps, Distance, Active time, Calories.**



## Viewing your workout report

Your workout log displays your active time, steps, distance, and active calories.


- 1 Open the **Fit** app and swipe up until the workout report appears.
- 2 Tap each goal option to show workout information and a graph depicting weekly data.



## Measuring your heart rate

To measure your heart rate more accurately with the device, wear the device firmly around your lower arm just above the wrist bone. See *Using the Heart Rate Sensor* for details.

- 1 Open the **Fit** app and swipe up until heart rate screen is displayed.
- 2 Tap **Measure** (♥) to start measuring your heart rate.
- 3 To view a history of your heart rate, swipe up from the heart rate screen.



### **WARNING**

- Never look directly at the heart rate sensor light as this may damage your eyes.

## Using the Fit Workout App

### Open the Fit Workout app

- 1 Open the **Fit** app and tap **Fit Workout** .

**OR**

Press the **Top Key** on the watch's Home screen.

**OR**

Open the **Apps** screen and then tap **Fit Workout**.

- 2 Tap the desired workout mode.

- 3 Tap **START** to start monitoring your workout. Your watch begins to measure your heart rate.

- Tap  to pause or  to resume the workout.
- Tap  to complete your workout and view your workout report.



### Changing the workout metrics

- 1 Open the **Fit** app, swipe up and then tap  to open the settings.
- 2 Tap **Units** and make the desired changes.

# Opening the Apps Installed On Your Watch

The apps list shows you all of the applications installed on the watch. Swipe up and down to scroll through the list, and then tap one to use it. The most recently used app is displayed at the top of the list.

## NOTE

- Default apps on the device are subject to updates. Support for these apps may be withdrawn without prior notice. If you have any questions about an app provided with the device, please contact an LG Service Center. For user-installed apps, please contact the relevant service provider.
- Modifying the device's operating system or installing software from unofficial sources may damage the device and lead to data corruption or loss. Such actions will violate your LG license agreement and void your warranty.

## Viewing the Apps List

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 Press the **Power Key** to open the Apps screen.

## Downloading Other Apps

After copying your companion device's Google accounts to your watch, you can download more apps on Google Play™ .

To use same apps which are already installed on your companion device, download again on your watch. You can download them easily via 'Apps on your phone' category on Google Play™ .

### NOTE

- The apps on your device, and their functions, may vary according to country, region or hardware specifications. LG will not be responsible for any performance issues which arise from using applications developed by providers other than LG.
- LG will not be responsible for performance or incompatibility issues which arise from edited registry settings or modified operating system software.
- Any attempt to customize your operating system may lead to the device or its apps not working correctly.
- Software, audio, wallpaper, images, and other media supplied with your device are licensed for limited use. If you extract and use these materials for commercial or other purposes, you may be infringing copyright laws. As a user, you are entirely responsible for the illegal use of media.
- Additional charges may apply for data services, such as messaging, uploading, downloading, auto-syncing and location services. To avoid additional charges, select a data plan suitable to your needs. Contact your service provider for details.
- This content is not supported in iOS version.



# Tasks Using Voice Command

# Getting help from your Voice Actions on Your Watch

Your watch has the Voice Actions built in. Ask it questions. Tell it to do things. It's your own personal Google. Just say "OK Google" or press and hold the **Power Key** until you see **Hi, how can I help?**

## NOTE

- To get help from your Voice Actions a data or Wi-Fi connection is required on your companion device, and the devices must be within Bluetooth range.
- This feature may vary or may not be supported, depending on the area, languages, or paired devices.

## Taking or Viewing a Note

You can ask your Voice Actions to create a note or view existing notes.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch's Home screen, say "OK Google" or press and hold the **Power Key** until you see **Hi, how can I help?**
- 3 Say "**Take a note**".
- 4 Say your note when prompted (e.g., "Try the new restaurant on Main Street"). Your note will automatically be saved after a few seconds. Tap the  to cancel without saving it.

If you install two or more note taking apps on your companion device, select the app you want to use, and it will become the default app for future notes.

## NOTE

If you installed Google Keep on your companion device:

- The app turns the words you speak into text. When you have finished speaking, your text note is saved to your default note app on your mobile device.
- View and edit your notes by opening the app on your mobile device.

## Setting a Reminder

You can ask your Voice Actions to set a reminder. When a reminder is set, a card will appear at the reminder time.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch's Home screen, say **"OK Google"** or press and hold the **Power Key** until you see **Hi, how can I help?**
- 3 Say **"Remind me"**.
- 4 Complete your reminder when prompted. Your reminder will automatically save after a few seconds (tap the ⊗ before it finishes saving to cancel it.)

## Seeing Your Step Count

You can view your step count goal, the number of steps you have taken today and each day over the last week, as measured by the Fit app.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch's Home screen, say **"OK Google"** or press and hold the **Power Key** until you see **Hi, how can I help?**
- 3 Say **"Show me my steps"**. You will see your daily step count information.

# Using the Heart Rate Sensor


You can use the Heart Rate app to measure and record your current heart rate.

## NOTE

- The device's heart rate measurement feature is not meant for clinical or medical diagnosis. Follow the guidelines in **Measuring Heart Rate** and **Getting Accurate Measurements** to make sure your heart rate measurements are accurate.

## Measuring Heart Rate

Make sure the watch is positioned on your wrist correctly before measuring your heart rate.



- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch's Home screen, say "OK Google" or press and hold the **Power Key** until you see **Hi, how can I help?**
- 3 Say "**Show me my heart rate**".
- 4 Your watch will start measuring your heart rate, then display your heart rate.

 **NOTE**

- Wearing your watch too loosely or moving excessively may cause inaccurate measurements.
- Escaping light may lead to inaccurate measurements. Do not wear the device so that it is directly over your wrist bone when taking measurements.

 **WARNING**

- Never look directly at the heart rate sensor light as this may damage your eyes.

## Getting Accurate Measurements

Heart rate readings may be inaccurate depending on the conditions and your surroundings. Follow these steps for more accurate heart rate readings:

- Never measure your heart rate after smoking or drinking alcohol. Smoking and/or alcohol can affect your heart rate.
- Never take heart rate measurements at low temperatures. Keep yourself warm when you measure your heart rate.
- Users with thin wrists may find their heart rate measurements are inaccurate.
- When measuring your pulse for workout purposes, take the measurement while seated and relaxed before exercise, then proceed with your workout.
- If the measurement significantly differs from predicted values, relax and measure again in 30 minutes.
- Confirm your pulse by taking repeated measurements (about 5 times).
- If you speak, yawn, or breathe deeply during the measurement, you may see inaccurate values.
- Your circulation, blood pressure, or skin condition can affect the light reflection process and may lead to inaccurate measurements.
- If light reflection is blocked by body hair or other items, you may obtain inaccurate measurements.

- If the heart rate sensor is dirty, wipe the sensor and try again for a more accurate measurement.
- Your watch measures your heart rate using a light reflection process. Light reflection may affect your watch's ability to take an accurate heart rate reading.

## Sending a Text


You can ask your Voice Actions to send text messages using your voice. You can also reply to any text message cards that you receive on your watch.

## Sending a Message

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch's Home screen, say **"OK Google"** or press and hold the **Power Key** until you see **Hi, how can I help?**
- 3 Say **"Send a text"**.
- 4 **To whom?** will appear. Say the name of the contact you want to send a text message to. You can also say a mobile phone number for numbers not saved in your companion device's Contacts list.
- 5 You will be prompted to say the message you want to send. Say your message.
- 6 Tap  to send the text message (tap  to cancel it).

## Replying to a Message

When you get message notifications on your companion device, cards will appear on your watch. Tap the notification and swipe up until **Reply** appears. Tap **Reply**, then say your message or insert emoticons or input a message using the keyboard. To insert an emoticon, like a smiley, into the message, tap 😊.



### NOTE

- This content is not supported in iOS version.

## Sending and Reading Email

Your watch can be used to write and read emails from your companion device.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch's Home screen, say "OK Google" or press and hold the **Power Key** until you see **Hi, how can I help?**
- 3 Say "**Send email**".
- 4 **To whom?** will be displayed.
- 5 Say the name of the contact (from the companion device's Contacts list) you want to send an email to. If a list appears, select the contact you want.
- 6 You will be prompted to say the message you want to send.
- 7 Tap ➤ to send the email (tap ✕ to cancel it).

## Replying to an Email

When reading an email notification card on your watch, swipe the card up to access actions you can take. Tap , select **Reply** and say your message, insert emoticons or input your message using the keyboard. To insert an emoticon, like a smiley, into the message, tap one of the emoticons at the bottom of the screen. Tap  to send the email (tap  to cancel it).

### NOTE

- This content is not supported in iOS version.

## Deleting Email Messages

When reading an email notification card on your watch, swipe the card up and tap **Delete**.

## Setting a Timer

You can ask your Voice Actions to set a timer. Once a timer set, a card is displayed with the countdown.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch's Home screen, say "**OK Google**" or press and hold the **Power Key** until you see **Hi, how can I help?**
- 3 Say "**Set a timer**".
- 4 Say the desired amount of time.

## Using the Stopwatch

Measure how much time has passed by starting a stopwatch.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch's Home screen, say "**OK Google**" or press and hold the **Power Key** until you see **Hi, how can I help?**
- 3 Say "**Start stopwatch**".
- 4 Tap  to start.

## Setting an Alarm

Multiple alarms can be set on your watch separately from alarms set on your companion device. Alarms set on your watch will not transfer to your companion device, but alarms activated on your companion device will display an alarm card (with vibration and sound, if set) on your watch.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch's Home screen, say "OK Google" or press and hold the **Power Key** until you see **Hi, how can I help?**
- 3 Say "**Set an alarm**".

## Managing Your Alarms

You can view, edit, and delete the alarms that you set on your watch.

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 From the watch's Home screen, say "OK Google" or press and hold the **Power Key** until you see **Hi, how can I help?**
- 3 Say "**Show alarms**".

### NOTE

- Tap  next to an alarm to edit or tap  to delete it.
- Tap  to manually set an alarm.

A decorative graphic consisting of several groups of horizontal white lines of varying lengths, arranged in a descending staircase pattern from the top left towards the bottom right. The background is a solid red color.

# Using Apps

The app list provides a list of the applications included on the watch.

## To Reach the Apps Installed on Your Watch

- 1 If your screen is dimmed, tap the screen to wake up the watch.
- 2 Press the **Power Key** to open the apps list.

## Downloading Other Apps

You can see a list of recommended apps in the **Play Store** .

Open the **Android Wear**  app to download more apps on your phone.

## Phone

### Making a Call

You can make and receive calls directly from your watch. Your watch can display the dialpad so you can dial a number.

- 1 Press the **Power key** to open the apps list, then touch **Phone** .
- 2 Swipe left until the dialer appears.
- 3 Enter the number using the dialer. Touch the  if you want to delete a digit.
- 4 After entering the desired number, tap  to place the call.
- 5 If you want to hang up the phone, then tap .

#### **NOTE**

- You can also make a call from the **Recent** list and **Contacts** list.

## Answering and Rejecting a Call

During an incoming call, you can answer or reject the call.

- Press  to answer the call.
- Press  to reject the call.

## To View the Contact List

You can see the contact list from your watch as easily as on your phone.

- 1 Press the **Power key** to open the apps list.
- 2 Tap **Contacts**.

# Call Forwarding

This feature allows you to forward calls to your watch using **Call forwarding**  when incoming calls are not answered on your mobile phone.

## How to activate call forwarding when paired to a GSM device

- 1 Press the **Power key** to open the apps list, then touch **Settings** .
- 2 From the **Settings** menu, tap **Connectivity** > **Cellular** > **Call forwarding** > **Turn on call forwarding** > **Request activation**.

### **NOTE**

- You can also use the LG Call forwarding app to activate the feature while paired with a GSM device.

### **NOTE**

- Descriptions, screen images and supported languages in this guide may differ due to app updates.
- The call forwarding feature for your watch is not supported by all carriers. Please contact your service provider for supported features.

### **WARNING**

- Depending on your service provider, you may have to register for call forwarding service in advance.
- This feature may not work depending on network conditions. Please check with your service provider if you have any issues.
- For call forwarding service information, please check with your service provider.

# Messenger

You can send and respond to messages directly for your watch.

## Sending a Message

- 1 Press the **Power key** to open the apps list, then touch **Messenger** .
- 2 Tap **New message**  and then select the contact you want to send the message.
- 3 You will be prompted to say the messages you want to send or select the message you want to send.
- 4 Your message will send automatically.

## Replying to a Message

You get message notifications on your phone or watch. To see your phone text messages, install Messenger. With Messenger on your phone, you can reply to all your phone's conversations from your watch.

- 1 Press the **Power key** to open the apps list, then touch **Messenger** .
- 2 Select the message thread from the list.
- 3 Drag  up and tap **Reply**.
- 4 Speak a reply, draw emojis, or send a preset message.

# LG Health

The LG Health app helps you manage your health and maintain good exercise habits by tracking logs and letting you compete with others.

- 1 Press the **Power key** to open the apps list, then tap **LG Health** .
- 2 To start using this app, enter your profile and tap .
- 3 Select the desired item. Use the options below to begin tracking your activity.
  - **Tracker:** Select an exercise type and intensity and record your exercise or receive coaching.
  - **Stress:** Receive messages about your stress index (step 4) and step-by-step guides. Fasten the watch to your wrist before use. (Keep it away from your wrist bone.)
  - **Settings:** Drag the screen upwards to access LG Health options such as Profile, Goal unit, Daily goal, Units, Exercise notification, Tracker layout, and Delete data. View or edit the profile that you set on your first use. Delete data recorded in LG Health, such as Tracker logs and Stress logs.

## NOTE

- This feature is provided for user convenience. Please use for reference only.

# Use the Google Fit App

The Fit app lets you count steps and view how far you have walked. You can also see your heart rate measurements.

Installing the Google Fit app on the phone that your Android Wear watch is paired with lets you sync data between the two devices and enjoy all of Fit's features.

Press the **Power key** to open the apps list, then tap **Fit** ❤️.

Swipe up and down to see details.

## See Today's Step Estimate

Speak or use the menu to see an estimate of how many steps you've taken.

Say "OK Google". When you see the **Hi, how can I help?** prompt, say "**Show me my steps**" (See *Seeing Your Step Count* section for more information).

**OR**

Open the **Fit** ❤️ app.

## Check Your Heart Rate

Speak or use the menu to check your heart rate.

Say "OK Google". When you see the **Hi, how can I help?** prompt, say "**Show me my heart rate**" (See *Using the Heart Rate Sensor* section for more information).

**OR**

- 1 Open the **Fit** ❤️ app and swipe up until the Heart rate appears.
- 2 Swipe up to see your measurement history or tap 📌 to measure your heart rate.



# Settings

# Opening the Settings Menu

If your screen is dimmed, tap the screen to wake up the watch.

- Press the **Power Key** to open the Apps screen, then tap **Settings** 
- OR**
- Swipe down on the watch's Home screen, then tap **Settings** .

## Display

From the **Settings** , tap **Display**.

- **Change watch face:** You can add more watch faces and personalize your watch to your style.
- **Adjust brightness:** You can set the level of brightness for your watch's display.
- **Font size:** You can set the size of the font displayed on your watch's screen.
- **Always-on screen:** When you're not using the watch, the screen can either turn off or show the current time, depending on your settings.

## Sound & notifications

From the **Settings** , tap **Sound & notifications**.

- Set the following options: **Media volume**, **Alarm volume**, **Ring volume**, **Also vibrate for calls**, **Watch ringtone**, **Notification previews**, **Do not disturb unless...**, **Vibration pattern**, and **Wireless emergency alerts**.

# Apps

From the **Settings** , tap **Apps** > **System Apps**.

- Allows you to view and manage the apps on your device. To stop the app from running, tap an entry to view more information, tap **Force stop**, then .
- You can set control permissions for individual applications.

# Gestures

From the **Settings** , tap **Gestures**.

- **Tilt-to-wake**: You can set to tilt your watch to turn on the screen.
- **Wrist gestures**: You can set to flick your wrist to browse the screen.
- **Launch tutorial**: View a tutorial about using gestures on your watch.
- **More tips**: Opens a webpage on your companion device to help you with more tips for gestures.

# Connectivity

From the **Settings** , tap **Connectivity**.

## Bluetooth

- **Bluetooth**: Tap the switch to toggle it On or Off. On allows you to pair and connect with other Bluetooth devices. You can also manage your Bluetooth devices.
- **Available devices**: Displays all of the Bluetooth devices that are within your companion device's range. Tap one to pair and connect.
- **Play phone voice call on watch**: Tap the switch to toggle it On or Off. On allows you to receive call notifications, accept incoming calls, and make outgoing calls on your companion device via your watch.

## NOTE

- The Play phone voice call on watch menu is not supported in iOS version.
- When using Bluetooth to connect to other mobile devices, the devices must be positioned close to each other. If not, it may cause abnormal operation or noise, depending on the use environment.
- In an open space, the Bluetooth communication range usually spans approximately 10m. This range may vary depending on the use environment.
- Do not place obstacles between your product and connected devices. Outgoing/incoming signals can weaken due to user's body, walls, corners or obstacles. Use where there is no obstacle.
- Only Bluetooth devices that support the A2DP and HFP profile are supported.

## Wi-Fi

- **Wi-Fi:** Tap the switch to toggle it On or Off. On allows you to connect to a Wi-Fi network (from your list of available, detected networks).
- **Add network:** Allows you to manually add a Wi-Fi network by entering its name (SSID), security, and password.
- **Saved networks:** Displays your saved Wi-Fi networks allowing you to manage them.
- **About Wi-Fi:** Displays information about Wi-Fi networks.

## NOTE

- When using a Wi-Fi connection, your watch can get notifications from your device even if Bluetooth is unavailable.
- Your watch will search and connect to the nearest Wi-Fi network based on the Wi-Fi list registered on your device.

## Cellular

- **Cellular:** Tap the switch to toggle it On or Off. On allows you to connect to the mobile network.
- **Data usage:** You can set the date limit and data usage that will trigger an alert. You can also view how much data apps are using.
- **Data roaming:** Enabling this option will allow you to use data while you are roaming.
- **SIM status:** Displays the SIM information.

You can also configure various other settings including **Require SIM lock**, **Call forwarding**, **Default SMS app**, **Displayed phone number**, **Voicemail number**, and **Advanced**.

## NFC

Tap the switch to toggle it On or Off.

- **Tap & pay:** Accesses the tap & pay app(s) you've downloaded to your companion device which allow you to pay for items just by touching your watch to a reader at a register. If your device doesn't have a default app, you can browse the Play Store and App Store for other payment apps. NFC must be enabled to activate this menu.

## Airplane mode

Tap the switch to toggle it On or Off. When Airplane mode is on, you can use still many of the features on your watch (such as Heart Rate) when you are on an airplane or anywhere else where sending or receiving data is prohibited.

### NOTE

- Turning on Airplane mode on your watch does not activate it on the your companion device. If you want to activate airplane mode on your companion device, you'll need to turn it on separately.

## Location

Tap the switch to toggle it On or Off. You can manage your location services for determining your approximate location. Some apps like Weather and Maps need your location to work.

### NOTE

- When paired with a companion device, the watch will use the location of the companion device. To improve location accuracy when paired with a device, turn on High accuracy in your companion device's location settings.
- Turn on the location setting on your watch if you want to use the location service when your watch is not paired with your companion device.

## Accessibility

From the **Settings** , tap **Accessibility**.

- Set the following options: **Magnification gestures**, **Text-to-speech output**, **TalkBack** and **Power button ends call**.

## Personalization

From the **Settings** , tap **Personalization**.

- **Input methods**: You can customize language and keyboard settings for your device.
- **Accounts**: You can add or remove a Google account to your watch.
- **Customize hardware buttons**: You can customize the **Top Key** and **Bottom Key**.
- **"Ok Google" detection**: Allows your watch to detect when you say "OK Google" voice actions.
- **Device administration**: Allows you to view and disable your device administrators.
- **Screen lock**: You can set a screen lock to prevent unauthorized access to your device.

# System

From the **Settings** , tap **System**.

- **Date & time:** You can set how your watch syncs and displays the date, time, and time zone.
- **Disconnect & reset:** You can unpair the watch from your companion device and reset your watch's settings to their factory default values. Please note that this deletes all of your data on your watch.
- **Restart:** You can restart your device.
- **Turn off:** You can turn off your device
- **About:** Displays the Model, Device name, Versions (for Google and Android software), Serial number, IMEI, Build number, Connection, and Battery information. The following options are also available:
  - **System updates:** Check to see if the latest software is loaded on your watch.
  - **Regulatory information:** Displays regulatory information.
  - **Legal notices:** Instructs you to see your companion device for legal notices.



**More Information**

# Open Source Software Notice Information

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit <http://opensource.lge.com>.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to [opensource@lge.com](mailto:opensource@lge.com).

This offer is valid for a period of three years after our last shipment of this product. This offer is valid to anyone in receipt of this information.

## Trademarks

- Copyright ©2017 LG Electronics, Inc. All rights reserved. LG and the LG logo are registered trademarks of LG Group and its related entities.
- Google™, Google Maps™, Gmail™, YouTube™, Hangouts™ and Play Store™ are trademarks of Google, Inc.
- Bluetooth® is a registered trademark of Bluetooth SIG, Inc. worldwide.
- Wi-Fi® and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance.
- All other trademarks and copyrights are the property of their respective owners.

## Regulatory information

- 1 Press the **Power Key** to display the apps list.
- 2 Tap **Settings** > **System** > **About** > **Regulatory information** to get regulatory information.

## How to update your device

Access to latest firmware releases, new software functions and improvements.

- 1 Press the **Power Key** to display the apps list.
- 2 Tap **Settings** > **System** > **About** > **System updates** on your device.

