



Please read this manual carefully before operating your set and retain it for future reference.

To view the instructions of advanced features, visit <a href="http://www.lg.com">http://www.lg.com</a> and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL SJ4



FRANÇAIS


www.lg.com Copyright © 2017-2019 LG Electronics Inc. All Rights Reserved. 1904 Rev02




· Adjusts Volume

#### Front Panel

The buttons are located on the rear.



#### Rear Panel



If the optical cable is not connected in the correct direction, it may cause damage of optical jack.

# 1 Subwoofer Connection


Place the wireless subwoofer near the speaker and follow steps below.

- Connect the power cord of wireless subwoofer and sound bar to the outlet.
- 2 Turn on the main unit: The sound bar and wireless subwoofer will be automatically connected. The subwoofer's green LED turns on.

# Subwoofer Connection Manually

If the subwoofer does not make sound, try to connect manually.

- 1 Press **Pairing** button on the rear of the wireless subwoofer.
  - The green LED on the rear of wireless subwoofer blinks quickly.
- 2 Turn on the main unit.
- 3 Pairing is completed.
  - The green LED on the rear of wireless subwoofer turns on.




# 2 TV Connection

Connect with the Sound Bar and TV using Optical (A) or HDMI ARC (B).

#### A Optical Connection

- Connect the sound bar to the TV using Optical cable.
- 2 Set up [External Speaker (Optical)] on your TV setting menu.



#### B HDMI(ARC) Connection


- Connect the sound bar to the TV using HDMI cable.
- Set up [External Speaker (HDMI ARC)] on your TV setting menu.



- HDMI connection is unavailable if your TV does not support HDMI ARC.
- If this unit is connected by OPTICAL and ARC at the same time, the ARC signal is a high priority.

#### Additional Device Connection

1 Connect to the external device as follows.



Set the input source by pressing F on the remote control or unit repeatedly.

#### Remote control




ASC/STANDARD/CINEMA: Selects the sound effect.

NIGHT ON/OFF: Turns down the volume at night.

**WOOFER LEVEL +/-:** Adjusts the volume level of

**AUTO POWER ON/OFF:** Automatically turns on by an input source.

#### Replacement of battery



#### Additional Information

# Specification

Power consumption	Refer to the main label.
	Networked standby : 1.5 W (If all network ports are activated.)
AC adapter	<ul> <li>Model: DA-38A25</li> <li>Manufacturer: Asian Power Devices Inc.</li> <li>Input:         <ul> <li>100 - 240 V ~ 50 - 60 Hz</li> <li>1.2 A</li> </ul> </li> <li>Output: 25 V === 1.52 A</li> </ul>
Dimensions (W x H x D)	Approx. 890 mm x 55 mm x 85 mm With foot
Bus Power Supply (USB)	5 V === 500 mA
Amplifier (Total RMS Output power)	300 W RMS

Design and specifications are subject to change without notice

# How to disconnect the wireless network connection or the wireless device

Set up the AUTO POWER ON/OFF function to off and turn off the unit.

# OPEN SOURCE SOFTWARE NOTICE INFORMATION

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit <a href="http://opensource.lge.com">http://opensource.lge.com</a>.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping and handling) upon email request to <a href="mailto:opensource@lge.com">opensource@lge.com</a>. This offer is valid for three (3) years from the date on which you purchased the product.

#### **Declaration of Conformity**



Hereby, LG Electronics declares that the radio equipment type Wireless Sound Bar is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

http://www.lg.com/global/support/cedoc/cedoc#

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

Frequency range	Output power (Max.)
2402 to 2480 MHz	10 dBm
5730 to 5821 MHz	13 dBm

