



OWNER'S MANUAL

# MICROWAVE OVEN

PLEASE READ THIS OWNER'S MANUAL THOROUGHLY BEFORE OPERATING.

MH604\*\*\*

(optional, please check model specification)



MFL68645602

[www.lg.com](http://www.lg.com)

# Precautions

## Precautions to avoid possible exposure to excessive microwave energy.

You cannot operate your oven with the door open due to the safety interlocks built into the door mechanism. These safety interlocks automatically switch off any cooking activity when the door is opened; which in the case of a microwave oven could result in harmful exposure to microwave energy.

**It is important not to tamper with the safety interlocks.**

Do not place any object between the oven front face and the door or allow food or cleaner residue to accumulate on sealing surfaces.

Do not operate your oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the: (1) door(bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.

Your oven should not be adjusted or repaired by anyone except qualified service personnel.

### **Warning**

**Please ensure cooking times are correctly set as over cooking may result in the FOOD catching fire and subsequent damage to your oven.**

When heating liquids, e.g. soups, sauces and beverages in your microwave oven, delayed eruptive boiling can occur without evidence of bubbling. This could result in a sudden boil over of the hot liquid. To prevent this possibility the following steps should be taken:

1. Avoid using straight sided containers with narrow necks.
2. Do not overheat.
3. Stir the liquid before placing the container in the oven and again halfway through the heating time.
4. After heating, allow to stand in the oven for a short time, stir or shake them(especially the contents of feeding bottles and baby food jars) again carefully and check the temperature of them before consumption to avoid burns (especially, contents of feeding bottles and baby food jars).  
Be careful when handling the container.

### **Warning**

**Always allow food to stand after being cooked by microwaves and check the temperature of them before consumption. Especially contents of feeding bottles and baby food jars.**

## How the Microwave Oven Works

Microwaves are a form of energy similar to radio and television waves and ordinary daylight. Normally, microwaves spread outwards as they travel through the atmosphere and disappear without effect. Microwave ovens, however, have a magnetron which is designed to make use of the energy in microwaves. Electricity, supplied to the magnetron tube, is used to create microwave energy.

These microwaves enter the cooking area through openings inside the oven. A turntable or tray is located at the bottom of the oven. Microwaves cannot pass through metal walls of the oven, but they can penetrate such materials as glass, porcelain and paper, the materials out of which microwave-safe cooking dishes are constructed.

Microwaves do not heat cookware, though cooking vessels will eventually get hot from the heat generated by the food.

## A very safe appliance



**Your microwave oven is one of the safest of all home appliances. When the door is opened, the oven automatically stops producing microwaves. Microwave energy is converted completely to heat when it enters food, leaving no "left over" energy to harm you when you eat your food.**

Precautions .....	2
Contents .....	3
Unpacking & Installing .....	4 ~ 5
Setting the Clock .....	6
Child Lock .....	7
Micro Power Cooking .....	8
Micro Power Level .....	9
Two Stage Cooking .....	10
Quick Start .....	11
Grill Cooking .....	12
Combination Cooking .....	13
Continental Menu .....	14 ~ 17
Arabian Menu .....	18 ~ 21
European Menu .....	22 ~ 25
Oriental Menu .....	26 ~ 29
Auto Defrost .....	30 ~ 31
Quick Defrost .....	32 ~ 33
Energy Saving .....	34
Important safety instructions .....	35 ~36
Microwave - safe Utensils .....	37
Food characteristics & Microwave cooking .....	38 ~ 39
Questions & Answers .....	40
Plug wiring information/Technical Specifications .....	41

# Unpacking & Installing

By following the basic steps on these two pages you will be able to quickly check that your oven is operating correctly. Please pay particular attention to the guidance on where to install your oven. When unpacking your oven make sure you remove all accessories and packing. Check to make sure that your oven has not been damaged during delivery.

- 1** Unpack your oven and place it on a flat level surface.



**GRILL RACK**




**GLASS TRAY**



**ROTATING RING**

- 2** Place the oven in the level location of your choice with more than 85cm height but make sure there is at least 30cm of space on the top and 10cm at the rear for proper ventilation. The front of the oven should be at least 8cm from the edge of the surface to prevent tipping. An exhaust outlet is located on top or side of the oven. Blocking the outlet can damage the oven.




**THIS OVEN SHOULD NOT BE USED FOR COMMERCIAL CATERING PURPOSES**

**3** Plug your oven into a standard household socket. Make sure your oven is the only appliance connected to the socket. If your oven does not operate properly, unplug it from the electrical socket and then plug it back in.

**4** Open your oven door. Place the **ROTATING RING** inside the oven and place the **GLASS TRAY** on top.

**5** Fill a **microwave safe container** with 300 ml (1/2 pint) of water. Place on the **GLASS TRAY** and close the oven door. If you have any doubts about what type of container to use please refer to page 37.



**6** Press the **STOP/CLEAR** button, and press the **START** button 1 time to set 30 seconds of cooking time. You will hear a BEEP when you press the button.



**7** The **DISPLAY** will count down from 30 seconds. When it reaches 0 it will sound BEEPS. Open the oven door and test the temperature of the water. If your oven is operating the water should be warm. **Be careful when removing the container it may be hot.**



# Setting the Clock



When your oven is plugged in for the first time or when power resumes after a power cut, a "0" will be shown in the display; you will have to reset the clock.

If the clock (or display) shows any strange looking symbols, unplug your oven from the electrical socket and plug it back in and reset the clock.

During clock setting the colon will flash. After setting, the colon will stop flashing.

You can set either 12 hour clock or 24 hour clock .

In the following example I will show you how to set the time for 14:35 when using the 24 clock.

Make sure that you have removed all packaging from your oven.


Make sure that you have correctly installed your oven as described earlier in this book.

Press **STOP/CLEAR**.



Press **CLOCK** once for 24 hour clock .


(If you want to use 12 hour clock, Press **CLOCK** once more.  
If you want to change different option after setting clock, you have to unplug and plug it back in.)



Press **10 MIN** fifteen times.


Press **1 MIN** three times.

Press **10 SEC** five times.



Press **CLOCK** to set the time.

The clock starts counting.



# Child Lock



Your oven has a safety feature that prevents accidental running of the oven. Once the child lock is set, you will be unable to use any functions and no cooking can take place. However your child can still open the oven door!

Press **STOP/CLEAR**.



ECO ON STOP CLEAR START Q-START

Press and hold **STOP/CLEAR** until “L” appears in the display and BEEP sounds. The **CHILD LOCK** is now set.



The time will disappear on the display if you have set the clock.

ECO ON STOP CLEAR START Q-START

“L” remains displayed to let you know that **CHILD LOCK** is set.



To cancel **CHILD LOCK** press and hold **STOP/CLEAR** until “L” disappears. You will hear BEEP when it's released.



ECO ON STOP CLEAR START Q-START

# Micro Power Cooking

In the following example I will show you how to cook some food on 80% power for 5 minutes and 30 seconds.



Your oven has five microwave Power settings. High power is automatically selected but repeated press of the **MICRO** key will select a different power level .

POWER	Power output	%
<b>HIGH</b>	700W	100%
<b>MEDIUM HIGH</b>	560W	80%
<b>MEDIUM</b>	420W	60%
<b>MEDIUM LOW</b>	280W	40%
<b>LOW</b>	140W	20%


Make sure that you have correctly installed your oven as described earlier in this book.

Press **STOP/CLEAR**.




Press **MICRO** twice to select 80% power.

"560" appears on the display.



Press **1 MIN** five times.

Press **10 SEC** three times.



Press **START**.

After cooking is over, End Reminder Beep Sounds per 1 minute for 5 minutes until the oven door is opened.



# Micro Power Level

Your microwave oven is equipped with 5 power levels to give you maximum flexibility and control over cooking. The table below shows the examples of food and their recommended cooking power levels for use with this microwave oven.

POWER LEVEL	OUTPUT	USE
<b>HIGH</b>	100% (700W)	<ul style="list-style-type: none"> <li>* Boil Water</li> <li>* Brown minced beef</li> <li>* Cook poultry pieces, fish, vegetables</li> <li>* Cook tender cuts of meat</li> </ul>
<b>MEDIUM HIGH</b>	80% (560W)	<ul style="list-style-type: none"> <li>* Reheating( Liquid )</li> <li>* Roast meat and poultry</li> <li>* Cook mushrooms and shellfish</li> <li>* Cook foods containing cheese and eggs</li> </ul>
<b>MEDIUM</b>	60% (420W)	<ul style="list-style-type: none"> <li>* Reheating (Mashed potato,Plated meal, Ready meal)</li> <li>* Bake cakes and scones</li> <li>* Prepare eggs</li> <li>* Cook custard</li> <li>* Prepare rice, soup</li> </ul>
<b>MEDIUM LOW</b>	40% (280W)	<ul style="list-style-type: none"> <li>* Melt butter and chocolate</li> <li>* Cook less tender cuts of meat</li> </ul>
<b>LOW</b>	20% (140W)	<ul style="list-style-type: none"> <li>* Soften butter &amp; cheese</li> <li>* Soften ice cream</li> <li>* Raise yeast dough</li> <li>* All thawing</li> </ul>



# Two stage Cooking

In the following example I will show you how to cook some food in two stages. The first stage will cook your food for 11 minutes on HIGH; the second will cook for 35 minutes on 40%(280W).



During two stage cooking the oven door can be opened and food checked. Close the oven door and press **START** and the cooking stage will continue.

At the end of stage1, BEEP sounds and stage 2 commences.

Should you wish to clear the programme press **STOP** twice.

Press **STOP/CLEAR**.




Set the power and the cooking time **for stage 1**.

Press **MICRO** once to select HIGH power.

Press **10 MIN** once.

Press **1 MIN** once.




Set the power and the cooking time **for stage 2**.

Press **MICRO** four times to select 40% power.

Press **10 MIN** three times.

Press **1 MIN** five times.



Press **START**.



# Quick Start

In the following example I will show you how to set 2 minutes of cooking on high power.



The **QUICK START** feature allows you to set 30 seconds intervals of HIGH power cooking with a touch of the **START** key.

Press **STOP/CLEAR**.



Press **START** four times to select 2 minutes on HIGH power. Your oven will start before you have finished the fourth press.



During **QUICK START** cooking, you can extend the cooking time up to 10 minutes by repeatedly pressing the **START** key.




# Grill Cooking

In the following example I will show you how to use the grill to cook some food for 12 minutes and 30 seconds.



This feature will allow you to brown and crisp food quickly.



**GRILL RACK**

Press **STOP/CLEAR**.

1

ECO ON STOP CLEAR START Q-START

Press **GRILL**.

2

Micro Grill Combi.

Set the cooking time.

3

Press **10 MIN** once.

Press **1 MIN** twice.

Press **10 SEC** three times.

10 min. 1 min. 10 sec.

Press **START**.

4

ECO ON STOP CLEAR START Q-START

# Combination Cooking

In the following example I will show you how to programme your oven with combi mode co-3 for a cooking time of 25 minutes.



Your oven has a combination cooking feature which allows you to cook food with **heater** and **microwave** at the same time. This generally means it takes less time to cook your food.

The **sheath heater** grills the surface of the food while **microwave** heats inside.

Press **STOP/CLEAR**.

Press **COMBI**, three times.  
"Co-3" appears on the display.

Set the cooking time.  
Press **10 MIN** two times.  
Press **1 MIN** five times.

Press **START**.

*Be careful when removing your food because the container will be hot!*



### Combination Cooking Mode

CATEGORY	MICRO POWER (%)	HEATER POWER (%)
Co-1	25	75
Co-2	45	55
Co-3	65	35

# Continental Menu

In the following example I will show you how to cook 0.4 kg of Couscous .




**CONTINENTAL MENU** allows you to cook most of your favorite food easily by selecting the food type and entering the weight of the food.

Category	Press Continental Menu	
Couscous	<b>1</b>	time
Jollof Rice	<b>2</b>	times
Fufu	<b>3</b>	times
Potato Gratin	<b>4</b>	times
Chicken Tagine	<b>5</b>	times


Press **STOP/CLEAR**.



Press **Continental Menu** once.



Press **MORE** four times to enter 0.4 kg.



Press **START**.



Category	Weight Limit	Utensil	Food Temp	Instructions															
Couscous (Cc-1)	0.1~0.4kg	Microwave-safe bowl	Room	<p><b>Ingredients</b></p> <table border="1" data-bbox="758 199 1497 297"> <tr> <td>Couscous</td> <td>0.1 kg</td> <td>0.2 kg</td> <td>0.3 kg</td> <td>0.4 kg</td> </tr> <tr> <td>Water</td> <td>120 ml</td> <td>240 ml</td> <td>360 ml</td> <td>480 ml</td> </tr> <tr> <td>butter</td> <td>1 Tablespoon</td> <td colspan="2">2 Tablespoons</td> <td>3 tablespoons</td> </tr> </table> <p>Vegetable mixture</p> <ol style="list-style-type: none"> <li>1. Pour water, butter in a large bowl and mix well. cover with plastic wrap and vent.</li> <li>2. Place food in the oven. Choose the menu and press start to cook.</li> <li>3. After cooking remove bowl from oven and cover, let stand for 15~20 minutes.</li> <li>4. With a fork, fluff the couscous and mix the couscous with some of the vegetable sauce.</li> </ol> <p><b>* Vegetable mixture</b></p> <p>15 peeled pearl onions or 2 cups sliced onions \ 15oz Can chick peas  2 large boiled potatoes cubed \ 1 sliced carrots  1/2 cup chopped cilantro \ 1/4 cup chopped parsley  2 tablespoons minced garlic \ 1 teaspoon paprika  1/4 teaspoon nutmeg \ 1/2 teaspoon salt \ 1/2 teaspoon black pepper  2 cans tomato sauce \ 1 Chicken broth  1 1/2 cups water \ 2 tablespoons butter</p> <ol style="list-style-type: none"> <li>1. Cook onions and butter for 5 minutes until caramelized.</li> <li>2. Add carrots and garbanzo beans and cook for another 5 minutes, and add garlic, cilantro, parsley, potatoes and 1/2 tsp salt and mix vegetables.</li> <li>3. In a large 4 quart sauce pan bring tomato sauce and 1 1/2 cup of water to a simmer.</li> <li>4. Add seasonings and spices to the sauce then add vegetable mixture to tomato sauce and simmer for 10~12 minutes.</li> </ol>	Couscous	0.1 kg	0.2 kg	0.3 kg	0.4 kg	Water	120 ml	240 ml	360 ml	480 ml	butter	1 Tablespoon	2 Tablespoons		3 tablespoons
Couscous	0.1 kg	0.2 kg	0.3 kg	0.4 kg															
Water	120 ml	240 ml	360 ml	480 ml															
butter	1 Tablespoon	2 Tablespoons		3 tablespoons															

Category	Weight Limit	Utensil	Food Temp	Instructions				
Jollof Rice (Cc-2)	0.1~0.4 kg	Microwave-safe bowl	Room	<b>Ingredients</b>				
				Rice	0.1 kg	0.2 kg	0.3 kg	0.4 kg
				Stock (meat or vegetable)	150 ml	300 ml	450 ml	600 ml
				Vegetable oil	1 Tbs	2 Tbs	3 Tbs	
				Onion	1/2 onion	1 onion	2 onion	
				Tomato paste	1 1/2 teaspoon	3 teaspoon	6 teaspoon	
				<p>some green chili, seeded and chopped</p> <ol style="list-style-type: none"> <li>1. Cook onion, chili and tomato paste in a lightly oiled frying pan until lightly browned.</li> <li>2. Place the cooked tomato mixture into a deep and large bowl and add rice and water. Cover with plastic wrap and vent.</li> <li>3. Place food in the oven. Choose the menu and press start to cook. Stir at least twice during cooking.</li> </ol>				
Fufu (Cc-3)	0.5~1.0 kg	Microwave-safe bowl	Room	<b>Ingredients</b>				
				Cassava or white yam	0.5 kg	0.75 kg	1.0 kg	
				Water	1 cup	1 cup	2 cup	
				2 tablespoons of butter Salt and pepper				
				<ol style="list-style-type: none"> <li>1. Place the unpeeled yams or cassava in a large bowl, and pour water. cover with plastic wrap and vent.</li> <li>2. Place food in the oven. Choose the menu and press start to cook.</li> <li>3. Drain the yams or cassava and let them cool.</li> <li>4. Peel the yams or cassava, chop them into large pieces and place them into a large bowl with the butter, salt and pepper.</li> <li>5. Mash with a potato masher until very smooth.</li> <li>6. Place the fufu into a large serving bowl. Wet your hands with water, form into a large ball and serve. You can also make smaller balls for individual servings.</li> </ol>				

Category	Weight Limit	Utensil	Food Temp	Instructions
Potato Gratin (Cc-4)	2.0 kg	Microwave-safe baking dish on the rack	Room	<p><b>Ingredients</b>            Potato mixture \ 250ml heavy cream            350g grated Gruyere cheese</p> <p><b>For Potato mixture :</b>            1kg potatoes \ 400ml milk \ 1 1/2 teaspoons salt            Pinch ground nutmeg</p> <p>Slice potatoes into 3mm thickness. Combine all ingredients in a saucepan and simmer over medium heat until milk boils and thickness. Keep stirring potatoes and scraping bottom of pan regularly to prevent sticking.</p> <ol style="list-style-type: none"> <li>1. Place half of the potato mixture into a greased 25*25cm baking dish, pour half of heavy cream and sprinkle 100g Gruyere cheese.</li> <li>2. Add the rest of potato mixture, pour remaining cream and finally sprinkle top with remaining Gruyere cheese.</li> <li>3. Place baking dish on the rack. Choose the menu and weight, press start.</li> </ol>
Chicken Tagine (Cc-5)	1.0 kg	Microwave-safe bowl	Room	<p><b>Ingredients</b>            2 tablespoons olive oil \ 8 skinless boneless chicken thighs , halved if large \ 150ml water \ 1 onion , chopped \ 2 teaspoons grated fresh root ginger \ pinch saffron or tumeric \ 1 tablespoon honey \ 300g carrots , cut into sticks \ small bunch parsley , roughly chopped \ lemon wedges, to serve</p> <ol style="list-style-type: none"> <li>1. Add all ingredients in a deep and large bowl and mix well. Cover with plastic wrap and vent.</li> <li>2. Place food in the oven. Choose the menu and press start to cook. Stir at least twice during cooking.</li> </ol>

# Arabian Menu

In the following example I will show you how to cook 0.4 kg of Saffron Rice.



**ARABIAN MENU** allows you to cook most of your favorite food easily by selecting the food type and entering the weight of the food.

Category	Press Arabian Menu
Grape Leaf	<b>1</b> time
Saffron Rice	<b>2</b> times
Kabsa	<b>3</b> times
Kafta	<b>4</b> times
Kebab	<b>5</b> times


Press **STOP/CLEAR**.



Press **Arabian Menu** twice.



Press **MORE** four times to enter 0.4 kg.



Press **START**.



Category	Weight Limit	Utensil	Food Temp	Instructions																									
Grape Leaf (Ac-1)	1 kg	Microwave-safe bowl	Room	<div style="border: 1px solid black; padding: 5px;"> <p><b>Ingredients</b></p> <p>1 pot of grape leaves \ 2 large onions, finely chopped  1/2 cup olive oil \ 1 garlic cloves, crushed \ 1 tomato, chopped  1 cup lemon juice \ 1 tablespoon tomato paste \ Kosher salt  Freshly ground black pepper  1 cup white rice \ 1/2 cup water \ 1/4 cup chopped dill</p> </div> <ol style="list-style-type: none"> <li>1. Cook onions, garlic, tomato, tomato paste, and lemon juice in a lightly oiled frying pan until lightly browned.</li> <li>2. Add cooked rice, vegetable mixture, salt and pepper in a bowl and mix well.</li> <li>3. Place grape leaf on a flat surface and place 1 1/2 spoonfuls of the rice mixture in the center of the leaf. Wrap rice mixture with leaf.</li> <li>4. Put all wrapped leaves in rows into a deep and large bowl and add water. Cover with plastic wrap.</li> <li>5. Place food in the oven. Choose the menu and press start to cook.</li> <li>6. After cooking, serve with sour cream or as desired.</li> </ol>																									
Saffron Rice (Ac-2)	0.1~0.4 kg	Microwave-safe bowl (deep glass pot)	Room	<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr> <td>Rice</td> <td>0.1 kg</td> <td>0.2 kg</td> <td>0.3 kg</td> <td>0.4 kg</td> </tr> <tr> <td>Water</td> <td>250 ml</td> <td>500 ml</td> <td>750 ml</td> <td>1000 ml</td> </tr> <tr> <td>Oil(liquid)</td> <td>1 tablespoon</td> <td colspan="2">2 tablespoons</td> <td>3 tablespoons</td> </tr> <tr> <td>Saffron water</td> <td>1 teaspoon</td> <td colspan="2">2 teaspoons</td> <td>3 teaspoons</td> </tr> <tr> <td>Salt</td> <td colspan="4">To taste</td> </tr> </table> <ol style="list-style-type: none"> <li>1. Wash rice and drain. Add rice, water, salt, liquid oil and saffron water into a deep glass bowl and mix them.</li> <li>2. Do not cover to vaporize whole water. Place food in the oven.</li> <li>3. When BEEP, stir rice and then cover with lid. Press start to continue cooking.</li> <li>4. After cooking, stir and stand covered for 5 minutes.</li> </ol>	Rice	0.1 kg	0.2 kg	0.3 kg	0.4 kg	Water	250 ml	500 ml	750 ml	1000 ml	Oil(liquid)	1 tablespoon	2 tablespoons		3 tablespoons	Saffron water	1 teaspoon	2 teaspoons		3 teaspoons	Salt	To taste			
Rice	0.1 kg	0.2 kg	0.3 kg	0.4 kg																									
Water	250 ml	500 ml	750 ml	1000 ml																									
Oil(liquid)	1 tablespoon	2 tablespoons		3 tablespoons																									
Saffron water	1 teaspoon	2 teaspoons		3 teaspoons																									
Salt	To taste																												

Category	Weight Limit	Utensil	Food Temp	Instructions
Kabsa (Ac-3)	2.0 kg	Microwave-safe bowl	Room	<p><b>Ingredients</b></p> <ul style="list-style-type: none"> <li>1/4 cup butter</li> <li>1.2kg chicken, cut into 8-10 pieces</li> <li>1 large onion, finely chopped</li> <li>3 garlic cloves, minced</li> <li>1/4 cup tomato puree</li> <li>1 tomato, chopped</li> <li>2 medium carrots, chopped</li> <li>1 pinch grated nutmeg</li> <li>1 pinch ground cumin</li> <li>1 pinch ground coriander</li> <li>salt &amp; freshly ground black pepper</li> <li>2 cups hot water</li> <li>1 chicken stock cube</li> <li>200g long grain rice (don't rinse or soak this)</li> <li>1/4 cup raisins</li> <li>1/4 cup slivered almond, toasted</li> </ul> <ol style="list-style-type: none"> <li>1. Cook chicken, carrots, tomato sauce, garlic, onion and butter in a lightly oiled frying pan until lightly browned.</li> <li>2. Place the cooked chicken mixture into a deep and large bowl and add rice, water and spices. Cover with plastic wrap and vent.</li> <li>3. Place food in the oven. Choose the menu and press start to cook. Stir at least twice during cooking.</li> </ol>

Category	Weight Limit	Utensil	Food Temp	Instructions
Kafta (Ac-4)	0.2 ~ 0.4 kg	Rack on a drip dish	Room	<div data-bbox="759 172 1485 451" style="border: 1px solid black; padding: 5px;"> <p><b>Ingredients for marinade</b></p> <p>460g beef minced  1 cup parsley, chopped  1 onion, chopped  2 bread, sliced  1/2 teaspoon all-spices  1/4 teaspoon paprika powder  1/4 teaspoon cinnamon powder  Salt and pepper as per taste</p> </div> <ol style="list-style-type: none"> <li>1. Combine all ingredients in a large bowl and mix well.</li> <li>2. Divide and shape into small sausages (100g / each one).</li> <li>3. Place food on the rack. Choose the menu and press start to cook.</li> <li>4. When beep, turn over the food.</li> </ol>
Kebab (Ac-5)	0.2 ~ 0.4 kg	Rack on a drip dish	Room	<div data-bbox="759 595 1509 729" style="border: 1px solid black; padding: 5px;"> <p><b>Ingredients for marinade</b></p> <p>2 onion juice  3 tablespoons olive oil  2 tablespoons saffron</p> </div> <ol style="list-style-type: none"> <li>1. Combine the ingredients of the marinade, cut meats under 1.5 cm thickness each and marinate the meats for 3-4 hours.</li> <li>2. Skewer the pieces of vegetable with the skewer.</li> <li>3. Place skewers on the rack.</li> <li>4. Choose the menu and weight, press start.</li> <li>5. When beep, turn over the food.</li> </ol>

# European Menu

In the following example I will show you how to cook 1.0 kg of Spaghetti Bolognese.



**EUROPEAN MENU** allows you to cook most of your favorite food easily by selecting the food type and entering the weight of the food.

Category	Press European Menu
Spaghetti Bolognese	<b>1</b> time
Spaghetti Carbonara	<b>2</b> times
Stuffed Tomato	<b>3</b> times
Apple Pie	<b>4</b> times
Lasagna	<b>5</b> times

Press **STOP/CLEAR**.



Press **European Menu** once.



Press **START**.



Category	Weight Limit	Utensil	Food Temp	Instructions
Spaghetti Bolognese (Sc-1)	1.0 kg	Microwave-safe bowl	Room	<p><b>Ingredients for bolognaise sauce</b>  1 tablespoon olive oil \ 1 onion, chopped \ 1 garlic clove, crushed  400 g ground beef \ 100 g tomato paste \ 2 chopped tomatoes  1 tablespoon dried greens \ Salt and pepper to taste</p> <p><b>Ingredients for pasta</b>  150 g pasta, cooked as package direction  1 tablespoon parmesan cheese</p> <ol style="list-style-type: none"> <li>1. Add all ingredients of the bolognaise sauce in a deep and large bowl and mix well. cover with plastic wrap and vent.</li> <li>2. Place food in the oven. Choose the menu and press start to cook. Stir at least twice during cooking.</li> <li>3. After cooking, stir and add bolognaise sauce to cooked pasta and garnish with parmesan cheese or as desired before serving.</li> </ol>
Spaghetti carbonara (Sc-2)	0.4 kg	Microwave-safe bowl	Room	<p><b>Ingredients for carbonara sauce</b>  100 g smoked bacon, chopped \ 1 garlic clove, crushed  1/2 cup cream \ 4 egg yolks \ 100 g parmesan cheese  Salt and pepper to taste</p> <p><b>Ingredients for pasta</b>  150 g pasta, cooked as package direction  1 tablespoon parmesan cheese</p> <ol style="list-style-type: none"> <li>1. Cook bacon in a lightly oiled frying pan with garlic until lightly browned and drain away excess fat.</li> <li>2. Add cooked bacon, cream, egg yolks, parmesan cheese, salt and pepper in a deep and large bowl and mix well. Cover with plastic wrap and vent.</li> <li>3. Place food in the oven. Choose the menu and press start to cook.</li> <li>4. After cooking, stir and add carbonara sauce to cooked pasta and garnish with parmesan cheese or as desired before serving.</li> </ol>

Category	Weight Limit	Utensil	Food Temp	Instructions
Stuffed Tomato (Sc-3)	1.2 kg	Microwave-safe dish	Room	<p><b>Ingredients</b></p> <p>4 medium tomatoes Salt and pepper to taste 400g ground beef 1/2 cup bread crumbs 2 garlic cloves, crushed 1 tablespoon Dijon mustard 1 tablespoon dried greens 1 tablespoon parmesan cheese</p> <ol style="list-style-type: none"> <li>1. Cut tops off tomatoes to form hats and remove seeds, taking care not to pierce flesh or skin. Then sprinkle each tomatoes with salt and pepper.</li> <li>2. Add the rest of the ingredients in a bowl, mix well.</li> <li>3. Stuff tomatoes with beef mixture and replace hat.</li> <li>4. Place stuffed tomatoes on a dish and cover with plastic wrap.</li> <li>5. Place food in the oven. Choose the menu and press start to cook.</li> </ol>
Apple pie (Sc-4)	1	21cm Heat-proof glass dish	Room	<p><b>Ingredients</b></p> <p>baked pastry (baked on 21cm baking dish) 50g apple jam 1 apples (sliced)</p> <ol style="list-style-type: none"> <li>1. Put baked pastry on a glass shallow dish.</li> <li>2. Spread jam and sliced apples on the pastry.</li> <li>3. Place food in the oven. Choose the menu, press start.</li> </ol>

Category	Weight Limit	Utensil	Food Temp	Instructions
Lasagna (Sc-5)	1.2 kg	20x20 kg baking dish	Room	<div data-bbox="759 169 1485 306" style="border: 1px solid black; padding: 5px;"> <p><b>Ingredients for meat sauce</b>  6 lasagna noodles, cooked as package direction  1kg meat and tomato sauce  40g grated cheese</p> </div> <ol style="list-style-type: none"> <li>1. Place 2 lasagna noodles side by side on bottom of a baking dish, covering bottom. Spread 1/3 of meat and tomato sauce on top.</li> <li>2. Continue with 2 lasagna noodles and another 1/3 of meat and tomato sauce then finish with last 2 lasagna noodles and remaining meat and tomato sauce.</li> <li>3. Sprinkle grated cheese on top.</li> <li>4. Place food in the oven. Choose the menu, press start.</li> </ol> <div data-bbox="759 524 1509 1009" style="border: 1px solid black; padding: 5px;"> <p><b>* Meat and tomato sauce</b>  1 celery stalk, chopped  1 onion, chopped  1 clove garlic, crushed  800g well-ripe tomatoes, chopped  1 sprig thyme  1 bay leaf  300g ground beef  Salt and pepper to taste</p> <ol style="list-style-type: none"> <li>1. Cook celery, onions and garlic in a lightly oiled frying pan until soft.</li> <li>2. Add tomatoes, thyme, bay leaf, salt and pepper. Stir and simmer for 30 minutes.</li> <li>3. Cook ground meat in another lightly oiled frying pan for 5 minutes while stirring constantly. Pour tomato mixture into meat and cook for 5 minutes.</li> </ol> </div>

# Oriental Menu

In the following example I will show you how to cook 1.5 kg of Curry Chicken.



**ORIENTAL MENU** allows you to cook most of your favorite food easily by selecting the food type and entering the weight of the food.

Category	Press Oriental Menu	
Curry Chicken	<b>1</b>	time
Dolma	<b>2</b>	times
Veg. Biryani	<b>3</b>	times
Chicken Tikka	<b>4</b>	times
Flapjack (Koutaba)	<b>5</b>	times

Press **STOP/CLEAR**.



Press **Oriental Menu** once.



Press **START**.



Category	Weight Limit	Utensil	Food Temp	Instructions
Curry chicken (Oc-1)	1.5 kg	Microwave-safe bowl	Room	<p><b>Ingredients</b>  400 g chicken breasts, cut into chunks \ 1/4 cup olive oil  2 onions, chopped \ 4 garlic cloves, crushed \ 1 ginger root, peeled  1 cinnamon stick \ 2 dried red chilies \ 1 teaspoon tumeric powder  400 g tomato sauce \ 1/2 cup water or stock \ 1/2 cup plain yogurt  1 tablespoon lemon juice  Salt and pepper to taste</p> <ol style="list-style-type: none"> <li>1. Add all ingredients in a deep and large bowl and mix well. Cover with plastic wrap and vent.</li> <li>2. Place food in the oven. Choose the menu and press start to cook. Stir at least twice during cooking.</li> </ol>
Dolma (Oc-2)	1.0 kg	Microwave-safe bowl	Room	<p><b>Ingredients</b>  1 pot of grapes leaves \ 200 g cooked rice  500 g ground beef  1 onion, chopped  Salt and pepper to taste  1/2 cup water  1/2 cup sour cream</p> <ol style="list-style-type: none"> <li>1. Add cooked rice, ground beef, onion, salt and pepper in a bowl and mix well.</li> <li>2. Place grape leaf on a flat surface and place 1 1/2 spoonfuls of the rice mixture in the center of the leaf. Wrap rice mixture with leaf.</li> <li>3. Put all wrapped leaves in rows into a deep and large bowl and add water. Cover with plastic wrap.</li> <li>4. Place food in the oven. Choose the menu and press start to cook.</li> <li>5. After cooking, serve with sour cream or as desired.</li> </ol>

Category	Weight Limit	Utensil	Food Temp	Instructions
Veg. Biryani (Oc-3)	1.0 kg	Microwave-safe bowl	Room	<p><b>Ingredients</b></p> <ul style="list-style-type: none"> <li>1 1/2 cups Basmati rice</li> <li>400 g water</li> <li>2 cups Chopped onions</li> <li>1 Tomato, chopped</li> <li>1 cup Vegetables (carrot, beans, peas, potato), chopped</li> <li>2 Green chilly, chopped</li> <li>1 teaspoon Ginger garlic paste</li> <li>1 1/2 teaspoon Red chilly powder</li> <li>1 teaspoon Coriander powder</li> <li>1 teaspoon Cumin powder</li> <li>1 tablespoon Biryani masala</li> <li>1 Cinnamon 2 Cardamom</li> <li>2 Cloves</li> <li>2 Small bay leaves</li> <li>1 teaspoon Fennel seeds</li> <li>A bunch of finely chopped coriander leaves (cilantro) and mint leaves</li> <li>1 tablespoon Oil</li> <li>2 tablespoons Ghee or clarified butter</li> <li>Salt to taste</li> </ul> <ol style="list-style-type: none"> <li>1. Cook all vegetables and spices in a lightly oiled frying pan until lightly browned.</li> <li>2. Place the cooked vegetable mixture into a deep and large bowl and add rice and water. Cover with plastic wrap and vent.</li> <li>3. Place food in the oven. Choose the menu and press start to cook. Stir at least twice during cooking.</li> </ol>

Category	Weight Limit	Utensil	Food Temp	Instructions
Chicken Tikka (Oc-4)	0.2 kg ~ 0.4 kg	Microwave-safe bowl	Room	<div data-bbox="759 172 1485 385" style="border: 1px solid black; padding: 5px;"> <p><b>Ingredients</b>  4 Chicken breasts, cut into Cubes \ 1 cup natural yogurt \ 1 tablespoon ground cumin \ 1 tablespoon garam masala powder \ 1 teaspoon ground coriander \ 1 teaspoon ground turmeric \ 1 tablespoons red chilli powder \ 1 lemon Juice \ 8 cloves garlic, finely chopped \ 1 inch grated ginger, finely chopped \ 1/4 teaspoon red food color \ 1 Lemon</p> </div> <ol style="list-style-type: none"> <li>1. Mix the spices, coloring, lemon juice, ginger and garlic up into a paste with a little water.</li> <li>2. Stir in well with the yogurt to make a tandoori marinade.</li> <li>3. Marinate the chicken in the marinade for 2-3 hours.</li> <li>4. Shake off excess marinade and skewer the pieces of vegetable with the skewer.</li> <li>6. Place skewers on the rack.</li> <li>7. Choose the menu and weight, press start.</li> <li>8. When beep, turn over the food.</li> </ol>
Flapjack (Koutaba) (Oc-5)	0.7 kg	Heat-proof glass dish		<div data-bbox="759 676 1509 770" style="border: 1px solid black; padding: 5px;"> <p><b>Ingredients</b>  200g butter \ 114g brown sugar \ 4 tablespoons syrup \ 280g porridge oats \ 55g plain flour</p> </div> <ol style="list-style-type: none"> <li>1. Melt the margarine, sugar and golden syrup over a low light until melted and combined.</li> <li>2. Take off the heat and add the porridge oats and plain flour and mix well.</li> <li>3. Pour the mixture into a greased glass baking dish.</li> <li>4. Place food in the oven. Choose the menu and press start to cook.</li> <li>5. After cook, cool enough and cut into some pieces.</li> </ol>

# Auto Defrost



Your oven has four microwave defrost settings: - **MEAT**, **POULTRY**, **FISH** and **BREAD**; each defrost category has different power settings. Repeated presses of the **AUTO DEFROST** key will select a different setting.

	Press	
<b>MEAT</b>	<b>1</b>	time
<b>POULTRY</b>	<b>2</b>	times
<b>FISH</b>	<b>3</b>	times
<b>BREAD</b>	<b>4</b>	times

The temperature and density of food varies, I would recommend that the food is checked before cooking commences. Pay particular attention to large joints of meat and chicken, some foods should not be completely thawed before cooking. For example fish cooks so quickly that it is sometimes better to begin cooking while still slightly frozen. The **BREAD** programme is suitable for defrosting small items such as rolls or a small loaf. These will require a standing time to allow the centre to thaw. In the following example I will show you how to defrost 1.4 kg of frozen poultry.

Press **STOP/CLEAR**.

Weigh the food that you are about to defrost. Be certain to remove any metallic ties or wraps; then place the food in your oven and close the oven door.




Press **AUTO DEFROST** twice to select the **POULTRY** defrosting programme. "dEF2" appears on the display window.



Enter the weight of the frozen food that you are about to defrost.

Press the **MORE** key fourteen times to enter 1.4 Kg.



Press **START**.



During defrosting your oven will "BEEP", at which point open the oven door, turn food over and separate to ensure even thawing. Remove any portions that have thawed or shield them to help slow down thawing. After checking close the oven door and press **START** to resume defrosting.

**Your oven will not stop defrosting (even when the beep sounds) unless the door is opened.**

## AUTO WEIGHT DEFROST GUIDE

- \* Food to be defrosted should be in a suitable microwave proof container and place uncovered on the glass turntable.
- \* If necessary, shield small areas of meat or poultry with flat pieces of aluminum foil. This will prevent thin areas becoming warm during defrosting. Ensure the foil does not touch the oven walls.
- \* Separate items like minced meat, chops, sausages and beef as soon as possible.
- \* When BEEP, at this point remove the food from the microwave oven, turn the food over and return to the microwave oven. Press start to continue. At the end of the program, remove the food from the microwave oven, cover with foil and allow to stand until completely thawed. To thaw completely , for example joints of meat and whole chickens should STAND for a minimum of 1 hour before cooking.

CATEGORY	WEIGHT LIMIT	UTENSIL	FOOD
Meat (dEF1)  Poultry (dEF2)  Fish (dEF3)	0.1 ~ 4.0 kg	Microwave ware (Flat plate)	<p><b>Meat</b> Minced beef, Fillet steak, Cubes for stew, Sirloin steak, Pot roast, Rump roast, Beef burger Lamb chops, Lamp chops, Rolled roast, Sausage, Cutlets(2cm)</p> <p>Turn food over at beep. After defrosting, let stand for 5-15 minutes.</p> <p><b>Poultry</b> Whole chicken, Legs, Breasts, Turkey breasts(under 2.0kg)</p> <p>Turn food over at beep. After defrosting, let stand for 20-30 minutes.</p> <p><b>Fish</b> Filletts, Steaks, Whole fish, Sea foods</p> <p>Turn food over at beep. After defrosting, let stand for 10-20 minutes.</p>
Bread (dEF4)	0.1 ~ 0.5 kg	Paper towel or flat plate	<p>Sliced bread, Buns, Baguette, etc. Separate slices and place between paper towel or flat plate. Turn food over at beep. After defrosting, let stand for 1-2 minutes.</p>

# Quick Defrost

Use this function to thaw only 0.5kg of Minced meat very quickly. This will require a standing time to allow the center to thaw. In the following example will show you how to defrost 0.5kg of frozen minced meat.



Your oven has a microwave quick defrost setting (MEAT).

Press **STOP/CLEAR**.

Weight the food that you are about to defrost. Be certain to remove any metallic ties or wraps; then place the food in your oven and close the oven door.



Press **QUICK DEFROST**.

The oven will start automatically.



During defrosting your oven will "BEEP", at which point open the oven door, turn food over and separate to ensure even thawing. Remove any portions that have thawed or shield them to help slow down thawing. After checking close the oven door and press **START** to resume defrosting.

**Your oven will not stop defrosting (even when the beep sounded) unless the door is opened.**

## **QUICK DEFROST GUIDE**

Use this function to defrost quickly for minced meat.

Remove the meat completely from its wrapping. Place the mince onto a microwave-safe plate. When BEEP, at this point remove the mince from the microwave oven, turn the mince over and return to the microwave oven. Press start to continue. At the end of the program remove the mince from the microwave oven, cover with foil and allow to stand 5-15 minutes or until completely thawed.

<b>CATEGORY</b>	<b>WEIGHT</b>	<b>UTENSIL</b>	<b>INSTRUCTIONS</b>
<b>Minced Meat</b>	0.5kg	Microwave ware (Flat plate)	Minced meat Turn food over at beep. After defrosting, let stand for 5-15 minutes.

# Energy Saving



The **ECO ON** feature allows you to save energy through display off during stand-by status, or after 5 minutes with door open or closing, display will off automatically.

Press **STOP /CLEAR(ECO ON)**.  
"O" appears on the display.



Press **STOP /CLEAR(ECO ON)** or  
After 5 minutes with door open or closing, display off.



During **ECO ON** status,if you press any key,display will on.



## **⚠ WARNING**

Please ensure cooking times are correctly set as over cooking may result in **FIRE** and subsequent **DAMAGE** to the **OVEN**.

# **Important safety instructions**


## **Read carefully and keep for future reference**


- 1 Do not attempt to tamper with, or make any adjustments or repairs to the door, control panel, safety interlock switches or any other part of the oven. It is hazardous for anyone to carry out any service or repair operation which involves the removal of any cover which gives protection against exposure to microwave energy. Repairs should only be undertaken by a qualified service technician.
- 2 Do not operate the oven when empty. It is best to leave a glass of water in the oven when not in use. The water will safely absorb all microwave energy, if the oven is accidentally started.
- 3 Do not use the oven for the purpose of dehumidification. It can be the cause of serious damage of safety. (ex. Operating the microwave oven with the wet newspapers, clothes, toys, pet or portable electric devices, etc.)
- 4 Do not cook food wrapped in paper towels, unless your cook book contains instructions, for the food you are cooking.
- 5 Do not use newspaper in place of paper towels for cooking.
- 6 Do not use wooden containers. They may heat-up and char. Do not use ceramic containers which have metallic (e.g. gold or silver) inlays. Always remove metal twist ties. Metal objects in the oven may arc, which can cause serious damage.
- 7 Do not operate the oven with a kitchen towel, a napkin or any other obstruction between the door and the front edges of the oven, which may cause microwave energy leakage.
- 8 Do not use recycled paper products since they may contain impurities which may cause sparks and/or fires when used in cooking.
- 9 Do not rinse the turntable by placing it in water just after cooking. This may cause breakage or damage.
- 10 Small amounts of food require shorter cooking or heating time. If normal times are allowed they may overheat and burn.
- 11 Be certain to place the oven so the front of the door is 8 cm or more behind the edge of the surface on which it is placed, to avoid accidental tipping of the appliance.
- 12 Before cooking, pierce the skin of potatoes, apples or any such fruit or vegetable.
- 13 Do not cook eggs in their shell. Pressure will build up inside the egg which will burst.
- 14 Do not attempt deep fat frying in your oven.
- 15 Remove the plastic wrapping from food before cooking or defrosting. Note though that in some cases food should be covered with plastic film, for heating or cooking.
- 16 If the oven door or door seals are damaged, the oven must not be operated until it has been repaired by a qualified service technician.
- 17 If smoke is observed, switch off or disconnect the oven from the power supply and keep the oven door closed in order to stifle any flames.
- 18 When food is heated or cooked in disposable containers of plastic, paper or other combustible materials, check the oven frequently due to the possibility of the food container is deteriorating.
- 19 Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.
- 20 Liquids or other foods must not be heated in sealed containers since they are liable to explode.
- 21 Do not operate the oven, if the door seals and adjacent parts of the microwave oven are faulty, until the oven has been repaired by a qualified service technician.
- 22 Check the utensils are suitable for use in microwave ovens before use.
- 23 Do not touch the oven door, outer cabinet, rear cabinet, oven cavity, accessories and dishes during grill mode, convection mode and auto cook operations, unless wearing thick oven gloves, as they will become hot. Before clearing make sure they are not hot.


# Important safety instructions


## Read carefully and keep for future reference


- 24 Only use utensils that are suitable for use in microwave ovens.
- 25 When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition.
- 26 If smoke is observed, switch off or unplug the appliance and keep the door closed in order to stifle any flames.
- 27 Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container.
- 28 The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns.
- 29 Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended.
- 30 Details for cleaning door seals, cavities and adjacent parts.
- 31 The oven should be cleaned regularly and any food deposits removed.
- 32 Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation.
- 33 Only use the temperature probe recommended for this oven (for appliances having a facility to use a temperature-sensing probe).
- 34 If heating elements are provided, during use the appliance becomes hot. Care should be taken to avoid touching heating elements inside the oven.
- 35 The appliance is not intended for use by young children or infirm persons without supervision.
- 36 The microwave oven must be operated with the decorative door open.
- 37 This connection may be achieved by having the plug accessible or by incorporation a switch in the fixed wiring in accordance with the wiring rules.
- 38 Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.
- 39 This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

 **WARNING:** If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.

 **WARNING:** It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy.

 **WARNING:** Liquids and other foods must not be heated in sealed containers since they are liable to explode.

 **WARNING:** Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.

 **WARNING:** Accessible parts may become hot during use. Young children should be kept away.

# Microwave-safe Utensils

## Never use metal or metal trimmed utensils in your microwave oven

Microwaves cannot penetrate metal. They will bounce off any metal object in the oven and cause arcing, an alarming phenomenon that resembles lightning. Most heat resistant non metallic cooking utensils are safe for use in your microwave oven. However, some may contain materials that render them unsuitable as microwave cookware. If you have any doubts about a particular utensil, there's a simple way to find out if it can be used in your microwave oven. Place the utensil in question next to a glass bowl filled with water in the microwave oven. Microwave at power HIGH for 1 minute. If the water heats up but the utensil remains cool to the touch, the utensil is microwave~safe. However, if the water does not change temperature but the utensil becomes warm, microwaves are being absorbed by the utensil and it is not safe for use in the microwave oven. You probably have many items on hand in your kitchen right now that can be used as cooking equipment in your microwave oven. Just read through the following checklist.

## Dinner plates

Many kinds of dinner-ware are microwave-safe. If in doubt consult the manufacturer's literature or perform the microwave test.

## Glassware

Glassware that is heat-resistant is microwave-safe. This would include all brands of oven tempered glass cookware. However, do not use delicate glassware, such as tumblers or wine glasses, as these might shatter as the food warms.

## Plastic storage containers

These can be used to hold foods that are to be quickly reheated. However, they should not be used to hold foods that will need considerable time in the oven as hot foods will eventually warp or melt plastic containers.

## Paper

Paper plates and containers are convenient and safe to use in your microwave oven, provided that the cooking time is short and foods to be cooked are low in fat and moisture. Paper towels are also very useful for wrapping foods and for lining baking trays in which greasy foods such as beef are cooked. In general, avoid coloured paper products as the colour may run. Some recycled paper products may contain impurities which could cause arcing or fires when used in the microwave oven.

## Plastic cooking bags

Provided they are made specially for cooking, cooking bags are microwave safe. However, be sure to make a slit in the bag so that steam can escape. Never use ordinary plastic bags for cooking in your microwave oven, as they will melt and rupture.

## Plastic microwave cookware

A variety of shapes and sizes of microwave cookware are available. For the most part, you can probably use items you already have on hand rather than investing in new kitchen equipment.

## Pottery, stoneware and ceramic

Containers made of these materials are usually fine for use in your microwave oven, but they should be tested to be sure.

## CAUTION

**Some items with high lead or iron content are not suitable for cooking utensils.**

**Utensils should be checked to ensure that they are suitable for use in microwave ovens.**

# Food characteristics & Microwave cooking

## Keeping an eye on things

The recipes in the book have been formulated with great care, but your success in preparing them depends on how much attention you pay to the food as it cooks. Always watch your food while it cooks. Your microwave oven is equipped with a light that turns on automatically when the oven is in operation so that you can see inside and check the progress of your food. Directions given in recipes to elevate, stir, and the like should be thought of as the minimum steps recommended. If the food seems to be cooking unevenly, simply make the necessary adjustments you think appropriate to correct the problem.

## Factors affecting microwave cooking times

Many factors affect cooking times. The temperature of ingredients used in a recipe makes a big difference in cooking times. For example, a cake made with ice-cold butter, milk, and eggs will take considerably longer to bake than one made with ingredients that are at room temperature. All of the recipes in this book give a range of cooking times. In general, you will find that the food remains under-cooked at the lower end of the time range, and you may sometimes want to cook your food beyond the maximum time given, according to personal preference. The governing philosophy of this book is that it is best for a recipe to be conservative in giving cooking times. While overcooked food is ruined for good. Some of the recipes, particularly those for bread, cake, and custards, recommend that food be removed from the oven when they are slightly undercooked. This is not a mistake. When allowed to stand, usually covered, these foods will continue to cook outside of the oven as the heat trapped within the outer portions of the food gradually travels inward. If the food is left in the oven until it is cooked all the way through, the outer portions will become overcooked or even burnt. You will become increasingly skilful in estimating both cooking and standing times for various foods.

## Density of food

Light, porous food such as cakes and breads cook more quickly than heavy, dense foods such as roasts and casseroles. You must take care when microwaving porous food that the outer edges do not become dry and brittle.

## Height of food

The upper portion of tall food, particularly roasts, will cook more quickly than the lower portion. Therefore, it is wise to turn tall food during cooking, sometimes several times.

## Moisture content of food

Since the heat generated from microwaves tends to evaporate moisture, relatively dry food such as roasts and some vegetables should either be sprinkled with water prior to cooking or covered to retain moisture.

## Bone and fat content of food

Bones conduct heat and fat cooks more quickly than meat. Care must be taken when cooking bony or fatty cuts of meat that they do not cook unevenly and do not become overcooked.

## Quantity of food

The number of microwaves in your oven remains constant regardless of how much food is being cooked. Therefore, the more food you place in the oven, the longer the cooking time. Remember to decrease cooking times by at least one third when halving a recipe.

## Shape of food

Microwaves penetrate only about 2.cm into food, the interior portion of thick foods are cooked as the heat generated on the outside travels inward. Only the outer edge of food is cooked by microwave energy; the rest is cooked by conduction. The worst possible shape for a food that is to be microwaved is a thick square. The corners will burn long before the centre is even warm. Round thin foods and ring shaped foods cook successfully in the microwave.

## Covering

A cover traps heat and steam which causes food to cook more quickly. Use a lid or microwave cling film with a corner folded back to prevent splitting.

## Browning

Meats and poultry that are cooked fifteen minutes or longer will brown lightly in their own fat. Foods that are cooked for a shorter period of time may be brushed with a browning sauce such as worcestershire sauce, soy sauce or barbecue sauce to achieve an appetizing colour. Since relatively small amounts of browning sauces are added to food the original flavour of the recipe is not altered.

## Covering with greaseproof paper

Greaseproofing effectively prevents spattering and helps food retain some heat. But because it makes a looser cover than a lid or clingfilm, it allows the food to dry out slightly.

## Arranging and spacing

Individual foods such as baked potatoes, small cakes and hors d'oeuvres will heat more evenly if placed in the oven an equal distance apart, preferably in a circular pattern. Never stack foods on top of one another.

# Food characteristics & Microwave cooking

## Stirring

Stirring is one of the most important of all microwaving techniques. In conventional cooking, food is stirred for the purpose of blending. Microwaved food, however, is stirred in order to spread and redistribute heat. Always stir from the outside towards the centre as the outside of the food heats first.

## Turning over

Large, tall foods such as roasts and whole chickens should be turned so that the top and bottom will cook evenly. It is also a good idea to turn cut up chicken and chops.

## Placing thicker portions facing outwards

Since microwaves are attracted to the outside portion of food, it makes sense to place thicker portions of meat, poultry and fish to the outer edge of the baking dish. This way, thicker portions will receive the most microwave energy and the food will cook evenly.

## Shielding

Strips of aluminium foil (which block microwaves) can be placed over the corners or edges of square and rectangular foods to prevent those portions from overcooking. Never use too much foil and make sure the foil is secured to the dish or it may cause 'arcing' in the oven.

## Elevating

Thick or dense foods can be elevated so that microwaves can be absorbed by the underside and centre of the foods.

## Piercing

Foods enclosed in a shell, skin or membrane are likely to burst in the oven unless they are pierced prior to cooking. Such foods include yolks and whites of eggs, clams and oysters and whole vegetables and fruits.

## Testing if cooked

Food cooks so quickly in a microwave oven, it is necessary to test it frequently. Some foods are left in the microwave until completely cooked, but most foods, including meats and poultry, are removed from the oven while still slightly undercooked and allowed to finish cooking during standing time. The internal temperature of foods will rise between 5°F (3°C) and 15°F (8°C) during standing time.

## Standing time

Foods are often allowed to stand for 3 to 10 minutes after being removed from the microwave oven. Usually the foods are covered during standing time to retain heat unless they are supposed to be dry in texture (some cakes and biscuits, for example). Standing allows foods to finish cooking and also helps flavour blend and develop.

## To Clean Your Oven

### 1. Keep the inside of the oven clean

Food spatters or spilled liquids stick to oven walls and between seal and door surface. It is best to wipe up spillovers with a damp cloth right away. Crumbs and spillovers will absorb microwave energy and lengthen cooking times. Use a damp cloth to wipe out crumbs that fall between the door and the frame. It is important to keep this area clean to assure a tight seal. Remove greasy spatters with a soapy cloth then rinse and dry. Do not use harsh detergent or abrasive cleaners. The glass tray can be washed by hand or in the dishwasher.

### 2. Keep the outside of the oven clean

Clean the outside of your oven with soap and water then with clean water and dry with a soft cloth or paper towel. To prevent damage to the operating parts inside the oven, the water should not be allowed to seep into the ventilation openings. To clean control panel, open the door to prevent oven from accidentally starting, and wipe a damp cloth followed immediately by a dry cloth. Press STOP after cleaning.

3. If steam accumulates inside or around the outside of the oven door, wipe the panels with a soft cloth. This may occur when the microwave oven is operated under high humidity conditions and in no way indicates a malfunction of the unit.
4. The door and door seals should be kept clean. Use only warm, soapy water, rinse then dry thoroughly.  
DO NOT USE ABRASIVE MATERIALS, SUCH AS CLEANING POWDERS OR STEEL AND PLASTIC PADS.  
Metal parts will be easier to maintain if wiped frequently with a damp cloth.
5. Do not use any steam cleaner.

# Questions & Answers

## **Q. What's wrong when the oven light will not glow?**

- A. There may be several reasons why the oven light will not glow.
- Light bulb has blown
  - Door is not closed

## **Q. Does microwave energy pass through the viewing screen in the door?**

- A. No. The holes, or ports, are made to allow light to pass; they do not let microwave energy through.

## **Q. Why does the beep tone sound when a pad on the Control Panel is touched?**

- A. The beep tone sounds to assure that the setting is being properly entered.

## **Q. Will the microwave oven be damaged if it operates empty?**

- A. Yes Never run it empty or without the glass tray.

## **Q. Why do eggs sometimes pop?**

- A. When baking, frying, or poaching eggs, the yolk may pop due to steam build up inside the yolk membrane. To prevent this, simply pierce the yolk before cooking. Never microwave eggs in the shell.

## **Q. Why is standing time recommended after microwave cooking is over?**

- A. After microwave cooking is finished, food keeps on cooking during standing time. This standing time finishes cooking evenly throughout the food. The amount of standing time depends on the density of the food.

## **Q. Is it possible to pop corn in a microwave oven?**

- A. Yes, if using one of the two methods described below
1. Popcorn-popping utensils designed specifically for microwave cooking.
  2. Prepackaged commercial microwave popcorn that contains specific times and power outputs needed for an acceptable final product.

FOLLOW EXACT DIRECTIONS GIVEN BY EACH MANUFACTURER FOR THEIR POPCORN PRODUCT. DO NOT LEAVE THE OVEN UNATTENDED WHILE THE CORN IS BEING POPPED. IF CORN FAILS TO POP AFTER THE SUGGESTED TIMES, DISCONTINUE COOKING. OVERCOOKING COULD RESULT IN THE CORN CATCHING FIRE.

## **⚠ CAUTION**

NEVER USE A BROWN PAPER BAG FOR POPPING CORN. NEVER ATTEMPT TO POP LEFTOVER KERNELS.

## **Q. Why doesn't my oven always cook as fast as the cooking guide says?**

- A. Check your cooking guide again to make sure you've followed directions correctly, and to see what might cause variations in cooking time. Cooking guide times and heat settings are suggestions, chosen to help prevent overcooking, the most common problem in getting used to a microwave oven. Variations in the size, shape, weight and dimensions of the food require longer cooking time. Use your own judgement along with the cooking guide suggestions to test food condition, just as you would do with a conventional cooker.

# Plug wiring information/ Technical Specifications

## **Warning**


This appliance must be earthed

The wires in this mains lead are colored in accordance with the following codes  
BLUE ~ Neutral  
BROWN ~ Live  
GREEN & YELLOW ~ Earth

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:

The wire which is colored BLUE must be connected to the terminal which is marked with the letter N or Colored BLACK.

The wire which is colored BROWN must be connected to the terminal which is marked with the letter L or colored RED.

The wire which is colored GREEN & YELLOW or GREEN must be connected to the terminal which is marked with the letter E or .

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard;

For Singapore If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.

## Technical Specification

		MH604***
Power Input		230V AC / 50 Hz
Output		700 W (IEC60705 rating standard)
Microwave Frequency		2450 MHz
Outside Dimension		455 mm(W) X 260 mm(H) X 330 mm(D)
Power	Microwave	1000 Watts
Consumption	Grill	600 Watts
	Combination	1150 Watts

