



## Language Setting



With the power turned on, press and hold the  (POWER) button and LEVEL(档位) button for approximately 3 seconds each time you want to change the language.

## Cleansing the inner corners of your face



Use the edge of the silicone brush head to cleanse the inner corners of your face, for example inner corners of your nose and between your eyebrows.

### Precautions for use

- The recommended usage of the unit is once a day (Skin sensitivity may increase if used more than two times a day).
- If you are undergoing skin treatment or cosmetic surgery, it is recommended that you use it when your skin has healed (after more than 1 month).
- Individuals who are pregnant or lactating are not recommended to use this unit.
- Individuals who are wearing a cardiac pacemaker or device implantation are not recommended to use this unit.
- Individuals who have acne, contact dermatitis, allergies or other intractable skin disease are not recommended to use this unit.

⚠ Please refer to the full text on safety skin information in the owner's manual.

## Change cleansing time



With the power turned off, press and hold the  (POWER) button for approximately 5 seconds until you hear the voice assistance guide. (70 seconds ↔ 120 seconds)

## Set voice guide function



With the power turned on, press and hold the LEVEL(档位) button for approximately 5 seconds each time you want to change the function. (Voice guide → Sound effect guide → Turn off guide (mute))

## How to hold the device



Please hold the unit naturally without blocking the speaker as shown on the image.



MBM67452415

2012\_Rev01

How to use  Use unit once a day  Use bubble foam cleansing



1 Use lukewarm water to wet your face or brush head.




2 Lather up your cleansing product and apply on your face.  
ⓘ Allow sufficient amount of bubbles to form before you start cleansing.



3 Press the  (POWER) button to turn on.



4 Press the LEVEL(档位) button and select the cleansing vibration speed and level (1 → 2 → 3 → 4).



5 Cleanse the face by gently move the brush in a small circular motion, avoiding the eye area.  
(Default setting: 70 seconds / Setting method: refer to the first page)

**70 seconds** ① Left cheek (10's) → ② Right cheek (10's) → ③ Nose (20's) → ④ Chin (10's) → ⑤ Forehead (20's) → Power off

**120 seconds** ① Left cheek (20's) → ② Right cheek (20's) → ③ Nose (30's) → ④ Chin (20's) → ⑤ Forehead (30's) → Power off



6 Rinse your face sufficiently with lukewarm water after cleansing.