



## Additional Information

### Specification

Power consumption	Refer to the main label.
	Networked standby : 0.5 W (If all network ports are activated.)
AC adapter	<ul style="list-style-type: none"><li>• Model : DA-38A25</li><li>• Manufacturer : Asian Power Devices Inc.</li><li>• Input : 100 - 240 V ~ 50 - 60 Hz 1.2 A</li><li>• Output : 25 V  1.52 A</li></ul>
Dimensions (W x H x D)	Approx. 890 mm x 53 mm x 85 mm Without foot
Net Weight	Approx. 2.34 kg
Bus Power Supply (USB)	5 V  500 mA
Amplifier (Total RMS Output power)	300 W

Design and specifications are subject to change without notice.

#### How to disconnect the wireless network connection or the wireless device

Set up the AUTO POWER ON/OFF function to off and turn off the unit.



## SIMPLE MANUAL

# Wireless Sound Bar

To view the instructions of advanced features,  
visit <http://www.lg.com> and then download Owner's Manual.  
Some of the content in this manual may differ from your unit.


MODEL  
SH4



[www.lg.com](http://www.lg.com)




## Front Panel



The buttons are located on the rear.

<b>P/I</b>	Standby / On
<b>F</b>	Selects Function
<b>- +</b>	Adjusts Volume

## Rear Panel



<b>OPTICAL IN</b>	Connect to an Optical device
<b>PORTABLE IN</b>	Connect to a Portable device
<b>USB port</b>	Connect to a USB device
<b>HDMI IN</b>	Connect to HDMI out on a device
<b>HDMI OUT (TV ARC)</b>	Connect to a TV

## 1 Subwoofer Connection

Place the wireless subwoofer near the speaker and follow steps below.

- 1 Connect the power cord of wireless subwoofer to the outlet.
- 2 Turn on the main unit :  
The sound bar and wireless subwoofer will be **automatically** connected. The subwoofer's green LED turns on.


### Subwoofer Connection Manually

- 1 Reset the Subwoofer  
If the green LED on the subwoofer blinks quickly, skip this step and go to **2**
  - Press and hold **Pairing** button for 5 seconds.
  - The LED lights up alternately in red and green.
  - Plug out the power cord. After the LED turns off completely, plug in the power cord again.
- 2 Reset the sound bar
  - Adjust volume to minimum until the red LED on the sound bar lights up for a while.
  - Press and hold **Mute** button on the remote control for 3 seconds.
  - The red LED on the sound bar blinks quickly
  - Turn the sound bar's power off and on while the subwoofer's green LED blinks.

When the connection is completed, you can see the green LED on the subwoofer.



Keep the sound bar and the subwoofer away from the device (ex. wireless router, microwave oven, etc.) over 1m to prevent wireless interference.




## 2 TV Connection

Connect with the Sound Bar and TV using Optical (A) or HDMI ARC (B).


### A Optical Connection

- 1 Connect the sound bar to the TV using Optical cable.
- 2 Set up [External Speaker (Optical)] on your TV setting menu.



### B HDMI(ARC) Connection


- 1 Connect the sound bar to the TV using HDMI cable.
- 2 Set up [External Speaker (HDMI ARC)] on your TV setting menu.



HDMI connection is unavailable if your TV does not support HDMI ARC.


### Additional Device Connection

- 1 Connect to the external device as follows.



- 2 Set the input source by pressing **F** on the remote control or unit repeatedly.

## Remote control



**ASC/STANDARD/CINEMA:** Selects the sound effect.

**NIGHT ON/OFF:** Turns down the volume at night.

**WOOFER LEVEL +/-:** Adjusts the volume level of subwoofer.

**AUTO POWER ON/OFF:** Automatically turns on by an input source.

### Replacement of battery

