









NANO77*
NANO73*
NANO75*








Quick Start Guide




Images shown in manual may vary depending on model
Unpacking
Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item.



CAUTION
Image shown may differ from your TV
When attaching the stand to the TV set, place the screen facing down on a cushioned table or flat surface to protect the screen from scratches.







NOTE

- Do not look into the optical output ports, looking at the laser beam may damage your vision.
- Audio with ACP (Audio Copy Protection) function may block digital audio output.

NOTE

- Some USB Hubs may not work, if a USB device connected using a USB Hub is not detected, connect it to the USB port on the TV directly.
- Connect the external power source if your USB is needed.





NOTE


- Some USB Hubs may not work, if a USB device connected using a USB Hub is not detected, connect it to the USB port on the TV directly.
- Connect the external power source if your USB is needed.

ARC (Audio Return Channel)
An external audio device that supports SIMPLINK and ARC must be connected using HDMI IN eARC/ARC port.

When connected with a high-speed HDMI cable, the external audio device that supports ARC outputs SPDIF audio without additional audio cable and supports the SIMPLINK function.



		A	B	C	D	E	F	F-G
		(mm)					(kg)	
43NANO73SQA	43NANO776QA	967	622	216	564	57.7	9.3	9.2
43NANO75SQA	43NANO756QA							
Power requirement					AC 100-240 V - 50/60 Hz			



A	B	C x D (mm)	E
Wallmount	43NANO73* 43NANO75* 43NANO77*	200 x 200	M6



• Read **Safety and Reference**.

• The Analog Gender adapter can be purchased separately at Customer Service.

+ : Depending on model