



SIMPLE MANUAL

LG ThinQ® View

Smart Display with
the Google Assistant

MODEL
WK9



MFL70441306

1903_Rev03

www.lg.com

Copyright © 2018-2019 LG Electronics Inc.
All Rights Reserved.

Safety Information

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING:

- TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.
- Do not install this equipment in a confined space such as a book case or similar unit.
- This unit contains magnets which can be harmful to some kind of object (Ex: Magnetic card, Pacemaker etc.).

CAUTION:

- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings shall never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.

- The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- To avoid fire or electric shock, do not open the unit: contact to qualified personnel only.
- Do not leave the unit in a place near the heating appliances or subject to direct sunlight, moisture, or mechanical shock.
- The Power Plug is the disconnecting device. In case of an emergency, the Power Plug must remain readily accessible.
- To clean the unit, use a soft, dry cloth. If the surfaces are extremely dirty, use a soft cloth lightly moistened with a mild detergent solution. Do not use strong solvents such as alcohol, benzene, or thinner, as these might damage the surface of the unit.
- Do not use volatile liquids such as insecticide spray near the unit. Wiping with strong pressure may damage the surface. Do not leave rubber or plastic products in contact with the unit for a long period of time.
- Do not place the unit over the vehicle's air bag. When the air bag deploys, it may result in injury. Before using in the car, fix the unit.
- Do not use the handsfree function during driving a car.
- Do not leave the unit on an unstable place such as high shelves. It may fall down because of the vibration of the sound.
- Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock.

CAUTION when using this product in environments of low humidity.

- It may cause static electricity in environments of low humidity.
- It is recommended to use this product after touching any metal object which conducts electricity.

NOTICE: For safety marking information including product identification and supply ratings, please refer to the main label on the bottom or the other surface of the product.

For models using an adapter

Only use the AC adapter supplied with this device. Do not use a power supply from another device or another manufacturer. Using any other power cable or power supply may cause damage to the device and void your warranty.

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20 cm (7.8 inches) between the antenna and your body. Users must follow the specific operating instructions for satisfying RF exposure compliance.

FCC Radio Frequency Interference Requirements:

High power radars are allocated as primary users of the 5.25 to 5.35 GHz and 5.65 to 5.85 GHz bands. These radar stations can cause interference with and/or damage this device. This device cannot be co-located with any other transmitter.

Responsible Party:

LG Electronics USA, Inc.
1000 Sylvan Avenue
Englewood Cliffs, NJ 07632
Tel: 1-800-243-0000

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.

12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

USA Only (Product with embedded rechargeable battery ONLY)

In case rechargeable battery is included in this product, the entire device should be recycled in compliance with rechargeable battery recycling standards because of the internal battery.

To dispose of properly, call (800) 822-8837 or visit www.call2recycle.org.

OPEN SOURCE SOFTWARE NOTICE INFORMATION

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit <http://opensource.lge.com>.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download. LG Electronics will also provide open source code to you on CDROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping and handling) upon email request to opensource@lge.com. This offer is valid for a period of three years after our last shipment of this product. This offer is valid to anyone in receipt of this information.

For more information about Google's open source, visit device settings of Google Home app.

Disclaimers


- Google, Google Home, Google Play, Google Duo, Chromecast built-in and other related marks and logos are trademarks of Google LLC.
- The Google Assistant requires an internet/ data connection. Data rates may apply.
- The Google Assistant is not available in certain languages and countries.
- Subscriptions may be required, and additional terms, conditions and/or charges may apply.
- Controlling certain devices and features in your home requires a compatible smart device.
- Details of services may vary by country.
- Please note that AI Service may be changed, removed or terminated, without notice, by LGE or its third-party providers.

Set up

Step 1. Connect the AC adapter


After connecting the AC adapter, the Smart Display starts booting. Then screen turns on

- 1 LG booting logo appears on the screen.
- 2 Google logo appears on the screen.
- 3 Setup screen appears on the screen.



Step 2. Install "Google Home" App

Download the Google Home App from the Google Play or App Store.



NOTE

The Smart Display is not compatible with the "Smart ThinQ" app. So it can not be used for setup or for control by using the "Smart ThinQ" app.

Step 3. Set up the Wi-Fi connection with app

- 1 Connect your smart device to the Wi-Fi network that you'll use for your Smart Display.



NOTE

In case of iOS devices, it should be turned on **Bluetooth** setting on your smart device.

- 2 Launch the "Google Home" app.
- 3 Follow the steps for Wi-Fi connection on the app.



NOTE

You will need a Google Account to use this app.

- ④ Smart Display is properly connected to Wi-Fi, main screen will appear.



! NOTE

"Google Home" app is provided by Google. It might be revised by a change of Google Policy.

Getting Google Assistant help

For more information and inquiries, please refer to the below guide.

- Visit the Google Assistant Help Center or Google Product Forums on the web site.
- Visit <http://www.lg.com> and then search "WK9".

Then follow these instructions.

[Support] → [Help Library]

! NOTE

Site address is subject to change.

How to Use the "Google Assistant"


Make sure the Smart Display is connected to Wi-Fi. (Page 9-11)

Just start with "Hey Google" and then ask it questions. Quickly manage tasks, view glanceable answers, stay connected with loved ones, enjoy your entertainment, and control your smart home -- all hands-free.

Say "Hey Google"



Hey Google





NOTE

Voice command

- **Timers and alarms**

"Set a timer for 15 minutes"

"Wake me up tomorrow at 6am"

- **Weather and traffic**

"What's the weather this weekend"

"How's the traffic to work today?"

- **Calendar and reminders**

"What's on my agenda?"

"Add doctor's appointment to my calendar"

- **Media**

"Show me football highlights on YouTube"

"Show me my playlists"

"Play the news"

- **Photos**

"Show my photos of Mom"

"Show my photos from Yosemite"

and more

For more information on the voice commands, refer to the "Google Home" app screen.

Additional

Smart Home Control

With the Google Assistant, you can control compatible smart home devices such as TV's, lights, switches, plugs, thermostats and more by simply using your voice.



NOTE

Compatible LG appliance models:

Visit <http://www.lg.com> and then search the information

Make video calls

You can use Google Duo to make video calls to your family and friends. With Google Duo, you can enjoy video calls between this unit and any smartphone or tablet that has the Google Duo app installed.




NOTE

If you need more information about Google Duo, please contact Google or visit the Google Duo Help Center.

Bluetooth Connection

Step 1. Connect the Wi-Fi

Make sure the Smart Display connects to Wi-Fi by using "Google Home" app (Page 9-11).



! NOTE


The **Bluetooth** connection may not work properly before connecting to Wi-Fi.

Step 2. Set up to be able to pair with a Bluetooth device on "Google Home" app

You can set to be able to pair with a Bluetooth device on "Google Home" app.


"Google Home" app, follow these instructions.

[] → [] → [Settings] → [Paired Bluetooth devices]




Step 3. Find and select your Smart Display name on setting of your device

Select Smart Display name that is set on "Google Home" app from phone's smart device list.




Basic Operation




Volume	Volume Control Tap - or +
Microphone	Enable / Disable Voice Recognition Press
Camera	Enable / Disable Camera Slide Camera Switch.

Device Gestures



- Swipe right from left edge to go back to your home screen.




- Swipe up from bottom edge to access to your quick settings.

Important Notice

Resetting

To initialize information of existing connection, follow these instructions.

- 1 Press and hold **—** and **+** button for 10 seconds at the same.



- 2 Before Smart Display enter reset mode, pop-up window is displayed on the screen of Smart Display.
- 3 When you select [Yes, do it!], the Smart Display is reset.

NOTE

When you reset this Smart Display, it needs to reconnect Wi-Fi, **Bluetooth**.

Specification


Power consumption:

- Refer to the main label.

Dimensions (W x H x D):

- Approx. 321 mm X 136 mm X 133 mm
(12.64 inch x 5.35 inch x 5.24 inch)

AC Adapter:

- Model: LCAP16B-A
- Manufacturer: Lien Chang Electronic Enterprise Co., Ltd.
- Input: 100-240 V~ 50-60 Hz
- Output: 19 V  2.1 A
- Design and specifications are subject to change without notice.

For more information, download the online owner's manual. <http://www.lg.com>



LG Customer Information Center

1-800-243-0000

USA, Consumer

1-888-865-3026

USA, Commercial

Register your product Online!

www.lg.com

Printed in China