



LG

Life's Good

Owner's Manual

Blu-ray Disc™ Recorder

BR629T

BR625T

Please read this manual carefully before operating your set and retain it for future reference.



EAB35AH 2VMN00103 ★★★★★

<http://www.lg.com>

Safety Information



CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's

enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING: TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

WARNING: Do not install this equipment in a confined space such as a book case or similar unit.

CAUTION: Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings shall be never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.



CAUTION: This product is classified as a class 1 laser product. This product employs a Laser System. To ensure proper use of this product, please read this owner's manual carefully and retain it for future reference. Shall the unit require maintenance, contact an authorized service centre. Only a qualified service person should the cover or attempt to service this device, due to possible eye injury.

Use of controls, adjustments or the performance of procedures other than those specified herein may result in hazardous radiation exposure. To prevent direct exposure to laser beam, do not try to open the enclosure.

CAUTION: CLASS 3R VISIBLE AND INVISIBLE LASER RADIATION WHEN OPEN, AVOID DIRECT EYE EXPOSURE.

LOCATION: INSIDE, NEAR THE DECK MECHANISM.

CAUTION concerning the Power Cord

The main power supply is engaged when the main plug is plugged in a 220-240 V~, 50Hz AC outlet.

Most appliances recommend they be placed upon a dedicated circuit;

That is, a single outlet circuit which powers only that appliance and has no additional outlets or branch circuits. Check the specification page of this owner's manual to

be certain. Do not overload wall outlets. Overloaded wall outlets, loose or damaged wall outlets, extension cords, frayed power cords, or damaged or cracked wire insulation are dangerous. Any of these conditions could result in electric shock or fire. Periodically examine the cord of your appliance, and if its appearance indicates damage or deterioration, unplug it, discontinue use of the appliance, and have the cord replaced with an exact replacement part by an authorized service centre. Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, closed in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the appliance. To disconnect power from the mains, pull out the mains cord plug. When installing the product, ensure that the plug is easily accessible.

This device is equipped with a portable battery or accumulator.

Safety way to remove the battery or the battery from the equipment: Remove the old battery or battery pack, follow the steps in reverse order than the assembly. To prevent contamination of the environment and bring on possible threat to human and animal health, the old battery or the battery put it in the appropriate container at designated collection points. Do not dispose of batteries or battery together with other waste. It is recommended that you use local, free reimbursement systems batteries and accumulators. The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

CAUTION: The apparatus shall not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, shall be placed on the apparatus.

- The appliance is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they do not play with appliance.
- If the appliance is supplied from a cord extension set or an electrical portable outlet device, the cord extension set on electrical portable outlet device must be positioned so that it is not subject to splashing or ingress of moisture.

Never use a gas duster on this unit.

The gas trapped inside of this unit may cause ignition and explosion.

Do not place any combustible objects on the unit (candles, etc.)

This apparatus should not be placed in a built-in installation, such as a bookcase or rack unless proper ventilation is provided. Make sure to leave space as follows.

- Front: 5 cm with no obstacles
- Depth: 10 cm
- Height: 10 cm

◆ When viewing 3D content

When viewing 3D content, please note the following. Also, please carefully read the user manuals of your 3D television and 3D glasses.

- **Do not view 3D content if**
 - you have a possibility of epilepsy
 - you have photosensitive reaction or have a history of photosensitivity.
 - you have a heart condition
 - you are feeling sick

These may be exacerbated.
- **It is recommended that you view 3D content in proper posture from the proper position.**
- **If the following occur while viewing 3D content, stop viewing immediately.**
 - If you experience double-vision
 - If the images do not seem to be 3D (Please confirm the 3D settings on your 3D devices.)
- **Viewing 3D content is recommended for ages of 6 and older.**

Children may not show visible signs of fatigue and discomfort. When a child is viewing 3D content, please monitor their condition.
- **When viewing 3D content, take a rest every title.**

Viewing for a long time may cause ocular fatigue.
- **Stop viewing immediately if you feel fatigued and/or discomfort while viewing 3D content.**

If continued, it may lead to deconditioning. Please take an adequate rest.
- **If you are on medication, you may be strongly affected by the 3D vision. If you feel anything unusual, stop viewing immediately.**
- **If you have experienced a major illness or you are pregnant, you may be strongly affected by the 3D vision. If you feel anything unusual, stop viewing immediately.**
- **For 3D vision, how it appears depends on the viewer and physical condition. If you feel discomfort, do not view 3D content.**

Trademark Information



Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.



Manufactured under license under U.S. Patent Nos: 5,956,674; 5,974,380; 6,226,616; 6,487,535; 7,392,195; 7,272,567; 7,333,929; 7,212,872 & other U.S. and worldwide patents issued & pending. DTS-HD, the Symbol, & DTS-HD and the Symbol together are registered trademarks & DTS-HD Master Audio | Essential is a trademark of DTS, Inc. Product includes software. © DTS, Inc. All Rights Reserved.



Blu-ray Disc™, Blu-ray™, Blu-ray 3D™, BD-Live™, BONUSVIEW™, and the logos are trademarks of the Blu-ray Disc Association.



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.



Java and all Java based trademarks and logos are trademarks or registered trademarks of Oracle and/or its affiliates.



“AVCHD” and the “AVCHD” logo are trademarks of Panasonic Corporation and Sony Corporation.

x.v.Colour

“x.v.Colour” and “x.v.Colour” logo are trademarks of Sony Corporation.



DLNA®, the DLNA Logo and DLNA CERTIFIED® are trademarks, service marks, or certification marks of the Digital Living Network Alliance.



is a trademark of DVD Format/Logo Licensing Corporation.



DivX®, DivX Certified® and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license.



Windows Media and the Windows logo are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.

THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD (“AVC VIDEO”) AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L. L. C. SEE [HTTP://WWW.MPEGLA.COM](http://www.mpegla.com)

THIS PRODUCT IS LICENSED UNDER THE VC-1 PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE VC-1 STANDARD (“VC-1 VIDEO”) AND/OR (ii) DECODE VC-1 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NONCOMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE VC-1 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE [HTTP://WWW.MPEGLA.COM](http://www.mpegla.com)

MPEG Layer-3 audio coding technology licensed from Fraunhofer IIS and Thomson.

THIS PRODUCT IS LICENSED UNDER THE MPEG-4 VISUAL PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER FOR (i) ENCODING VIDEO IN COMPLIANCE WITH THE MPEG-4 VISUAL STANDARD (“MPEG-4 VIDEO”) AND/OR (ii) DECODING MPEG-4 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED BY MPEG LA TO PROVIDE MPEG-4 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION INCLUDING THAT RELATING TO PROMOTIONAL, INTERNAL AND COMMERCIAL USES AND LICENSING MAY BE OBTAINED FROM MPEG LA, L. L. C. SEE [HTTP://WWW.MPEGLA.COM](http://www.mpegla.com)

◆ About copyright

Unauthorised copying, broadcasting, public performance and lending of discs are prohibited.

This item incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited.


Verification and Preparation

Verifying the supplied accessories

If any part is missing, please contact the retailer you purchased the product from.

- Remote control (1)
- Batteries (R6, 1.5V) (2)
- RF cable (1)
- Video cable (1)
- Audio cables (1)
- AC cord (1)
- Owner's Manual (This booklet) (1)
- Warranty card (1)

Verifying the types of terminals



1. AC inlet
 - Plug in the AC cord.
2. ANTENNA IN / OUT
 - Connect the RF cable to it to view / record the digital broadcast programmes.
3. HDMI OUT
 - Used to connect this unit and a TV using an HDMI cable. HDMI connection provides high picture / sound quality*.
(*Picture / sound quality depends on the TV's capability.)
4. LAN terminal
 - To connect to the network.
5. DIGITAL OUT (OPTICAL) Jack
 - To connect this unit to an audio amplifier with a built-in digital audio output decoder and such.
6. OUT jacks (AUDIO L/R, VIDEO)
 - To connect to the input jacks* on the TV using audio / video cables.
(*Yellow: to the video input
Red / White: to the audio input)
7. IN jacks (AUDIO L/R, VIDEO)
 - To connect a set-top box / another device to this unit. Also used to record (dub) from another device.






























Note

- The cooling fan on the rear panel spins when this unit is powered on and during the time set for the "Quick Booting".
- It is recommended to use an HDMI connection when your TV has an HDMI input. An HDMI connection requires one cable only.

About This Manual

- Operating instructions in this manual are based on use of the remote control.

◆ Symbols of supported media / file format

Symbol	Description
	Internal hard disk drive
	USB external hard disk drive
	BD-RE disc recorded in BDAV format
	BD-R disc recorded in BDAV format
	Commercially available BD-Video disc
	 DVD-RW disc recorded in VR format
	 DVD-RW disc recorded in Video format
	DVD-R disc recorded in Video format
	DVD+RW disc recorded in +VR format
	DVD+R disc recorded in +VR format
	Commercially available DVD-Video disc
	Audio CD (CD-DA), finalised CD-RW / CD-R discs formatted in Audio CD format
	DVD-RW / -R, DVD+RW / +R disc containing movies in AVCHD format
	BD-RE / -R, DVD-RW / -R, DVD+RW / +R, CD-RW / -R disc containing JPEG files
	BD-RE / -R, DVD-RW / -R, DVD+RW / +R, CD-RW / -R disc containing DivX® files
	BD-RE / -R, DVD-RW / -R, DVD+RW / +R, CD-RW / -R disc containing MP3 files
	BD-RE / -R, DVD-RW / -R, DVD+RW / +R, CD-RW / -R disc containing Windows Media™ Audio files
	USB device containing movies in AVCHD format
	USB device containing DivX® files
	USB device containing MP3 files
	USB device containing Windows Media™ Audio files
	USB device containing JPEG files
	AVCHD files*
	DivX® files
	MP3 files
	Windows Media™ Audio files
	JPEG files

* AVCHD files cannot be played back directly from a USB storage device.

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified® device that plays DivX video. Visit divx.com for more information and software tools to convert your files into DivX videos.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on how to complete your registration.

- Media containing the DivX® files with the DivX® GMC (Global Motion Compensation) playback feature, which is DivX® supplemental function, cannot be played back on this unit.

Table of Contents

2 Getting Started 1

- 2 **Safety Information**
- 3 **Trademark Information**
- 4 **Verification and Preparation**
- 4 Verifying the supplied accessories
- 5 Verifying the types of terminals
- 5 **About This Manual**
- 8 **Functional Overview**
- 8 Remote control
- 9 Front panel
- 9 Display panel

10 On-Screen Display

11 Home Menu

12 Connections 2

- 12 **Antenna Connection**
- 12 **Connections to Your TV**
- 13 When connecting the home terminal / set-top box to this unit
- 13 **Network Connection**
- 13 Direct connection to a DLNA client device
- 13 Connection to a DLNA client device via a hub / broadband router

14 Connection to an Audio System

15 Basic Setup 3

- 15 **After All Connections Have Been Made**
- 15 Turn on this unit
- 15 **Preparation for the Remote Control**
- 15 Battery installation
- 15 Operable range of the remote control
- 16 Operating the TV
- 16 Setting up the supplied remote control to control your TV
- 16 **Basic Setup / DTV Operations**
- 16 Basic setup
- 17 **Basic Setup for DTV**
- 17 Available configuration options in "DTV Menu"
- 17 Limiting the access to the particular channels
- 18 **Network Setup**
- 19 **Receiving the Programme Guide**
- 20 **SIMPLINK**
- 20 **Registration / Deregistration of a USB-HDD**
- 21 **DTV Operations**

22 Viewing 4

- 22 **Viewing a Programme Currently On Air**
- 22 Selecting a channel
- 22 Selecting a channel from the "Programme List" window
- 22 Editing favourite groups
- 22 Switching the audio
- 22 Switching the subtitles
- 23 Switching the image quality (Super Resolution)
- 23 Unlock the DTV rating temporarily
- 23 **Viewing from an External Device**
- 23 Switching to the external input
- 23 Viewing a cable-TV programme

24 Supported Media 5

- 24 **Supported Media**
- 25 About HDD (internal HDD)
- 25 About USB-HDD (external HDD)
- 25 About discs
- 26 **Preparation for a Disc**
- 26 Place a disc
- 27 Initialise (format) a brand-new Blu-ray Disc™
- 27 Format a brand-new DVD
- 27 About DVD recording format
- 28 **Preparation for a USB Device**
- 28 Connecting a USB device

29 Recording 6

- 29 **Before Recording**
- 29 Select a media to record to
- 29 Recording mode (image quality) and approx. recording time
- 30 Recording along with bilingual audio (dual audio) / multi audio / surround audio / subtitles
- 31 Simultaneous operations
- 33 **Recording a Programme Currently On Air**
- 33 Changing the recording mode (image quality)
- 33 ITR (Instant Timer Recording)
- 34 **Before Timer Programming**
- 34 About "Programme Guide"
- 34 **Programming a Timer Recording from "Programme Guide"**
- 35 **Manual Timer Programming**
- 35 **Dual Recording**
- 36 **Recording from an External Device**
- 36 To record a cable-TV programme
- 36 **Confirming / Modifying / Cancelling Timer Programmes, Stopping a Timer Recording**
- 36 Confirming timer programmes

- 36 Skipping weekly / daily timer recording temporarily
- 37 Modifying a timer programme
- 37 Cancel an unnecessary timer programme
- 38 Stopping the timer recording in process
- 38 Additional Information about Recording**

40 Playback 7

- 40 Before Playback**
- 40 Contents list
- 40 Resume point
- 41 Playing Back a Programme (Title)**
- 41 Playing Back a Commercially Available Disc**
- 41 Playing back a Blu-ray Disc™ / DVD
- 41 Playing an Audio CD
- 41 Playing back a Blu-ray 3D™ disc
- 42 Playing back a media containing MP3 / WMA / DivX® / JPEG Files
- 42 Various Playback Functions**
- 42 Change the playback speed
- 43 Skipping forward / backward
- 43 Repeat playback
- 44 Playing back a playlist created on another device
- 44 Chase play during recording
- 44 Switching Settings During Playback**
- 44 Switching the audio language / subtitle language / camera angle
- 45 Noise reduction
- 45 Super resolution
- 45 PiP (BONUSVIEW™) setting
- 46 Virtual package
- 46 PIN Code entry screen
- 46 Viewing JPEG Files**
- 46 Playing a slide show
- 46 Recommended spec
- 47 Playing Back a Disc Containing an AVCHD High-Definition Video**
- 47 Additional Information about Playback**

48 Editing 8

- 48 Before Editing**
- 48 Available editing functions
- 49 Adding / Deleting a Chapter Mark**
- 49 Adding a chapter mark
- 49 Deleting a chapter mark
- 49 Hiding chapters
- 49 Changing a Title Name / Protecting a Title**
- 50 Changing a title name

- 50 Protecting a title
- 50 Deleting Unnecessary Titles**
- 50 Deleting a single title
- 50 Delete multiple titles at one time
- 51 Deleting Parts of a Title**
- 51 Dividing a Title**
- 51 Converting the Recording Mode (Image Quality)**

52 Media Management 9

- 52 Media Management**
- 52 Renaming a disc / USB-HDD
- 52 Protecting a disc / USB-HDD
- 52 Finalising a disc recorded on this unit
- 52 Undoing finalisation
- 53 Deleting all recording data on the HDD / USB-HDD
- 53 Reinitialising (reformatting) a disc

54 Dubbing 10

- 54 Before Dubbing**
- 54 Available dubbing types
- 54 Recording mode for dubbing
- 55 About the “High-speed dubbing” and “Normal-speed dubbing”
- 55 About dubbing restrictions
- 55 About “Copy” and “Move”
- 56 Dubbing along with bilingual recording audio (dual audio) / surround audio / subtitles
- 56 One Title Dubbing from “Contents List” screen**
- 56 Dubbing Multiple Titles at One Time**
- 57 Dubbing from a VCR / Camcorder**
- 58 Additional Information about Dubbing**

60 Useful Functions 11


- 60 Using This Unit as a Home Media Server**
- 60 Function Setup**
- 60 Using “Settings” menu
- 66 Software Update**
- 67 Language Code List

68 Others 12

- 68 Troubleshooting**
- 73 If a following message appears...
- 74 Glossary**
- 76 Specifications**
- 77 License**

Functional Overview

Remote control




1. **[⏻ POWER]** (standby / on) button
 - Press to switch the unit on / off.
2. Media buttons (**[HDD]** / **[DISC]** / **[USB]**)
 - Press to switch to the media to operate.
3. Number buttons
 - Used to enter numbers or letters.
4. **[SUBTITLE]** button
 - Press to select a subtitle language.
5. **[⏮]** (skip) button
 - During playback, press once to return to the beginning of the current title / chapter / track / File.
 - During playback, press twice to return to the previous title / chapter / track / File.
 - During the JPEG playback, press to return to the previous File.
6. **[■]** (stop) button
 - Press to stop playback / recording.

7. **[TV VOL + / -]** button
 - Used to control the TV volume.
8. **[● REC.]** button
 - Press to start recording.
9. **[↺ I.REPLAY]** button
 - Press for the instant replay function.
10. **[→ I.SKIP]** button
 - Press for the instant skip function.
11. **[🏠 HOME]** button
 - Press to display the home menu.
12. **[^ / v / < / >]** buttons
 - Press to select items or settings.
13. **[↶ BACK]** button
 - Press to return to the previously displayed menu or screen.
14. Coloured buttons (**[RED]** / **[GREEN]** / **[YELLOW]** / **[BLUE]**)
 - Press to activate shortcut keys on some BD-Video functions. They are also used to switch between pages in a file / contents list.
 - These buttons are also used for "Programme Guide" and "Edit Channels" in "DTV Menu".
15. **[EXIT]** button
 - Press to exit from the various screen / windows.
16. TV control buttons
 - **[⏻]** (TV power) button
 - Press to turn the TV on / off.
 - **[AV / INPUT]** button
 - Press to switch the TV's source input.
 - **[PR/CH ^ / v]** buttons
 - Press to switch TV's channels.
17. **[⏮ OPEN/CLOSE]** button
 - Press to open / close the disc tray.
18. **[🔇 MUTE]** button
 - Press to switch "On" / "Off" the audio.
19. **[AUDIO]** button
 - Press to select the audio channel (audio language).
20. **[▶▶]** (skip) button
 - During playback, press to skip to the next chapter / track / file.
 - When playback is in pause mode, press to forward the playback frame by frame.
21. **[⏮ / ▶▶]** (reverse / forward) button
 - During playback, press to fast reverse / fast forward the playback.
22. **[⏸]** (pause) button
 - Press to pause playback.
23. **[▶]** (play) button
 - Press to start playback / resume playback.
24. **[CH ^ / v]** button
 - Press to switch up / down through the memorised channels.
25. **[GUIDE]** button
 - Press to display the programme guide screen.
26. **[CONTENTS LIST]** button
 - Press to display the contents list.
27. **[⏻ ENTER]** button
 - Press to confirm or select menu items.
28. **[SUB MENU]** button
 - Press to display the sub menu / play menu.
29. **[DISC MENU]** button
 - For BD-Video, press to display the pop-up menu / top menu.
 - For DVD-Video, press to display the top menu / disc menu.
30. **[DISPLAY]** button
 - Press to display chapter / time information.


31. **[TEXT]** button
 - Press to switch between teletext mode and normal TV viewing.
32. **[INFO]** button
 - Press to display the information on the programme. Information is available on the programme guide screen and while viewing a DTV programme.
33. **[TIMER REC.]** button
 - Press to display the timer programming screen.

Front panel



Open the front cover

How to open the front cover




1. Disc tray
2. Infrared sensor window
3. Indicators
 - HDD / DISC / USB
 - Currently selected media is on when the unit is powered on. "HDD" is on when "Quick Booting" is standing by.
 - REC1 is on while recording. It blinks when the recording is in pause mode.
 - REC2 is on while the second recording is in progress. It blinks when the recording is in pause mode.
 - D.OFF is off when "Panel Display" is set to "On" and this unit is in standby mode.
 - D.OFF is on when "Panel Display" is set to "Off" and this unit is in standby mode.
 - D.OFF is on when "Panel Display" is set to "Power Interlock" and this unit is in standby mode.
4. Display panel
5. OPEN / CLOSE button
 - To open / close the disc tray.
6. USB port
 - To connect a USB-HDD / USB device.
7. Reset button
 - Press in case this unit operates unexpectedly or does not operate.
8. POWER (standby / on) button
 - To turn the unit on / off.

Display panel



Display panel



1. Displayed during dubbing.
2. Displayed while updating the firmware, converting a pre-existing title to a different recording mode (image quality).
3. Displayed while streaming content over DLNA.
4. Displayed when a timer programme is set.
5. Displayed during playback.
(It blinks when the playback is in pause mode.)
6. Displayed when a disc is in this unit.
7. Displayed when a USB-HDD / USB device is connected.

Unit's behaviour

HELLO	Displayed when the unit is turned on.
BYE	Displayed when the unit is turned off.
OPEN	Displayed when the disc tray opens.
CLOSE	Displayed when the disc tray closes.
LOADING	Displayed while the unit is loading the disc.
WAIT	Displayed when the unit is finishing a recording / when the unit is plugged in / when the unit recovered from a power outage. (This unit is inoperable while "WAIT" is displayed.)
DTV 123	Displayed when a DTV programme is being viewed.

External input

AV	Displayed when the unit is switched to the external input (AV).
----	---

On-Screen Display

◆ Displaying the unit's status / information

On screen:


You can call up the information windows by pressing [DISPLAY] when viewing a DTV programme.

Press [DISPLAY] once...



1. Channel number
2. Service name
3. Event name
4. Current time, day, date / month / year

Press [DISPLAY] twice...



5. Current title / Total title numbers
 - "----" will be displayed in stop mode when there is no resume point.
6. Current chapter / Total chapter numbers
 - "----" will be displayed in stop mode when there is no resume point.
7. Elapsed time / total duration
8. Unit's status
9. Remaining time
 - Remaining time (approx.) by recording mode.
10. List of remaining time / current recording duration
 - In stop mode, remaining time for HD / SD will be displayed. (Remaining time will not be displayed when using the external input (AV)).
 - While recording, the recording media / station name / current recording duration will be displayed.
11. Media type

! Note

- For the discs recorded on other devices, information may not be displayed properly.

◆ About icons

Power of this unit

	Loading	This unit is turned on
--	---------	------------------------

Media

	Disc tray is opening / closing
	Loading a disc / USB device

Media types

	HDD
	USB-HDD
	Disc
	BD-RE/-R
	BD-Video
	BDAV (original)
	BDAV (playlist)
	DVD-RW/-R
	DVD+RW/+R
	DVD-Video
	VR (original)
	VR (playlist)
	DVD+RW/+R formatted in +VR
	USB device
	Audio CD
	Data CD
	Disc containing an AVCHD content
	No disc is in this unit

Common operations

	Recording
	Pausing the recording
	Finishing the recording
	In stop mode
	In resume stop mode
	Playback
	Pausing the playback
	Fast forward playback with audio
	Fast forward / fast reverse
	Slow forward / slow reverse playback
	Skipping forward / backward
	Dubbing e.g. From the HDD to a disc
	Dubbing e.g. From a USB-HDD to the internal HDD

Others


	Title
	Chapter
	Track
	Time (playback)

! Note

- If "⊘" appears on screen, the attempted operation is prohibited.

Home Menu

◆ The home menu screen



Some of the functions are operable from the home menu.

You can call up the home menu by pressing [**HOME**].

- Home menu can be called up during recording / playback. If the home menu is called up during playback, the playback will automatically stop.
- Items which cannot be selected / operated are greyed out.

DTV

- Switches the unit from the home menu to the DTV viewing screen.

GUIDE

- Enables you to programme timer recordings from the programme guide screen. (Refer to page 34)

Timer Programming

- Displays the timer programming screen.
- You can also programme a timer recording manually by pressing [**SUB MENU**], then selecting “New Programme”. (Refer to page 35)

Contents List

- Displays the contents list.
- Various playback and editing operations can be performed from the submenu in the contents list. (Refer to page 40)

Media Manager

- The following operations are available on each media. (Refer to page 52)

HDD Menu

Delete All Titles (Refer to page 53)

Delete All Unprotected Titles (Refer to page 53)

BD/DVD Menu

Format (Refer to page 53)

Finalise (Refer to page 52)

Edit Disc Name (Refer to page 52)

Disc Protect Off→On (Refer to page 52)

Disc Protect On→Off (Refer to page 52)

USB-HDD Menu

Register USB-HDD setting (Refer to page 20)

Delete All Titles (Refer to page 53)

Delete All Unprotected Titles (Refer to page 53)

Edit USB-HDD Name (Refer to page 52)

USB-HDD Protect Off→On (Refer to page 52)

USB-HDD Protect On→Off (Refer to page 52)

Dubbing

- Enables you to select the dubbing direction and programme dubbings to the dubbing list. (Refer to page 54)


DTV Menu

- Allows you to configure DTV settings. Refer to “Basic Setup for DTV” on page 17 for details.

Settings

- Allows you to access various kinds of menus to customise as you prefer. Refer to “Function Setup” on page 60 for details.


Antenna Connection



Connections to Your TV


◆ Connection to the TV using an HDMI cable

HDMI connection allows you to enjoy high picture / sound quality with one single cable. By connecting this unit and your high-definition TV, you can enjoy the HD broadcast programmes. HDMI connection also enables "SIMPLINK" (Refer to page 20).



◆ Connection to the TV using video / audio cables

AV cable connection is used if an HDMI input is not available on the TV.




! Note

- Use a High-Speed HDMI cable (with the HDMI logo) which is complying with the HDMI standard.
- Make sure the shapes of the HDMI cable's connector and this unit's HDMI OUT jack are matched.
- This unit's HDMI OUT does not support a DVI-HDMI converter cable. Connect an HDMI cable to a TV / display monitor with an HDMI input jack which is complying with the HDMI standard.
- When using Video / Audio cables, connect this unit and the TV directly.
- If connecting this unit and the TV using via another device, using Video / Audio cables, images may be distorted due to the copyright protection system.
- According to the AACSS copy protection rule there may be no Video output via the analog Video Out terminal.

When connecting the home terminal / set-top box to this unit

The cable-TV service can only be received in the service areas, and you need to become a cable subscriber for each home terminal / set-top box. Depending on the cable-TV service provider, the specifications of the home terminal / set-top box, connection method and receivable programmes vary.




Note

- When recording a high-definition DTV programme through the home terminal / set-top box, it will be recorded in standard-definition quality.
- Pass-through type is a way of broadcasting in which a cable-TV service provider sends out DTV signals as-is without converting or compressing.
- If your cable-TV service is the pass-through type, you can directly select channels on this unit and use the EPG.


Network Connection

By connecting this unit to your broadband Internet, you can enjoy the network features, such as BD-Live™ functions. Please contact each content provider for details. You can also use this unit as a DLNA server, which enables you to play back contents stored on this unit's HDD / USB-HDD through a DLNA (client) player. Please refer to the user manual of the DLNA (client) player for how to operate it.

Direct connection to a DLNA client device



Connection to a DLNA client device via a hub / broadband router



If your Internet modem does not have a router function, use a broadband router.

About BD-Live™

This unit supports BD-Video with the BD-LIVE™ functions (BD-ROM Profile 2.0).

By connecting this unit to the Internet, you can enjoy various functions, such as special movie clips, subtitles, additional contents, network games and so on.


- BD-Live™ functions vary depending on the disc. Please refer to the descriptions on screen or on the package for details.
- In order to activate BD-LIVE™ functions, network configurations are required. Please refer to “Network Connection” on page 13, and “Network Setup” on page 18.
- Depending on the disc, you may be required to change the setting in “Home Menu” > “Settings” > “Network Settings” > “BD-Live Setting” to “Allow” or “Limited Allow”.
- It may take extra time to connect to the server or may be unable to connect.
- The unit or the disc ID may be sent to the content provider when playing back a disc with BD-Live™ functions. To prevent data transmission, change the setting of “BD-Live Setting”.

Note

- Please purchase shielded LAN cables at your local store and use them to connect the unit to the network equipment.
- When connecting a LAN cable to this unit, you need to configure the network setting in “Home Menu” > “Settings” > “Network Settings” > “Network Connection”, then select “Auto” or “Manual”.
- For a LAN cable, use a category 5 (or higher) straight cable.
- If you need the MAC address of this unit, you can confirm it in “Home Menu” > “Settings” > “Network Settings” > “Displaying network status”.

Connection to an Audio System

You can enjoy multi channel audio by connecting this unit to a digital audio system.

◆ Using an optical audio cable**◆ This unit — Amplifier — TV connection using HDMI cables**

- When the amplifier supports PCM 7.1 ch, you can enjoy BD-Video with 7.1 ch audio.
- When the amplifier supports Dolby Digital Plus / Dolby TrueHD / DTS-HD®, you can enjoy each audio output. (With this connection, audio may not be output from the TV. In this case, output audio from the speakers connected to the amplifier. Please refer to the user manual of the amplifier and TV for details.)
- Use HDMI cables (with the HDMI logo) which are complying with the HDMI standard.

Note


When connecting this unit to a digital audio system / HDMI compatible amplifier, please configure this unit's audio settings in “Home Menu” > “Settings” > “Video/Audio”.

- Audio may be distorted or may not be output if the audio settings are not configured correctly.

After All Connections Have Been Made

Turn on this unit

1. After all connections have been made, plug the AC cord into an AC power outlet.
 - The display on the front panel will show "WAIT". This unit is inoperable while "WAIT" is being displayed.




2. Turn on the TV, then tune it to the correct source input associated with this unit.
3. Turn on this unit.
 - Please refer to "Basic setup" on page 16 for details. Please go on to "◆ Initial Setting" on page 16.


Preparation for the Remote Control

Battery installation

Install 2 R6 (1.5V) batteries matching the polarity as indicated inside battery compartment.




Operable range of the remote control



- Line of sight: approx. 7 m
- Either side of the centre: approx. 5 m within 30°
- Above and below: approx. 5 m within 30°

Operating the TV

1. Point the remote control at the TV's infrared sensor window.
2. Operate the TV. (Operating the TV with the buttons shown below.)



! Note

Use of the remote control with improper battery installation may cause heat generation, burn and malfunction.

- Replace both the batteries with new ones in case of the following:
 - Operable distance for the remote control has decreased.
 - The unit does not react to certain button pressed on the remote control.
- The supplied batteries are meant for operation check. It is recommended to replace them with new batteries immediately.

Do not use the following types of batteries as they may cause poor operation or inoperability of the remote control.

- Oxiride batteries (ZR6)
- Evolta batteries (LR6)
- If the remote control will not be used for an extended period of time, please remove the batteries from the battery compartment.
- When disposing of used batteries, please comply with governmental regulations or environmental public rules that apply in your country or area.

Setting up the supplied remote control to control your TV

You can operate your TV with the supplied remote control. If your TV is listed in the table below, set the appropriate manufacturer code.

1. While holding down [⏻] (TV power), enter the manufacturer code for your TV using [number buttons].

Manufacturer	Code Number	Manufacturer	Code Number
LG	1(Default), 2	Samsung	6, 7
Zenith	1, 3, 4	Sony	8, 9
GoldStar	1, 2	Hitachi	4

2. Release [⏻] (TV power) to complete setting.

- Depending on your TV, some or all buttons may not function on the TV, even after entering the correct manufacturer code. When you replace the batteries of the remote, the code number you have set may be reset to the default setting. Set the appropriate code number again.

Basic Setup / DTV Operations

Basic setup

◆ Finding the viewing source input

1. After having made all the necessary connections, press [⏻ **POWER**] to turn on the unit.
2. Turn on the TV.
3. Find the button on the TV's remote control that accesses the external source input. Press the button repeatedly until you see the "Initial Setting" screen on the TV screen. (The button may be labelled "SOURCE", "AV", "AUX" or "SELECT". Refer to your TV's user manual.)


If you see the "Initial Setting" screen, that is the correct viewing source input associated with this unit's output. Make sure to always select this source input on your TV when using this unit.

- If the TV is connected using an HDMI cable, it may take extra time for the opening picture to appear.


◆ Initial Setting

When you turn on this unit for the first time, "Initial Setting" will start automatically.

1. Press [⏻ **POWER**].
2. Turn on the TV. Select the source input which is associated with this unit.
 - "Initial Setting" screen will appear.



3. Select the region where you live using [^/∨], then press [⊙ **ENTER**].
4. "Auto Tuning" screen will appear. Press [⊙ **ENTER**] to start "Auto Tuning".



- “Clock Setting” screen will appear. It will automatically adjust the time and date based on the time zone.
 - If the automatic clock setup fails, please set it up manually by following the instructions on the screen.

◆ Redoing “Initial Setting”

[HOME] > “DTV Menu” > “Initial Setting”

- Press [ENTER] when “Initial Setting” is highlighted.
- Follow step 3 to 5 in “◆ Initial Setting” on page 16.

Basic Setup for DTV

◆ Audio language for DTV programmes

Refer to “Audio Language” section in the “Function Setup” table on page 61 and complete all the necessary setups.

◆ Subtitle language for DTV programmes

Refer to “Subtitle Language” section in the “Function Setup” table on page 61 and complete all the necessary setups.

◆ Updating DTV channels automatically

With this function, you can have the unit automatically search for new channels. If new channels are found, they will be added in the channel map automatically.

Press [HOME], then select “DTV Menu” > “Installation” > “Service Update” > “Auto”, then press [ENTER].

- The tuner will start searching for new channel when the unit is powered off at 1:00 AM.
- You can also add new channels manually by selecting “Add New Channels”.

Available configuration options in “DTV Menu”

Press [HOME], then select “DTV Menu”.

Menus	Options	
Edit Channels		
Installation	Auto Tuning	
	Add New Channels	
	Service Update	Auto Off
Parental Control	Channel Lock	Unlock
		Lock
	DTV Rating	Unlock
		P (Kids)
		C
		G
		PG
		M
		MA 15 +
		AV 15 +
		R (Adult)
		All
	Change PIN Code	
Signal Information		
Initial Setting		

Limiting the access to the particular channels

You can set limits to access to particular channels for parental control purposes.

Once a channel is locked, the PIN Code will be required to perform the following functions:

- “Auto Tuning”
- Editing the channel map.
- Programming a timer recording of the locked channel.
- Tuning into the locked channel.

! Note


- “PIN Code” referred to here is for DTV parental control and is not to unlock the limitation on a commercially available video disc.

- Press [HOME], then select “DTV Menu” > “Edit Channels”, then press [ENTER].
- Use [</>] to select the desired channel to limit the access, then press [RED] for your desired setting.
 - For channel lock
Press [RED] once: → The icon will be highlighted. The locked channels will stay in the channel map and can be selected, but PIN Code entry is required to view the programme.
 - For access prohibition
Press [RED] twice: → The icon will be highlighted. Access-prohibited channels will not be listed in the channel map and cannot be selected.
- Press [BACK] to return to the previous screen.
- Select “Parental Control”, then press [ENTER].
- Select “Channel Lock”, then press [ENTER].
 - PIN Code entry field will appear. Enter the PIN Code to proceed.
 - “0000” cannot be used for a PIN Code.
 - If you forget the PIN Code, you can reset it. Press [HOME], then select > “DTV Menu” > “Parental Control”, then highlight “Channel Lock” or “DTV Rating”, then enter “210499” using [number buttons].
- Use [^/∨] to select “Lock”, then press [ENTER].
- Press [BACK] repeatedly to exit.

Network Setup

Network settings are to enable the BD-Live™ features on this unit using the broadband Internet connection. Please also refer to the information provided by your ISP (Internet Service Provider) and the user manual of your modem / router.

Press [**HOME**], then select “Settings” > “Network Settings” > “Network Connection” > “Auto” or “Manual”.



“Auto”:

Automatically configures each setting item in “Network Connection”, and then performs a connection test.

“Manual”:

Requests you to manually configure the setting A – E on pages 18 to 19.

! Note

- Please perform a connection test when changing the network settings in “Network Connection”.

◆ For “Manual”

A: IP Address Setting

1. Configure IP Address / Subnet Mask / Default Gateway.

- 1) Use [**^**/**v**] to select “IP Address Setting”, then press [**ENTER**].
 - The acquisition method will be displayed.
- 2) Select your desired method, then press [**ENTER**].
 - “Auto(DHCP)” is recommended in most cases.

“Auto(DHCP)”:
Automatically configures the IP Address / Subnet Mask / Default Gateway. Please proceed to (B).

“Manual”:
Requires you to manually configure the IP address / Subnet Mask / Default Gateway. In case your router does not have a DHCP server function or you would rather not use it, please select “Manual”, then proceed to 3).
- 3) Use [**^**/**v**] to select “IP Address”, then press [**ENTER**].
 - Entry screen will be displayed.
- 4) Enter number using [**number buttons**], then press [**ENTER**].
 - To move from a number cell to another, use [**</>**].
 - For an IP Address for this unit, refer to the IP address on your PC on the same local area network, then change the last 2-digit number to your desired number (up to 3-digit numbers).

e.g.) When the PC’s IP Address is “192.168.10.12”, enter a number such as “192.168.10.223”. The “223” can be any number except “12”.

- For “Subnet Mask” and “Default Gateway”, please enter the same numbers as those on your PC’s network setting.
- When you enter a wrong number, select “Clear” to clear the incorrect number, then press [**ENTER**].
- After having entered all the necessary numbers, select “OK”, then press [**ENTER**].
- Configure “Subnet Mask” and “Default Gateway” in the same manner as “IP Address”.

2. After having configured all the network settings, select “OK” in the sub menu using [**>**], then press [**ENTER**].

3. Press [**BACK**] repeatedly to exit.

B: DNS Setting

1. Configure the primary DNS / secondary DNS.

- 1) Use [**^**/**v**] to select “DNS Setting”, then press [**ENTER**].
 - The acquisition method will be displayed.
- 2) Select your desired method, then press [**ENTER**].
 - “Auto(DHCP)” is recommended in most cases.

“Auto(DHCP)”:
Automatically configures the primary DNS / secondary DNS by the DHCP server function. Please proceed to (C).

“Manual”:
Requires you to manually configure the primary DNS / secondary DNS. In case your router does not have a DHCP server function or you would rather not use it, please select “Manual”, then proceed to 3).
- 3) Use [**^**/**v**] to select “Primary DNS”, then press [**ENTER**].
 - Entry screen will be displayed.
- 4) Enter number using [**number buttons**], then press [**ENTER**].
 - To move from a number cell to another, use [**</>**].
 - For the primary DNS, enter the same numbers as those in Preferred DNS Server on your PC’s network setting. When you enter a wrong number, select “Clear” to clear the incorrect number, then press [**ENTER**].
 - After having entered all the necessary numbers, select “OK”, then press [**ENTER**].
- 5) Configure “Secondary DNS” in the same manner as “Primary DNS”.
 - For the secondary DNS, enter the same numbers as those in Alternate DNS Server on your PC’s network setting.

2. After having configured all the network settings, select “OK” in the sub menu using [**>**], then press [**ENTER**].

3. Press [**BACK**] repeatedly to exit.

C: Proxy Setting

Proxy settings will be needed when this unit is connected to a broadband Internet connection and your ISP requires proxy settings.

If you are not required to configure proxy setting, proceed to (D).

1. Enter the Proxy Address and the proxy port.
 - 1) Use [**^**/**v**] to select "Proxy Setting", then press [**⊙ ENTER**].
 - 2) Select "Use", then press [**⊙ ENTER**].
 - Entry screen will appear.
 - 3) Use [**number buttons**] to enter the proxy address provided by your ISP, then press [**⊙ ENTER**].
 - The port number entry screen will appear.
 - 4) Use [**number buttons**] to enter the port number, then press [**⊙ ENTER**]. The highlight will automatically move on "OK", then press [**⊙ ENTER**].

D: Connection Speed

"Auto" is recommended in most cases. If a connection test fails after IP Address setting and DNS-IP setting, then try following.

1. Configure the connection speed.
 - 1) Use [**^**/**v**] to select "Connection Speed", then press [**⊙ ENTER**].
 - Available speeds will be displayed.
 - 2) Select the desired speed according to your network environment, then press [**⊙ ENTER**].
2. After having configured all the network settings, select "OK" in the sub menu using [**>**], then press [**⊙ ENTER**].
3. Press [**↩ BACK**] repeatedly to exit.

E: Connection Test

1. Perform a connection test.
 - 1) Use [**^**/**v**] to select "Connection Test", then press [**⊙ ENTER**].
 - A connection test will start.
 - If the test is successful, a confirmation message will appear. Press [**⊙ ENTER**].
 - If the test fails, an error message will appear. Please follow the instructions and configure necessary settings.
2. After having configured all the network settings, select "OK" in the sub menu using [**>**], then press [**⊙ ENTER**].
3. Press [**↩ BACK**] repeatedly to exit.

! Note

- Depending on the networking device, it may lose its connection to the network after changing the connection speed.


Receiving the Programme Guide

The programme guide, also known as EPG (Electronic Programme Guide), gives you a list of the DTV programmes and detailed information about programmes.

By selecting a programme in the programme guide, you can view the programme or set a timer recording.

Guide to the "Programme Guide" screen

To call up the "Programme Guide" screen, press [**GUIDE**] in DTV viewing mode.



1. Mode: Weekly / Daily
2. Current time, day, date / month / year
3. Start time - End time of the selected programme
4. Programme name
5. Genre / Rating
6. Day, date / month of the programme list
7. Time-shift for 2 hours
8. Channel list (Referring to the channel map)
9. Programme list
10. Operation guide: [**RED**] / [**GREEN**] / [**⊙ ENTER**] / [**◀** / **▶**] / [**INFO**]

◆ About programme guide

Programme guide will be available after receiving the EPG data.

- The EPG data will be received after completing "Installation" in "DTV Menu".

! Note

- In the following cases, an EPG data reception will not complete and blank cells will be shown or the old data will remain.
 - In the case of power outage or the AC cord is unplugged
 - Under poor reception conditions
- In the following case, the programme guide will not be available until next EPG data reception.
 - When retuning channels
- When a broadcast station airs a different programme from the scheduled programme. This may cause an inconsistency between the actual air and the information in the programme guide.

SIMPLINK

What's SIMPLINK?

The SIMPLINK function can control an LG's HDMI compatible television and other devices connected to this unit. SIMPLINK may control some of the functions of a non SIMPLINK compatible device if it meets the HDMI standard; however, it is not guaranteed.

Example of SIMPLINK control

- When this unit is turned on, the TV's source input will automatically be switched to the correct source input.
 - Press [▶].
 - Press [GUIDE].
 - Press [CONTENTS LIST].
- When changing the TV channel during playback from HDD / DISC, playback will automatically stop.
- When turning off the TV, this unit will automatically be turned off. (When this unit is booting or recording to HDD / DISC, it is not the case.)
- Depending on the connected device, it may operate unexpectedly. In this case, set "SIMPLINK" to "Off".

To activate "SIMPLINK" function, please follow the instructions below.

- Before activating, complete your TV's SIMPLINK setup. (Please refer to your TV's owner's manual for details.)
1. Press [HOME], then select "Settings" > "HDMI" > "SIMPLINK" > "On", then press [ENTER].
 2. Press [BACK] repeatedly to exit.


Registration / Deregistration of a USB-HDD

Connect a USB-HDD to this unit and register it. The USB-HDD is not ready to use until it is registered. If you connect an unregistered USB-HDD, a message for registration will appear. In this case, select "Yes" and follow the instructions in "◆ To register".


◆ To register

Press [HOME], then select "Media Manager" > "USB-HDD Menu" > "Register USB-HDD setting".

1. The list of USB-HDD registration screen will appear. Use [^/∨] to select a row with "unregistered", then press [ENTER].



2. A pop-up window will appear. Use [^/∨] to select "Register USB-HDD in this device", then press [ENTER].




- Confirmation messages will appear. If you agree, select "Yes" using [^/∨], then press [ENTER].
3. If you wish to change the name of the USB-HDD, use [^/∨] to select "Yes", then press [ENTER]. If you wish to change the name later, select "No", then press [ENTER].
 - If "Yes" is selected > Proceed to step 4.
 - If "No" is selected > Registration will be completed, then exit the screen.
 4. The editing screen will appear. Enter a name, then press [ENTER].
 - A confirmation message will appear. Use [^/∨] to select "Yes", then press [ENTER].
 5. Press [BACK] repeatedly to exit.


◆ To deregister

Press [**HOME**], then select "Media Manager" > "USB-HDD Menu" > "Register USB-HDD setting".

1. The list of USB-HDD registration screen will appear. Use [**^**/**v**] to select the desired USB-HDD, then press [**ENTER**].



2. A pop-up window will appear. Use [**^**/**v**] to select "Deregister USB-HDD", then press [**ENTER**].



- Confirmation messages will appear. If you agree, select "Yes" using [**^**/**v**], then press [**ENTER**].

3. Press [**BACK**] repeatedly to exit.

! Note

- When a USB-HDD is registered to this unit, it will be initialised in this unit's dedicated format. Note that all recorded titles on the USB-HDD will be deleted.
- A USB-HDD deregistered from this unit will no longer be recordable or playable. If you wish to re-register the USB-HDD, it will be initialised again, and all recorded titles will be deleted. Please be careful when deregistering a USB-HDD.
- Recorded titles on a USB-HDD registered to this unit can only be used on this particular unit and is not compatible with PC's or any other recorders including the same model of this unit.
- Up to 8 USB-HDD's can be registered to this unit; however, one single USB-HDD can be connected to this unit.
- This unit does not support a USB hub.

DTV Operations


>> Preparation

- Connect this unit to the TV.

1. Turn on the TV.
2. Press the button on the TV's remote control which accesses the external source input repeatedly until you see the DTV broadcasting from this unit.
 - The button on the TV's remote control may vary on the TV brand and model. (e.g., SOURCE / AV / AUX / SELECT and so on.)

! Note

- "HELLO" will be displayed on the display of the unit. After a while, the DTV broadcasting this unit is receiving will appear on screen.
- If you see the "Initial Setting" screen, this unit has not been completed with the initial setting. Please perform "◆ Initial Setting" on page 16.



Viewing a Programme Currently On Air

Selecting a channel


1. Press [**HOME**], then select “DTV”.



2. Select a channel.
 - **For use of [CH ^/∨] for up / down**
Press [CH ^/∨].
 - **For use of a 3 digit number**
Use [number buttons] to enter a channel number. (e.g.)
To select the channel 123, press [1] > [2] > [3].
 - **If the PIN Code entry screen is displayed, refer to “Unlock the DTV rating temporarily” on page 23.**

Selecting a channel from the “Programme List” window

1. While viewing a DTV programme, press [**ENTER**].
 - “Programme List” window will appear. The currently selected channel is highlighted.
2. Use [</>] to select a favourite group.
 - If no group has been created, [</>] is not available.
 - A group with no channel will be skipped.
3. Use [^/∨] to select the desired channel, then press [**ENTER**].




4. Press [**BACK**] to finish.
 - As to “Favourite Group”, refer to “Editing favourite groups” on page 22.

Editing favourite groups

You can sort DTV channels into 4 different favourite groups (1 - 4). One channel can be assigned to multiple favourite groups.

1. Press [**HOME**], then select “DTV Menu” > “Edit Channels”, then press [**ENTER**].
2. Select the channel you wish to add to a favourite group, using [</>].
3. Press a group number [1] / [2] / [3] / [4].



- To delete a channel from a favourite group, select the channel you wish to delete, then press the group number [1] / [2] / [3] / [4] from which you wish to delete the channel.
4. Press [**BACK**] repeatedly to exit.

Switching the audio

You can switch the audio if the programme has multiple audio streams.

1. Press [**AUDIO**] to call up the audio information.
 - You can also call up the audio information by pressing [**SUB MENU**], then selecting “Audio”.
2. Use [^/∨/ </>] to select your desired setting.
3. Press [**ENTER**] to finish.

Switching the subtitles

1. Press [**SUBTITLE**] to call up the subtitle information.
 - You can also call up the subtitle information by pressing [**SUB MENU**], then selecting “Subtitle”.
2. Use [^/∨] to select your desired setting.
3. Press [**ENTER**] to finish.

Switching the image quality (Super Resolution)

Super Resolution enhances SD quality images output in 1080i / 1080p from the HDMI jack, which gives more crisp images.

1. When viewing an SD quality programme, press **[SUB MENU]** to call up the sub menu.
2. Use **[^/∨]** to select “Super Resolution”, then press **[⊙ ENTER]**.
 - Setting information will appear.
3. Use **[^/∨]** to select “On”, then press **[⊙ ENTER]**.

Unlock the DTV rating temporarily

If the PIN Code entry screen appears while viewing a programme, please enter the PIN Code.

1. Use **[number buttons]** to enter the PIN Code.
 - To turn off “DTV Rating”, press **[🏠 HOME]**, then select “DTV Menu” > “Parental Control” > “DTV Rating” > “Unlock”, then press **[⊙ ENTER]**.

Viewing from an External Device

To view from an external device connected to this unit, switch this unit to the external input (AV). For how to operate the external device, please refer to the user manual of the device.

Switching to the external input

1. Press **[SUB MENU]** to call up the sub menu.
2. Use **[^/∨]** to select “Switch DTV or AV”, then press **[⊙ ENTER]**.
3. Use **[^/∨]** to select “AV”, then press **[⊙ ENTER]**.

! Note

- In the following case, “AV” is not available.
 - During a dual recording of 2 DTV programmes

Viewing a cable-TV programme

To view a cable-TV programme through this unit, select a channel on the home terminal / set-top box provided by the cable-TV service provider, then switch this unit to the external input. If your cable-TV service is the pass-through type, you can directly select channels on this unit (you do not need to switch the unit to the external input.)

- Please contact your cable-TV service provider for details.
- Please refer to the user manual of the connected device as well.

>> Preparation

- Connect the cable-TV's home terminal / set-top box to this unit's external input.
1. Select a channel on the home terminal / set-top box.
 2. Switch this unit to the external input.
 - Refer to steps 1 to 3 in “Switching to the external input” on page 23.

Supported Media

Media other than described below are not supported.

Recordable / playable

About media	
HDD	Internal hard disk drive
USB-HDD	USB external hard disk drive connected to this unit's USB port with a USB cable
BD-RE	BD-RE SL (Single layer) BD-RE DL (Dual layer) Ver 2.1 Usable disc: Up to 2 x
BD-R	BD-R SL (Single layer) BD-R DL (Dual layer) Ver 1.1 / 1.2 / 1.3 Usable disc: Up to 6 x
-RW	DVD-RW Ver 1.1 / 1.2 Usable disc: Up to 6 x
-R	DVD-R (Single layer) Ver 2.0 / 2.1 Usable disc: Up to 16 x
+RW	DVD+RW Usable disc: Up to 8 x
+R	DVD+R (Single layer) Usable disc: Up to 16 x

Type of media		HDD	USB-HDD	BD-RE	BD-R	-RW		-R	+RW	+R	
						-RW(VR)	-RW(Video)	-R(Video)	+RW+VR	+R(+VR)	
Recording (directly to the media)	Digital broadcasting	✓ ^{HD}	✓ ^{HD}	✓ ^{HD}	✓ ^{HD}	—	—	—	—	—	✓: Recordable in HD quality ✓ ^{SD} : Recordable in SD quality ✓ ^{SD} : Only copy-free titles are recordable in SD quality —: Not available
	External input (AV)	✓ ^{SD}	—	✓ ^{SD}	✓ ^{SD}	—	—	—	—	—	
Dubbing ¹	Digital broadcasting	✓ ^{HD}	✓ ^{HD}	✓ ^{HD}	✓ ^{HD}	✓ ^{SD}	✓ ^{SD}	✓ ^{SD}	✓ ^{SD}	✓ ^{SD}	
	External input (AV)	✓ ^{SD}	✓ ^{SD}	✓ ^{SD}	✓ ^{SD}	✓ ^{SD}	✓ ^{SD} ²	✓ ^{SD} ²	✓ ^{SD}	✓ ^{SD}	
Recording multiple times		✓	✓	✓	—	✓	✓ ³	—	✓	—	✓: Operable —: Not available
Playback		✓	✓	✓	✓	✓	✓ ²	✓ ²	✓	✓	
Playback from "Contents List"		✓	✓	✓	✓	✓	— ²	— ²	✓	✓	
Chase play		✓	✓	—	—	—	—	—	—	—	

¹ When dubbing a copy-once programme, refer to "About dubbing restrictions" on page 55 to learn if the dubbing will be "copy" or "move".

² When dubbing to DVD-RW (Video) / DVD-R (Video), the disc will automatically be finalised after dubbing is completed. In this owner's manual, finalised DVD-RW (Video) / DVD-R (Video) discs are described as DVD-Video .




³ If you wish to add a recording to a finalised DVD-RW (Video) disc, please format the disc again. (Refer to "Reinitialising (reformatting) a disc" on page 53). Note that all data on the disc will be deleted.

- For DVD-RW discs, "VR" and "Video" format are supported. For DVD-R discs, only "Video" format is supported.
- The 3-layer / 4-layer BD-RE / -R discs are not supported.
- For DVD-R (Single layer), only "Video" format is supported. Only DVD-R (VR) discs recorded and finalised on another unit are playable on this unit.
- For DVD-R (Dual layer) discs, neither recording nor dubbing is possible on this unit. Only discs recorded and finalised on another unit are playable on this unit.
- For DVD+R (Dual layer) discs, neither recording nor dubbing is possible on this unit. Only discs recorded and finalised on another unit are playable on this unit.
- AVCREC is not supported.

! Note

- When dubbing a copy-once programme to a DVD-RW (VR) disc, use a CPRM compatible disc.

Only playable

About media			
BD-Video	Disc including the region code 	AVCHD	High-definition movies recorded on digital camcorders, in AVCHD format
DVD-Video	Disc including the region code  or 	MP3	For media containing audio files encoded in MP3 format
Audio CD	<ul style="list-style-type: none"> Audio CD (CD-DA) Finalised CD-RW / CD-R discs recorded in Audio CD format 	WMA	For media containing audio files encoded in Windows Media™ Audio format
JPEG	JPEG image files (from digital cameras)	DivX®	For media containing movie files encoded in DivX® format

Type of media	BD-Video	DVD-Video	Audio CD	JPEG		AVCHD		MP3		WMA		DivX®	
				DISC(JPEG)	USB(JPEG)	DISC(AVCHD) ⁴	USB(AVCHD)	DISC(MP3)	USB(MP3)	DISC(WMA)	USB(WMA)	DISC(DivX®)	USB(DivX®)
Playback	✓	✓	✓	✓	✓	✓	— ⁵	✓	✓	✓	✓	✓	✓
Playback from "Contents List"	—	—	✓	✓	✓	— ⁵	—	✓	✓	✓	✓	✓	✓

✓ : Available

— : Not available

⁴ Including finalised DVD-RW / DVD-R / DVD+RW / DVD+R (including dual-layered discs)

⁵ By copying (dubbing) the contents to the HDD, it will become possible to play back from "Contents List".

- For Audio CD / JPEG / MP3 / WMA and DivX®, its special contents list screen will appear.
- AVCREC is not supported.
- For the dual-layered DVD-R / DVD+R discs, only those recorded and finalised on another unit are playable on this unit.
- VCD / SVCD are not supported.
- AVCHD Ver 2.0 is not supported.

About HDD (internal HDD)

Caution about HDD handling

- Do not subject it to vibration or strong impact, especially when the unit power is on. HDD is also susceptible to temperature and moisture.
- Operating the unit under such conditions described above may cause loss of data or malfunctions.
- If a HDD is damaged, the recorded data may be lost.
- Do not unplug the power cord when the unit power is on.
- Do not lift or move the unit soon after the power is turned off. (Please wait at least 2 minutes.)
- Do not operate this unit under dew condensation conditions.

Please use the HDD as a temporary data storage device.

- It is highly recommended to copy important recordings to discs.
- For mechanical reasons, the HDD may degrade quickly.

Other information

- The internal HDD is unreplaceable. Attempting to replace it causes malfunctions and voids your warranty.
- Please turn the unit power off when it will not be used for an extended period of time.
- No data is recorded on the HDD. Please record on your own media before playback.

About USB-HDD (external HDD)

◆ Available functions

The registered USB-HDD can be used in the same manner as the internal HDD.

Differences from the Internal HDD

- When recording directly to the USB-HDD, recording mode is TS only.
- USB-HDD cannot record 2 programmes simultaneously.
- One title dubbing cannot be performed from a USB-HDD.
- Recording / editing on a protected USB-HDD is not possible.

About discs

◆ Blu-ray Disc™ / DVD / CD

A disc cannot record or play back properly in the following cases.

- The source recording is in a bad condition, an incompatible disc, with scratches / dirt, the unit's lens for recording / playback is dirty, under dew condensation conditions.
- When attempting to play back a disc (recorded on the unit) on a PC / car GPS system / car audio system / video game console.
- When attempting to play back a disc authored on a PC.
- When the DVD's are recorded in an incompatible format, such as the NTSC system. (This unit is compatible with the PAL system.)
- When attempting to play back an unauthorised disc (illegally-copied disc).
- When the disc contains a title with closed captioning.

How to hold a disc

- Hold the disc edges and the centre hole. Try not to touch the recording surface (shiny side).
- If a disc is dirty, clean with a moist, soft cloth, then wipe from the centre to the outer edge with a dry cloth. Do not use commercially available liquid cleaner, thinner, benzene or alcohol.

Do not use the following discs!

- The following discs may cause damage to the disc and the unit.
 - Scratched disc
 - Disc with a label applied on the surface
 - Disc with a label that is coming unglued
 - Disc with a glued label and the glue is running off
 - Cracked / deformed disc repaired with glue
 - Specially-shaped disc (e.g., a hexagon disc)

Continued on next page

When using an 8 cm disc

- 8 cm disc can only be played back on this unit.
Recording / editing cannot be performed.
- Carefully place the disc to the inner disc tray guide.

◆ **BD-RE / BD-R**

- This unit may not play back unfinalised BD-R discs recorded on another device or the disc may lose data.
- Initialise a brand-new BD-RE / BD-R disc before using.
- BD-RE Ver 1.0 discs (the cartridge type) are not compatible with this unit.

◆ **DVD-RW / DVD-R**

- This unit cannot record directly to a DVD-RW / DVD-R disc.
- This unit may not play back unfinalised DVD-RW / DVD-R discs recorded on another device or the disc may lose data.
- DVD-RW (VR) discs can only be played back on VR compatible recorders / players.
- CPRM compatible discs can only be played back on CPRM compatible recorders / players.
- DVD-RW (Video) / DVD-R (Video) discs will automatically be finalised after the dubbing process finishes. This unit recognises these finalised discs as DVD-Video discs.
- It may take extra time to eject x 1 speed disc.


◆ **DVD+RW / DVD+R**

- This unit cannot record directly to a DVD+RW / DVD+R disc.
- If you make an additional recording to a finalised DVD+RW disc, it will be unfinalised.

◆ **BD-Video / DVD-Video**

- Some discs may behave unexpectedly because of the software producer's purpose. Please refer to the instructions of the disc.

◆ **Audio CD**




- Please make sure there is a  mark on the label side of the CD.
- Audio CD's other than the CD standard, such as a CD with a copy-control, may not play properly or be completely incompatible.

◆ **About USB devices**

- USB devices which can be connect to the USB port on the front of this unit are;
 - USB-HDD
 - USB memory stick
 - Digital camera containing JPEG files
 - Digital camcorder containing AVCHD contents
- Do not connect any other types of USB device other than the examples above or it may cause damage to this unit or loss of data. Operations in use of a USB hub or USB extension cable are not guaranteed.
- Do not charge a cell phone / portable audio player's battery using this unit's USB port or it may cause malfunction of the unit.

◆ **About Titles / Tracks / Files**

The contents of HDD / disc are generally divided into sections or folders (groups of titles / files) as shown below.



Title: Content on the HDD / disc, which is equivalent to, for example, one episode of a TV drama series

Chapter: A smaller part in a title, which is equivalent to a chapter in a book

Track: A song in an Audio CD


Folder: A directory which can contain files and other folders

File: Content (data) on the HDD / disc

Preparation for a Disc

Place a disc

1. Press [**▲ OPEN/CLOSE**] to open the disc tray.
2. Place a disc on the tray with the label side facing up.



- **When playing back a double-sided disc, place the disc with the playback side down.**
3. Press [**▲ OPEN/CLOSE**] to close the disc tray.
 - It may take extra time to read some discs.
 - Some video discs automatically start playback.
 - "●" will appear on the display on the front panel when disc loading is completed.

Initialise (format) a brand-new Blu-ray Disc™

BD-RE **BD-R**

When putting a brand-new disc in the unit, the initialisation (format) screen will appear. This is a necessary process to make the disc recordable.

BD-RE	<ul style="list-style-type: none"> A brand-new disc is not formatted. Format it before using. BD-RE discs can be formatted multiple times. Note that this process deletes all data on the disc.
BD-R	<ul style="list-style-type: none"> A brand-new disc is not formatted. Format it before using. BD-R discs can be formatted only once.

- Place a brand-new disc in the unit.
- Use [**^**/**v**] to select “Yes”, then press [**⊙ ENTER**].



- It may take extra time to complete.

! Note

- Do not unplug the AC cord while loading a disc or performing a disc format. Doing so may cause damage to the disc or malfunction of the unit.
- It is not possible to cancel the formatting process once it has begun.

Format a brand-new DVD

-RW **+RW(+VR)**

When placing a brand-new DVD-RW / DVD+RW disc in the unit, the initialisation (format) screen will appear. It is not possible to record on an unformatted disc. (Direct recording to a DVD is not possible.)


DVD-RW	<ul style="list-style-type: none"> A brand-new DVD-RW is not formatted. Format it in VR or Video mode before using. DVD-RW discs can be formatted multiple times. Note that this process deletes all data on the disc. (Refer to page 53.)
DVD-R	<ul style="list-style-type: none"> A brand-new DVD-R is formatted in Video mode at the factory. No need to re-format the disc before using. DVD-R discs cannot be re-formatted.
DVD+RW	<ul style="list-style-type: none"> A brand-new DVD+RW is not formatted. Format it in +VR mode before using. DVD+RW discs can be formatted multiple times. Note that this process deletes all data on the disc. (Refer to page 53.)
DVD+R	<ul style="list-style-type: none"> DVD+R discs cannot be re-formatted. A brand-new DVD-R is formatted in +VR mode at the factory. No need to re-format the disc before using.

- Place a brand-new disc in the unit.
- Use [**^**/**v**] to select “Yes”, then press [**⊙ ENTER**].



- For DVD+RW, formatting will begin right after you press [**⊙ ENTER**] on “Yes”.
- For DVD-RW, proceed to step 3.

- Use [**^**/**v**] to select the desired format mode, then press [**⊙ ENTER**].



- It may take a while to complete.
- To cancel the formatting process, select “Cancel”, then press [**⊙ ENTER**].

About DVD recording format

◆ VR format (DVD Video Recording Format)

-RW(VR)

- Offers advanced editing features.
- Can record and edit repeatedly.
- Playable only on VR compatible Blu-ray Disc™ / DVD players.
- Finalisation recommended.
- By unfinalising a finalised disc, additional recordings can be performed.

◆ +VR format

+RW(+VR) **+R(+VR)**

- Offers basic editing features.
- Can record and edit repeatedly.
- Playable on most Blu-ray Disc™/DVD players.
- Finalisation recommended.
- For DVD+RW, if additional recording is made, the disc will automatically be unfinalised.
- For DVD+R, additional recordings are not available after finalisation.

◆ Video format (DVD Video Format)


-RW(Video) **+R(Video)**

- Same recording format used for the most commercial DVD-Video.
- Playable on most Blu-ray Disc™ / DVD players.
- When dubbing is completed, the disc will automatically be finalised.
- Additional recordings are not available after finalisation.

Preparation for a USB Device

Connecting a USB device

With this unit, you can play back JPEG / AVCHD / MP3 / WMA / DivX® files recorded on a USB device, such as a USB memory stick or a digital camera. JPEG files can be played back directly from the USB device. AVCHD files should first be dubbed to the internal HDD. Also, you can connect a USB-HDD to this unit and record broadcast programmes to it or play back the recorded titles in the same manner as the internal HDD.



! Note

- Be sure to turn off this unit and the USB-HDD before disconnecting the USB-HDD. If “Quick Booting” is activated, be sure to deactivate it before turning off this unit. (Refer to page 65.) No indicators on the display panel should be lighted when the unit is powered off.
- Do not turn off or disconnect the USB-HDD while it is running. It may cause data loss or malfunction of this unit.
- We are not responsible for data-loss or damage to your USB-HDD caused by malfunction of this unit, repairing of the USB-HDD or the uninstructed connection of the USB-HDD to other devices.

◆ When USB device is connected to this unit...

- The display on the front panel will show “”.
- Setting menu may appear on the display of the connected device. In such case, select PC connection mode. (Refer to the user manual of the USB device for details.)
- It may take a while to recognise the USB device.
- This unit does not support AVCHD Ver 2.0.
- If your USB-HDD has a power switch, turn on the USB-HDD first before you turn on this unit.
- **To disconnect the USB device, make sure the playback is stopped, then slowly pull out the device. As for USB-HDD, make sure the power of this unit and the USB-HDD are turned off before disconnecting.**

Before Recording

Select a media to record to

For some programmes, recording is prohibited or restricted for copyright protection reasons.

Restriction on recording	HDD	BD-RE	-RW(VR)	-RW(Video)	+RW(+VR)
	USB-HDD ¹	BD-R ²		-R(Video)	+R(+VR)
Copy-free programme	✓	✓			
Copy-once programme	✓	✓	—	—	—
Copy-protected programme	—	—			

- ✓ : Available
— : Not available

*1 In the following cases, recording will be performed to the HDD even if a timer recording is set for the USB-HDD.


- When the USB-HDD is not registered to this unit.
- When the USB-HDD is not connected to this unit.
- When the USB-HDD is not powered on when a timer recording starts.
- When the USB-HDD does not have enough capacity to record.

*2 In the following cases, recording will be performed to the HDD even if a timer recording is set for a BD-RE/R disc.

- No recordable disc is in the unit.
- The disc does not have enough capacity to record.

! Note

- Direct recording to a DVD is not possible.
- When recording a programme with no copy restriction and copy-once programme in a row at one time, the start time and the end time makes the recording one title. Hence, it will "move" when dubbing this title.



- Data broadcasting cannot be recorded.
- Radio broadcasting can be recorded to the HDD only.
- This unit will pause recording when a programme changes to a copy-protected programme or parental-lock programme. The recording will be resumed when the programme changes back to the recordable programme.
- For recording modes and restrictions on recordings with audio / subtitles, refer to pages 29 to 31.

Recording mode (image quality) and approx. recording time

"Recording mode" refers to the image quality. You can choose whether to give priority to image quality or recording duration.

Image quality and recording duration by recording mode			
TS	• Digital broadcasting	As is broadcasted	High image quality
AF	• Digital broadcasting	Compressed HD quality	Rec. duration
AN			image quality
AE	• Digital broadcasting	SD quality	Standard image quality
XP			Rec. duration
SP			image quality
LP			Rec. duration
EP	• External input		

HDD

Recording mode and Approximate bit rate		Maximum recordable duration	
		BR629T (1TB)	BR625T (500GB)
TS	DTV (HD): 15 Mbps	147 hours	73 hours
	DTV (SD): 8 Mbps	276 hours	137 hours
AF	12.9 Mbps	171 hours	85 hours
AN	8.6 Mbps	257 hours	128 hours
AE	4.36 Mbps	506 hours	252 hours
	2 Mbps	1097 hours	547 hours
XP	1 hr mode: 9.5 Mbps	231 hours	115 hours
SP	2 hr mode: 4.7 Mbps	462 hours	230 hours
LP	4 hr mode: 2.3 Mbps	930 hours	464 hours
EP	6 hr mode: 1.6 Mbps	1375 hours	686 hours
	8 hr mode: 1.2 Mbps	1845 hours	920 hours

BD-RE BD-R

Recording mode and Approximate bit rate		Maximum recordable duration	
		Single layer (25GB)	Dual layer (50GB)
TS	DTV (HD): 15 Mbps	3 hours and 20 minutes	7 hours
	DTV (SD): 8 Mbps	6 hours and 30 minutes	13 hours
AF	12.9 Mbps	4 hours	8 hours
AN	8.6 Mbps	6 hours	12 hours
AE	4.36 Mbps	12 hours	24 hours
	2 Mbps	26 hours	53 hours
XP	1 hr mode: 9.5 Mbps	5 hours and 15 minutes	11 hours
SP	2 hr mode: 4.7 Mbps	10 hours and 30 minutes	22 hours
LP	4 hr mode: 2.3 Mbps	21 hours	44 hours
EP	6 hr mode: 1.6 Mbps	32 hours	66 hours
	8 hr mode: 1.2 Mbps	43 hours	88 hours

-RW -R(Video) +RW(+VR) +R(+VR) (for dubbing only)

Recording mode and Approximate bit rate		Maximum recordable duration
XP	1 hr mode: 9.5 Mbps	1 hour
SP	2 hr mode: 4.7 Mbps	2 hours
LP	4 hr mode: 2.3 Mbps	4 hours
EP	6 hr mode: 1.6 Mbps	6 hours
	8 hr mode: 1.2 Mbps	8 hours

! Note

- Maximum recordable duration is approximate and will depend on the content.
- Bit rate defers depending on the programme and the possible recordable duration will defer.
- Programmes containing scenes with quick motion or rapid changes in brightness, such as sports and concerts, may cause block noise.
- The possible recording duration of the recording mode, AE and EP, can be configured in “Home Menu” > “Settings” > “Recording” > “AE Mode” or “EP Mode”.
- In some cases, the recordable capacity of the disc may decrease due to information, such as chapter markers and other management information, written along with the recording data.
- This unit employs VBR (Variable Bit Rate) for efficient recording and the possible recording duration differs depending on the content.
- The longest recording duration is 8 hours. This unit will automatically stop recording when a recording duration reaches 8 hours.
- Direct recording of DTV programme to the HDD / USB-HDD / BD is only available in TS mode.
 - AF / AN / AE, XP / SP / LP / EP mode can be used for TS → AVC/PS conversion and dubbing to the HDD / USB-HDD.
 - TS → AVC/PS conversion is not available for BD-RE / BD-R discs. When dubbing, AF / AN / AE, XP / SP / LP / EP can be used.
- Recording from the external device to a USB-HDD is not possible.

Recording along with bilingual audio (dual audio) / multi audio / surround audio / subtitles

Before recording, please confirm the recording mode and the setting in “Home Menu” > “Settings” > “Recording” are configured as you wish.

◆ When recording a programme along with bilingual audio (dual audio) / multi audio / surround audio / subtitles

Rec. to	(For dubbing / recording mode changing)									
	HDD	USB-HDD	BD-RE	HDD	USB-HDD	BD-RE	HDD	USB-HDD	BD-RE	
Rec. mode	TS			AF / AN / AE		XP / SP / LP / EP		XP / SP / LP / EP		
Bilingual audio (Dual audio)	Both Main / Sub audio will be recorded • It is switchable during playback.			Both Main / Sub audio will be recorded • It is switchable during playback. ⁴		Both Main / Sub audio will be recorded. ¹ • The audio is switchable during playback.		Only the audio selected in “Bilingual Recording Audio” (Main or Sub) will be recorded.		
Multi audio	Multiple audio will be recorded. • It is switchable during playback.			When recording / dubbing, one of the audio streams will be recorded. If a programme contains an English audio stream, it will be recorded. If multiple English audio streams are contained, they will be recorded in the following order. • HE-AAC > AAC > AC3 > MPEG If the programme does not contain an English audio stream, “Audio 1” will be recorded. • It is not switchable during playback.						
Surround audio	Surround audio as is broadcasted will be recorded.					It will be recorded in stereo.				
Subtitles	Subtitle information will be recorded. ² • It is switchable (On / Off) during playback.			<p>■ If “Settings” > “Recording” > “Subtitle Recording” is set to “On”... When recording / dubbing, one of the subtitles will be recorded. If the programme contains an English subtitles, it will be recorded. If multiple English subtitles are contained, they will be recorded in the following order. • Teletext for the hearing impaired > Teletext > Subtitle for the hearing impaired > Subtitle</p> <p>If the programme does not contain an English subtitles, “Subtitles 1” will be recorded. • Subtitles will be burned in the images and it cannot be turned “On” / “Off”.</p> <p>■ If “Settings” > “Recording” > “Subtitle Recording” is set to “Off”... Subtitles will not be recorded.</p>						

◆ If recording a content along with bilingual audio from an external device...

Rec. to	(For dubbing)			
	HDD ⁵	USB-HDD	-RW(Video)	-R(Video)
	BD-RE ⁵	BD-R ⁵	+RW(+VR)	+R(+VR)
	-RW(VR)			
Rec. mode	XP / SP / LP / EP		XP / SP / LP / EP	
Bilingual audio ³	Both Main / Sub audio will be recorded. ¹ • It is switchable during playback.		Only the audio selected in "Bilingual Recording Audio" Main or Sub will be recorded.	

¹ If "Recording" > "Recording Audio Select(XP)" is set to "PCM" and recording in XP mode, the audio will be recorded based on the setting in "Recording" > "Bilingual Recording Audio". In this case, the audio is not switchable during playback.

Also, when dubbing to a DVD-RW (Video) / DVD-R (Video) / DVD+RW (+VR) / DVD+R (+VR) disc, the setting in "Bilingual Recording Audio" will be applied likewise.

² Subtitles can be switched "On" / "Off" during playback only when it is high-speed dubbing.

³ To record from the external input (AV) as a bilingual audio content, make sure the setting in "Recording" > "External Input Audio" is set to "Bilingual". If it is set to "Stereo", both Main and Sub audio will be output at the same time.

⁴ When dubbing a title recorded in TS mode using AF / AN / AE mode or converting it to AF / AN / AE mode, the audio will be recorded in stereo and when playing back the title, both Main / Sub audio will be output at the same time. In order to select either audio, switch the audio to Left ch or Right ch.

⁵ Direct recording is also possible.

! Note

- Recording from the external device to a USB-HDD is not possible.

Simultaneous operations

◆ Whether a timer recording can be performed during playback

Media being played	Recording media			
	HDD	USB-HDD	BD-RE	BD-R
HDD	USB-HDD	✓	✓	
BD-RE	BD-R	✓	✓	
-RW	-R	✓	— ^{*1}	
+RW	+R	✓	— ^{*1}	
BD-Video		✓	— ^{*1}	
DVD-Video	Audio CD	✓	— ^{*1}	
DISC(JPEG)	DISC(DivX [®])	✓	— ^{*1}	
DISC(MP3)	DISC(WMA)	✓	— ^{*1}	
USB(JPEG)	USB(DivX [®])	✓	✓	
USB(MP3)	USB(WMA)	✓	✓	
DISC(AVCHD)		✓	— ^{*1}	

✓ : Available

✓ : Available (Playback will stop 2 minutes before a timer recording starts.)

— : Not available

^{*1} The timer recording will be performed to the HDD in substitution for the originally intended media (alternative recording).

◆ Available operations while recording a programme

Currently recording media and the recording mode (single recording)		Playback media								
		HDD	USB-HDD	BD-RE	BD-R	BD-Video	DISC(JPEG)	DISC(DivX®)	DISC(MP3)	DISC(WMA)
				-RW	-R		USB(JPEG)	USB(DivX®)		
				+RW	+R		USB(MP3)	USB(WMA)		
		DVD-Video	Audio CD							
HDD	TS	✓		✓		✓				
	XP / SP / LP / EP	✓		✓		—				
USB-HDD	TS	✓		✓		✓				
BD-RE	TS, XP / SP / LP / EP	✓		—		—				
BD-R										

Currently recording media and the recording mode (dual recording)			Playback media								
			HDD	USB-HDD	BD-RE	BD-R	BD-Video	DISC(JPEG)	DISC(DivX®)	DISC(MP3)	DISC(WMA)
					-RW	-R		USB(JPEG)	USB(DivX®)		
					+RW	+R		USB(MP3)	USB(WMA)		
			DVD-Video	Audio CD							
HDD	TS	HDD	TS	✓		✓		✓			
		XP / SP / LP / EP	✓		✓		—				
		USB-HDD	TS	✓		✓		✓			
	XP / SP / LP / EP	BD-RE	TS, XP / SP / LP / EP	✓		—		—			
		BD-R									
		USB-HDD	TS	✓		✓		—			
USB-HDD	TS	BD-RE	TS, XP / SP / LP / EP	✓		—		—			
		BD-R									

- ✓ : Available (Chase play also available)
- ✓ : Available (Chase play not available)
- : Not available

◆ Playable media and a possible timer recording while dubbing a title

Dubbing direction	Dubbing speed	Playback								Timer recording			
		HDD	USB-HDD	BD-RE	BD-R	DISC(JPEG)	DISC(DivX®)	DISC(MP3)	DISC(WMA)	HDD	USB-HDD	BD-RE	BD-R
				-RW	-R								
				+RW	+R								
		BD-Video	DVD-Video	USB(JPEG)	USB(DivX®)	USB(MP3)	USB(WMA)						
HDD → USB-HDD	High	✓ ^{*1}		✓		—		—		✓		— ^{*2}	
USB-HDD → HDD	Normal	—		—		—		—		✓		✓	
HDD → HDD	High	BD-RE		—		—		—		✓		— ^{*2}	
		BD-R											
	-RW(VR)	Normal	—		—		—		—	✓		✓	
HDD → HDD	High	—		—		—		—		✓		— ^{*2}	
	Normal	—		—		—		—		✓		✓	
BD-RE → HDD	High	✓		—		—		—		✓		— ^{*2}	
	Normal	—		—		—		—		✓		✓	
-RW(VR)	High	✓		—		—		—		✓		— ^{*2}	
DISC(AVCHD)													
USB(AVCHD)													
+RW	Normal	—		—		—		—		✓		✓	
+R													

- ✓ : Available
- ✓ : Available (Dubbing will be cancelled 2 minutes before a timer recording starts.)
- : Not available

*1 When "moving", playback of the dubbing source is not possible.

*2 The timer recording will be performed to the HDD in substitution for the originally intended media (alternative recording).

Recording a Programme Currently On Air

HDD **USB-HDD** **BD-RE** **BD-R**

>> Preparation

- To record to a USB-HDD, connect it to the unit.
- To record to a disc, place a recordable disc in the unit.

1. Press **[HDD]** / **[DISC]** / **[USB]** to select the recording media.

2. Follow steps 1 and 2 in “Selecting a channel” on page 22.

3. Press **[● REC.]** to start recording.

- If pressing **[● REC.]** twice or more, the recording will be ITR (Instant Timer Recording).
- **To pause recording (for HDD / USB-HDD only)** Press **[HDD]** / **[USB]** to switch the unit to the recording media, then press **[||]**. To resume, press **[||]** again.
 - ITR cannot be paused.
- **To stop recording** Press **[■]**.
 - If you stop recording, the recording (from the beginning to where it was stopped) will be one title. (It may take a moment to accept the next operation.)
 - A confirmation message will appear. Use **[^/∨]** to select “Yes”, then press **[⊙ ENTER]**.
- **To pause the following operations, press [HDD] / [USB] to switch the unit to the recording media, then select the channel which is being recorded, then press [||]. (for HDD / USB-HDD only)**
 - Dual recording
 - Chase play
 - Simultaneous rec/play
- **To stop the following operations, press [HDD] / [USB] to switch the unit to the recording media, then select the channel which is being recorded, then press [■].**
 - Dual recording
 - Chase play
 - Simultaneous rec/play


! Note

- You can check the channel of the programme currently being recorded and the recording media by pressing **[DISPLAY]**.

Changing the recording mode (image quality)

You can change the recording mode (image quality) when recording from an external device. (For DTV recording, only “TS” is available and it is not changeable.)

1. Press **[SUB MENU]** to call up the sub menu.
2. Use **[^/∨]** to select “Rec Mode”, then press **[⊙ ENTER]**.
3. Use **[^/∨]** to select the desired setting, then press **[⊙ ENTER]**.



! Note

- For recording to a USB-HDD, recording mode is not changeable.

ITR (Instant Timer Recording)

HDD **USB-HDD** **BD-RE** **BD-R**

You can instantly set the recording duration to stop the recording automatically.

In step 3 in “Recording a Programme Currently On Air” on page 33, by pressing **[● REC.]** more than twice, the recording duration increases by 15 minutes. (e.g., pressing **[● REC.]** twice sets the unit to stop the recording in 15 minutes, 3 times 30 minutes.)


- You can set an ITR up to 4 hours.
- To cancel an ITR, press **[● REC.]** repeatedly until a duration time on the TV screen disappears.
- A confirmation message will appear when the ITR finishes, then the unit will automatically be turned off after 1 minute.
- If no ITR is set, the recording will automatically stop in 8 hours.
- The ITR duration will be displayed on the display panel.
- To stop recording during an ITR:
 - When recording one programme, refer to “Recording a Programme Currently On Air” on page 33.
 - When recording 2 programmes simultaneously or during chase play, refer to “Dual Recording” on page 35.
- Recording cannot be paused during an ITR.

Before Timer Programming

Guide to the "Timer Programming" screen

To call up the "Timer Programming" screen

- 1) Press **[TIMER REC.]**.
 - You also can access the timer programming screen from "Home Menu" > "Timer Programming".



Icons used on the timer programming screen

: Information

: Recording in progress

: Recording media

Skip : This daily timer programme will be skipped this time.

About "Programme Guide"

On the programme guide screen, select the desired programme for a timer recording, then press **[ENTER]**.

- The programme guide can display programmes for the next 8 days.
- "Ⓞ" will appear on the programmed timer recording.
- **To see the detailed information of a programme**
 - On the programme guide screen, select a programme, then press **[INFO]**.

Programme genre icons

Undefined	Movie	News
Entertainment	Sport	Children's
Music	Arts/Culture	Current affairs
Education	Infotainment	Special
Comedy	Drama	Documentary

Note

- The programme guide is not available when you first set up this unit. This unit needs to receive the EPG data. (Refer to "Receiving the Programme Guide" on page 19.)
- If programme information is unavailable, please view the channel for a while, then try and call up the programme guide screen again.
- There are cases in which a broadcast station airs a different programme from the scheduled programme. This may cause an inconsistency between the actual air and the information in the programme guide.

Programming a Timer Recording from "Programme Guide"

HDD **USB-HDD** **BD-RE** **BD-R**

You can programme timer recordings for the next 8 days.
>> Preparation

- To record to a USB-HDD, connect it to the unit.
- To record to a disc, place a recordable disc in the unit.


1. Press **[GUIDE]**.

- You can also call up the programme guide screen from "Home Menu" > "GUIDE".
- You can switch between "Daily Mode" / "Weekly Mode" by pressing **[RED]** / **[GREEN]**.

2. Use **[^/~/</>]** to select a programme to record, then press **[ENTER]**.

- "Timer Programming" screen will appear.
- You can modify the end time, recording media and recording mode.

3. Use **[>]** to select "OK", then press **[ENTER]**.



4. Press **[BACK]** to finish.

Manual Timer Programming


HDD **USB-HDD** **BD-RE** **BD-R**

If the programme you wish to record is unable to set from the programme guide screen, you can manually programme a timer recording for it. Manual timer programming allows you to programme timer recordings for the next one month.

>> Preparation

- To record to a USB-HDD, connect it to the unit.
- To record to a disc, place a recordable disc in the unit.

1. Press **[TIMER REC.]** to call up “Timer Programming” screen.
2. Press **[SUB MENU]** to call up the sub menu.
3. Use **[^/∨]** to select “New Programme”, then press **[⊙ ENTER]**.



4. Use **[</>]** to select “Date”, “Start”, “End”, “CH” and “REC To”, then set each item using **[^/∨]**.
 - For every week / every day recording
You can select it at “Date” pressing **[∨]** multiple times.
5. Press **[>]** to move to the sub menu.
6. Press **[^]** to select “Mode”, then press **[⊙ ENTER]**. The recording mode list will appear. Use **[^/∨]** to select your desired recording mode, then press **[⊙ ENTER]**.
 - When timer programming a DTV channel in the recording mode other than TS, the programme will be recorded in TS mode first, then it will be converted to the selected recording mode after the unit is turned off.
 - When timer programming a DTV channel in the recording mode other than TS, “Remain” in the timer programming screen still shows the remaining time based on TS mode recording.
 - When timer programming a DTV channel to a BD-RE / BD-R disc, only TS mode is available.
7. Press **[∨]** to move to “OK”, then press **[⊙ ENTER]**.
 - **If timer programmes overlap, refer to “When timer programmes overlap” on page 38.**
 - **To programme another timer recording, repeat steps 2 to 7.**
8. Press **[↶ BACK]** to finish.

Dual Recording

This unit can record 2 DTV programmes or record 1 DTV programme and another recording from an external device simultaneously.

>> Preparation

- Start recording the first programme.

1. Start recording another programme.

- To record a programme currently being viewed (Refer to “Recording a Programme Currently On Air” on page 33.)
- To programme a timer recording from the programme guide (Refer to “Programming a Timer Recording from “Programme Guide”” on page 34.)
- To manually programme a timer recording (Refer to “Manual Timer Programming” on page 35.)
- **To pause a dual recording**
Refer to “To pause recording (for HDD / USB-HDD only)” in “Recording a Programme Currently On Air” on page 33.
- **To pause the recording during chase play or simultaneous rec/play, press [■] to stop playback beforehand.**
- **To stop a dual recording**
Refer to “To stop recording” in “Recording a Programme Currently On Air” on page 33.
- **To stop the recording during chase play or simultaneous rec/play, press [■] to stop playback beforehand.**

◆ Possible dual recording on this unit

- **When recording both to **HDD****
 - DTV → **HDD**
 - DTV or external input → **HDD**
- **When recording to **HDD** and **USB-HDD****
 - DTV or external input → **HDD**
 - DTV → **USB-HDD**
- **When recording to **HDD** and **BD-RE** **BD-R****
 - DTV or external input → **HDD**
 - DTV or external input → **BD-RE** **BD-R**
- **When recording to **USB-HDD** and **BD-RE** **BD-R****
 - DTV → **USB-HDD**
 - DTV or external input → **BD-RE** **BD-R**
- This unit cannot record from an external device to a USB-HDD or to the HDD and a BDAV disc simultaneously.
- For DTV programme recording, the recording mode is TS only. The titles recorded in TS mode, however, can be converted to AF / AN / AE, XP / SP / LP / EP mode after this unit is turned off.
- Dual recording cannot be performed to a USB-HDD.
- This unit can record 2 DTV programmes or 1 DTV programme and content from the external input (AV) simultaneously.
- Dual recording from the external input (AV) is not possible.
- During high-speed dubbing for HDD > BD-RE / BD-R, this unit can perform a dual recording to the HDD/USB-HDD other than the dubbing.

! Note

- During dual recording, channels other than the recording channels cannot be viewed.

Recording from an External Device

To record from an external device connected to this unit, switch this unit to the external input (AV). For how to operate the external device, please refer to the user manual of the device.

To record a cable-TV programme

>> Preparation

- Connect the cable-TV's home terminal / set-top box.
- Complete "External Input Audio" setting.
- Switch the cable-TV's home terminal / set-top box to the desired channel.

1. Switch this unit to the external input. (Refer to "Viewing from an External Device" on page 23.)
2. Start recording.
 - Refer to page 33 for how to record.
 - Refer to page 35 for how to programme a timer recording.


! Note

- Please turn on the home terminal / set-top box before a timer recording starts.
- During a dual recording, you can only view the currently recorded channels on this unit.

Confirming / Modifying / Cancelling Timer Programmes, Stopping a Timer Recording

Confirming timer programmes

1. Press [TIMER REC.] to call up "Timer Programming" screen. (Refer to "Guide to the "Timer Programming" screen" on page 34.)




- To move to next page Press [RED] / [GREEN].
- For the timer programmes set from the programme guide, select a programme, then press [ENTER] or [SUB MENU]. In the sub menu, select "Information" to confirm the programme.

2. Press [BACK] to finish.

Skipping weekly / daily timer recording temporarily

1. Press [TIMER REC.] to call up "Timer Programming" screen.
2. Use [^/∨] to select a programme you wish to skip temporarily, then press [SUB MENU].
3. Use [^/∨] to select "Skip", then press [ENTER].



- "Skip" will appear. Next recording of this programme will be skipped.
- To cancel skip setting, proceed to steps 2 and 3 to cancel it.

4. Press [BACK] to finish.


! Note

- Skip setting will be effective one time only. Once a programme is skipped, the skip setting will be cancelled.

Modifying a timer programme

◆ Modifying a timer programme from “Timer Programming”

1. Press **[TIMER REC.]** to call up “Timer Programming” screen.
2. Use **[^/∨]** to select a timer programme to modify, then press **[SUB MENU]**.
3. Use **[^/∨]** to select “Programme Change”, then press **[⊙ ENTER]**.
4. Use **[</>]** to move to the item, then modify it using **[^/∨]**.



5. Use **[>/^]** to move to “Mode”, then press **[⊙ ENTER]**.
6. Use **[^/∨]** to select the desired recording mode, then press **[⊙ ENTER]**.
7. Use **[^/∨]** to select “OK”, then press **[⊙ ENTER]**.
 - If timer programmes overlap, refer to “When timer programmes overlap” on page 38.
8. Press **[↵ BACK]** to finish.

◆ Modifying a timer programme from “Programme Guide”

1. Press **[GUIDE]** to call up the programme guide screen (Refer to “Guide to the “Programme Guide” screen” on page 19.)
2. Use **[^/∨/⟨/⟩]** to select the timer programme to modify, then press **[⊙ ENTER]**.
3. Use **[^/∨]** to select “Programme Change”, then press **[⊙ ENTER]**.
4. Modify the timer programme.
5. Press **[>]**, then use **[^/∨]** to select “OK”, then press **[⊙ ENTER]**.
6. Press **[↵ BACK]** to finish.

⚠ Note

For timer recording in progress...

- For manual timer programme, only the end time can be modified.

Cancel an unnecessary timer programme

◆ Cancelling a timer programme set from the programme guide

- Cancellation will be one-by-one.
1. Press **[GUIDE]** to call up the programme guide screen. (Refer to “Guide to the “Programme Guide” screen” on page 19.)
 2. Use **[^/∨/⟨/⟩]** to select a timer programme to cancel, then press **[⊙ ENTER]**.
 3. Use **[^/∨]** to select “Delete”, then press **[⊙ ENTER]**.
 - A confirmation message will appear. Use **[^/∨]** to select “Yes”, then press **[⊙ ENTER]**.
 4. Press **[↵ BACK]** to finish.

◆ Cancelling a timer programme from the “Timer Programming” screen

1. To cancel one timer programme

- 1) Press [TIMER REC.] to call up the “Timer Programming” screen.
- 2) Use [^/∨] to select the timer programme to cancel, then press [SUB MENU].
- 3) Use [^/∨] to select “Delete”, then press [⊙ ENTER].

To cancel multiple timer programmes

- 4) Press [TIMER REC.] to call up the “Timer Programming” screen.
 - 5) Press [SUB MENU] to call up the sub menu.
 - 6) Use [^/∨] to select “Delete multi prog.”, then press [⊙ ENTER].
 - 7) Use [^/∨] to select the timer programmes to cancel, then press [⊙ ENTER].
 - “✓” will be displayed next to the selected timer programmes.
 - 8) Press [>] to select “OK”, then press [⊙ ENTER].
2. Use [^/∨] to select “Yes” in the confirmation message window, then press [⊙ ENTER].
3. Press [↩ BACK] to finish.

Stopping the timer recording in process

1. If chase play or simultaneous rec/play is being performed, press [■] to stop it beforehand.
2. Press [■] to stop the recording.
3. Use [^/∨] to select “Yes” in the confirmation message window, then press [⊙ ENTER].
 - The recording (from the beginning to where it was stopped) will be one title. (It may take a moment to accept next operation.)
 - **To stop a dual recording**
Switch to the recording channel, then press [■].

Additional Information about Recording

Overall recording

- Recording will automatically stop in case the HDD / disc becomes full.

Overall timer recording

◆ When a timer recording is set

- “⊙” appears on the display of the unit.

Right before the timer recording

- If the unit is powered off, it will automatically be turned on 2 minutes before a timer recording starts.

After a timer recording

- The recording will automatically stop.

Alternate recording

When a timer recording cannot be performed for the following reasons, the unit will record to the HDD (if possible), then notify on the “Timer Programming” screen.

- If the disc is not recordable or there is no disc in the unit.
- If the BD-RE/-R disc or the USB-HDD does not have enough capacity for the recording.
- If a recordable USB-HDD is not connected to the unit.

When a normal recording / instant timer recording / dubbing and a timer recording overlap

In the following cases, a normal recording / instant timer recording will be cancelled 2 minutes before the timer recording.

- When a dual recording is already being performed
- When a dual recording cannot be performed

For normal-speed dubbing, it will be cancelled 2 minutes before a timer recording starts.

When timer programmes overlap

◆ A confirmation message will be displayed when the last timer recording is set.


- Confirm the message, then press [⊙ ENTER]. “Timer Programming” screen will be displayed. If there is a programme which will not be recorded or partially recorded due to overlapping, “△” will appear and the programme will be shown in light blue.

◆ To confirm overlapping timer recordings


- Press [TIMER REC.] to call up “Timer Programming” screen. If there is a programme which will not be recorded or partially recorded due to overlapping, “△” will appear and the programme will be shown in light blue.

◆ When more than 3 timer recordings overlap


- If the entire programme or part of the programme overlaps, the programme of the later schedule will preferentially be recorded.



- When 2 timer recordings will start at the same time, the timer recording located lowest in the "Timer Programming" screen will preferentially be recorded.



- If the end time of a timer recording and the start time of next timer recording are exactly the same time, the last 15 seconds (approx.) of the earlier recording will be cut.



* (for about 15 seconds) will not be recorded.

◆ When more than 2 timer recordings overlap in the condition that a dual recording is not possible (Refer to page 35)

- The latter timer recording will be given priority.
- If the start time of both timer programmes are the same, the timer programme listed lower in the "Timer Programming" list will be given priority.
- In the earlier recording, the last 15 seconds before the latter recording overlaps will be cut (including the case that the end time of the earlier recording and the start time of the latter recording are exactly the same time).

When a power outage occurs

◆ Overall

- When recovered from a power outage, this unit will automatically be turned on and perform the system configuration. During system configuration, "WAIT" will be displayed on the display panel.
- If a timer recording is interrupted due to a power outage, a notification message will appear in the "Timer Programming" screen.

◆ By type of recording

If a power outage occurs during normal recording (by pressing [● REC.] while viewing a DTV programme)

- Recording will be terminated.
- This unit will automatically be turned off after system configuration.

If a power outage occurs before a timer recording.

- After recovering from a power outage, the clock will be readjusted. Timer programmes will remain.

If a power outage occurs while a timer recording is in progress.

- Recording will be terminated at the time of power outage.
- If recovering from the power outage before the end time of the timer recording, this unit will resume recording to the end time, after system configuration.
- If recovering from the power outage after the end time of the timer recording, the recording will be terminated at the time of power outage. This unit will automatically be turned off after system configuration.

◆ By type of recording media

For HDD / USB-HDD

- The recording title will be split into 2 pieces (before and after power outage) and listed in the "Contents List" screen.
- A small part of the recording right before a power outage may be lost.
- The entire recording before a power outage may be lost according to the circumstances of power outage.
- There are cases that you need to initialise the HDD / USB-HDD according to the circumstances of power outage.
- If a power outage occurs during a timer recording to the USB-HDD, depending on the USB-HDD, this unit may resume recording to the internal HDD.

For BD-RE / BD-R discs

- The disc may become no longer usable according to the circumstances of power outage.
- If there is a timer recording right after recovering from the power outage and this unit cannot record to the disc for some reason, the timer recording will be performed to the HDD. This recording will be listed in the "Contents List" for HDD.

When a timer recording fails

- "⓪" appears on the failed timer programme in "Timer Programming" screen, and the programme is shown in grey. If selecting the programme then press [⓪ ENTER], information will be displayed. Selecting "Return" will bring you back to "Timer Programming" screen. Selecting "Delete message" will delete the programme from the "Timer Programming" screen.

Before Playback

Contents list

HDD **USB-HDD** **BD-RE** **BD-R** **-RW(VR)** **+RW(+VR)** **+R(+VR)**


To view a recorded title, call up the “Contents List” screen, then select the desired title to play back.

“Title” in this owner’s manual refers to a DTV programme recorded on this unit.

◆ To call up the “Contents List” screen

- 1) Press **[HDD]** / **[DISC]** / **[USB]** to select the media to operate.
 - 2) Press **[CONTENTS LIST]**.
- You can also call up the contents list by pressing **[HOME]**, then selecting “Contents List”.
 - **You can return to the DTV screen by pressing [CONTENTS LIST] again.**

Guide to the “Contents List” screen (e.g., HDD)



- **To view a different page, use [RED] / [GREEN] to switch between pages.**
- **If you wish to narrow down the titles by genre or sort...**
 - 1) Press **[SUB MENU]** to call up the sub menu.
 - 2) For disc operation, proceed to 4).
For HDD / USB-HDD operation, select “Genre/Order”, then press **[ENTER]**.
 - 3) To narrow down the titles by genre, use **[^/∨]** to select “Genre”, then press **[ENTER]**.
 - Select the desired genre from the genre list, then press **[ENTER]**.
 - 4) To sort titles, use **[^/∨]** to select “Order”, then press **[ENTER]**.
 - Sort types will be displayed. Select the desired sort type, then press **[ENTER]**. For a disc, sorting will start. For the HDD / USB-HDD, proceed to 5).

Sort type

Recording	Sorts titles in the order of recording date. (For discs, in the order of title number.)
Name	Sorts titles in alphabetical order.
New	Sorts titles in the order from new to old. (If the recording date is unknown, the title will appear at the end of the list.)
Old	Sorts titles in the order from old to new. (If the recording date is unknown, the title will appear at the end of the list.)

- 5) Use **[^/∨]** to select “OK”, then press **[ENTER]**.

! Note

- In disc mode, narrowing down by genre is not available.
- This unit cannot play back AVCHD files directly from a USB device.

Resume point

- The resume point will be saved by pressing **[STOP]** during playback.
- To remove the resume point, press **[STOP]** again in stop mode.

HDD **USB-HDD**

Only one resume point can be saved per title.

[▶] / [ENTER]	Restarts playback from the resume point.
[SUB MENU]	Allows you to select “Resume Playback” / “Play From Start”.

BD-RE **BD-R** **-RW(VR)** **+RW(+VR)** **+R(+VR)**

Only one resume point can be saved per disc.

[▶] / [ENTER]	Resumes playback only when you select the title which you last played. Otherwise, playback will start from the beginning of the title.
[SUB MENU]	Only “Play From Start” is available.

Audio CD **DISC(DiVX®)**

Only one resume point can be saved per disc.

[▶]	Resumes playback only when you select the track which you last played. Otherwise, playback will start from the beginning of the track.
[ENTER]	Resumes playback from the beginning of the track.
[SUB MENU]	Not available

HDD **USB-HDD** **BD-RE** **BD-R** **BD-Video** **-RW(VR)** **+RW(+VR)**
+R(+VR) **DVD-Video** **Audio CD** **DISC(JPEG)** **DISC(DiVX®)**

Pressing **[▶]** without calling up the “Contents List” screen will resume playback from the resume point of the title / track where it was last played.

! Note

- Resume playback may not function with some discs.
- In the following cases, the resume point will be lost.**
- When **[STOP]** is pressed in stop mode (For HDD, the currently selected title will lose the resume point.)
 - When deleting the title / editing the title or disc (The resume point in the undeleted / unedited title will be lost as well.)
 - When formatting
 - After recording, the resume point will be saved in the recorded title. (The resume point per title on the HDD will remain.)

For discs only

- When opening the disc tray
- When finalising the disc

Playing Back a Programme (Title)

HDD **USB-HDD** **BD-RE** **BD-R** **-RW(VR)** **+RW(+VR)** **+R(+VR)**

This unit can play back titles recorded on the HDD / disc, and AVCHD contents dubbed from USB devices.


>> Preparation

- When playing back from a USB-HDD, connect it to the unit
- When playing back a disc, place it in the unit.
- Press **[HDD]** / **[DISC]** / **[USB]** accordingly.

1. Press **[CONTENTS LIST]** to call up the "Contents List" screen.

- When you place an Audio CD in the unit, the "Contents List" screen will automatically be displayed.

2. Use **[^/∨]** to select the desired title.



3. Press **[▶]** or **[⊙ ENTER]** to start playback.

- For the HDD / USB-HDD, you can choose where to start playback from the sub menu. Refer to "Resume point" on page 40.

To stop playback

Press **[■]**. (Resume point will be saved.)

- If the password entry screen appears when playing back a disc, refer to "◆ Configuring "BD Rating Level" / "DVD Rating Level"" on page 66.
- If the PIN Code entry screen appears, refer to "PIN Code entry screen" on page 46.

! Note

- DVD's which are dubbed on this unit and finalised on other recorders are playable on this unit.

Playing Back a Commercially Available Disc

>> Preparation

- Press **[DISC]**.

! Note

- It may take extra time to read some discs.

Playing back a Blu-ray Disc™ / DVD

BD-Video **DVD-Video**

1. Place a disc in the unit.

- Some discs automatically start playback.
- If the disc menu appears, follow the instructions on screen.

2. Press **[▶]** to start playback.

◆ Operations from the disc menu or pop-up menu*

* Only when it is available on the disc.

Various operations are available on the disc menu. For BD-Video, various operations can be performed during playback. Please refer to the disc instructions on how to operate the contents of the disc menu / pop-up menu vary on the disc. Below is a general example.

[DISC MENU]	Used to call up the selection screen for the disc menu. Use [^/∨] to select the desired menu.
[CONTENTS LIST]	Used to call up the top menu of the disc.
[^/∨/⟨/⟩]	Used to select and confirm a menu item.
[⊙ ENTER]	Used to select and confirm a menu item.

! Note

- When connecting this BD unit and a TV using Video / Audio cables, you cannot watch a Blu-ray disc. Please connect this unit through an HDMI cable to the TV, then playback the Blu-ray disc.

Playing an Audio CD

Audio CD

1. Place an Audio CD in the unit.

- Track list will appear.
- Press **[CONTENTS LIST]** to call up the track list when a disc is already in the unit.

2. Use **[^/∨]** to select the desired track, then press **[▶]** or **[⊙ ENTER]**.

- To stop playing, press **[■]**. (Resume point will be saved.)

Playing back a Blu-ray 3D™ disc

BD-Video

>> Preparation

- Connect this unit and a 3D compatible TV with a High-Speed HDMI cable.
- On the 3D TV, activate the 3D mode (if necessary).
- Press **[DISC]**.

1. Place a Blu-ray 3D™ disc in the unit.

2. Press **[▶]**.

- To change the 3D setting on this unit "Home Menu" > "Settings" > "3D settings", then change further settings.
- To play back in the 2D mode "Home Menu" > "Settings" > "3D settings" > "3D Playback", then change "Auto(3D)" to "2D".

Playing back a media containing MP3 / WMA / DivX® / JPEG Files

DivX® MP3 WMA JPEG

>> Preparation

- When playing back from a disc, place it in the unit.
- Press **[DISC]**.

1. Press **[CONTENTS LIST]** to call up the contents list.
 - When playing back from a USB device, connect it to the unit, then go to “Home Menu” > “Contents List”, then select “USB”.
2. Select the desired file using **[^/~/</>]**, then press **[⊙ ENTER]**.

Playable file types and file extensions

- “.mp3” (MP3)
- “.wma” (WMA)
- “.divx” (DivX®)
- “.avi” (DivX®)
- “.mkv”
- “.jpg” (JPEG)
- “.jpeg” (JPEG)

Recommended spec for DivX® / MKV files


Item	Support
Playable Codec of DivX® (AVI) files	DivX® 3.x / 4.x / 5.x / 6.x
Playable Codec of MKV files	MPEG2 / MPEG4-AVC (H.264)
Maximum size of image	1,920 x 1,080
VBV maximum bit rate	20,000 kbps
Sampling frequency of audio	16 kHz - 48 kHz
Playable Audio type of DivX® (AVI) files	MPEG1 audio layer 3 (MP3) / MPEG1 audio layer 2 / Dolby Digital
Playable Audio type of MKV files	MPEG1 audio layer 3 (MP3) / Dolby Digital / MPEG BC / PCM / AAC
Playable Subtitle file extensions	.ass / .smi / .srt / .ssa / .sub* / .txt* *.sub and .txt files may not be recognised.

◆ Playing back a DivX® file with an external subtitle file

DivX®

Subtitles created by the user can be displayed during DivX® playback.

- Make sure that the appropriate language is selected in the “DivX Subtitle Language” in the setup menu in order to avoid character corruption. (Refer to page 62.)
1. In step 2 above, highlight the desired file to play back, then press **[YELLOW]**.
 - List of extensions of the subtitle files will appear.
 2. Select the desired extension, then press **[⊙ ENTER]**.



- DivX® with the subtitle will start playing back automatically.

! Note for USB device

- This unit cannot read files from a USB device in the following conditions.
 - When the disc tray is in motion
 - During disc load, HDD / disc recording, HDD / disc playback, editing or dubbing
 - While the title list or file list of disc is displayed
 - While the “Settings” / “Timer Programming” / “Programme Guide” screen is displayed
- Do not disconnect the USB device while the indicator on the device is flickering.

! Note for MP3 / WMA

- To stop playback, press **[■]** while playing.
- For MP3 / WMA files recorded in VBR (Variable Bit Rate), the unit may not display the actual elapsed time.

! Note for DivX® subtitle

- Playback file and the subtitle file must have the same name.
- Playback file and the subtitle file must locate in the same folder. (DivX® subtitle files are, however, not displayed in the list.)
- The subtitles that exceed the playback time will not be displayed.

Various Playback Functions

>> Preparation

- When playing back from a USB-HDD, connect it to the unit.
- When playing back a disc, place it in the unit.
- When playing back from a USB device, connect it to the unit.
- Press **[HDD]** / **[DISC]** / **[USB]** accordingly.

Change the playback speed

- Sound will be muted except for certain materials.

◆ Fast forward / fast reverse playback

HDD USB-HDD BD-RE BD-R BD-Video -RW -R(Video)
+RW(+VR) +R(+VR) DVD-Video DVD(AVCHD) Audio CD
DivX® MP3 WMA

During playback, press **[◀◀]** / **[▶▶]**.

- Each time you press of **[◀◀]** / **[▶▶]**, the speed increases up to 5 steps. (3 steps for Audio CD's / MP3 / WMA / DivX® files.)
- For Audio CD's / MP3 / WMA files, the sound is just about recognisable where it is playing.
- Press **[▶]** to return to normal playback.

◆ Fast forward playback with audio

HDD USB-HDD BD-RE BD-R BD-Video -RW -R(Video)
+RW(+VR) +R(+VR) DVD-Video DVD(AVCHD) DivX®

During playback, press **[▶▶]**.

- By one press of **[▶▶]**, the speed increases 1.3 x.
- Press **[▶]** to return to normal playback.

◆ Pause

HDD USB-HDD BD-RE BD-R BD-Video -RW -R(Video)
+RW(+VR) +R(+VR) DVD-Video DVD(AVCHD) Audio CD
DivX® MP3 WMA JPEG

During playback, press **[||]**.

- Press **[▶]** to resume playback.

◆ **Slow forward / slow reverse playback**

HDD USB-HDD BD-RE BD-R BD-Video -RW -R(Video)
 +RW(+VR) +R(+VR) DVD-Video DVD(AVCHD) DivX®

During pause, press [◀◀] / [▶▶].

- Each time you press [◀◀] / [▶▶], the speed increases up to 3 steps.
- Press [▶] to resume playback.
- Press [⏸] to pause playback.
- You can fast forward / fast reverse by pressing and holding [◀◀] / [▶▶].

◆ **Frame by frame playback**

HDD USB-HDD BD-RE BD-R BD-Video -RW -R(Video)
 +RW(+VR) +R(+VR) DVD-Video DVD(AVCHD) DivX®

- During playback, press [⏸], then press [⏮] / [⏭].

⚠ **Note**

- For the following media / files, slow reverse / frame by frame (reverse) are not available.
 - BD-Video / DVD-Video / DVD-RW(AVCHD) / DVD-R(AVCHD) / DVD+RW(AVCHD) / DVD+R(AVCHD) / DivX®
- For the following titles / recordings, the slow reverse playback speeds are up to 2 steps.
 - Titles / recordings recorded in the AF / AN / AE mode or MPEG-4 AVC/H.264 format.
- Fast forward playback with audio is not available when playing back a BD-Video disc in 3D. During fast forward / fast reverse, the images are displayed in 2D.

Skipping forward / backward

◆ **Skipping to the desired point**

HDD USB-HDD BD-RE BD-R BD-Video -RW -R(Video)
 +RW(+VR) +R(+VR) DVD-Video DVD(AVCHD) Audio CD
 DivX® MP3 WMA JPEG

Press [⏮] / [⏭] during playback.

- Every press of [⏮] / [⏭] will skip the current chapter / track.
- Single press of [⏮] will skip backward to the beginning of the current chapter.

◆ **Instant skip / Instant replay**

HDD USB-HDD BD-RE BD-R BD-Video -RW -R(Video)
 +RW(+VR) +R(+VR) DVD-Video DVD(AVCHD)


During playback, press [⏮ I.REPLAY] / [I.SKIP ▶].

- Every press of [⏮ I.REPLAY] / [I.SKIP ▶] skips / replays based on the setting in "Playback". (up to 10 presses at a time)

◆ **Search**

HDD USB-HDD BD-RE BD-R BD-Video -RW -R(Video)
 +RW(+VR) +R(+VR) DVD-Video DVD(AVCHD) Audio CD
 DivX® MP3 WMA JPEG

1. During playback, press [SUB MENU] to call up the play menu, then select "Search" using [^/∨], then press [⊙ ENTER].



2. Use [^/∨] to select the desired search option.

- Every press of [^/∨] shifts the search option.
- Available search options differ depending on the media / file being played back.

Playback media / file	Search options
HDD USB-HDD	Time search → Chapter search → Time search → ...
BD-RE BD-R BD-Video -RW -R(Video) +RW(+VR) +R(+VR) DVD-Video DVD(AVCHD)	Time search → Title search → Chapter search → Time search → ...
Audio CD DivX®	Time search → Track search → Time search → ...
MP3 WMA JPEG	Track search only


3. Press [>] to move to highlight the value (chapter number, track number, etc.) you wish to enter, then enter your desired value using [^/∨] or [number buttons], then press [⊙ ENTER].

- If you enter the wrong value, press [<].

Repeat playback

HDD USB-HDD BD-RE BD-R BD-Video -RW -R(Video)
 +RW(+VR) +R(+VR) DVD-Video DVD(AVCHD) Audio CD
 DivX® MP3 WMA JPEG

1. During playback, press [SUB MENU] to call up the play menu, then select "Repeat" using [^/∨], then press [⊙ ENTER].



2. Use [^/∨] to select the desired repeat playback option.

- Available repeat playback options differ depending on the media being played back.

Playback media / file			Repeat playback options
HDD	USB-HDD	BD-Video	Off → Chapter repeat → Title repeat → Off → ...
-RW(Video)	-R(Video)	+RW(+VR)	
+R(+VR)	DVD-Video	DVD(AVCHD)	
BD-RE	BD-R	-RW(VR)	Off → Chapter repeat → Title repeat → All → Off → ...
Audio CD	DivX®	MP3	Off → Track repeat → All → Off → ...
WMA	JPEG		

- To stop repeat playback, select "Off" in step 2.
- To completely stop playback, press [■].

! Note

- The repeat setting will be cancelled if an additional operation shown below goes beyond the current repeat range.
 - Skip - Chapter / Title / Track /Time search
 - Instant skip - Instant replay

Playing back a playlist created on another device

BD-RE BD-R -RW(VR)

1. While the "Contents List" screen is displayed, press [SUB MENU] to call up the sub menu, select "Playlist" using [^/∨], then press [⊙ ENTER].
- This unit cannot create or edit a playlist.

Chase play during recording

HDD USB-HDD

You can start playback from the beginning of the title during recording.

1. Press [HDD] / [USB] to switch to the recording media.
2. Press [CONTENTS LIST] to call up the "Contents List" screen.
3. Use [^/∨] to select the title which is being recorded with the icon (REC1) / (REC2).
4. Press [▶] for chase play.
 - **To stop chase play**
Press [■]. This will stop playback, but the recording is going on.
 - **To stop the recording**
Press [■], then select "Yes" at the confirmation message, then press [⊙ ENTER].

! Note

- If fast forward is performed during chase play, then chase play catches up to the ongoing recording, chase play will switch to normal playback. (The recording will keep going.)
- If the operation media (HDD / DISC / USB) is switched to another during chase play, playback will stop.

Switching Settings During Playback

>> Preparation

- To play back from a USB-HDD, connect it to the unit.
- To play back a disc, place it in the unit.
- Press [HDD] / [DISC] / [USB] accordingly.
- If the password entry screen appears when playing back a disc, refer to "◆ Configuring "BD Rating Level" / "DVD Rating Level"" on page 66.

Switching the audio language / subtitle language / camera angle

- If the password entry screen appears when playing back a disc, refer to "◆ Configuring "BD Rating Level" / "DVD Rating Level"" on page 66.

◆ Switching the audio language

HDD USB-HDD BD-RE BD-R BD-Video -RW -R(Video) +RW(+VR) +R(+VR) DVD-Video DVD(AVCHD) DivX®

You can switch the audio if the programme has multiple audio streams (Main / Sub).

1. Press [AUDIO] to call up the audio information.
 - You can also call up the audio information by pressing [SUB MENU], then selecting "Audio 1".
2. Selecting the desired audio stream.

HDD USB-HDD BD-RE BD-R -RW -R(Video) +RW(+VR) +R(+VR) DVD-Video DVD(AVCHD)


- Use [^/∨] to switch the audio.
 - When the selected audio is in stereo, and item selection appears to the right, you can switch "Stereo" > "Right" > "Left" using [^/∨].
 - When the selected audio has the main audio / sub audio, and item selection appears to the right, you can switch "Main/Sub" > "Main" > "Sub" using [^/∨].
- BD-Video
- Use [^/∨] to select "Primary" or "Secondary", then press [⊙ ENTER] to move to the audio selection area, then switch the audio using [^/∨].
 - When "Video/Audio" > "BD Audio Mode" is set to "HD Audio Output", the secondary audio will not be output.

◆ Switching the subtitles

HDD USB-HDD BD-RE BD-R -RW -R(Video) +RW(+VR) +R(+VR) DVD-Video DVD(AVCHD) DivX®

When the title has multiple subtitles, you can select a desired subtitle and set it on / off. (This function is available for the titles recorded on this unit in recording mode of TS.)

1. Press [SUBTITLE] to call up the subtitle information.
 - You can also call up the subtitle information by pressing [SUB MENU], then selecting "Subtitle".



- Use [^/∨] to select your desired subtitles.

◆ Switching the subtitles on BD-Video

BD-Video

For BD-Video, you can set the subtitles and subtitle style for each of the primary video / secondary video if available.


- During playback, press [SUB MENU] to call up the play menu, then select “Subtitle” using [^/∨], then press [⊙ ENTER].
- Select “Primary” / “Secondary” / “Style” using [^/∨], then press [⊙ ENTER] to move to the subtitle selecting area, then switch the subtitles using [^/∨].

◆ Switching the camera angles

BD-Video DVD-Video

When the title has multiple camera angles, you can view another angle of the scene during playback.

- During playback, press [SUB MENU] to call up the play menu, then select “Angle” using [^/∨], then press [⊙ ENTER].



- Use [^/∨] to select your desired angle.

! Note

- When another angle is available, “” will be displayed. (You can turn off the icon. Refer to page 62.)
- For BD / DVD-Video, please refer to the instructions of the disc for audio / subtitles / camera angle.

Noise reduction

HDD USB-HDD BD-RE BD-R BD-Video -RW -R(Video)
+RW(+VR) +R(+VR) DVD-Video DVD(AVCHD) DivX®

- During playback, press [SUB MENU] to call up the play menu, then select “Noise Reduction” using [^/∨], then press [⊙ ENTER].
- Use [^/∨] to select your desired setting.



Super resolution

HDD USB-HDD BD-RE BD-R BD-Video -RW -R(Video)
+RW(+VR) +R(+VR) DVD-Video DVD(AVCHD) DivX®

Super Resolution enhances SD quality images output in 1080i / 1080p from the HDMI jack, which gives crisper images.

- During playback, press [SUB MENU] to call up the play menu, then select “Super Resolution” using [^/∨], then press [⊙ ENTER].
- Use [^/∨] to select your desired setting.




PiP (BONUSVIEW™) setting

BD-Video

BD-Video discs have the PiP feature which enables to display the secondary video within the primary video screen. You can change the PiP setting whenever the scene contains the secondary video.

- Refer to the user manual of the disc for how to activate the secondary video.



- During BD-Video playback, press [SUB MENU] to call up the play menu, then use [^/∨] to select “PiP”, then press [⊙ ENTER].
 - Setting for the secondary video is only available when the primary and the secondary videos are playing simultaneously.
- Use [^/∨] to select the desired setting, then press [⊙ ENTER].



Virtual package

BD-Video

Virtual Package compatible BD-Video discs let you enjoy various functions during playback by using data copied and stored on the local storage device. This unit uses the internal HDD as a local storage device.

- Images / audio may stop during playback.
- To delete Virtual Package data stored on the HDD, press [**HOME**], then select "Settings" > "Others" > "Initialisation" > "Delete BD Video data", then perform "Delete Virtual package".

PIN Code entry screen

BD-RE BD-R

If a PIN Code has been set to the disc on another manufacturer's Blu-ray Disc™ recorder to restrict viewing of the disc, the PIN Code input screen will be displayed. Please enter the PIN Code. (This unit is unable to set or change a PIN Code.)


1. Use [**number buttons**] to enter the PIN Code.

Viewing JPEG Files

JPEG

Playing a slide show

Guide to the "Thumbnail" screen for JPEG files



>> Preparation

- When viewing from a disc, press [**DISC**].
1. Place a disc / connect a USB device which contains JPEG files.
 2. File type selection screen will appear. Use [**^/∨**] to select "Photo" or "View photos.", then press [**ENTER**].
 - The "Thumbnail" screen will be displayed.
 - For discs containing JPEG files only, the thumbnail screen will automatically appear (the file type selection screen will not appear).
 - **If the file type selection screen is not displayed**
 - 1) Press [**HOME**] to call up the home menu.
 - 2) Use [**^/∨/ </ >**] to select "Contents List", then press [**ENTER**].
 - 3) Use [**^/∨**] to select the media that contains JPEG files, then press [**ENTER**].
 - 4) Use [**^/∨**] to select "Photo", then press [**ENTER**].

3. Use [**^/∨/ </ >**] to select the desired file, then press [**ENTER**].
 - **If you wish to view all files in a folder**, use [**^/∨/ </ >**] to select the folder, then press [**ENTER**].
 - **To view a different page**, use [**RED**] / [**GREEN**] to switch between pages.
4. Press [**ENTER**] or [**▶**] to start a slide show.
 - A slide show will display the selected JPEG file followed by the rest of the files in turn.
 - The slide show speed can be set from "Home Menu" > "Settings" > "Playback" > "Slide Show".
 - **To rotate a picture**
During slide show, press [**</ >**]. The picture rotates 90 degrees.
 - **To pause or stop slide show**
Press [**|||**] to pause. (Press [**▶**] or [**|||**] to resume. Press [**■**] to stop the slide show.
 - A slide show from a USB device will not save the resume point.

! Note

- If there is an unrecognizable file, "⊘" will be displayed and the file will be skipped.
- A slide show will automatically stop 2 minutes before a timer recording starts.
- A slide show is not available during recording / dubbing.

Recommended spec

◆ Maximum number of folders / files

CD-RW / -R	255 folders / 999 files
Other media	999 folders / 9,999files

◆ Resolutions

Sub sampling (4:4:4)	32 × 32 - 4,096 × 4,096
Sub sampling (4:2:2 or 4:2:0)	32 × 32 - 5,120 × 5,120

- Each file must be smaller than 12 MB

! Note

- Files with extensions other than JPEG cannot be read.
- Progressive JPEG files are not compatible.
- Motion JPEG files are not compatible.
- Some JPEG files may not be read depending on the file condition.

Playing Back a Disc Containing an AVCHD High-Definition Video

DVD(AVCHD)

This unit can play back AVCHD High-Definition videos on a disc recorded on HD camcorders. (The disc needs to be finalised on said recording camcorder.)

This unit can also play back AVCHD High-Definition videos dubbed to the internal HDD.

>> Preparation

- Press [DISC].

1. Place a disc in the unit.

- If the disc contains an AVCHD video, it will automatically start playing back.
If it does not start, press [▶].
- If the disc menu is displayed, refer to the user manual of the recording device on how to operate. Below is a general example.

2. Use [^/~/</>] to select the desired title/item, then [⊙ ENTER].

- **To stop play back**, press [■]. (Resume point will be saved.)

! Note

- AVCHD videos stored on a USB device cannot be played back directly from the device. In order to play back on this unit, dub the videos to the internal HDD first.

Additional Information about Playback

Overall playback

- For Blu-ray Disc™ / DVD, the picture and audio may stop momentarily as the playback shifts from the first layer to the second layer of the disc.
- When playing back a title recorded in TS mode, the screen may stop or show block noise as the title shifts to another title.
- After finishing playback of a disc, the last image may be paused and left on screen or the disc menu may be displayed. If the same image is displayed over an extended time period, it may cause screen burn-in on a CRT display / plasma TV.
- Depending on the disc, some playback functions, such as resume playback / playback speed change / skipping / language change / angle change / repeat playback and others may be unavailable.
- Playback cannot be performed during finalisation / initialisation.
- This unit outputs a video in the same output format as the disc. For instance, if you place an NTSC format disc, the unit will output the video in NTSC.

Cinavia™

Cinavia Notice

This product uses Cinavia technology to limit the use of unauthorized copies of some commercially-produced film and videos and their soundtracks. When a prohibited use of an unauthorized copy is detected, a message will be displayed and playback or copying will be interrupted. More information about Cinavia technology is provided at the Cinavia Online Consumer Information Center at <http://www.cinavia.com>

To request additional information about Cinavia by mail, send a postcard with your mailing address to: Cinavia Consumer Information Center, P.O. Box 86851, San Diego, CA, 92138, USA. This product incorporates proprietary technology under license from Verance Corporation and is protected by U.S. Patent 7,369,677 and other U.S. and worldwide patents issued and pending as well as copyright and trade secret protection for certain aspects of such technology. Cinavia is a trademark of Verance Corporation. Copyright 2004-2012 Verance Corporation. All rights reserved by Verance. Reverse engineering or disassembly is prohibited.

About "Contents List"

- "Contents List" is not available with finalised DVD-RW / -R (Video) and DVD+RW / +R (+VR) discs. Please play the disc from the disc menu.
- If you call up "Contents List" during repeat playback, the repeat setting will be lost.
- When dubbing a disc authored on another device to this unit's HDD, the channel numbers shown in "Contents List" will be blank unless the disc has the channel information on it.

About audio / subtitles / camera angle switch

Audio / subtitle

- Some video discs let you switch audio / subtitles from the disc menu.
- When switching audio, the image may stop or the screen may go black momentarily.
- If this unit is turned off or the disc tray is opened, the setting will be restored to how they are set in "Settings" > "Language" > "Audio Language" / "Subtitle Language". (For some video discs, the setting will be restored to the disc's default setting.)
- When switching the subtitles, it may take a while to become effective.
- For BD-Video / DVD-Video, the subtitles during fast-forward / fast-reverse playback is not available except in 1.3 x playback mode.

Camera angle

- When switching the camera angle, it may take a while to become effective.
- If the disc tray is opened, the setting will be restored to "1".

Before Editing

Available editing functions

Editing items	HDD	USB-HDD	BD-R		+R	-R(Video)
			BD-RE	-RW(VR)	+RW	-RW(Video)
"Title Delete": To delete one title	✓	✓	✓	✓	✓	—
"Delete Multiple Titles": To delete multiple titles at one time	✓	✓	✓	✓	✓	—
"Delete All Titles": To delete all titles on the media	✓	✓	—	—	—	—
"Delete All Unprotected Titles": To delete all titles except protected titles	✓	✓	—	—	—	—
"Scene Delete": To delete parts of a title	✓	✓	—	—	—	—
"Edit Title Name": To rename the title	✓	✓	✓	✓	✓	—
"Add" / "Delete": To add / delete chapter marks	✓	✓	✓	✓	✓	—
"Hide Chapter": To set chapters to skip during playback	—	—	—	—	✓	—
"Title Dividing": To divide a title	✓ ^{*1}	✓ ^{*1}	—	—	✓ RW only	—
"Protect On→Off" / "Protect Off→On": To set the title protection "On" / "Off"	✓ ^{*1}	✓ ^{*1}	✓	✓	—	—
"Edit Disc Name": To rename the disc name	—	—	✓	✓	✓	✓ ^{*4}
"Edit USB-HDD Name": To rename the USB-HDD	—	✓	—	—	—	—
"Disc Protect On→Off" / "Disc Protect Off→On": To set the disc protection "On" / "On"	—	—	✓	✓	✓	—
"USB-HDD Protect On→Off" / "USB-HDD Protect Off→On": To set the USB-HDD protection "On" / "Off"	—	✓ ^{*1}	—	—	—	—
"Format": To format a disc	—	—	✓ RE only	✓	✓ RW only	✓ RW only
"Finalise": To finalise a disc	—	—	✓ R only	✓ ^{*2}	✓	✓ ^{*3}

✓ : Available

— : Not available

^{*1} For a title scheduled to convert to a different recording mode, editing for the title is not available.

^{*2} This unit can undo finalisation only on DVD-RW(VR) discs which were finalised on this unit.

^{*3} The disc will automatically be finalised after dubbing is completed.

^{*4} You can rename the disc when dubbing.

! Note

- When the title or the disc is protected, editing shown above cannot be performed during dubbing.
- During recording, only the following editing can be performed.
 - While recording to the HDD: One-title deletion / multiple-titles deletion on HDD / USB-HDD / BDAV / DVD-RW / DVD+RW / DVD+R
 - While recording to BDAV: One-title deletion / multiple-titles deletion on HDD / USB-HDD
 - While recording to a USB-HDD: One-title deletion / multiple-titles deletion on HDD / BDAV / USB-HDD / DVD-RW / DVD+RW / DVD+R
- On some BD-R discs, editing functions may not work properly.

Guide to the edit menu screen

>> Preparation

- When editing on a USB-HDD, connect it to the unit.
- When editing on a disc, place it in the unit.
- Press **[HDD]** / **[DISC]** / **[USB]** accordingly.

◆ Common operation for editing

1. Press **[CONTENTS LIST]** to call up the "Contents List" screen.
2. Use **[^/∨]** to select the title to edit, then press **[SUB MENU]**.
3. Use **[^/∨]** to select "Edit", then press **[⊙ ENTER]**.

Adding / Deleting a Chapter Mark


HDD USB-HDD BD-RE BD-R -RW(VR) +RW(+VR) +R(+VR)

Adding a chapter mark

1. Follow steps 1 to 3 in “◆ Common operation for editing” on page 48.
2. [**^**/**v**] to select “Chapter Mark”, then press [**⊙ ENTER**].
3. “Add” is highlighted. Press [**⊙ ENTER**].
4. Forward until you reach the point where you wish to add a chapter mark, then press [**⊙ ENTER**].
 - [**▶**] / [**⏪**] / [**▶▶**] / [**⏩**] / [**▶▶▶**] / [**⏮**] / [**▶▶▶**] / [**⏭**] are available to play back.
5. A confirmation message will appear. Use [**^**/**v**] to select “Yes”, then press [**⊙ ENTER**].

Deleting a chapter mark

1. Follow steps 1 to 3 in “◆ Common operation for editing” on page 48.
2. Use [**^**/**v**] to select “Chapter Mark”, then press [**⊙ ENTER**].
3. Use [**^**/**v**] to select “Delete”, then press [**⊙ ENTER**].
4. Play back the chapter which you wish to delete, then press [**⊙ ENTER**].



- If this chapter is to be deleted, press [**⊙ ENTER**] while this part is playing back.
 - [**▶**] / [**⏪**] / [**▶▶**] / [**⏩**] / [**▶▶▶**] / [**⏮**] / [**▶▶▶**] / [**⏭**] are available to play back.
5. A confirmation message will appear. Use [**^**/**v**] to select “Yes”, then press [**⊙ ENTER**].

Hiding chapters

+RW(+VR) +R(+VR)

1. Follow steps 1 to 3 in “◆ Common operation for editing” on page 48.
2. Use [**^**/**v**] to select “Hide Chapter”, then press [**⊙ ENTER**].

3. During the visible chapter playback (“Visible” appears on the preview screen), use [**^**/**v**] to select “Hidden”, then press [**⊙ ENTER**].
 - The chapter will be hidden.
 - [**▶**] / [**⏪**] / [**▶▶**] / [**⏩**] / [**▶▶▶**] / [**⏮**] / [**▶▶▶**] / [**⏭**] are available to play back.
 - You can make a hidden chapter visible again by selecting “Visible” during hidden chapter playback.

Changing a Title Name / Protecting a Title


Guide to editing a title name

◆ Available characters

Button	Roman character / Symbol	Number
[0]	Space	0
[1]	32 symbols ^{*1}	1
[2]	ABCabc	2
[3]	DEFdef	3
[4]	GHIghi	4
[5]	JKLjkl	5
[6]	MNOmno	6
[7]	PQRSpqrs	7
[8]	TUVtuv	8
[9]	WXYZwxyz	9
[RED]	Switch to Number	Switch to Roman character / Symbol
[GREEN]	—	—
[YELLOW]	—	—
[BLUE]	Delete	Delete

^{*1} Every press of [1] changes the character in the following order.
+ - = ` ^ ` ` | \ \$. , () < > [] { } / _ @ ~ : ; ! ? % & # *

1. Select the desired character set.



- You can switch the character set (“ABC” / “123”) by pressing [**RED**].
 - To enter a lower-case letter, “a” for instance, press [**2**] repeatedly until the “a” appears.
 - If you enter a wrong letter, press [**BLUE**] to delete it.
2. After having entered your desired name, press [**⊙ ENTER**].
 - A confirmation message will appear. Use [**^**/**v**] to select “Yes”, then press [**⊙ ENTER**].
 3. Press [**↩ BACK**] repeatedly to exit.

Changing a title name

HDD **USB-HDD** **BD-RE** **BD-R** **-RW(VR)** **+RW(+VR)** **+R(+VR)**

1. Follow steps 1 to 3 in “◆ Common operation for editing” on page 48.
2. Use [**^**/**v**] to select “Edit Title Name”, then press [**⊙ ENTER**].
3. Enter a new title name, then press [**⊙ ENTER**]. (Refer to “Guide to editing a title name” on page 49.)
4. A confirmation message will appear. Use [**^**/**v**] to select “Yes”, then press [**⊙ ENTER**].
5. Press [**↵ BACK**] to finish.

Protecting a title

HDD **USB-HDD** **BD-RE** **BD-R** **-RW(VR)**

1. Follow steps 1 to 3 in “◆ Common operation for editing” on page 48.
2. Use [**^**/**v**] to select “Protect Off→On”, then press [**⊙ ENTER**].
3. A confirmation message will appear. Use [**^**/**v**] to select “Yes”, then press [**⊙ ENTER**].
 - “**Ⓛ**” will appear on the protected titles.
4. Press [**↵ BACK**] to finish.
 - You can cancel protection by selecting “Protect On→Off” on a protected title in step 2.

Available operations for a protected title

Operations
Cancelling title protection
Dubbing protected titles
HDD initialisation (deleting all titles)
Disc initialisation (deleting all titles)

Deleting Unnecessary Titles

HDD **USB-HDD** **BD-RE** **BD-R** **-RW(VR)** **+RW(+VR)** **+R(+VR)**

! Note

- Once a title is deleted, it will not be able to undo. Make sure it is the correct title before deleting.

>> Preparation

- When editing on a USB-HDD, connect it to the unit.
- When editing on a disc, place it in the unit.
- Press [**HDD**] / [**DISC**] / [**USB**] accordingly.

Deleting a single title

1. Press [**CONTENTS LIST**] to call up the “Contents List” screen.
2. Use [**^**/**v**] to select a title to delete, then press [**SUB MENU**].
3. Press [**^**/**v**] to select “Title Delete”, then press [**⊙ ENTER**].
4. Confirmation message will appear. Use [**^**/**v**] to select “Yes”, then press [**⊙ ENTER**].
 - The title will be deleted.
5. Press [**↵ BACK**] to finish.

Delete multiple titles at one time

1. Press [**CONTENTS LIST**] to call up the “Contents List” screen.
2. Press [**SUB MENU**].
3. Use [**^**/**v**] to select “Delete Multiple Titles”, then press [**⊙ ENTER**].
4. In the title list, highlight the titles you wish to delete, then press [**⊙ ENTER**].
 - Repeat the procedure until all the titles you wish to delete are selected.
 - To deselect a title, press [**⊙ ENTER**] on a highlighted title.
5. Once you have selected all the unnecessary titles, press [**>**], then press [**⊙ ENTER**] on “OK”.
6. A confirmation message will appear. Use [**^**/**v**] to select “Yes”, then press [**⊙ ENTER**].
7. Press [**↵ BACK**] to finish.

! Note

- The title currently being recorded cannot be deleted.

About remaining time after deleting titles

HDD **USB-HDD** **BD-RE** Remaining time will increase.

-RW(VR) **+RW(+VR)**

BD-R **+R(+VR)**

Remaining time will not increase.

Deleting Parts of a Title

HDD USB-HDD

Deleting parts (scenes) cannot be undone. Make sure it is the correct part to delete.

- Follow steps 1 to 3 in “◆ Common operation for editing” on page 48.
- Use [^/∨] to select “Scene Delete”, then press [⊙ ENTER].
- With “Start” highlighted, find the start point, then press [⊙ ENTER].
- With “End” highlighted, find the end point, then press [⊙ ENTER].
- With “Preview” highlighted, then press [⊙ ENTER].
 - 5 seconds before and after the deleting scene will be previewed.
- Use [^/∨] to select “Delete”, then press [⊙ ENTER].
- A confirmation message will appear. Use [^/∨] to select “Yes”, then press [⊙ ENTER].
- Press [↵ BACK] to finish.
 - For steps 3 and 4, [▶] / [◀◀] / [▶▶] / [◀◀] / [▶▶] / [⏮] are available to play back.

Dividing a Title

HDD USB-HDD +RW(+VR)

! Note

- Dividing a title cannot be undone. Please make sure it is the correct title to divide.

>> Preparation

- When editing on a USB-HDD, connect it to the unit.
 - When editing on a disc, place it in the unit.
 - Press [HDD] / [DISC] / [USB] accordingly.
- Follow steps 1 to 3 in “◆ Common operation for editing” on page 48.
 - Use [^/∨] to select “Title Dividing”, then press [⊙ ENTER].
 - Find the point where you wish to divide the title, then press [⊙ ENTER].
 - [▶] / [◀◀] / [▶▶] / [◀◀] / [▶▶] / [⏮] are available to play back.

- A confirmation message will appear. Use [^/∨] to select “Yes”, then press [⊙ ENTER].
 - To continue dividing, select the title to divide, then press [SUB MENU], then select “Edit” and repeat steps 2 to 4.
- Press [↵ BACK] to finish.


Converting the Recording Mode (Image Quality)

HDD USB-HDD

By converting the recording mode (image quality) of a recorded title, you can use the HDD more efficiently. (Converting a title recorded in the TS quality into AF / AN / AE / XP / SP / LP / EP.)

>> Preparation

- When editing on a USB-HDD, connect it to the unit.
 - Press [HDD] or [USB] accordingly.
- Press [CONTENTS LIST] to call up the “Contents List” screen.
 - Use [^/∨] to select the title to edit, then press [SUB MENU].
 - Use [^/∨] to select “Recording Mode”, then press [⊙ ENTER].
 - Select the desired recording mode, then press [⊙ ENTER].



- Recording mode conversion will be performed 5 minutes after the unit is turned off. “↓” will be displayed on the display of this unit.
- Conversion will take the same length of time as the title duration.
- To verify the conversion has finished**
The conversion has finished if “- - -” is not displayed on the contents list screen.

! Note

- Conversion cannot be performed if the title is protected or the title is currently being recorded.
- Conversion will stop if the unit is turned on while converting a title. It will start again 5 minutes after the unit is turned off next time.
- Conversion will not be performed when attempting a conversion on a USB-HDD while it is not connected to the unit.

Media Management

Renaming a disc / USB-HDD

USB-HDD **BD-RE** **BD-R** **-RW(VR)** **+RW(+VR)** **+R(+VR)**

>> Preparation

- When editing on a USB-HDD, connect it to the unit.
- When editing on a disc, place it in the unit.

Press [**HOME**], then select “Media Manager”.

1. Use [**^**/**v**] to select “BD/DVD Menu” or “USB-HDD Menu”, then press [**ENTER**].
2. Use [**^**/**v**] to select “Edit Disc Name” or “Edit USB-HDD Name”, then press [**ENTER**].
 - “Edit USB-HDD Name” cannot be selected before registering the USB-HDD.
3. Enter a name for the disc or USB-HDD.
 - For the available characters and how to enter a name, refer to “Guide to editing a title name” on page 49.
 - Press [**ENTER**] when you have entered the name.
4. A confirmation message will appear. Use [**^**/**v**] to select “Yes”, then press [**ENTER**].
5. Press [**BACK**] to finish.

Protecting a disc / USB-HDD

USB-HDD **BD-RE** **BD-R** **-RW(VR)** **+RW(+VR)** **+R(+VR)**

>> Preparation

- When editing on a USB-HDD, connect it to the unit.
- When editing on a disc, place it in the unit.
- Press [**DISC**] / [**USB**] accordingly.

Press [**HOME**], then select “Media Manager”.

1. Use [**^**/**v**] to select “BD/DVD Menu” / “USB-HDD Menu”, then press [**ENTER**].
2. Use [**^**/**v**] to select “Disc Protect Off→On” / “USB-HDD Protect Off→On”, then press [**ENTER**].
3. A confirmation message will appear. Use [**^**/**v**] to select “Yes”, then press [**ENTER**].
4. Press [**BACK**] to finish.
 - You can cancel protection by selecting “Disc Protect On→Off” / “USB-HDD Protect On→Off” in step 2.

Finalising a disc recorded on this unit

BD-R **-RW(VR)** **+RW(+VR)** **+R(+VR)**

Finalising a disc recorded on this unit makes the disc playable on other devices, such as Blu-ray Disc™ players / recorders / PC's.

>> Preparation

- Place a disc in the unit to finalise.

Press [**HOME**], then select “Media Manager”.

1. Use [**^**/**v**] to select “BD/DVD Menu”, then press [**ENTER**].
2. Use [**^**/**v**] to select “Finalise”, then press [**ENTER**].
3. A confirmation message will appear. Use [**^**/**v**] to select “Yes”, then press [**ENTER**].
 - Finalisation process cannot be cancelled once it has begun.

◆ For DVD-Video

After dubbing is completed, the disc will automatically be finalised. You cannot manually finalise a disc.

! Note

- During a finalisation process, do not turn off the unit or unplug the AC cord as it may cause damage to the disc or malfunction of the unit.
- This unit may not be able to finalise a disc which was recorded on another device.
- For BD-R, finalisation cannot be performed when a timer recording will start within 2 minutes.
- For DVD-RW(VR) / DVD+RW(+VR) / DVD+R(+VR), finalisation cannot be performed when a timer recording will start within 90 minutes.
- Chapter information will remain after finalisation.
- Even if the disc is finalised, it may not be playable depending on the player / recorder / PC.
- If a power outage occurs during finalisation, the BD-R / DVD-R / DVD+R disc may become unusable.

Undoing finalisation

-RW(VR)

This unit can undo finalisation of DVD-RW (VR) discs only, which were finalised on this unit.

By undoing finalisation, you can record to the disc again. Please select “Undo Finalise” in step 2 in “Finalising a disc recorded on this unit”.

Deleting all recording data on the HDD / USB-HDD

! Note

- Recording data deleted due to disc initialisation cannot be undone. Make sure it is the correct media to initialise.

HDD USB-HDD

Press [**HOME**], then select "Media Manager".

- Use [**^**/**v**] to select "HDD Menu" / "USB-HDD Menu", then press [**ENTER**].
- If you wish to delete titles including the protected titles, select "Delete All Titles", if excluding the protected titles but other unprotected titles, select "Delete All Unprotected Titles" using [**^**/**v**], then press [**ENTER**].
- A confirmation message will appear. Use [**^**/**v**] to select "Yes", then press [**ENTER**].
 - Deleting process cannot be cancelled once it has begun.

Reinitialising (reformatting) a disc

BD-RE RW(Video) RW(VR) RW(+VR)

>> Preparation

- Press [**DISC**].

You can initialise a disc multiple times. Note that all data will be deleted.

Press [**HOME**], then select "Media Manager".

- Use [**^**/**v**] to select "BD/DVD Menu", then press [**ENTER**].
- Use [**^**/**v**] to select "Format", then press [**ENTER**].
 - For a DVD-RW disc, select a format type.
- A confirmation message will appear. Use [**^**/**v**] to select "Yes", then press [**ENTER**].
 - Initialisation process cannot be cancelled once it has begun.
 - For a BD-RE disc, it will be initialised in BDAV format.


! Note

- During the initialisation process, do not turn off the unit or unplug the AC cord as it may cause damage to the disc or malfunction of the unit.
- Disc initialisation cannot be performed when a timer recording starts within 15 minutes.
- This unit may not be able to re-finalise discs once finalised on another device.
- To initialise brand-new, unfinalised discs (BD-RE / BD-R / DVD-RW / DVD-R / DVD+RW / DVD+R), refer to "Initialise (format) a brand-new Blu-ray Disc™" on page 27.

Before Dubbing

Available dubbing types

◆ When dubbing multiple titles at one time (dubbing from the dubbing list)



Registering the titles to the dubbing list.

- You can select multiple titles at one time.
- You can dub in a different recording mode.

◆ When dubbing one title (dubbing from the contents list)



Easy dubbing from the “Contents List” screen.

- You can dub one title from the “Contents List” screen.

! Note

- Most commercially available video discs and rental video discs are protected with a copy guard. It is not possible to dub such discs.
- When dubbing a finalised DVD-RW(Video) / DVD-R(Video) disc to the HDD, please do it from an external device.
- For DVD-RW(AVCHD) / DVD-R(AVCHD) / DVD+RW(AVCHD) / DVD+R(AVCHD), only discs finalised on the recording device are possible to dub to this unit.

Recording mode for dubbing

◆ When dubbing from the contents list

Dubbing source		Dubbing to...			
Media	Rec. mode	Media	speed	Rec. mode (fixed)	
HDD	TS	BD-RE	High	Same as source	
		BD-R	Normal	Between AF / AN / AE, XP / SP / LP / EP	
	AF / AN / AE	-RW(VR)	Normal	Between XP / SP / LP / EP	
		-RW(Video)			
		-R(Video)	Normal	Between XP / SP / LP / EP	
		+RW			
XP / SP / LP / EP	BD-RE	High	Same as source		
	BD-R	Normal	Between XP / SP / LP / EP		
BD-RE BD-R	TS	BD-RE	High	Same as source	
		BD-R	Normal	Between AF / AN / AE, XP / SP / LP / EP	
	AF / AN / AE	HDD	High	Same as source	
		HDD	Normal	Between AF / AN / AE, XP / SP / LP / EP	
		XP / SP / LP / EP	HDD	Normal	Between XP / SP / LP / EP
			HDD	Normal	Between XP / SP / LP / EP
-RW(VR) +RW +R	XP / SP / LP / EP	HDD	High	Same as source	
		HDD	Normal	Between XP / SP / LP / EP	
		HDD	Normal	Between XP / SP / LP / EP	
-RW(Video) -R(Video)	XP / SP / LP / EP	HDD		Not possible	
		HDD		Not possible	

◆ When dubbing from the dubbing list

Dubbing source		Dubbing to...		
Media	Rec. mode	Media	speed	Available Rec. mode
HDD	TS	USB-HDD	High	High
			Normal	AF / AN / AE, XP / SP / LP / EP
		BD-RE BD-R	High	High
			Normal	AF / AN / AE, XP / SP / LP / EP
		-RW(VR) -RW(Video) -R(Video) +RW +R	Normal	XP / SP / LP / EP
				Not possible
	AF / AN / AE	USB-HDD	High	High
			Normal	AF / AN / AE, XP / SP / LP / EP
		BD-RE BD-R	High	High
			Normal	AF / AN / AE, XP / SP / LP / EP
		-RW(VR) -RW(Video) -R(Video) +RW +R	Normal	XP / SP / LP / EP
				Not possible
XP / SP / LP / EP	USB-HDD	High	High	
		Normal	XP / SP / LP / EP	
	BD-RE BD-R	High	High	
		Normal	XP / SP / LP / EP	
	-RW(VR) -RW(Video) -R(Video) +RW +R	Normal	XP / SP / LP / EP	
			Not possible	
USB-HDD	TS, AF / AN / AE	HDD	High	High
			Normal	AF / AN / AE, XP / SP / LP / EP
	XP / SP / LP / EP	HDD	High	High
			Normal	XP / SP / LP / EP
BD-RE BD-R	TS, AF / AN / AE	HDD	High	High
			Normal	AF / AN / AE, XP / SP / LP / EP
	XP / SP / LP / EP	HDD	Normal	XP / SP / LP / EP
			Not possible	
-RW(VR) +RW +R -RW(Video) -R(Video)	XP / SP / LP / EP	HDD	High	High
			Normal	XP / SP / LP / EP
			Not possible	
			Not possible	

! Note

- For a title with bilingual audio, high-speed dubbing from the HDD to a DVD-RW(Video) / DVD-R(Video) disc or DVD+RW(+VR) / DVD+R(+VR) disc cannot be performed.
- For a title recorded in EP mode, high-speed dubbing from the HDD to a DVD+RW(+VR) / DVD+R(+VR) disc cannot be performed.
- For a title longer than 5 hours, high-speed dubbing from the HDD to a DVD+RW(+VR) / DVD+R(+VR) disc cannot be performed.

About the “High-speed dubbing” and “Normal-speed dubbing”

◆ High-speed dubbing

- By using a high-speed recording compatible disc, dubbing will be performed for a shorter length of time than the title duration.
- High-speed dubbing is performed in the same recording mode (image quality) as the original title.
- While high-speed dubbing, the channel which is selected on the unit will be displayed.

◆ Normal-speed dubbing (at the speed of 1 x)

- Normal-speed dubbing takes the same length of time or longer as the original title.
- When the dubbing is in a different recording mode (image quality), it is performed as a normal-speed dubbing. Note that a higher recording mode will not make the image quality better when dubbing.

About dubbing restrictions

	Title with no copy restriction	Copy-once title
USB-HDD → HDD	Copy / Move	Move
BD-RE BD-R -RW(VR) +RW(+VR) +R(+VR)	Copy	Move ^{†1}
HDD → USB-HDD	Copy / Move	Move
HDD → BD-RE BD-R	Copy	Move
HDD → -RW(VR)	Copy	Move
HDD → -RW(Video) -R(Video)	Copy	—
HDD → +RW +R	Copy	—

— : Dubbing is not possible.

^{†1} Dubbing from a DVD or finalised BD-R disc is not possible.

◆ About programmes with no copy restriction

These programmes will be dubbed as “Copy” and the original titles (recording data) will remain on the source media.

◆ About copy-once programmes

These programmes will be dubbed as “Move” and the original titles (recording data) will be deleted from the source media.

About “Copy” and “Move”

For copy-once titles, “Copy” / “Move” will affect the original title (dubbing source) on the HDD. When copying, the original title will remain on the HDD whereas when moving, the original title will be deleted from the HDD.

For a title containing a part which must “Move” when dubbing

- If the title contains a part which must “Move” (not “Copy”), the whole title will be dubbed as “Move”.
- If the title contains a part which must “Move” and the part is deleted, the whole title will still be dubbed as “Move”. If such title is divided into the “Copy” part and “Move” part, the divided two titles will still be dubbed as “Move”.

Dubbing along with bilingual recording audio (dual audio) / surround audio / subtitles

Refer to “Recording along with bilingual audio (dual audio) / multi audio / surround audio / subtitles” on page 30.

! Note

- Please use the HDD as a temporary data storage device.
- It is highly recommended to copy important recordings to discs.
- A title containing still images authored on a video camcorder or PC cannot be dubbed.
- When dubbing from the HDD to a DVD-RW(Video) /-R (Video) disc, the disc will automatically be finalised. If you wish to dub multiple titles to a disc, please do it from the dubbing list.
 - When dubbing from the HDD to a DVD-RW(Video) /-R (Video) disc, you may need to change the setting in “Settings” > “Video/Audio” > “TV Aspect” to the appropriate aspect based on the dubbing source.
- This unit can perform dubbing from a DVD to the HDD only when the title has no copy protection. Copy-once titles and most commercially available videos cannot be dubbed.

One Title Dubbing from “Contents List” screen

HDD ↔ BD-RE BD-R DVD

>> Preparation

- When dubbing from a disc to the HDD, place the disc in the unit, then press [DISC].
- When dubbing from the HDD to a disc, place a recordable disc in the unit, then press [HDD].

1. Press [CONTENTS LIST] to call up the “Contents List” screen.
2. Use [^/∨] to select a title to dub, then press [SUB MENU].
3. Use [^/∨] to select “Dubbing”, then press [⊙ ENTER].
 - A confirmation message will appear. Use [^/∨] to select “Yes”, then press [⊙ ENTER].
 - Dubbing will start. “DUB” will be displayed on the display of the unit.
 - **To stop dubbing**
Press [■]. A confirmation message will appear. Use [^/∨] to select “Yes”, then press [⊙ ENTER].
 - “DUB” on the display will disappear when the dubbing finishes.

◆ When dubbing to a DVD-RW (Video) / -R (Video) disc

After dubbing finishes, the disc will automatically start finalising the disc.

! Note

- From the “Contents List” screen, only one title dubbing can be performed at a time.

Dubbing Multiple Titles at One Time


>> Preparation

- Prepare as follows according to the dubbing media.

Dubbing direction & Preparation	Proceed to ...
HDD → USB-HDD • Connect a USB-HDD to dub to (as a recording media).	Step 2
USB-HDD → HDD • Connect a USB-HDD to dub from (as a source).	
HDD → BD-RE / BD-R / +RW(VR) / -RW(Video) / -R(Video) / +RW(+VR) / +R(+VR) • Place a disc to dub to (as a recording media).	
BD-RE / BD-R / -RW(VR) / +RW(+VR) / +R(+VR) / DVD(AVCHD) → HDD • Place a disc to dub from (as a source).	Step 1
USB(AVCHD) → HDD • Connect a USB device (USB memory stick) to dub from (as a source). The selection screen will automatically appear.	

1. Use [^/∨] to select “Copy AVCHD to HDD”, then press [⊙ ENTER], then proceed to step 5.
2. Press [HOME] to call up the home menu.
3. Use [^/∨/⟨/⟩] to select “Dubbing”, then press [⊙ ENTER].
4. Use [^/∨] to select the dubbing direction, then press [⊙ ENTER].
5. Use [^/∨] to select a title to dub, then press [⊙ ENTER].
 - Pressing [⊙ ENTER] will show the numbers of the dubbing order next to the titles.
 - **To continue to select another title**
Repeat the same procedure.
 - **To deselect a title**
Highlight the title you wish to deselect, then press [⊙ ENTER].
6. After you have selected all the desired titles, press [>].
7. Press [^] to select “Picture quality”, then press [⊙ ENTER].
8. Use [^/∨] to select your desired recording mode (image quality), then press [⊙ ENTER].
 - Available recording modes differ depending on the recording mode of the source title and the recording method on the media.
9. After having selected the recording mode, press [>] to select “OK”, then press [⊙ ENTER].
 - Please confirm the dubbing list. If you wish to modify the list, see the following.

Dubbing list screen



- All the registered titles will be dubbed in order.
- ◆ **To add a title to the dubbing list**
 - 1) Use [^/∨] to select “Add”, then press [⊙ ENTER].
 - The title selection screen will appear.
 - 2) Use [^/∨] to select a title, then press [⊙ ENTER].
- ◆ **To delete a title from the dubbing list**
 - 1) Use [^/∨] to select “Delete”, then press [⊙ ENTER].
 - 2) Use [^/∨] to select a title, then press [⊙ ENTER].
 - 3) A confirmation message will appear. Use [^/∨] to select “Yes”, then press [⊙ ENTER].
- ◆ **To delete all titles from the dubbing list**
 - 1) Use [^/∨] to select “Delete All”, then press [⊙ ENTER].
 - 2) A confirmation message will appear. Use [^/∨] to select “Yes”, then press [⊙ ENTER].
- ◆ **To change dubbing order in the dubbing list**
 - 1) Use [^/∨] to select “Change order”, then press [⊙ ENTER].
 - 2) Use [^/∨] to select a title, then press [⊙ ENTER].
 - 3) Use [^/∨] to move the title to your desired position, then press [⊙ ENTER].
- 10. After the modification to the dubbing list, use [^/∨/⟨/⟩] to select “OK”, then press [⊙ ENTER].
- 11. “Start” is highlighted. Press [⊙ ENTER].
 - When the dubbing is HDD ↔ USB-HDD, “Start (move)” or “Start (copy)” will appear.
 - “DUB” will be displayed on the display of the unit.
 - **To stop dubbing**
Press [■], then select “Yes” in the confirmation window, then press [⊙ ENTER].
 - “DUB” on the display will disappear when the dubbing finishes.

◆ **When dubbing to a DVD-RW (Video) / -R (Video) disc**


After dubbing finishes, the disc will automatically start finalising the disc.

ⓘ **Note**

When the dubbing is from the HDD to a DVD-RW (Video) / DVD-R (Video) disc, you can rename the disc.

- 1) In step 11, select “Setting for disc name”, then press [⊙ ENTER].
- 2) Enter a name, then press [⊙ ENTER].

Dubbing from a VCR / Camcorder

◆ **Connection to an external device to this unit**

◆ Dubbing from an External Device

>> Preparation

- Press **[HDD]** when dubbing to the HDD.
- Place a recordable disc in the unit, then press **[DISC]** when dubbing to a disc.
- Configure the "External Input Audio" setting in "Home Menu" > "Settings" > "Recording".

1. Switch the unit to the external input.

- Follow step 1 to 3 in "Switching to the external input" on page 23.

2. Select a recording mode.

- Refer to "Changing the recording mode (image quality)" on page 33.
- Available recording modes are XP / SP / LP / EP.

3. Start playback on the connected device.

- To operate the connected device, refer to the user manual of the device.

4. Press **[● REC.]**.

- Recording will start.
- **To pause recording (HDD)**
Press **[III]**.
- To resume, press **[III]** again.
- **To stop recording**
Press **[■]**.
- If you stop recording, the recording (from the beginning to where it was stopped) will be one title. (It may take a moment to accept next operation.)
- **To stop recording (dual recording, chase play, simultaneous rec/play)**
Refer to "Recording a Programme Currently On Air" on page 33.

! Note

- This unit cannot dub commercially available video discs / rental video discs / rental video tapes for copyright protection reasons.

Additional Information about Dubbing

Overall dubbing

For HD-quality movies recorded on a digital camcorder

- Depending on the camcorder, scenes recorded on the same day may be separate titles. Please refer to the user manual of the camcorder for details.

Chapter marks when dubbing

- When dubbing, chapter marks will be dubbed along with the title. When normal-speed dubbing to DVD-Video, chapter marks will be added based on the chapter interval setting in "Settings" > "Recording" > "Auto Chapter".

Cinavia™

Cinavia Notice

This product uses Cinavia technology to limit the use of unauthorized copies of some commercially-produced film and videos and their soundtracks. When a prohibited use of an unauthorized copy is detected, a message will be displayed and playback or copying will be interrupted. More information about Cinavia technology is provided at the Cinavia Online Consumer Information Center at <http://www.cinavia.com>

To request additional information about Cinavia by mail, send a postcard with your mailing address to: Cinavia Consumer Information Center, P.O. Box 86851, San Diego, CA, 92138, USA. This product incorporates proprietary technology under license from Verance Corporation and is protected by U.S. Patent 7,369,677 and other U.S. and worldwide patents issued and pending as well as copyright and trade secret protection for certain aspects of such technology. Cinavia is a trademark of Verance Corporation. Copyright 2004-2012 Verance Corporation. All rights reserved by Verance. Reverse engineering or disassembly is prohibited.

If a dubbing is cancelled / a power outage occurs while dubbing

Other than **-RW(Video)** **-R(Video)**

- Dubbing source:
 - The contents remain.
- Dubbing to **HDD** **USB-HDD** **BD-RE** **-RW(VR)** **+RW(+VR)**:
 - The dubbing will not be performed.
- **BD-R** **+R(+VR)**:
 - The data will be written to the disc until the cancellation / power outage, yet it cannot be played back.

For **-RW(Video)** **-R(Video)**

- **-RW(Video)**:
 - Reformat will be required.
- **-R(Video)**:
 - The disc will become unplayable or unusable.
- If the message "Abnormality occurred in USB connection. USB device has been stopped automatically." appears while dubbing from a USB device, this unit will become inoperable. In this case, disconnect the USB device, and the message will disappear and this unit will become operable.

Approximate time required for a high-speed dubbing

When high-speed dubbing from the HDD to a disc

Dubbing a title (1 hour long) from the HDD to a 4x BD-R

Recording mode		Required time	Speed
TS	DTV (HD)	7 minutes	8 x
	DTV (SD)	4 minutes and 30 seconds	13 x
AF	DTV (HD)	6 minutes and 30 seconds	9 x
AN		5 minutes	12 x
AE	DTV (HD) 4.36 Mbps	3 minutes 10 seconds	19 x
	DTV (HD) 2Mbps	2 minutes	30 x

Dubbing a title (1 hour long) from the HDD to a 6x DVD-R

Recording mode		Required time	Speed
XP	DTV (HD)	10 minutes	6 x
SP		5 minutes and 30 seconds	11 x
LP		3 minutes	20 x
EP	DTV (HD) 6 hours	2 minutes and 20 seconds	26 x
	DTV (HD) 8 hours	2 minutes and 10 seconds	28 x

- Required time may differ depending on the conditions of the disc and dubbing source.
- The speed indication, such as 8x / 12x / 30x, is not the time ratio based on the actual title duration.
- For a 2x BD-RE/-R disc, a high-speed dubbing will be performed at the maximum speed of 2x. For a 4x / 6x BD-R disc, a high-speed dubbing will be performed at the maximum speed of 4x.
- If playback / recording on the HDD is performed while high-speed dubbing, it may take extra time to dub.

When high-speed dubbing from a disc to the HDD

- Dubbing will be performed at the equivalent speed of 2x of a HDD-to-disc dubbing.

Using This Unit as a Home Media Server

HDD **USB-HDD**

This function allows you to view contents recorded on this unit's HDD / USB-HDD* via DLNA client devices connected to your home network.

- * JPEG / MP3 / WMA / DivX® / MKV files stored on a USB device, such as USB memory stick, cannot be streamed over DLNA.
- “Client device” referred to here is a DLNA compatible player connected to the home network to which this unit is connected. These devices can access the contents stored on home media servers (e.g., this unit) over the home network.

To operate the DLNA client device, please refer to the user's manual of the device.

>> Preparation

- Connect this unit and a DLNA client device to the home network.
 - Press [**HOME**], then select “Settings” > “Network Settings” > “Media Share” > “On”.
1. On the client device, select this unit as a DLNA server.
 2. Select either the HDD folder or the USB-HDD folder according to the content (title) you wish to play back.
 3. Select the desired title, then start playback.

! Note

- This unit cannot be used as a client device.
- 2 or more client devices cannot play back simultaneously from this unit.

About playback on the client device

◆ In the following cases, playback on a client device is not possible.

When the following operations are being performed on this unit:

- During playback of BD-Video / DVD-RW (AVCHD) / DVD-R (AVCHD) disc
- Operation screen related to dubbing is being displayed.
- During dubbing
- When the following screen for a title on the HDD / USB-HDD is being displayed:

- “Edit”	- “Genre/Order”
- “Dubbing”	- “Title Delete”
- “Recording Mode”	- “Delete Multiple Titles”
- During configuration of the following in “Home Menu” > “Settings” > ...

- “Network Connection”	- “Initialisation”
- “Media Share”	- “Download Update”
- “Standby settings”	
- When the following menu is being displayed in “Home Menu” > “Media Manager” > ...
 - “HDD Menu”
 - “USB-HDD Menu”
- When simultaneous rec/play is performed on the USB-HDD or the contents list is being displayed during recording
- During recording mode conversion while the unit is powered off
- During software update

◆ In the following cases, playback on a client device will stop or a confirmation message will appear.

When the following operations are performed on this unit.

- When playing back a BD-Video / DVD-RW (AVCHD) / DVD-R (AVCHD) disc.
- While recording and playback are being performed simultaneously on the USB-HDD connected to the unit.
- When selecting a dubbing direction in the dubbing selection screen.
- When configuring the following in “Home Menu” > “Settings” > ...

- “Network Connection”	- “Initialisation”
- “Media Share”	- “Title Delete”
- “Media Share”	- “Download Update”
- When selecting “Home Menu” > “Media Manager” > “HDD Menu” while playing back a title on the internal HDD.
- When selecting “Home Menu” > “Media Manager” > “USB-HDD Menu” while playing back a title on the USB-HDD.
- When selecting the following for a title on the HDD / USB-HDD:

- “Edit”	- “Title Delete”
- “Dubbing”	- “Delete Multiple Titles”
- “Title Delete”	

◆ In the following case, the home network connection may be lost*.

- When the following operation is performed on this unit:
 - “Initial Setting”
 - *If you lost a connection, configure “Home Menu” > “Settings” > “Media Share” > “On” again.

◆ In the following cases, playback on a client device will stop.

- When playing back a title(s) on the USB-HDD from the client device and the unit simultaneously and then a timer recording starts.

Function Setup

Using “Settings” menu

In the “Settings” menu, you can access various kinds of menus, and customise them as you prefer.

1. Press [**HOME**] to call up the home menu.
2. Use [**^**/**v**/**</>**] to select “Settings”, then press [**ENTER**].
3. Use [**^**/**v**] to select the desired setting item, then press [**ENTER**].
 - Press [**BACK**] if you wish to move back to one left column.
 - If a confirmation message appears, use [**^**/**v**/**</>**] to select “Yes”, then press [**ENTER**].
4. Press [**BACK**] repeatedly to exit.

! Note


- If calling up the setting menu during playback, playback will automatically stop.

Category	Menus / Options		
Video/Audio	TV Aspect	4:3 Letter Box	Allows you to adjust the aspect ratio of the video source which is different from your TV's ratio to fit your TV monitor without distorting the picture. "4:3 Letter Box" : Outputs the image at 4:3 letter box in full width with black bars at the top and bottom. "4:3 Pan & Scan" : Outputs the image at 4:3 pan & scan in full height with both sides trimmed. "16:9 Wide" : Outputs the image at 16:9 wide. "16:9 Squeeze" : If the video source is 4:3, outputs the image at 4:3 squeeze. If the video source is 16:9, outputs the image at 16:9.
		4:3 Pan & Scan	
		16:9 Wide	
		16:9 Squeeze	
	Still Mode	Auto	Adjusts picture resolution and quality in still mode. "Auto" : Automatically selects the best resolution setting ("Frame" or "Field") based on the data characteristics of the pictures. "Field" : Stabilises the pictures, although the picture quality may become coarse due to the limited amount of data. Select "Field" when the pictures are still unstable even if "Auto" is selected. "Frame" : Displays relatively motionless pictures in higher resolution. "Frame" improves the picture quality, although it may unsteady the pictures due to alternate output of 2-field data. <ul style="list-style-type: none"> An individual picture on the TV screen is called "Frame", which consists of two separate images called "Field". Some pictures may be blurred at the auto setting in "Still Mode" setting due to their data characteristics.
		Field	
		Frame	
	Dolby D / Dolby D+ / Dolby TrueHD	PCM	Sets how to output the digital audio source. If your amplifier / receiver is compatible with multi-channel audio format such as Dolby Digital, DTS®, or MPEG, etc., select "Bitstream". If not, select "PCM".
		Bitstream	
	DTS / DTS-HD	PCM	When playing back a title in HDD, BD-RE/-R, or VR mode DVD-RW, select "PCM" so that you can switch to main audio (L), sub audio (R), or a combination of both (L / R) using your amplifier / decoder.
Bitstream			
MPEG	PCM		
	Bitstream		
BD Audio Mode	Mix Audio Output	For Blu-ray Disc™, selects whether to output the secondary and interactive audio with primary audio if it is available or only the primary audio. "Mix Audio Output" : The audio for the secondary video and the interactive application will be output together with the audio for the primary video. <ul style="list-style-type: none"> The secondary audio is the audio for the secondary video (Directors comment etc.) and the interactive audio is the audio for the interactive application (Button click sounds etc.). "HD Audio Output" : Outputs only the primary audio. Set this mode in order to output Dolby Digital, Dolby Digital Plus, Dolby TrueHD, DTS or DTS-HD audio of Blu-ray Disc™ through HDMI connection.	
	HD Audio Output		
DRC	Auto	Sets whether to compress the range of sound volume (Dynamic Range Control) when Dolby Digital, Dolby Digital Plus or Dolby TrueHD audio is played back. "Auto" : When the discs recorded in Dolby TrueHD format are in playback, this unit detects DRC setting of the disc and set "DRC" setting to "On" or "Off" automatically.	
	On		
	Off		
Video/Audio (Cont'd)	Down Sampling	On	Sets the digital audio output when playing back Blu-ray Disc™ or DVD recorded in LPCM. "On" : LPCM signals are converted to 48 kHz for output. Set to "On" when using digital connections to an AV amplifier that is not compatible with sampling frequencies of 96 kHz. "Off" : For Blu-ray Disc™ and DVD recorded in LPCM without copyright protection, 2-channel audio signals up to 96 kHz are output as LPCM signals. If the audio source is 192 kHz, it is down converted to 96 kHz.
		Off	
Language	Audio Language	Original	Sets the audio language for BD-Video or DVD-Video playback. "Original" : Activates the disc's original language. "Other" : If you select "Other", enter a 4-digit-code for the desired language (Refer to page 67). <ul style="list-style-type: none"> Only the languages which the disc supports can be selected.
		English	
		Other	
	Subtitle Language	Off	Sets the subtitle language for BD-Video or DVD-Video playback. "Other" : If you select "Other", enter a 4-digit-code for the desired language (Refer to page 67). <ul style="list-style-type: none"> Only the languages supported by the disc can be selected.
		English	
		Other	
Disc Menu Language	English	Sets the language for disc menu. "Other" : If you select "Other", enter a 4-digit code for the desired language (Refer to page 67). <ul style="list-style-type: none"> Only the languages supported by the disc can be selected. 	
	Other		

Continued on next page

Category	Menus / Options					
Language (Cont'd)	DivX Subtitle Language	Czech	German	Russian1	Sets the language for DivX [®] subtitle.	
		Dutch	Hungarian	Russian2		
		English	Italian	Spanish		
		French	Polish	Swedish		
HDMI	HDMI Video Resolution	Auto	720p	1080p	Sets the resolution of the video signal being output from the HDMI OUT jack. "Auto" : HDMI video resolution will be selected automatically depending on the connected HDMI device. <ul style="list-style-type: none"> When "1080p" is selected, even if the video source is 1080p24, it will be output in 1080p50. Even if the video material is 1080p24 and "1080p24" is selected, when connected device is not compatible with 1080p24, it will be output in 1080p50. Even if "720p" is selected, when the playing material is not 720p, it will be output in 1080i. By pressing and holding [▶] for 5 seconds or longer, "HDMI Video Resolution" will automatically be set to "Auto". 	
		480p/576p	1080i	1080p24		
	HDMI Deep Colour	Auto				Reduces the posterisation effect of the playback picture. "Auto" : Reduces the posterisation effect by automatically outputting up to 36 bit colour whenever the unit recognises the connected display device supports Deep Colour feature. "Off" : Outputs the standard 24 bit colour.
		Off				
	Progressive Mode	Auto				Sets the optimum progressive mode for the image material output from HDMI OUT jack. "Auto" : The progressive mode will detect 24-frame film material (movies) and automatically select appropriate progressive mode. "Video" : Suited for playing back video material discs (TV shows or animation).
		Video				
HDMI Audio Out	On			Sets whether to output the audio from the HDMI OUT jack.		
	Off					
SIMPLINK	On			Sets whether to utilise the SIMPLINK function.		
	Off					
3D settings	3D Playback	Auto(3D)			"Auto(3D)" : The images will be output in 3D for a 3D compatible TV, 2D for a conventional TV. "2D" : The 3D contents will be output in 2D. <ul style="list-style-type: none"> Some discs cannot output 2D images. 	
		2D				
	3D Type	Frame packing				"Frame packing" : Outputs 3D images in frame packing mode (Left and right image packed into one video frame). "Side by side" : Outputs 3D images in side by side mode (One video frame is split vertically into 2 parts: the left part is intended for the left eye, right part for the right eye.) "Checkerboard" : Outputs 3D images in checkerboard mode (Combines left and right images and outputs left / right / top / bottom parts alternately.) <ul style="list-style-type: none"> PAL contents in 720p cannot be played back.
		Side by side				
		Checkerboard				
	3D perspective					Allows you to set the perspective when outputting 3D images.
3D screen display	On (Side by side)			"On" : Displays the menu on the side of the screen. <ul style="list-style-type: none"> This setting may not work with some menus. "Off" : Displays the menu in its original position.		
	Off (Normal)					
Playback	BD Rating Level	Password	Off		Sets the rating level for Blu-ray Disc™ playback.	
			Age Setting			
	DVD Rating Level	Password	Off		Sets the rating level for DVD playback.	
			8	4		
			7	3		
			6	2		
			5	1		
	Password Change	Password			Sets new password for the parental lock.	
	Instant Skip	5 seconds		10 seconds		When you press [→] I.SKIP, the playback picture will skip forward by the amount of time you set here.
		30 seconds		1 minute		
5 minutes						
Instant Replay	5 seconds		10 seconds		When you press [←] I.REPLAY, the playback picture will skip backward by the amount of time you set here.	
	30 seconds		1 minute			
	5 minutes					
Angle Icon	On			Sets whether to display the angle icon on the TV when playing back the scene with various angles.		
	Off					

Category	Menus / Options			
Playback (Cont'd)	Slide Show	5 seconds	Sets the slide show speed. • Large-size JPEG files take a few moments to be displayed.	
		10 seconds		
Recording	Auto Chapter	Off	Inserts the chapter marks automatically with every time interval you set here. • The length of chapters may slightly deviate. • When dubbing a title which has chapter marks, the chapter marks will automatically be dubbed as they are and the interval setting of "Auto Chapter" will not be effective. However, in the case of normal-speed dubbing from the HDD to a DVD-RW (Video) / DVD-R (Video) disc, chapter marks will be added according to the interval setting of "Auto Chapter".	
		5 minutes		20 minutes
		10 minutes		30 minutes
		15 minutes		60 minutes
		AE Mode		4.36 Mbps
	EP Mode	6 hours	8 hours	
	Aspect Ratio (Video Format)	Auto		When dubbing to a video mode DVD at the normal speed, it allows you to choose the desired recording aspect ratio. "Auto": First aspect ratio of the title to be dubbed will be applied and be kept throughout the recording. "4:3": Records in the aspect ratio of 4:3. "16:9": Records in the aspect ratio of 16:9. • For BD-RE / -R, or VR mode DVD-RW, it will be recorded in the same aspect ratio with the title to be dubbed. • For DVD+RW / +R, the image will always be recorded in aspect ratio of 4:3.
		4:3		
		16:9		
	Recording Audio Select (XP)	PCM	Dolby D	Allows you to choose "PCM" or "Dolby D" when recording the external input audio in "XP" mode or when dubbing a title to Blu-ray Disc™ / DVD in "XP" mode. "PCM": Records PCM audio for the best quality sound. "Dolby D": Records Dolby Digital audio for good quality sound. • PCM stands for Pulse Code Modulation. It changes analogue sound to digital sound without compressing audio data. • When the recording mode is set to other than "XP", the unit records "Dolby D" audio automatically even if you select "PCM".
Dolby D				
Subtitle Recording	On	Off	When dubbing a title recorded in TS mode, and when it has subtitle information, you can choose whether to dub the subtitle as a part of the image. • The subtitle will be recorded as an image, so it cannot be turned on/off when playing back the dubbed title. • The English subtitles will preferentially be selected. • If the preset language does not exist in the title, no subtitle will be recorded.	
	Off			
Make Recording Compatible	On	Off	This unit prohibits the additional writing to the +VR which has different type of title list created on other unit. To make recording to such discs possible, select "On" in this menu. • When additional recording is made on this unit, the title list type will be replaced with this unit's.	
	Off			
Bilingual Recording Audio	Main	Sub	Selects either "Main" or "Sub" when dubbing a title with bilingual audio to a video mode or +VR mode DVD. • When recording to the HDD / Blu-ray Disc™ / DVD-RW (VR), both "Main" and "Sub" will be recorded regardless of your setting here. And you can choose the desired audio format as you playback later.	
	Sub			
External Input Audio	Stereo	Bilingual	When the external input audio is a bilingual broadcast, you can choose "Stereo" or "Bilingual" as the recording audio. • This setting is only for recording external input (AV). • See also "Bilingual Recording Audio" above.	
	Bilingual			
Video Colour System	Auto		Allows you to select the appropriate colour system to match your TV. "Auto": The video colour system will be set automatically according to the recording material. "PAL": The video colour system will be set to PAL. "SECAM": The video colour system will be set to SECAM. • During recording, when a signal other than PAL or SECAM is detected, an error message appears on the screen and recording will be paused. Recording will be resumed when a PAL or SECAM signal is detected. • Regardless of the setting here, recording colour system is fixed to PAL. • When PAL is selected, but the input signal is SECAM or vice versa, the colour will not be recorded correctly.	
	PAL			
	SECAM			

Category	Menus / Options				
Clock	Clock Setting		Press [⊙ ENTER] so that the entry fields will be available. Enter the date (day / month / year) and time using [^ / v], then press [⊙ ENTER]. <ul style="list-style-type: none"> Use [</>] to go back and forth among the fields. Your clock setting will be lost if either there is a power failure or the unit is unplugged for more than 30 seconds. If "Auto Clock Setting" is set to "On" you cannot select "Clock Setting". 		
					
	Auto Clock Setting	On Off	Allows the unit to adjust the clock automatically by referring to the DTV time signal. <ul style="list-style-type: none"> Make sure "Initial Setting" or "Auto Tuning" is completed. (Refer to page 16) Auto clock adjustment will be performed at the following time. NSW/ACT (3:00), VIC (3:00), TAS (3:00), QLD (2:00), SA (2:30), NT (1:30), WA (1:00) 		
	Time Zone	NSW/ACT VIC QLD SA	WA TAS NT	Sets the region where you live.	
Network Settings	Network Connection	Auto			
		Manual	IP Address Setting	Auto(DHCP) Manual	Sets the IP address. In most cases, you can connect to the Internet without making any changes to the default setting.
			IP Address		
			Subnet Mask		
			Default Gateway		
			DNS Setting	Auto(DHCP) Manual	Sets the DNS setting. In most cases, you can connect to the Internet without making any changes to the default setting.
			Primary DNS		
			Secondary DNS		
		Proxy Setting	Use Do Not Use	Sets the proxy server. In most cases, you can connect to the Internet without using proxy server.	
		Connection Speed	Auto	Sets the connection speed. In most cases, you can connect to the Internet without making any changes to the default setting.	
10BASE Half					
10BASE Full					
100BASE Half					
100BASE Full					
Connection Test		Perform a network connection test. After you change the IP address or DNS setting, always perform this test.			
BD-Live Setting	Allow	You can restrict Internet access when BD-Live™ functions are used.			
	Limited Allow				
	Prohibit				
Displaying network status		You can confirm "MAC Address", "Connected server", "IP Address", "Subnet Mask", "Default Gateway", "Primary DNS", "Secondary DNS", "Proxy Setting", "Proxy Port" and "Connection Speed".			
Media Share	On	By setting this to "On", you can use this unit as a home media server and your DLNA compatible devices / players can access the contents stored on this unit's HDD / USB-HDD. <ul style="list-style-type: none"> When this setting is "On", "Standby settings" will be set to "Normal Standby" automatically. 			
	Off				
Others	Auto Standby	On	Setting this to "On" places the unit in standby mode automatically if the unit remains inactive for more than 3 hours.		
		Off			
	Panel Display	On	"On": Always on.		
		Off	"Off": Always off.		
Power Interlock		"Power Interlock": When the unit is on, the display panel is on, when the unit is off, the display panel is off.			
TV screen protection	On	If the unit has been inactive for more than 15 minutes while displaying the home menu screen / setting screen, the screen will automatically be turned to the DTV screen. If the track list for Audio CD / DivX® / MP3 / WMA / contents list for JPEG files has been displayed, screen saver will start.			
	Off				

Category	Menus / Options			
Others (Cont'd)	Standby settings	Normal Standby	This setting allows you to select whether to have this unit in energy save mode. “Normal Standby”: The unit in “Normal Standby” mode can boot up faster than “ECO Standby”, power consumption during standby mode will increase. “ECO Standby”: The unit in “ECO Standby” mode takes longer to boot up than “Normal Standby”, power consumption during standby mode will decrease. <ul style="list-style-type: none"> When “SIMPLINK” or “Media Share” is set to “On”, this setting will automatically be set to “Normal Standby”. When set to “Normal Standby”, the unit is technically powered-on during standby mode and ... <ul style="list-style-type: none"> Power consumption during standby mode will increase. The cooling fan on the rear panel may spin to avoid a rise of temperature inside the cabinet. 	
		ECO Standby		
	Quick Booting	7:00~10:00	19:00~22:00	During the periods of time set here, the boot time will be shorter. <ul style="list-style-type: none"> You can select up to 2 periods of time. (e.g. 7:00 ~ 10:00 and 16:00 ~ 19:00) During the selected periods of time... <ul style="list-style-type: none"> Power consumption during standby mode will increase. The cooling fan on the rear panel may spin to avoid a rise of temperature inside the cabinet. Do not unplug the AC cord during the selected periods of time. It may cause malfunction of the unit. If unplugging, deactivate “Quick Booting” for the period of time, then turn this unit off before unplugging.
		10:00~13:00	22:00~1:00	
		13:00~16:00	1:00~4:00	
		16:00~19:00	4:00~7:00	
	DivX(R) VOD	Register		This menu item provides you with the DivX® VOD registration code. The DivX® registration code is required when downloading DivX® VOD files from the Internet. To learn more about DivX® VOD, visit www.divx.com/vod .
		Deregister		To deregister this unit from the activated device list of your DivX® VOD player, a deregistration code is required. This menu item provides you with the deregistration code, and also prompt you to the registration screen in case you wish to reregister this unit for another DivX®.
	Product Info			Indicates product info and the current software version.
Download Update			Downloads the latest software through the DTV signal.	
Download Update in Standby	On		Performs the “Download Update” automatically while the unit is in standby mode. As to the time schedule, refer to the explanation in “Auto Clock Setting” on page 64.	
	Off			
Initialisation	Delete BD Video data		Initialises all BD-Video data including application data (game score, etc.), virtual package data (downloaded special contents, audio, subtitles, etc.)	
	Initialise Settings		Resets the setting items to the default settings, except for “BD Rating Level”, “DVD Rating Level” and “Network Settings” in “Settings”.	
	Initialise for Network setting		Resets the setting items in “Network Settings” in “Settings” to the default settings.	
	Initialise for Personal information		Resets the unit to the factory default (the HDD will be initialised), then turn the unit off. <ul style="list-style-type: none"> Some settings on this unit contain your personal information. In case this unit is given away or discarded, it is recommended that you perform “Initialise for Personal information”. 	

◆ Configuring “BD Rating Level” / “DVD Rating Level”

BD-Video DVD-Video

1. Press [**HOME**], then select “Playback” > “BD Rating Level” or “DVD Rating Level”.
 - Password entry screen will appear.
2. Use [**0**] - [**9**] to enter a 4-digit number.
 - “0000” cannot be used for a password.
 - An entered number is replaced with an “*”.
 - If a password has not been registered yet, the number you just entered will be registered.
 - **If you enter a wrong number**
Use [**<**] to move back or use [**^/∨**] to select “Clear all”, then press [**ENTER**].
3. Use [**^/∨**] to select the desired item to modify.

DVD rating level

“Off”: No restriction

“8”: Weak (Most DVD's are allowed)

“1”: Strong (Only DVD's for children are allowed)

Blu-ray Disc™ rating level

“Off”: No restriction

“Age Setting”: Enter age using [**0**] - [**9**].

4. Press [**BACK**] repeatedly to exit.
 - **Unlocking the parental control on a commercially available disc**
Enter the same password used above.
 - Parental lock is unlocked until this unit is turned off.

◆ Changing the password

1. Press [**HOME**], then select “Playback” > “Password Change”
 - Password entry screen will appear.
2. Use [**0**] - [**9**] to enter the current password.
 - An entered number is replaced with an “*”.
 - New password entry screen will appear.
 - **If you enter a wrong number**
Use [**<**] to move back or use [**^/∨**] to select “Clear all”, then press [**ENTER**].
3. Use [**0**] - [**9**] to enter a new password.
 - “0000” cannot be used for a password.
4. Confirmation screen will appear. Enter the password again, then press [**ENTER**].
5. Press [**BACK**] repeatedly to exit.

Software Update

You can update the unit using the latest software to enhance the product's operation and / or add new features.

Downloading the Software through the DTV Signal:

You can download the latest software through the air and update this unit.

1. Press [**HOME**], then select “Settings” > “Others” > “Download Update”, then press [**ENTER**].
 - A confirmation message will appear.
2. Use [**^/∨**] to select “Yes”, then press [**ENTER**].
 - The unit will start scanning all the DTV channels for the latest software.

If software is found, the unit will start loading it automatically. After loading completes, the unit will automatically reboot and start updating. When updating completes, the unit will automatically reboot.

! Note

- If “Download Update in Standby” is set to “On” in “Settings”, the unit will perform “Download Update” automatically while the unit is in standby.

Using a USB memory stick:

You can download the latest software (if a newer version is available) from LG's website and save the software on a USB memory stick. By connecting the USB memory stick to the unit, you can update your unit.

>> Preparation

- Prepare an empty USB memory stick.
- Have your PC ready to use the Internet.

On PC

1. Using an Internet browser, go to <http://www.lg.com/global/support>, then download the latest software.
2. Save the software on a USB memory stick.

On Unit

3. In stop mode, connect the USB memory stick to the USB port on the front of the unit.
4. A confirmation message will appear. Use [**</>**] to select “Yes”, then press [**ENTER**].
5. After 2 reboots, disconnect the USB memory stick.

! Note

- Do not change the file name of the downloaded file.
- Do not save any other files than the downloaded software on the USB memory stick.
- Do not turn off the unit or disconnect the USB memory stick during update process.
- Software update cannot be performed when there is a timer recording within 15 minutes.
- It may take extra time to load the software.
- You can confirm the current software version on the unit by pressing [**HOME**], then select “Settings” > “Others” > “Product Info”.

Language Code List

Language	Abbrev.	Code	Language	Abbrev.	Code	Language	Abbrev.	Code
Afar	aa	4747	Georgian	ka	5747	Sesotho	st	6566
Abkhazian	ab	4748	Kazakh	kk	5757	Sundanese	su	6567
Afrikaans	af	4752	Greenlandic	kl	5758	Swedish	sv	6568
Amharic	am	4759	Cambodian	km	5759	Swahili	sw	6569
Arabic	ar	4764	Kannada	kn	5760	Tamil	ta	6647
Assamese	as	4765	Korean	ko	5761	Telugu	te	6651
Aymara	ay	4771	Kashmiri	ks	5765	Tajik	tg	6653
Azerbaijani	az	4772	Kurdish	ku	5767	Thai	th	6654
Bashkir	ba	4847	Kirghiz	ky	5771	Tigrinya	ti	6655
Byelorussian	be	4851	Latin	la	5847	Turkmen	tk	6657
Bulgarian	bg	4853	Lingala	ln	5860	Tagalog	tl	6658
Bihari	bh	4854	Laothian	lo	5861	Setswana	tn	6660
Bislama	bi	4855	Lithuanian	lt	5866	Tonga	to	6661
Bengali; Bangla	bn	4860	Latvian; Lettish	lv	5868	Turkish	tr	6664
Tibetan	bo	4861	Malagasy	mg	5953	Tsonga	ts	6665
Breton	br	4864	Maori	mi	5955	Tatar	tt	6666
Catalan	ca	4947	Macedonian	mk	5957	Twi	tw	6669
Corsican	co	4961	Malayalam	ml	5958	Ukrainian	uk	6757
Czech	cs	4965	Mongolian	mn	5960	Urdu	ur	6764
Welsh	cy	4971	Moldavian	mo	5961	Uzbek	uz	6772
Danish	da	5047	Marathi	mr	5964	Vietnamese	vi	6855
German	de	5051	Malay	ms	5965	Volapuk	vo	6861
Bhutani	dz	5072	Maltese	mt	5966	Wolof	wo	6961
Greek	el	5158	Burmese	my	5971	Xhosa	xh	7054
English	en	5160	Nauru	na	6047	Yiddish	yi	7155
Esperanto	eo	5161	Nepali	ne	6051	Yoruba	yo	7161
Spanish	es	5165	Dutch	nl	6058	Chinese	zh	7254
Estonian	et	5166	Norwegian	no	6061	Zulu	zu	7267
Basque	eu	5167	Occitan	oc	6149			
Persian	fa	5247	(Afan)Oromo	om	6159			
Finnish	fi	5255	Oriya	or	6164			
Fiji	fj	5256	Panjabi	pa	6247			
Faroese	fo	5261	Polish	pl	6258			
French	fr	5264	Pashto; Pushto	ps	6265			
Frisian	fy	5271	Portuguese	pt	6266			
Irish	ga	5347	Quechua	qu	6367			
Scots Gaelic	gd	5350	Rhaeto-Romance	rm	6459			
Galician	gl	5358	Kirundi	rn	6460			
Guarani	gn	5360	Romanian	ro	6461			
Gujarati	gu	5367	Russian	ru	6467			
Hausa	ha	5447	Kinyarwanda	rw	6469			
Hebrew	he	5451	Sanskrit	sa	6547			
Hindi	hi	5455	Sindhi	sd	6550			
Croatian	hr	5464	Sangho	sg	6553			
Hungarian	hu	5467	Serbo-Croatian	sh	6554			
Armenian	hy	5471	Singhalese	si	6555			
Interlingua	ia	5547	Slovak	sk	6557			
Indonesian	id	5550	Slovenian	sl	6558			
Interlingue	ie	5551	Samoan	sm	6559			
Inupiak	ik	5557	Shona	sn	6560			
Icelandic	is	5565	Somali	so	6561			
Italian	it	5566	Albanian	sq	6563			
Japanese	ja	5647	Serbian	sr	6564			
Javanese	ju	5668	Siswat	ss	6565			

Troubleshooting

If the unit operates unexpectedly, follow the instructions below first, before requesting service for this unit.

Some simple checks or a minor adjustment on your part may solve the problem and restore proper operation.

- Also check the antenna, TV, AV amplifier and other devices connected to the unit and read the user manuals.

◆ Trouble checkup

1. Refer to “Symptom / Things to check” in the following chart and try to find your situation.

- If it does not solve the problem, proceed to step 2.

2. Try the following.

- Please remove the disc, disconnect the USB-HDD / USB device beforehand if possible.

1) Press the power button on the front panel to turn off the unit. (By pressing and holding the power button for 8 seconds or longer, you can force turn off the unit.)

2) Unplug the AC power cord, then wait a few seconds.

3) Plug the AC power cord back in.

4) Turn on the unit and see if the unit operates properly.

- If it does not solve the problem, proceed to step 3.

3. Try the following.

1) Press the reset button inside the front cover using a paper clip or other straight, thin object.

- This unit will automatically be turned on, perform the system configuration, then will be turned off.

- This unit is not operable during system configuration. Please wait until it is completed.

2) Turn on the unit and see if the unit operates properly.

! Note

- After reset, please perform the necessary configurations, such as timer programming and other settings.
- If you have tried all the above then the problem has still not been solved, unplug the AC cord and contact the retailer you purchased the unit from.

Symptom		Things to check
Power	The power does not turn on.	<ul style="list-style-type: none"> • Is the AC power cord connected securely? • Are the batteries in the remote control still good? • If none of above, try step 2 in “◆ Trouble checkup” on page 68.
	The unit automatically turns on by itself.	<ul style="list-style-type: none"> • If “↓D” is shown on the display panel, the unit is in the process of recording mode conversion. • If “↓D” and “UPDATE” are shown on the display panel, the unit is downloading for a software update. • The unit will automatically turns on 2 minutes before a timer recording.
	The “Initial Setting” screen is displayed when turning on the unit.	<ul style="list-style-type: none"> • The “Initial Setting” screen appears when you turn on this unit for the first time.
	When turning on / off the TV, the unit turns on / off automatically.	<ul style="list-style-type: none"> • This happens when connecting the unit to an LG brand TV which supports the “SIMPLINK” functions and both the unit and TV’s “SIMPLINK” is set to “On”. (It may not function depending on the model.)
	The unit automatically turns off.	<ul style="list-style-type: none"> • Is “Settings” > “Others” > “Auto Standby” not set to “On”? • If above is not the case, try step 2 in “◆ Trouble checkup” on page 68.
	It takes a while to shut down the unit.	<ul style="list-style-type: none"> • When the unit is in the process of finishing the system or updating the system information, it may take extra time to shut down the unit.
Overall the unit / Disc / USB	The display panel is off.	<ul style="list-style-type: none"> • Is “Settings” > “Others” > “Panel Display” not set to “Off”?
	The unit is not operable.	<ul style="list-style-type: none"> • When “⊙” is displayed on screen, the operation is prohibited. • Are the batteries in the remote control still good? • When this unit is turned on for the first time after purchase, the “Initial Setting” screen will appear. • During “Initial Setting”, recording / playback and other operations are not possible. • If none of above, try step 2 in “◆ Trouble checkup” on page 68. • The more titles there are stored on the HDD, the longer the unit will take to boot up when plugging in the AC power cord.
	The HDD is not operable.	<ul style="list-style-type: none"> • Is “HDD” on the front panel lighted? If no, press [HDD] on the remote control.

		Symptom	Things to check
Overall the unit / Disc / USB (Cont'd)		The disc is not operable.	<ul style="list-style-type: none"> Is "DISC" on the front panel lighted? If no, press [DISC] on the remote control. Is a disc in this unit? Depending on the disc, playback speed control is not available.
		The disc tray does not open / close.	<ul style="list-style-type: none"> When the dubbing list is displayed, the disc tray may not open / close. If an unsupported disc is placed in this unit, the disc tray may not open. In this case, press the power button on the unit for 8 seconds or longer to turn off the unit, then press [▲ OPEN/CLOSE] button. If this does not solve the problem, try step 2 in "◆ Trouble checkup" on page 68.
		The setting screen / sub menu are not displayed or items are not selectable.	<ul style="list-style-type: none"> When the operation is not available, the item may not be displayed or selectable. Does your TV's external source input corresponds to the unit's output?
		This unit does not operate properly.	<ul style="list-style-type: none"> If the unit is under condensation conditions, let the unit sit (powered on) for at least 2 hours.
		The display panel shows an abnormal indication.	<ul style="list-style-type: none"> Try step 2 in "◆ Trouble checkup" on page 68.
		The USB device is not operable. The USB device is not readable.	<ul style="list-style-type: none"> Is the USB device compatible with this unit? Is the USB cable connected securely? If connecting a USB device during recording / playback / dubbing, it may not be recognised.
		While a USB device is connected, this unit becomes inoperable.	<ul style="list-style-type: none"> It is caused by the USB device which has a problem during playback / slide show or while dubbing the contents to the HDD. In this case, disconnect the USB cable, then reconnect it.
Viewing a programme / switching channels		TV programme is not displayed.	<ul style="list-style-type: none"> Are the connections, the antenna — this unit — TV, made correctly? Are the cables / cords connected to the correct terminals (including input / output)? Are the cables / cords connected securely? When connecting this unit and TV with an HDMI cable, be sure that the resolution in "Settings" > "HDMI" > "HDMI Video Resolution" is set to the correct resolution which the TV supports. If you are not sure, press and hold [▶] for 5 seconds or longer. This configures the resolution to "Auto" and the selected channel should be displayed. When "HDMI Video Resolution" is set to "Auto" or "1080p24", the video out jack (yellow) may not output a signal. In this case, disconnect the HDMI cable or set the current resolution to another. Does your TV's external source input corresponds to the unit's output?
		TV's image quality became low after connecting this unit.	<ul style="list-style-type: none"> Do you use a DTV signal splitter? If so, a TV signal booster (commercially available) may improve. If a signal booster is not effective, contact the retailer you purchased the unit from. When this is not in use, place it in standby mode (turn off the unit, not unplug the AC power cord). Avoid arranging the RF cable, HDMI cable and LAN cable, etc. close together. Try "Auto Tuning" in "DTV Menu" > "Installation".
		Unable to switch channels.	<ul style="list-style-type: none"> During a dual recording, other than the recording channels cannot be viewed. During playback, this unit is unable to switch channels.
		Subtitles are not displayed while viewing a DTV programme.	<ul style="list-style-type: none"> Be sure "Subtitle" in the sub menu is not set to "Off". <ul style="list-style-type: none"> The sub menu can be called up by pressing [SUB MENU] while viewing a DTV programme. There are cases in which a subtitle language appears available while the subtitle information is not actually broadcasted.
		"Programme Guide" is not displayed.	<ul style="list-style-type: none"> "Programme Guide" is not available until this unit receive the EPG data after tuning is completed.
		A different programme is recorded from the timer programming set from "Programme Guide".	<ul style="list-style-type: none"> There are cases in which a broadcast station airs a different programme from the scheduled programme. This causes an inconsistency between the actual air and the information in the programme guide.

	Symptom	Things to check
Recording / Timer programming	Unable to record.	<ul style="list-style-type: none"> Is the title copy-protected? Is the programme record-prohibited? Is there enough capacity on the recording media? If no, delete unnecessary titles or use another recording media. The recording media may have reached the maximum number of titles?. In this case, delete unnecessary titles or use another recording media. Is the antenna connection made properly?
	Unable to record to the disc.	<ul style="list-style-type: none"> Use a recordable disc. This unit is unable to record directly to a DVD-RW / -R disc and +RW / +R disc. (Dubbing to the disc is possible.) This unit may be unable to make additional recording to a disc which is recorded on another device. Recording may fail if the disc is scratched or dirty. Is the disc protected or finalised?
	Unable to record from another device, such as the cable tv's set-top box / VCR, etc.	<ul style="list-style-type: none"> Is this unit switched to the external input (AV)? Is the connected device turned on? Are the cables / cords connected to the correct terminals (including input / output)? Direct recording from the external input (AV) to a USB-HDD is not possible. (Dubbing from the HDD to a USB-HDD is possible.)
	Unable to programme a timer recording / Programmed timer recording failed.	<ul style="list-style-type: none"> If a timer programme is set to skip, it will not be recorded. If a power outage occurs, a timer recording may not be performed properly. If the unit is in the process which cannot be interrupted, such as finalising / formatting a disc, downloading a software update, a timer recording cannot be performed.
	The recorded title cuts before the programme ends.	<ul style="list-style-type: none"> Do multiple timer programmes overlap? This also happens when the end time of the earlier programme and the start time of the latter programme are exactly the same.
	Unable to perform a dual recording.	<ul style="list-style-type: none"> This unit is unable to perform a dual recording (both programmes) simultaneously to one disc / USB-HDD.
	Unable to record to a USB-HDD.	<ul style="list-style-type: none"> Is the USB-HDD connected to the unit recordable? The USB-HDD formatted on another device is not compatible with this unit. Is the USB-HDD not protected? Direct recording from the external input (AV) to a USB-HDD is not possible. (Dubbing from the HDD to a USB-HDD is possible.)
Playback	Unable to play back a disc.	<ul style="list-style-type: none"> Is the TV switched to the correct source input which is associated with this unit? Is the disc compatible with this unit? Is the disc a blank disc? Is the disc placed upside-down? This unit may not play back a disc recorded on another recorder or PC. This unit cannot play back an unfinalised DVD-RW (Video) / DVD-R (Video) disc recorded on another recorder. Some discs may not be playable depending on the recording conditions, the specifications of the disc or due to scratches / dirt on the disc. Confirm BD / DVD-Video rating level in "Settings" > "Playback" > "BD Rating Level" or "DVD Rating Level".
	Playback does not start from the beginning of the title.	<ul style="list-style-type: none"> Select "Play From Start" in the sub menu.
	The picture and audio stops momentarily.	<ul style="list-style-type: none"> This happens when the playback shifts from the first layer to the second layer of the disc.
	The screen aspect does not seem correct.	<ul style="list-style-type: none"> Is the setting in "Settings" > "Video/Audio" > "TV Aspect" is set to the correct aspect? When the DVD disc has the specific screen aspect setting (e.g. 4:3, 16:9 LB, 16:9 PS), the pictures may be displayed in a different aspect from the TV.
	Unable to see an analog Video picture while playing back a Blu-ray disc.	<ul style="list-style-type: none"> According to the AACS copy protection rule, analog Video output is prohibited while playing a BD disc. If you want to see the BD disc, please connect an HDMI cable to the TV.

	Symptom	Things to check
Playback (Cont'd)	During playback, the images are distorted / discoloured.	<ul style="list-style-type: none"> The images may be distorted during fast forward / fast reverse. Is the unit connected directly to the TV? If connected via a VCR, playback may not operate properly due to the copy guard. Electric waves from a cell-phone and other devices near this unit may cause distortion of images.
	DVD stops playback on its own.	<ul style="list-style-type: none"> Some DVD's have a pause signal which automatically stops playback.
	Audio is not output / Subtitles are not displayed.	<ul style="list-style-type: none"> For connected devices (e.g. AV amplifier), confirm the following. <ul style="list-style-type: none"> Is the connected device turned on? Is the IN/OUT switch of the connected device selected correctly? Are the cables / cords connected to the correct terminals (including input / output)? Is the "Video/Audio" setting in "Settings" set correctly based on the capability of the connected device? The selected subtitle language must be included on the disc.
	When playing back a title recorded from the external input (AV), it outputs 2 mixed audio.	<ul style="list-style-type: none"> Before recording, change the setting in "Settings" > "Recording" > "External Input Audio" > "Stereo" to "Bilingual".
	Unable to switch the dual audio of digital audio.	<ul style="list-style-type: none"> When "Settings" > "Video/Audio" > "Dolby D / Dolby D+ / Dolby TrueHD" / "DTS / DTS-HD" or "MPEG" is set to "Bitstream" and the audio is output from DIGITAL OUT (OPTICAL), the audio is not switchable. In this case, change the setting from "Bitstream" to "PCM".
	Unable to switch the audio language and subtitle language when playing back a disc.	<ul style="list-style-type: none"> Does the disc contain multiple languages? Some discs let you switch the audio language and subtitle language using the disc menu. Refer to the manual of the disc for how to operate.
	Unable to switch the camera angles	<ul style="list-style-type: none"> This function is only available in the scenes with multiple angles.
For a title recorded in other than TS mode, "TS→XX" (e.g. TS→AE) is displayed.	<ul style="list-style-type: none"> All direct recordings are performed in TS mode. In the case of "TS→AE", it means the title was recorded in TS mode and it will be converted to AE mode after the unit goes standby. Recording mode conversion will be performed in the order of older to newer titles in the contents list. 	
Title deletion / Editing / Dubbing	Unable to delete a title / Unable to edit a title / chapter marks / disc.	<ul style="list-style-type: none"> If the title / media is protected, it is not possible to delete or edit. Cancel protection on the media before editing. For a finalised disc, title deletion / editing is not possible. For a title to be converted to a different recording mode, title dividing / title protecting is not possible. If a USB-HDD contains a title which is waiting to be converted, this USB-HDD cannot be protected.
	Unable to add a chapter.	<ul style="list-style-type: none"> The number of chapters may have reached the maximum number for the media. In this case, delete unnecessary chapter marks.
	Disc capacity will not increase after deleting some titles.	<ul style="list-style-type: none"> For BD-R / DVD-R / DVD+R discs, title deletion will not increase the disc capacity.
	Unable to redo title deletion / dividing.	<ul style="list-style-type: none"> Deleted / divided titles cannot be undone. Make sure the title is the correct one when editing.
	The disc finalised on this unit cannot be played on another DVD player.	<ul style="list-style-type: none"> Some DVD players cannot play back a disc finalised on this unit.
	Unable to undo finalisation.	<ul style="list-style-type: none"> This unit can only undo finalisation on DVD-RW (VR) finalised on this unit.
	Unable to dub a disc.	<ul style="list-style-type: none"> Most commercially available video discs are protected with a copy guard. It is not possible to dub such discs. Unfinalised DVD-RW (Video) / DVD-R (Video) discs recorded on another recorder cannot be dubbed. This unit may be unable to dub the disc if it is scratched and dirty. This unit may be unable to dub the disc if it is formatted on another recorder. To dub a protected copy-once title, cancel protection first.
	After dubbing, the original title will be deleted.	<ul style="list-style-type: none"> For copy-once titles, the title will be dubbed as "move" to another media and the original title on the source media will be deleted.
The subtitles will not be dubbed.	<ul style="list-style-type: none"> Set "Settings" > "Recording" > "Subtitle Recording" to "On". With this setting, the subtitles will be burned in the images and it cannot be turned "On" / "Off". 	

Symptom		Things to check
USB-HDD	The USB-HDD is not usable.	<ul style="list-style-type: none"> Turn on the USB-HDD first, then turn on this unit. Connect the USB-HDD securely to this unit and configured it properly. A newly connected USB-HDD needs to be registered to this unit before using.
	Unable to record to the USB-HDD.	<ul style="list-style-type: none"> The USB-HDD may be full. If that is the case, dub some titles to the internal HDD or delete some titles to make room for the new recording.
	The titles stored on the USB-HDD disappeared.	<ul style="list-style-type: none"> If a power failure occurs (e.g. lightning, unplugging the AC cord, the circuit breaker was thrown, etc.), the contents on the USB-HDD may disappear. If this happens and/or the USB-HDD became inoperable, reregister the USB-HDD.
	The programme that was supposed to be recorded to the USB-HDD was recorded to the internal HDD.	<ul style="list-style-type: none"> Confirm that the USB-HDD is connected securely to this unit and turned on. Make sure that the USB-HDD is registered to this unit. There are cases, depending on the connected device, that programmed timer recordings will be performed to the HDD (alternate recording) if a power outage occurs.
	The titles on the USB-HDD cannot be played back.	<ul style="list-style-type: none"> After recording, the USB-HDD may have been unregistered. If unregistered, the titles on the USB-HDD will be unplayable. When reregistering the USB-HDD, it will be formatted.
SIMPLINK	The SIMPLINK functions do not operate.	<ul style="list-style-type: none"> The SIMPLINK functions are only available when connecting this unit and LG's SIMPLINK compatible TV with an HDMI cable and the SIMPLINK setting on both devices is completed. The SIMPLINK functions will no longer be effective if this unit's AC cord or HDMI cable is unplugged. To restore the settings, connect the AC cord and HDMI cable securely to this unit, switch the TV's external source input to this unit, or set "Settings" > "HDMI" > "SIMPLINK" to "Off", then set it "On" again.
Remote control	The remote control does not operate .	<ul style="list-style-type: none"> Are the batteries in the remote control still good?
	The HDD is not operable.	<ul style="list-style-type: none"> Is the "HDD" on the front panel lighted? If no, press [HDD].
	The disc is not operable.	<ul style="list-style-type: none"> Is the "DISC" on the front panel lighted? If no, press [DISC].
	The USB-HDD is not operable.	<ul style="list-style-type: none"> Is the "USB" on the front panel lighted? If no, press [USB].
	The TV is not operable.	<ul style="list-style-type: none"> Are the batteries in the remote control still good? If the batteries are exhausted, only TV control may become inoperable.
Others	A lot of noise is generated from inside this unit's cabinet.	<ul style="list-style-type: none"> While downloading the EPG data and software update, this unit may generate noise. When high-speed dubbing and the cooling fan is spinning fast, this unit may generate more noise than usual.
	The password for "BD Rating Level" / "DVD Rating Level" or the PIN Code for "Parental Control" is forgotten.	<ul style="list-style-type: none"> For "BD Rating Level" / "DVD Rating Level", go to "Home Menu" > "Settings" > "Playback", then highlight either "BD Rating Level" or "DVD Rating Level", then enter "210499" using [number buttons]. For "Parental Control", go to "Home Menu" > "DTV Menu", "Parental Control", then highlight "Channel Lock" or "DTV Rating", then enter "210499" using [number buttons].

If a following message appears...

	Message example	Meaning / what to do
Overall operations	⊘ This device will be powered off soon by auto off function.	<ul style="list-style-type: none"> Currently, the operation is prohibited. Because "Auto Standby" is set to "On", this unit will be powered off shortly. Any operation will cancel the auto-standby function this time. If you wish to turn off the function, set "Settings" > "Others" > "Auto Standby" to "Off".
	You cannot operate this during dubbing.	<ul style="list-style-type: none"> Because a dubbing is being performed, the operation is currently not available.
	Please insert the valid disc.	<ul style="list-style-type: none"> Although a timer recording to a disc will start shortly, a recordable disc is not found in the unit. Check the disc.
	Please connect valid USB-HDD.	<ul style="list-style-type: none"> Although a timer recording to a USB-HDD will start shortly, a recordable USB-HDD is not found. Please check the USB-HDD.
Disc / USB device	Please eject the disc. Playback feature may not be available on this Disc.	<ul style="list-style-type: none"> The disc may be unsupported or scratched and dirty. Remove the disc and check the disc.
	Region Error Playback is not authorized in your region.	<ul style="list-style-type: none"> The region code of the disc does not correspond to this unit. Eject the disc.
	Abnormality occurred in USB connection. USB device has been stopped automatically.	<ul style="list-style-type: none"> The USB device has a problem during playback / slide show or while dubbing the contents. Disconnect the USB device.
	Cannot find USB-HDD, Or USB-HDD which cannot be recorded in this device is connected.	<ul style="list-style-type: none"> This unit cannot recognise the USB-HDD. Check the USB-HDD. Recognisable USB-HDD's are from 64 GB to 4 TB.
Recording	It was not completed properly because of an error.	<ul style="list-style-type: none"> An error occurred and the recording was interrupted. It may be caused by a malfunction of the HDD or scratches and dirt on the disc.
	You cannot record because it is prohibited to record.	<ul style="list-style-type: none"> The programme is record-prohibited.
	Cancel recording because of insufficient capacity	<ul style="list-style-type: none"> The recording was cancelled because the recording media became full.
	The recording time exceeded 8 hours. Recording was stopped.	<ul style="list-style-type: none"> The maximum duration of one title is 8 hours.
Timer programming	Built-in HDD does not have enough space to record. If space is not ensured when you record, at the end of the programme cannot be recorded.	<ul style="list-style-type: none"> There is not enough capacity on the HDD / USB-HDD / disc to complete a recording. Press [⊙ ENTER], then check the capacity of the recording media.
	Remaining capacity of disc is not enough. If space is not ensured when you record, a programme will be recorded on HDD if the HDD has enough space.	
	Remaining capacity of the USB-HDD is not enough, If space is not ensured when you record, a programme will be recorded on HDD if the HDD has enough space.	
Deletion / editing / dubbing	It was not completed properly because of an error.	<ul style="list-style-type: none"> The disc may be scratched or dirty. Press [⊙ ENTER] to close the message window, then eject the disc and check the disc.
	The title is protected / This title is not dubbed as this disc is protected.	<ul style="list-style-type: none"> Cancel disc protection.
	This title can be registered only once.	<ul style="list-style-type: none"> A title which will be dubbed as "move" can be registered to the dubbing list only once.
	Cannot add title. Limit exceeded.	<ul style="list-style-type: none"> The dubbing list is full. The maximum number of titles in the dubbing list is 36 titles.
	Exceeds 8 hours	<ul style="list-style-type: none"> A title longer than 8 hours cannot be dubbed.
Display panel	Disc is full. Cannot dub to this disc.	<ul style="list-style-type: none"> The total data size of the dubbing titles exceeds the available capacity of the dubbing media. Try to dub less titles or prepare a larger dubbing media.
	⬇	<ul style="list-style-type: none"> "⬇" and "UPDATE" indicate that this unit is downloading a software update. Do not turn off the unit until an update is completed. "⬇" may be displayed while organising the system data.
	WAIT	<ul style="list-style-type: none"> This unit is in a process of system configuration and not operable. The unit will become operable after the indicator disappears.

Glossary

AAC (Advanced Audio Coding)

A lossy compression and encoding scheme for digital audio. Audio files which have been encoded with AAC generally achieve better sound quality than MP3 at similar bit rates.

AACS (Advanced Access Content System)

A content protection scheme used with Blu-ray Disc™.

AVCHD

AVCHD is a new format for high definition video camcorders which can record and play high-resolution HD images.

BD-J

Some BD-Video discs contain Java application software called BD-J, which enables various interactive functions other than normal content playback.

BD-Live™

BD-ROM version 2 Profile 2.0, which contains new functions (e.g. Internet connection), in addition to the BONUSVIEW™ function.

Bit rate

The amount of data of audio / video conveyed or processed per second.

Bitstream

Audio signal which is compressed and converted to a digital signal. It is converted to a compatible audio signal according to the capability of the audio amplifier.

Chapter

Just as a book is split up into several chapters, a title on a BD-Video or DVD-Video disc is usually divided into chapters. See also "Title".

Copy protection

The function for prevention of unauthorised copying of broadcast programmes and video materials. For this reason, this unit does not record broadcast programmes and videos with an embedded copy-protection signal.

Copy-once broadcast

Digital broadcast programmes which allow you to record only once for the copyright protection and prevention of unauthorised copying. When a copy-once broadcast programme is recorded then copied to another storage device, the programme moves to the destination device, and will be deleted from the original device.

CPRM (Content Protection for Recordable Media)

Copyright protection technology for the copy-once broadcast programmes. To record copy-once programmes and/or the dubbing-ten programmes to a DVD, a CPRM compatible disc is needed.

Deep Colour

Deep colour reproduces more realistic colours without colour banding than the traditional 8-bit colour system.

DivX®

DivX® is a codec (compression / decompression) which can compress images to a very small amount of data. The software can compress video data from almost any devices to the size that can be sent on the Internet without dropping visual quality of the images.

Dolby Digital Plus

The next generation digital audio compression technology developed as an extension to Dolby Digital. Blu-ray Disc™ supports 7.1 multi-channel surround sound output.

Dolby Digital

A method to compress digital sound developed by Dolby Laboratories. It offers you stereo sound (2ch) or multi-channel audio.

DRC (Dynamic Range Control)

Dynamic range is audio level differences between the minimum and maximum level in the audio source of a title recorded in the Dolby Digital format. DRC makes it easier to hear audio at a lower volume while viewing a movie at night.

EPG

Electronic Programme Guide.

Finalising

The process to make BD-R, DVD-RW/-R and DVD+RW/+R discs recorded on this unit, compatible with other players.

GB (Gigabyte)

A unit for the capacity of storage devices and recording media, such as HDD's / USB-HDD's / USB memory sticks / discs (Blu-ray™ / DVD).

HD quality

The picture quality of High-Definition digital broadcasting. The effective scan lines of the screen is 720 or 1080. HD digital broadcasting enables higher picture and sound quality than SD (Standard-Definition) broadcasting.

HDD (Hard Disk Drive)

Large capacity data storage device used in digital video recorders, PC's, etc. HDD is able to read and write data quickly, with high retrieval performance. This unit is equipped with an internal HDD (You cannot replace the internal HDD on your own).

HDMI (High-Definition Multimedia Interface)

A digital interface between an audio and video source. It can transmit component video, audio and control signal with one cable connection.

Initialisation (formatting)

This process initialises a recordable disc to be ready for this unit or to change the recording method.

Interlace scanning (576i)

The process of building an image from two fields, which has been used by the majority of televisions. The first field consists of the odd numbered scan lines and the second field even numbered lines. This process displays an image at the frame rate of 25 frames per second.

JPEG (Joint Photographic Experts Group)

A method of compressing still picture files. You can copy JPEG files on BD-RE / -R, DVD-RW / -R, DVD+RW / +R, CD-RW / -R or a USB memory stick from a computer and play back the files on this unit.

Letterbox

A method to fit the wide screen (16:9) images in a standard-definition television screen (4:3), keeping the aspect ratio by adding black bars on both the top and bottom of the television screen.

Linear PCM (Linear Pulse Code Modulation)

A method to record digital audio without compression.

MP3 (MPEG audio layer 3)

MP3 is a method of compressing files. You can copy MP3 files on BD-RE / -R, DVD-RW / -R, DVD+RW / +R, CD-RW / -R, or USB memory stick from the computer and play back the files on this unit.

MPEG, MPEG-2, MPEG-4 AVC/H.264

MPEG stands for Moving Picture Experts, which is the international standard of video / audio compression. MPEG-2 is used to record materials for DVD's. MPEG-4 AVC/H.264 is used to record High-Definition materials.

Pan & scan

A method to fit the wide screen (16:9) images in a standard-definition television screen (4:3), keeping the aspect ratio by cropping both the left and right sides of the original images.

Parental level

Setting in digital broadcast programmes and video materials which makes it possible to control the types of viewable scenes. This function prevents children from viewing violent scenes and such.

Progressive scanning (576p)

As opposed to interlace scanning, this process displays 576 scan lines at a time at the frame rate of 50 frames per second. Progressive scanning enables denser and less flickering images than interlace scanning.

Region code

Region associated discs and players with the particular areas of the world. This unit will only play discs with the compatible region code. The region code of this unit may be found on the rear panel. Some discs are compatible with more than one region or all regions.

Resume playback

This unit memorises where you stopped playback, so you can continue from where you left off.

SD quality

The quality of the Standard-Definition digital broadcasting. The effective scan lines of the screen is 576.

SIMPLINK

It enables the integrated system control between this unit and an LG television.

Title

A collection of chapters on BD-video or DVD-video. See also "Chapter".

Track

Audio CD uses tracks to divide up the content of a disc. The BD-Video or DVD-Video equivalent is called a Chapter. See also "Chapter".

USB (Universal Serial Bus)

An interface to connect electronic devices. For this unit, USB is used to connect to a digital camcorder / digital camera to view JPEG photos on your television screen and retrieve High-Definition movies (recorded in the AVCHD format) from a camcorder.

VBR (Variable Bit Rate)

A recording method which controls the amount of data in a recording by detecting the differences in the speed of motions in the content. This technology makes the recorder record more efficiently and produce smaller movie files.

Virtual Package

The function which copies data to other media (local storage) from the Internet and plays the secondary video, secondary audio and subtitles at the same time. The method of the playback varies depending on the disc.

WMA (Windows Media™ Audio)

Windows Media™ Audio is the audio compressing technology developed by Microsoft. You can copy Windows Media™ Audio files on BD-RE / -R, DVD-RW / -R, DVD+RW / +R, CD-RW / -R, or USB memory stick from a computer and play back on this unit.

Specifications

General

HDD	1 TB (BR629T) / 500 GB (BR625T)
Power requirements	220 – 240 V ± 10 %, 50 Hz ± 0.5 %
Power consumption	31 W (BR629T) / 27 W (BR625T)
Weight	3.0 kg (BR629T) / 2.7 kg (BR625T)
Dimensions (width x height x depth)	430.3 x 53.2 x 262.5 mm
Operating temperature	5°C to 40°C
Operating humidity	Less than 80% (no condensation)
TV system	DVB-T Standard Compliant

Recording

Recording format	BDAV format (BD-RE, BD-R), Video Recording (VR) format (DVD-RW only), video format (DVD-RW, DVD-R), +VR format (DVD+RW, DVD+R)
Recordable discs	BD-RE, BD-R, DVD-ReWritable, DVD-Recordable, DVD+ReWritable, DVD+Recordable

Video recording format

Compression format	MPEG-2, MPEG-4 AVC(H.264)
--------------------	---------------------------

Audio recording format

Sampling frequency	48 kHz
Compression format	Dolby Digital Linear PCM (XP mode) Dolby Digital Plus (TS mode) MPEG (TS mode) AAC(TS mode) HE-AAC(TS mode)

Tuner

DVB-T channels

VHF Band III	6 - 12 ch
UHF Band IV	27 - 35 ch
UHF Band V	36 - 69 ch

Input / Output

Front Panel:

USB port (TYPE A)	USB 2.0 (DC 5 V Max 500 mA)
-------------------	------------------------------

Rear Panel:

VHF / UHF antenna input / output terminal	75 Ω
Audio input /output	Two RCA connectors each
Video input /output	One RCA connector each
Input /output level	1 Vp-p (75 Ω) each
Audio output	Two RCA connectors
Output level	2 Vrms (output impedance less than 1 KΩ)
Video output	One RCA connector
Output level	1 Vp-p (75 Ω)
Digital audio output	One Optical jack
HDMI output	HDMI Jack
LAN terminal	10 BASE-T / 100 BASE-TX

! Note

- The specifications and design of this product are subject to change without notice.

Maximum number of titles / chapters / characters

The actual number which a media can contain may be smaller than the numbers shown here depending on the contents and for other reasons.

For HDD / USB-HDD

Titles: 2,000
Chapters per title: 999

For BD-RE / BD-R disc

Titles: 200
Chapters per title: 100
Chapters per disc: 999

For DVD-RW (VR)

Titles: 99
Chapters per disc: 999

For DVD-RW (Video) / DVD-R (Video)

Titles: 36
Chapters per title: 99

For DVD+RW (+VR) / DVD+R (+VR)

Titles: 49
Chapters per title: 99
Chapters per disc: 254

Others

Timer programmes: 100
Titles in the dubbing list: 36
Maximum duration of a recording title: 8 hours
Title name / disc name: Up to 60 characters*

* For DVD-RW (Video) / DVD-R (Video), up to 30 characters for a title name, up to 60 characters for a disc name.

License

This section describes software license used for this product. This product uses some open source software:

Program name	EULA
linux	Exhibit A
busybox	Exhibit A
dhcpcd	Exhibit A
directfb	Exhibit B
glibc	Exhibit B
gmp	Exhibit B
liexif	Exhibit B

Program name	EULA
FLAC	Exhibit C
Tremor	Exhibit C
Oniguruma	Exhibit C
universalchardet	Exhibit D

Program name	EULA
expat	Exhibit E
giflib	Exhibit E
libxml2	Exhibit E
cURL	Exhibit E
Free Type	Exhibit F
LibJPEG	Exhibit F
Open SSL	Exhibit F
Vera Fonts	Exhibit F
TIFF	Exhibit F

- Reverse engineering, disassembling, decompiling, dismantling, or otherwise attempting to analyse or modify the software included in this product is prohibited.

Exhibit A

GPL

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public

Continued on next page

License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the

same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.
5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.
6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.
7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.
9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.
10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.
12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO

OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and a brief idea of what it does.>

Copyright (C) <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'. This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details.

The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicks or menu items—whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program `Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon>, 1 April 1989

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

Exhibit B

LGPL

GNU LESSER GENERAL PUBLIC LICENSE Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc. 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages—typically libraries—of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

GNU LESSER GENERAL PUBLIC LICENSE
TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

Continued on next page

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- The modified work must itself be a software library.
- You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.
- You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.
- If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.

(For example, a function in a library to compute square roots has a purpose that is entirely welldefined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2)

in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the Library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

- Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)
- Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.

- Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.

- If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.

- Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.

b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF

MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General

Public License).

To apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

```
<one line to give the library's name and a brief idea of what it does.> Copyright (C)
<year> <name of author>
```

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

Also add information on how to contact you by electronic and paper mail.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the library, if necessary. Here is a sample; alter the names:

Yoodyne, Inc., hereby disclaims all copyright interest in the library 'Frob' (a library for tweaking knobs) written by James Random Hacker.

```
<signature of Ty Coon>, 1 April 1990
Ty Coon, President of Vice
```

That's all there is to it!

Exhibit C

BSD

Copyright (c) 2002, Xiph.org Foundation

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

- Neither the name of the Xiph.org Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Exhibit D

MPL

MOZILLA PUBLIC LICENSE

Version 1.1

1. Definitions.

1.0.1. "Commercial Use" means distribution or otherwise making the Covered Code available to a third party.

1.1. "Contributor" means each entity that creates or contributes to the creation of Modifications.

1.2. "Contributor Version" means the combination of the Original Code, prior Modifications used by a Contributor, and the Modifications made by that particular Contributor.

1.3. "Covered Code" means the Original Code or Modifications or the combination of the Original Code and Modifications, in each case including portions thereof.

1.4. "Electronic Distribution Mechanism" means a mechanism generally accepted in the software development community for the electronic transfer of data.

1.5. "Executable" means Covered Code in any form other than Source Code.

1.6. "Initial Developer" means the individual or entity identified as the Initial Developer in the Source Code notice required by Exhibit A.

1.7. "Larger Work" means a work which combines Covered Code or portions thereof with code not governed by the terms of this License.

1.8. "License" means this document.

1.8.1. "Licensable" means having the right to grant, to the maximum extent possible, whether at the time of the initial grant or subsequently acquired, any and all of the rights conveyed herein.

1.9. "Modifications" means any addition to or deletion from the substance or structure of either the Original Code or any previous Modifications. When Covered Code is released as a series of files, a Modification is:

A. Any addition to or deletion from the contents of a file containing Original Code or previous Modifications.

B. Any new file that contains any part of the Original Code or previous Modifications.

1.10. "Original Code" means Source Code of computer software code which is described in the Source Code notice required by Exhibit A as Original Code, and which, at the time of its release under this License is not already Covered Code governed by this License.

1.10.1. "Patent Claims" means any patent claim(s), now owned or hereafter acquired, including without limitation, method, process, and apparatus claims, in any patent Licensable by grantor.

1.11. "Source Code" means the preferred form of the Covered Code for making modifications to it, including all modules it contains, plus any associated interface definition files, scripts used to control compilation and installation of an Executable, or source code differential comparisons against either the Original Code or another well known, available Covered Code of the Contributor's choice. The Source Code can be in a compressed or archival form, provided the appropriate decompression or de-archiving software is widely available for no charge.

1.12. "You" (or "Your") means an individual or a legal entity exercising rights under,

and complying with all of the terms of, this License or a future version of this License issued under Section 6.1. For legal entities, "You" includes any entity which controls, is controlled by, or is under common control with You. For purposes of this definition, "control" means (a) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (b) ownership of more than fifty percent (50%) of the outstanding shares or beneficial ownership of such entity.

2. Source Code License.

2.1. The Initial Developer Grant.

The Initial Developer hereby grants You a world-wide, royalty-free, non-exclusive license, subject to third party intellectual property claims:

(a) under intellectual property rights (other than patent or trademark) Licensable by Initial Developer to use, reproduce, modify, display, perform, sublicense and distribute the Original Code (or portions thereof) with or without Modifications, and/or as part of a Larger Work; and

(b) under Patents Claims infringed by the making, using or selling of Original Code, to make, have made, use, practice, sell, and offer for sale, and/or otherwise dispose of the Original Code (or portions thereof).

(c) the licenses granted in this Section 2.1(a) and (b) are effective on the date Initial Developer first distributes Original Code under the terms of this License.

(d) Notwithstanding Section 2.1(b) above, no patent license is granted: 1) for code that You delete from the Original Code; 2) separate from the Original Code; or 3) for infringements caused by: i) the modification of the Original Code or ii) the combination of the Original Code with other software or devices.

2.2. Contributor Grant.

Subject to third party intellectual property claims, each Contributor hereby grants You a world-wide, royalty-free, non-exclusive license

(a) under intellectual property rights (other than patent or trademark) Licensable by Contributor, to use, reproduce, modify, display, perform, sublicense and distribute the Modifications created by such Contributor (or portions thereof) either on an unmodified basis, with other Modifications, as Covered Code and/or as part of a Larger Work; and

(b) under Patent Claims infringed by the making, using, or selling of Modifications made by that Contributor either alone and/or in combination with its Contributor Version (or portions of such combination), to make, use, sell, offer for sale, have made, and/or otherwise dispose of: 1) Modifications made by that Contributor (or portions thereof); and 2) the combination of Modifications made by that Contributor with its Contributor Version (or portions of such combination).

(c) the licenses granted in Sections 2.2(a) and 2.2(b) are effective on the date Contributor first makes Commercial Use of the Covered Code.

(d) Notwithstanding Section 2.2(b) above, no patent license is granted: 1) for any code that Contributor has deleted from the Contributor Version; 2) separate from the Contributor Version; 3) for infringements caused by: i) third party modifications of Contributor Version or ii) the combination of Modifications made by that Contributor with other software (except as part of the Contributor Version) or other devices; or 4) under Patent Claims infringed by Covered Code in the absence of Modifications made by that Contributor.

3. Distribution Obligations.

3.1. Application of License.

The Modifications which You create or to which You contribute are governed by the terms of this License, including without limitation Section 2.2. The Source Code version of Covered Code may be distributed only under the terms of this License or a future version of this License released under Section 6.1, and You must include a copy of this License with every copy of the Source Code You distribute. You may not offer or impose any terms on any Source Code version that alters or restricts the applicable version of this License or the recipients' rights hereunder. However, You may include an additional document offering the additional rights described in Section 3.5.

3.2. Availability of Source Code.

Any Modification which You create or to which You contribute must be made available in Source Code form under the terms of this License either on the same media as an Executable version or via an accepted Electronic Distribution Mechanism to anyone to whom you made an Executable version available; and if made available via Electronic Distribution Mechanism, must remain available for at least twelve (12) months after the date it initially became available, or at least six (6) months after a subsequent version of that particular Modification has been made available to such recipients. You are responsible for ensuring that the Source Code version remains available even if the Electronic Distribution Mechanism is maintained by a third party.

3.3. Description of Modifications.

You must cause all Covered Code to which You contribute to contain a file documenting the changes You made to create that Covered Code and the date of any change.

You must include a prominent statement that the Modification is derived, directly or indirectly, from Original Code provided by the Initial Developer and including the name of the Initial Developer in (a) the Source Code, and (b) in any notice in an Executable version or related documentation in which You describe the origin or ownership of the Covered Code.

3.4. Intellectual Property Matters

(a) Third Party Claims.

If Contributor has knowledge that a license under a third party's intellectual property rights is required to exercise the rights granted by such Contributor under Sections 2.1 or 2.2, Contributor must include a text file with the Source Code distribution titled "LEGAL" which describes the claim and the party making the claim in sufficient detail that a recipient will know whom to contact. If Contributor obtains such knowledge after the Modification is made available as described in Section 3.2, Contributor shall promptly modify the LEGAL file in all copies Contributor makes available thereafter and shall take other steps (such as notifying appropriate mailing lists or newsgroups) reasonably calculated to inform those who received the Covered Code that new knowledge has been obtained.

(b) Contributor APIs.

If Contributor's Modifications include an application programming interface and Contributor has knowledge of patent licenses which are reasonably necessary to implement that API, Contributor must also include this information in the LEGAL file.

(c) Representations.

Contributor represents that, except as disclosed pursuant to Section 3.4(a) above, Contributor believes that Contributor's Modifications are Contributor's original creation(s) and/or Contributor has sufficient rights to grant the rights conveyed by this License.

3.5. Required Notices.

You must duplicate the notice in Exhibit A in each file of the Source Code. If it is not possible to put such notice in a particular Source Code file due to its structure, then You must include such notice in a location (such as a relevant directory) where a user would be likely to look for such a notice. If You created one or more Modification(s) You may add your name as a Contributor to the notice described in Exhibit A. You must also duplicate this License in any documentation for the Source Code where You describe recipients' rights or ownership rights relating to Covered Code. You may choose to offer, and to charge a fee for, warranty, support, indemnity or liability obligations to one or more recipients of Covered Code. However, You may do so only on Your own behalf, and not on behalf of the Initial Developer or any Contributor. You must make it absolutely clear that any such warranty, support, indemnity or liability obligation is offered by You alone, and You hereby agree to indemnify the Initial Developer and every Contributor for any liability incurred by the Initial Developer or such Contributor as a result of warranty, support, indemnity or liability terms You offer.

3.6. Distribution of Executable Versions.

You may distribute Covered Code in Executable form only if the requirements of Section 3.1-3.5 have been met for that Covered Code, and if You include a notice stating that the Source Code version of the Covered Code is available under the terms of this License, including a description of how and where You have fulfilled the obligations of Section 3.2. The notice must be conspicuously included in any notice in an Executable version, related documentation or collateral in which You describe recipients' rights relating to the Covered Code. You may distribute the Executable version of Covered Code or ownership rights under a license of Your choice, which may contain terms different from this License, provided that You are in compliance with the terms of this License and that the license for the Executable version does not attempt to limit or alter the recipient's rights in the Source Code version from the rights set forth in this License. If You distribute the Executable version under a different license You must make it absolutely clear that any terms which differ from this License are offered by You alone, not by the Initial Developer or any Contributor. You hereby agree to indemnify the Initial Developer and every Contributor for any liability incurred by the Initial Developer or such Contributor as a result of any such terms You offer.

3.7. Larger Works.

You may create a Larger Work by combining Covered Code with other code not governed by the terms of this License and distribute the Larger Work as a single product. In such a case, You must make sure the requirements of this License are fulfilled for the Covered Code.

4. Inability to Comply Due to Statute or Regulation.

If it is impossible for You to comply with any of the terms of this License with respect to some or all of the Covered Code due to statute, judicial order, or regulation then You must: (a) comply with the terms of this License to the maximum extent possible; and (b) describe the limitations and the code they affect. Such description must be included in the LEGAL file described in Section 3.4 and must be included with all distributions of the Source Code. Except to the extent prohibited by statute or regulation, such description must be sufficiently detailed for a recipient of ordinary skill to be able to understand it.

5. Application of this License.

This License applies to code to which the Initial Developer has attached the notice in Exhibit A and to related Covered Code.

6. Versions of the License.

6.1. New Versions.

Netscape Communications Corporation ("Netscape") may publish revised and/or new versions of the License from time to time. Each version will be given a distinguishing version number.

6.2. Effect of New Versions.

Once Covered Code has been published under a particular version of the License, You may always continue to use it under the terms of that version. You may also choose to use such Covered Code under the terms of any subsequent version of the License published by Netscape. No one other than Netscape has the right to modify the terms applicable to Covered Code created under this License.

6.3. Derivative Works.

If You create or use a modified version of this License (which you may only do in order to apply it to code which is not already Covered Code governed by this License), You must (a) rename Your license so that the phrases "Mozilla", "MOZILLAPL", "MOZPL", "Netscape", "MPL", "NPL" or any confusingly similar phrase do not appear in your license (except to note that your license differs from this License) and (b) otherwise make it clear that Your version of the license contains terms which differ from the Mozilla Public License and Netscape Public License. (Filling in the name of the Initial Developer, Original Code or Contributor in the notice described in Exhibit A shall not of themselves be deemed to be modifications of this License.)

7. DISCLAIMER OF WARRANTY.

COVERED CODE IS PROVIDED UNDER THIS LICENSE ON AN "AS IS" BASIS, WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, WARRANTIES THAT THE COVERED CODE IS FREE OF DEFECTS, MERCHANTABILITY, FIT FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE COVERED CODE IS WITH YOU. SHOULD ANY COVERED CODE PROVE DEFECTIVE IN ANY RESPECT, YOU (NOT THE INITIAL DEVELOPER OR ANY OTHER CONTRIBUTOR) ASSUME THE COST OF ANY NECESSARY SERVICING, REPAIR OR CORRECTION. THIS DISCLAIMER OF WARRANTY CONSTITUTES AN ESSENTIAL PART OF THIS LICENSE. NO USE OF ANY COVERED CODE IS AUTHORIZED HEREUNDER EXCEPT UNDER THIS DISCLAIMER.

8. TERMINATION.

8.1. This License and the rights granted hereunder will terminate automatically if You fail to comply with terms herein and fail to cure such breach within 30 days of becoming aware of the breach. All sublicenses to the Covered Code which are properly granted shall survive any termination of this License. Provisions which, by their nature, must remain in effect beyond the termination of this License shall survive.

8.2. If You initiate litigation by asserting a patent infringement claim (excluding declaratory judgment actions) against Initial Developer or a Contributor (the Initial Developer or Contributor against whom You file such action is referred to as "Participant") alleging that:

(a) such Participant's Contributor Version directly or indirectly infringes any patent, then any and all rights granted by such Participant to You under Sections 2.1 and/or 2.2 of this License shall, upon 60 days notice from Participant terminate prospectively, unless if within 60 days after receipt of notice You either: (i) agree in writing to pay Participant a mutually agreeable reasonable royalty for Your past and future use of Modifications made by such Participant, or (ii) withdraw Your litigation claim with respect to the Contributor Version against such Participant. If within 60 days of notice, a reasonable royalty and payment arrangement are not mutually agreed upon in writing by the parties or the litigation claim is not withdrawn, the rights granted by Participant to You under Sections 2.1 and/or 2.2 automatically terminate at the expiration of the 60 day notice period specified above.

(b) any software, hardware, or device, other than such Participant's Contributor Version, directly or indirectly infringes any patent, then any rights granted to You by such Participant under Sections 2.1(b) and 2.2(b) are revoked effective as of the date You first made, used, sold, distributed, or had made, Modifications made by that Participant.

8.3. If You assert a patent infringement claim against Participant alleging that such Participant's Contributor Version directly or indirectly infringes any patent where such claim is resolved (such as by license or settlement) prior to the initiation of patent infringement litigation, then the reasonable value of the licenses granted by such Participant under Sections 2.1 or 2.2 shall be taken into account in determining the amount or value of any payment or license.

8.4. In the event of termination under Sections 8.1 or 8.2 above, all end user license agreements (excluding distributors and resellers) which have been validly granted by You or any distributor hereunder prior to termination shall survive termination.

9. LIMITATION OF LIABILITY.

UNDER NO CIRCUMSTANCES AND UNDER NO LEGAL THEORY, WHETHER TORT (INCLUDING NEGLIGENCE), CONTRACT, OR OTHERWISE, SHALL YOU, THE INITIAL DEVELOPER, ANY OTHER CONTRIBUTOR, OR ANY DISTRIBUTOR OF COVERED CODE, OR ANY SUPPLIER OF ANY OF SUCH PARTIES, BE LIABLE TO ANY PERSON FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY CHARACTER INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF GOODWILL, WORK STOPPAGE, COMPUTER FAILURE OR MALFUNCTION, OR ANY AND ALL OTHER COMMERCIAL DAMAGES OR LOSSES, EVEN IF SUCH PARTY SHALL HAVE BEEN INFORMED OF THE POSSIBILITY OF SUCH DAMAGES. THIS LIMITATION OF LIABILITY SHALL NOT APPLY TO LIABILITY FOR DEATH OR PERSONAL INJURY RESULTING FROM SUCH PARTY'S NEGLIGENCE TO THE EXTENT APPLICABLE LAW PROHIBITS SUCH LIMITATION. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THIS EXCLUSION AND LIMITATION MAY NOT APPLY TO YOU.

10. U.S. GOVERNMENT END USERS.

The Covered Code is a "commercial item," as that term is defined in 48 C.F.R. 2.101 (Oct. 1995), consisting of "commercial computer software" and "commercial computer software documentation," as such terms are used in 48 C.F.R. 12.212 (Sept. 1995). Consistent with 48 C.F.R. 12.212 and 48 C.F.R. 227.7202-1 through 227.7202-4 (June 1995), all U.S. Government End Users acquire Covered Code with only those rights set forth herein.

11. MISCELLANEOUS.

This License represents the complete agreement concerning subject matter hereof. If any provision of this License is held to be unenforceable, such provision shall be reformed only to the extent necessary to make it enforceable. This License shall be governed by California law provisions (except to the extent applicable law, if any, provides otherwise), excluding its conflict-of-law provisions. With respect to disputes in which at least one party is a citizen of, or an entity chartered or registered to do business in the United States of America, any litigation relating to this License shall be subject to the jurisdiction of the Federal Courts of the Northern District of California, with venue lying in Santa Clara County, California, with the losing party responsible for costs, including without limitation, court costs and reasonable attorneys' fees and expenses. The application of the United Nations Convention on Contracts for the International Sale of Goods is expressly excluded. Any law or regulation which provides that the language of a contract shall be construed against the drafter shall not apply to this License.

12. RESPONSIBILITY FOR CLAIMS.

As between Initial Developer and the Contributors, each party is responsible for claims and damages arising, directly or indirectly, out of its utilization of rights under this License and You agree to work with Initial Developer and Contributors to distribute such responsibility on an equitable basis. Nothing herein is intended or shall be deemed to constitute any admission of liability.

13. MULTIPLE-LICENSED CODE.

Initial Developer may designate portions of the Covered Code as "Multiple-Licensed". "Multiple-Licensed" means that the Initial Developer permits you to utilize portions of the Covered Code under Your choice of the NPL or the alternative licenses, if any, specified by the Initial Developer in the file described in Exhibit A.

EXHIBIT A -Mozilla Public License.

"The contents of this file are subject to the Mozilla Public License Version 1.1 (the "License"); you may not use this file except in compliance with the License. You may obtain a copy of the License at <http://www.mozilla.org/MPL/>

Software distributed under the License is distributed on an "AS IS" basis, WITHOUT WARRANTY OF ANY KIND, either express or implied. See the License for the specific language governing rights and limitations under the License.

The Original Code is _____.

The Initial Developer of the Original Code is _____.

Portions created by _____ are Copyright (C) _____.

_____. All Rights Reserved.

Contributor(s): _____.

Alternatively, the contents of this file may be used under the terms of the _____ license (the "[] License"), in which case the provisions of [] License are applicable instead of those above. If you wish to allow use of your version of this file only under the terms of the [] License and not to allow others to use your version of this file under the MPL, indicate your decision by deleting the provisions above and replace them with the notice and other provisions required by the [] License. If you do not delete the provisions above, a recipient may use your version of this file under either the MPL

or the [] License."

[NOTE: The text of this Exhibit A may differ slightly from the text of the notices in the Source Code files of the Original Code. You should use the text of this Exhibit A rather than the text found in the Original Code Source Code for Your Modifications.]

Exhibit E**MIT**

Copyright (c)

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

expat

Copyright (c) 1998, 1999, 2000 Thai Open Source Software Center Ltd

and Clark Cooper

Copyright (c) 2001, 2002, 2003, 2004, 2005, 2006 Expat maintainers.

giflib

The GIFLIB distribution is Copyright (c) 1997 Eric S. Raymond

libxml2

Except where otherwise noted in the source code (e.g. the files hash.c, list.c and the trio files, which are covered by a similar licence but with different Copyright notices) all the files are:

Copyright (C) 1998-2003 Daniel Veillard. All Rights Reser

cURL

COPYRIGHT AND PERMISSION NOTICE

Copyright (c) 1996 - 2010, Daniel Stenberg, <daniel@haxx.se>.

All rights reserved.

Permission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OF THIRD PARTY RIGHTS. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the name of a copyright holder shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization of the copyright holder.

Exhibit F**Free Type**

The FreeType Project LICENSE

2006-Jan-27

Copyright 1996-2002, 2006 by

David Turner, Robert Wilhelm, and Werner Lemberg

Introduction

The FreeType Project is distributed in several archive packages; some of them may contain, in addition to the FreeType font engine, various tools and contributions which rely on, or relate to, the FreeType Project.

This license applies to all files found in such packages, and which do not fall under their own explicit license. The license affects thus the FreeType font engine, the test programs, documentation and

makefiles, at the very least.

This license was inspired by the BSD, Artistic, and IJG (Independent JPEG Group) licenses, which all encourage inclusion and use of free software in commercial and freeware products alike. As a consequence, its main points are that:

- We don't promise that this software works. However, we will be interested in any kind of bug reports. ('as is' distribution)
• You can use this software for whatever you want, in parts or full form, without having to pay us. ('royalty-free' usage)
• You may not pretend that you wrote this software. If you use it, or only parts of it, in a program, you must acknowledge somewhere in your documentation that you have used the FreeType code. ('credits')

We specifically permit and encourage the inclusion of this software, with or without modifications, in commercial products. We disclaim all warranties covering The FreeType Project and assume no liability related to The FreeType Project.

Finally, many people asked us for a preferred form for a credit/disclaimer to use in compliance with this license. We thus encourage you to use the following text:

====
Portions of this software are copyright© <year> The FreeType Project (www.freetype.org). All rights reserved.
====

Please replace <year> with the value from the FreeType version you actually use.

Legal Terms

0. Definitions

Throughout this license, the terms 'package', 'FreeType Project', and 'FreeType archive' refer to the set of files originally distributed by the authors (David Turner, Robert Wilhelm, and Werner Lemberg) as the 'FreeType Project', be they named as alpha, beta or final release.

'You' refers to the licensee, or person using the project, where 'using' is a generic term including compiling the project's source code as well as linking it to form a 'program' or 'executable'. This program is referred to as 'a program using the FreeType engine'.

This license applies to all files distributed in the original FreeType Project, including all source code, binaries and documentation, unless otherwise stated in the file in its original, unmodified form as distributed in the original archive. If you are unsure whether or not a particular file is covered by this license, you must contact us to verify this.

The FreeType Project is copyright (C) 1996-2000 by David Turner, Robert Wilhelm, and Werner Lemberg. All rights reserved except as specified below.

1. No Warranty

THE FREETYPE PROJECT IS PROVIDED 'AS IS' WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT WILL ANY

OF THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY DAMAGES CAUSED BY THE USE OR THE INABILITY TO USE, OF THE FREETYPE PROJECT.

2. Redistribution

This license grants a worldwide, royalty-free, perpetual and irrevocable right and license to use, execute, perform, compile, display, copy, create derivative works of, distribute and sublicense the FreeType Project (in both source and object code forms) and derivative works thereof for any purpose; and to authorize others to exercise some or all of the rights granted herein, subject to the following conditions:

- Redistribution of source code must retain this license file ('FTL.TXT') unaltered; any additions, deletions or changes to the original files must be clearly indicated in accompanying documentation. The copyright notices of the unaltered, original files must be preserved in all copies of source files.
• Redistribution in binary form must provide a disclaimer that states that the software is based in part of the work of the FreeType Team, in the distribution documentation. We also encourage you to put an URL to the FreeType web page in your documentation, though this isn't mandatory.

These conditions apply to any software derived from or based on the FreeType Project, not just the unmodified files. If you use our work, you must acknowledge us. However, no fee need be paid to us.

3. Advertising

Neither the FreeType authors and contributors nor you shall use the name of the other for commercial, advertising, or promotional purposes without specific prior written permission.

We suggest, but do not require, that you use one or more of the following phrases to refer to this software in your documentation or advertising materials: 'FreeType Project', 'FreeType Engine', 'FreeType library', or 'FreeType Distribution'.

As you have not signed this license, you are not required to accept it. However, as the FreeType Project is copyrighted material, only this license, or another one contracted with the authors, grants you the right to use, distribute, and modify it. Therefore, by using, distributing, or modifying the FreeType Project, you indicate that you understand and accept all the terms of this license.

4. Contacts

There are two mailing lists related to FreeType:

- freetype@nongnu.org Discusses general use and applications of FreeType, as well as future and wanted additions to the library and distribution. If you are looking for support, start in this list if you haven't found anything to help you in the documentation.
• freetype-devel@nongnu.org Discusses bugs, as well as engine internals, design issues, specific licenses, porting, etc.

Our home page can be found at

http://www.freetype.org

LibJPEG

LEGAL ISSUES

=====

In plain English:

- 1. We don't promise that this software works. (But if you find any bugs, please let us know!)
2. You can use this software for whatever you want. You don't have to pay us.
3. You may not pretend that you wrote this software. If you use it in a program, you must acknowledge somewhere in your documentation that you've used the IJG code.

In legalese:

The authors make NO WARRANTY or representation, either express or implied, with respect to this software, its quality, accuracy, merchantability, or fitness for a particular purpose. This software is provided 'AS IS', and you, its user, assume the entire risk as to its quality and accuracy.

Continued on next page

This software is copyright (C) 1991-1998, Thomas G. Lane. All Rights Reserved except as specified below.

Permission is hereby granted to use, copy, modify, and distribute this software (or portions thereof) for any purpose, without fee, subject to these conditions:

- (1) If any part of the source code for this software is distributed, then this README file must be included, with this copyright and no-warranty notice unaltered; and any additions, deletions, or changes to the original files must be clearly indicated in accompanying documentation.
- (2) If only executable code is distributed, then the accompanying documentation must state that "this software is based in part on the work of the Independent JPEG Group".
- (3) Permission for use of this software is granted only if the user accepts full responsibility for any undesirable consequences; the authors accept NO LIABILITY for damages of any kind.

These conditions apply to any software derived from or based on the IJG code, not just to the unmodified library. If you use our work, you ought to acknowledge us.

Permission is NOT granted for the use of any IJG author's name or company name in advertising or publicity relating to this software or products derived from it. This software may be referred to only as "the Independent JPEG Group's software".

We specifically permit and encourage the use of this software as the basis of commercial products, provided that all warranty or liability claims are assumed by the product vendor.

ansi2knr.c is included in this distribution by permission of L. Peter Deutsch, sole proprietor of its copyright holder, Aladdin Enterprises of Menlo Park, CA.

ansi2knr.c is NOT covered by the above copyright and conditions, but instead by the usual distribution terms of the Free Software Foundation; principally, that

you must include source code if you redistribute it. (See the file ansi2knr.c for full details.)

However, since ansi2knr.c is not needed as part of any program generated from the IJG code, this does not limit you more than the foregoing paragraphs do.

The Unix configuration script "configure" was produced with GNU Autoconf.

It is copyright by the Free Software Foundation but is freely distributable.

The same holds for its supporting scripts (config.guess, config.sub, ltconfig, ltmain.sh). Another support script, install-sh, is copyright by M.I.T. but is also freely distributable.

It appears that the arithmetic coding option of the JPEG spec is covered by patents owned by IBM, AT&T, and Mitsubishi. Hence arithmetic coding cannot

legally be used without obtaining one or more licenses. For this reason, support for arithmetic coding has been removed from the free JPEG software.

(Since arithmetic coding provides only a marginal gain over the unpatented Huffman mode, it is unlikely that very many implementations will support it.)

So far as we are aware, there are no patent restrictions on the remaining code.

The IJG distribution formerly included code to read and write GIF files.

To avoid entanglement with the Unisys LZW patent, GIF reading support has been removed altogether, and the GIF writer has been simplified to produce

"uncompressed GIFs". This technique does not use the LZW algorithm; the resulting GIF files are larger than usual, but are readable by all standard

GIF decoders.

We are required to state that

"The Graphics Interchange Format(c) is the Copyright property of

CompuServe Incorporated. GIF(sm) is a Service Mark property of

CompuServe Incorporated."

Open SSL

LICENSE ISSUES

=====

The OpenSSL toolkit stays under a dual license, i.e. both the conditions of

the OpenSSL License and the original SSLeay license apply to the toolkit.

See below for the actual license texts. Actually both licenses are BSD-style

Open Source licenses. In case of any license issues related to OpenSSL

please contact openssl-core@openssl.org.

OpenSSL License

/*

Copyright (c) 1998-2008 The OpenSSL Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided

that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgment: "This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (<http://www.openssl.org/>)"
4. The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact openssl-core@openssl.org.
5. Products derived from this software may not be called "OpenSSL" nor may "OpenSSL" appear in their names without prior written permission of the OpenSSL Project.
6. Redistributions of any form whatsoever must retain the following acknowledgment: "This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>)"

THIS SOFTWARE IS PROVIDED BY THE OPENSSL PROJECT "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OPENSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com). This product includes software written by Tim Hudson (tjh@cryptsoft.com).

*/

Original SSLeay License

/* Copyright (C) 1995-1998 Eric Young (eay@cryptsoft.com) All rights reserved.

This package is an SSL implementation written by Eric Young (eay@cryptsoft.com).

The implementation was written so as to conform with Netscapes SSL.

This library is free for commercial and non-commercial use as long as the following conditions are adhered to. The following conditions apply to all code found in this distribution, be it the RC4, RSA, lhash, DES, etc., code; not just the SSL code. The SSL documentation included with this distribution is covered by the same copyright terms except that the holder is Tim Hudson (tjh@cryptsoft.com).

Copyright remains Eric Young's, and as such any Copyright notices in the code are not to be removed.

If this package is used in a product, Eric Young should be given attribution as the author of the parts of the library used. This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement: "This product includes cryptographic software written by Eric Young (eay@cryptsoft.com)" The word 'cryptographic' can be left out if the routines from the library being used are not cryptographic related :-).
4. If you include any Windows specific code (or a derivative thereof) from the apps directory (application code) you must include an acknowledgement: "This product includes software written by Tim Hudson (tjh@cryptsoft.com)"

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The licence and distribution terms for any publically available version or derivative of this code cannot be changed. i.e. this code cannot simply be copied and put under another distribution licence [including the GNU Public Licence.]

*/

Vera Fonts

Copyright

Copyright (c) 2003 by Bitstream, Inc. All Rights Reserved. Bitstream Vera is a trademark of Bitstream, Inc.

Permission is hereby granted, free of charge, to any person obtaining a copy of the fonts accompanying this license ("Fonts") and associated documentation files (the "Font Software"), to reproduce and distribute the Font Software, including without limitation the rights to use, copy, merge, publish, distribute, and/or sell copies of the Font Software, and to permit persons to whom the Font Software is furnished to do so, subject to the following conditions:

The above copyright and trademark notices and this permission notice shall be included in all copies of one or more of the Font Software typefaces.

The Font Software may be modified, altered, or added to, and in particular the designs of glyphs or characters in the Fonts may be modified and additional glyphs or characters may be added to the Fonts, only if the fonts are renamed to names not containing either the words "Bitstream" or the word "Vera".

This License becomes null and void to the extent applicable to Fonts or Font Software that has been modified and is distributed under the "Bitstream Vera" names.

The Font Software may be sold as part of a larger software package but no copy of one or more of the Font Software typefaces may be sold by itself.

THE FONT SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OF COPYRIGHT, PATENT, TRADEMARK, OR OTHER RIGHT. IN NO EVENT SHALL BITSTREAM OR THE GNOME FOUNDATION BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, INCLUDING ANY GENERAL, SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF THE USE OR INABILITY TO USE THE FONT SOFTWARE OR FROM OTHER DEALINGS IN THE FONT SOFTWARE.

Except as contained in this notice, the names of Gnome, the Gnome Foundation, and Bitstream Inc., shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Font Software without prior written authorization from the Gnome Foundation or Bitstream Inc., respectively. For further information, contact: fonts at gnome dot org.

TIFF

Copyright (c) 1988-1997 Sam Leffler

Copyright (c) 1991-1997 Silicon Graphics, Inc.

Permission to use, copy, modify, distribute, and sell this software and its documentation for any purpose is hereby granted without fee, provided that (i) the above copyright notices and this permission notice appear in all copies of the software and related documentation, and (ii) the names of Sam Leffler and Silicon Graphics may not be used in any advertising or publicity relating to the software without the specific, prior written permission of Sam Leffler and Silicon Graphics.

THE SOFTWARE IS PROVIDED "AS-IS" AND WITHOUT WARRANTY OF ANY KIND, EXPRESS,

IMPLIED OR OTHERWISE, INCLUDING WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

IN NO EVENT SHALL SAM LEFFLER OR SILICON GRAPHICS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER OR NOT ADVISED OF THE POSSIBILITY OF DAMAGE, AND ON ANY THEORY OF LIABILITY, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

