

Wireless Speaker

NP3530

Product Overview

Press and hold to turn on or off.

ON/OFF

Charging

Approx. 3 hours

Note
Operating time is approx. 15 hours. (Based on 30% volume, 1kHz signal, 500 mV portable input and fully charged status)
It may vary depending on the battery status and operational conditions.

App Installation

To use this unit more comfortably, install "LG Bluetooth Remote" on your bluetooth devices. Select a way of installation (a, b or c).

a Searching for "LG Bluetooth Remote" on the Google Play Store.

b Scanning QR code below.

c Tagging on the NFC sticker, if available.

Bluetooth Connection

1 Press and hold to turn on the unit.

2 Within 10 m

Select "LG Portable(XXXX)" on your Bluetooth device. (XXXX means the last four digits of BT address.)

- Depending on the bluetooth device, you need to enter the PIN code (0000).
- Once a pairing operation is performed, it does not need to be performed again every time you turn on the unit. (Only if the PORT.IN is not connected and the unit is registered on the Bluetooth device.)

3

4 Press and hold to disconnect.

Wired Connection

Note: When bluetooth device is connected without BT remote App, PORT.IN connection does NOT work.

ENGLISH OWNER'S MANUAL
Please read this manual carefully before operating your set and retain it for future reference.

Printed in Indonesia
<http://www.lg.com>

Safety Information

5 V 2.0 A

Using handsfree function

Preparation: Your smartphone must be paired with the unit via bluetooth.

Press to accept an incoming call.

Press to hang up the call.

Press and hold to toggle the voice output.

Press and hold to reject an incoming call.

About LED Indicator

	Turned on red		Turned on white		Turned off		Beep sound
	In Charging		Fully Charged (Power Off mode)				
	In Charging		Fully Charged (Power On mode)				
			Power is turned on.				
	X 2		Bluetooth is paired.				
			Battery is discharged. (Blinks rapidly.)				
	X 2		A button is pressed.				
			The unit operates abnormally. Leave the unit at room temperature (0 - 35 °C) for a while and try again.				

Additional Information

LG Bluetooth Remote
Scan to install the App.

Resetting
Reset hole

In case that the unit freezes due to malfunction, press the reset hole for 5 seconds using an object like a thin pin.

About Ferrite Core (Optional)
This ferrite core can reduce noises.

- Pull the stopper [a] of the ferrite core to open.
- Wind the portable cable and USB cable on the ferrite core.
- Close the ferrite core until it clicks.


Notice for Auto Power Off
This unit is turned off automatically, if no button is pressed for 6 hours when the bluetooth is disconnected.

LG Customer Information Center
1-800-243-0000 USA, Consumer
1-888-865-3026 USA, Commercial


Register your product Online!
www.lg.com

Specification

Power Supply:

- 5 V  2.0 A (AC Adapter)
- Built-in rechargeable battery

AC Adaptor:

- Model: WB-10A05FU
- Manufacturer: Yang Ming Industrial
- Input: AC100-240 V, 50/60 Hz
- Output: 5 V  2.0 A

Dimensions (W x H x D): Approx. 193 mm x 65 mm x 65 mm

Net Weight: Approx. 520 g

Operating Temperature: 0 °C to 35 °C

Operating Humidity: 5 % to 60 %

External Connector:

- ø 3.5 mm mini jack
- Micro USB port for charging battery

Communication: Bluetooth 3.0

Amplifier:

- 3 W + 3 W (8 Ω at 1 kHz)
- THD: 1.0%

Speaker:

- Type : Built-in
- Impedance Rate : 8 Ω
- Rated Input Power : 3 W
- Max. Input Power : 6 W

Android O/S for App installation:

- Version 2.3.3 (or higher)
- Design and specifications are subject to change without notice.

Troubleshooting

No power

- The battery is discharged. Recharge the battery.
- Connect the unit to the power supply with the AC adapter

No sound or sound distortion

- The unit or your smart device's volume is set to minimum. Check and adjust the volume of the unit or bluetooth device's volume.
- When you use an external device at high volume, the sound quality may be deteriorated. Lower the volume of the devices.
- If you use the unit for purposes other than listening to music, the sound quality may be lowered or the unit may not work properly.


Bluetooth pairing does not work well.

- Switch bluetooth off and on again on your bluetooth device, then try pairing again.
- Be sure your bluetooth device is on.
- Remove the obstacle in the path of the bluetooth device and the unit.
- Depending on the type of the bluetooth device or surrounding environment, your device may not be paired with the unit.
- While using Bluetooth, you may not be able to activate BT app. Disconnect Bluetooth device you have connected before to use BT app properly.
- When your Bluetooth device have been already connected with other unit, disconnect the Bluetooth connection first. Then you can control your unit through BT app.
- Depending on the Bluetooth device, BT app may work restrictively not work.
- The connection you've made may be disconnected if you select other application or change the setting of the connected device via BT app. In such case, please check the connection status.

The unit does not operate normally.

- In case of malfunction, LED indicator is lit in red and white alternately. Please use the unit in proper place where the temperature or humidity is not so high or low.

Safety Information



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING:

- To prevent fire or electric shock hazard, do not expose this product to rain or moisture.

- Do not install this equipment in a confined space such as a book case or similar unit.

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Wash hands after handling.

CAUTION:

- The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- Internal lithium battery in the unit should not be replaced by user because of danger of explosion if battery is incorrectly replaced, and must be replaced with the same type battery by expert.
- Only use the AC adaptor supplied with this device. Do not use a power supply from another device or another manufacturer. Using any other power cable or power supply may cause damage to the device and void your warranty.
- To avoid fire or electric shock, do not open the unit. Contact to qualified personnel only.
- Do not leave the unit in a place near the heating appliances or subject to direct sunlight, moisture, or mechanical shock.
- To clean the unit, use a soft, dry cloth. If the surfaces are extremely dirty, use a soft cloth lightly moistened with a mild detergent solution. Do not use strong solvents such as alcohol, benzene, or thinner, as these might damage the surface of the unit.
- Do not use volatile liquids such as insecticide spray near the unit. Wiping with strong pressure may damage the surface. Do not leave rubber or plastic products in contact with the unit for a long period of time.
- Do not place the unit over the vehicle's air bag. When the air bag deploys, it may result in injury. Before using in the car, fix the unit.
- Do not use the handsfree function during driving a car.
- Do not leave the unit on an unstable place such as high shelves. It may fall down because of the vibration of the sound.

CAUTION concerning the Power Cord

Most appliances recommend they be placed upon a dedicated circuit. That is, a single outlet circuit which powers only that appliance and has no additional outlets or branch circuits. Check the specification page of this owner's manual to be certain. Do not overload wall outlets. Overloaded wall outlets, loose or damaged wall outlets, extension cords, frayed power cords, or damaged or cracked wire insulation are dangerous. Any of these conditions could result in electric shock or fire. Periodically examine the cord of your appliance, and if its appearance indicates damage or deterioration, unplug it, discontinue use of the appliance, and have the cord replaced with an exact replacement part by an authorized service center. Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, closed in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the appliance. To disconnect power from the mains, pull out the mains cord plug. When installing the product, ensure that the plug is easily accessible.

This device is equipped with a portable battery or accumulator.

Safety way to remove the battery or the battery from the equipment: Remove the old battery or battery pack, follow the steps in reverse order than the assembly. To prevent contamination of the environment and bring on possible threat to human and animal health, the old battery or the battery put it in the appropriate container at designated collection points. Do not dispose of batteries or battery together with other waste. It is recommended that you use local, free reimbursement systems batteries and accumulators. The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

NOTICE: For safety making information including product identification and supply ratings, please refer to the main label on the bottom of the apparatus.

FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC WARNING: This equipment may generate or use radio frequency energy, changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

FCC RF Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

CAUTION: Regulations of the FCC and FAA prohibit airborne operation of radio-frequency wireless devices because their signals could interfere with critical aircraft instruments.

Responsible Party :

LG Electronics USA, Inc. 1000 Sylvan Avenue Englewood Cliffs, NJ 07632
TEL : +1-800-243-0000

Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with apparatus. When a cart is used, use caution when moving the cart/ apparatus combination to avoid injury from tip-over.



13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.