



## OWNER'S MANUAL

# AIR PURIFIER

---



For safe and easy use of the product please read the instruction manual before use.

**EN ENGLISH**

AS10GD Series/AS65GD Series



MFL71891943  
Rev.00\_053023

[www.lg.com](http://www.lg.com)

Copyright © 2023 LG Electronics Inc. All Rights Reserved.

# TABLE OF CONTENTS

This manual may contain images or content that may be different from the model you purchased.  
This manual is subject to revision by the manufacturer.

## SAFETY INSTRUCTIONS

- READ AND SAVE THESE INSTRUCTIONS..... 5**
  - Safety Messages.....5
- IMPORTANT SAFETY INSTRUCTIONS ..... 5**
  - Children in the Household .....5
  - Installation .....6
  - Operation .....6
  - Maintenance .....7
  - Battery .....8
- CAUTION INSTRUCTIONS ..... 8**
  - Installation .....8
  - Operation .....8
  - Maintenance .....10
  - Battery .....10

## INSTALLATION

- Appliance Overview ..... 11**
  - Front View .....11
  - Rear View.....12
  - Components .....12
  - Filter system.....13
  - Unpacking the Appliance .....13
  - Installation Location Requirements.....14
  - Transportation Requirements .....14

## OPERATION

- Control Panel ..... 15**
  - Control Panel Features .....15
  - Status Display Panel.....16
- Remote Controller ..... 17**
  - Remote Controller Features .....17
- Operating the air purifier ..... 18**
  - Operation starting .....18

Using the Mode .....	18
Smart Mode .....	18
Booster Mode .....	18
Dual Mode : Only for the relevant product.....	18
Single Mode : Only for the relevant product .....	19
Normal Mode : Only for the relevant product.....	19
Adjusting the Fan Speed .....	19
Clean Booster Fan Speed .....	19

## **Using the Extra Functions ..... 20**

Using the Air Ionizer .....	20
Setting the Sleep Timer .....	20
Locking the Control Panel.....	20

## **Checking the Air Quality ..... 21**

Overview the Overall Air Quality .....	21
Turning the air quality light On/Off .....	22
Checking the Particles concentration .....	22
Checking the Air Status from the Status Display Panel.....	23

## **SMART FUNCTIONS**

### **LG ThinQ Application ..... 24**

LG ThinQ Application Features.....	24
Before using LG ThinQ Application.....	24
Installing the LG ThinQ Application .....	25
Wireless LAN Module Specifications.....	25
Open Source Software Notice Information .....	25

### **Smart Diagnosis ..... 25**

Using LG ThinQ to Diagnose Issues.....	25
Using Audible Diagnosis to Diagnose Issues .....	26

## **MAINTENANCE**

### **Maintaining the Product ..... 27**

Scheduled maintenance.....	27
Alerts on the Status Display Panel .....	27
Storage .....	27

### **Cleaning the Appliance..... 28**

Cleaning the exterior .....	28
Cleaning the Particles Sensor .....	28

### **Maintaining the Filter..... 28**

Cleaning the Filters .....	28
Replacing the filter.....	29

# TROUBLESHOOTING

<b>Before Calling for Service .....</b>	<b>31</b>
Operation .....	31
Performance .....	32
Noise .....	33
Odor .....	33
Wi-Fi .....	34

# APPENDIX

<b>Information.....</b>	<b>35</b>
APPLIANCE SPECIFICATIONS .....	35

# SAFETY INSTRUCTIONS

## READ AND SAVE THESE INSTRUCTIONS

The following safety guidelines are intended to prevent unforeseen risks or damage from unsafe or incorrect operation of the appliance. The guidelines are separated into 'WARNING' and 'CAUTION' as described below.

### Safety Messages



This symbol is displayed to indicate matters and operation that can cause risk. Read the text marked with this symbol carefully and follow the instructions in order to avoid risk.



#### **WARNING**

This indicates that failure to follow the instructions can cause serious injury or death.



#### **CAUTION**

This indicates that failure to follow the instructions can cause minor injury or damage to the product.

## IMPORTANT SAFETY INSTRUCTIONS

### **WARNING**

- To reduce the risk of explosion, fire, death, electric shock, injury or scalding to persons when using this product, follow basic precautions, including the following:

### **Children in the Household**

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person

responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

### **Installation**

- Do not install the appliance on an uneven or inclined surface.
- Do not install the appliance in an area exposed to direct sunlight or near heat-generating equipment.
- Do not install the product in a place where combustible gas may leak or industrial oil or metallic particulates are present.
- Do not allow the appliance to push against the power cord or plug.
- Do not touch the power plug with wet hands.
- When unplugging the power cord, always pull it by the plug.
- Unplug the appliance during thunder or lightning storms or when not in use for a long time.
- Do not bend the power cable excessively or place a heavy object on top of it.
- Do not extend the length of the power cable or alter it.
- Do not use several devices on a multi-socket extension outlet.
- Make the connection securely so that screw in terminals may not be loosened when the cable is pulled.
- Make sure that the power cable cannot be pulled out or damaged during operation.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.

### **Operation**

- If the appliance is immersed in water, stop using it and contact an LG Electronics Customer Information Center.
- If there is a gas leakage (isobutane, propane, LNG, etc.), do not touch the appliance or power plug and ventilate the area immediately.

- Do not clean the appliance with brushes, cloths or sponges which are abrasive or made of metal.
- If you detect any abnormal noise, odor or smoke, unplug the appliance immediately and contact an LG Electronics Customer Information Center.
- Only an authorized repair person should disassemble, repair, or modify the appliance.
- Do not use or store fire, combustibles (ether, benzene, alcohol, drugs, propane, butane, combustible spray, insecticide, air freshener, cosmetics, etc.) or flammable materials (candles, lamps, etc.) near the product.
- Do not place the power cord under rugs, carpeting or mats.
- Do not allow animals or pets to chew on the power cord.
- Do not move the appliance when it is in operation.
- Do not hit the appliance.
- Do not insert hands or metal objects into the air inlet or outlet.
- Do not install and use broken parts.
- Do not put flammables into the appliance.
- Do not move or operate the appliance while its cover is open.
- Do not allow children to climb on or play with the appliance.
- Do not place anything on top of the appliance.
- The fan is not a toy. It should not be played with or placed where young children can reach it.

## Maintenance

- Dispose of the packing materials (vinyl, styrofoam, etc.) to keep them out of reach of children.
- Take care not to injure or pinch yourself when you detach and reattach parts of the appliance.
- Turn off and unplug the appliance before cleaning it or replacing the filter.

## Battery

- A button/coin-shaped battery is used in the remote controller of the appliance. If you accidentally swallow the battery, consult a doctor immediately for emergency treatment. If you fail to receive first aid within 2 hours after you swallow the battery, you may experience damage to your internal organs or death in severe cases.
- Do not swallow the battery.
- If the battery tray is not secured firmly, stop using the remote immediately and keep it away from children.

## CAUTION INSTRUCTIONS

---

### CAUTION

- To reduce the risk of minor injury to persons, malfunction, or damage to the product or property when using this product, follow basic precautions, including the following:
- 

## Installation

- Do not tilt the appliance to pull or push it when transporting.
- Do not install the appliance in a vehicle, RV, or marine vessel.
- Do not place the appliance near a TV or stereo equipment.
- Do not place the appliance under bright light.
- The appliance must be installed in accordance with national wiring regulations.
- When moving or storing the appliance, wrap the power cord around the base of the appliance to prevent personal injury, damage to the cord or damage to floors.
- Do not place the appliance near curtains.

## Operation

- Do not use the product for removal of toxic gas such as carbon monoxide.

- Do not use the product for ventilation purposes.
- Do not use the appliance for a long time in a region with unstable voltage.
- Do not place obstacles around the air inlet or outlet.
- For safe use of the appliance, children or others with reduced mental capabilities need to be closely monitored by a person who is responsible for their safety.
- Do not use the product for special purposes such as preserving plants, precision instruments, artworks, etc.
- Do not operate the appliance with wet hands.
- Do not let the moisture from a humidifier directly touch the appliance.
- Do not use the appliance while it is not in an upright position.
- Do not use the appliance near objects vulnerable to heat.
- Do not use detergents, cosmetics, chemicals, air fresheners, or disinfectants in the appliance.
- Do not touch any internal parts while the unit is operating or immediately after operation.
- Use the filter only for its intended purpose.
- The Deodorizing Care filter and Safe Plus filter are assembled together. Do not try to detach them from each other.
- Do not insert any objects into the clean booster.
- Do not operate the product while the clean booster cover and grille are separated.
- Do not insert hands or metal objects into the moving parts of the clean booster.
- Do not press multiple buttons at the same time on the remote controller.
- Do not kick or step on the remote controller.
- Do not use the remote controller near water or in areas with high humidity.
- Do not expose the remote controller to fire or high temperatures.

### **Maintenance**

- Do not use strong detergents or solvents to clean the appliance. Use a soft cloth to clean.
- Do not clean the appliance with an alkaline detergent.
- Do not wipe the appliance surface using sulfuric acid, hydrochloric acid or organic solvents (thinner, kerosene etc.) or attach a sticker on the appliance.
- Do not allow water inside the appliance.
- Do not wash the filter with water.
- Be careful not to damage the ultra-fine filter when cleaning it with a vacuum cleaner.
- Do not disassemble the clean booster.

### **Battery**


- Do not modify the battery.
- An improperly installed battery may cause an explosion.
- Do not recharge or take apart the battery.
- Do not dispose of the battery by placing it in a fire, or expose it to high temperatures.
- Remove and store the battery in a safe location if you don't intend to use the remote controller for a long time.

# INSTALLATION


- The exterior or components of the product may vary depending on the model.

## Appliance Overview

### Front View



Dual Model



Single Model

#### ① Air outlet (top) / Clean booster

- Purified air from the filter is emitted.
- Allows you to adjust the direction of wind emission.

#### ② Air quality light

- The current air quality is indicated by a color.

#### ③ Air inlet (top)

- Allows you to disassemble the front and the rear covers separately.

#### ④ Bottom air outlet

- Purified air is emitted from the bottom filter.

#### ⑤ Bottom air inlet

- Allows you to disassemble the front and the rear covers separately.

#### ⑥ Status Display Panel


- Use it to check the settings of the appliance and the air quality.

#### ⑦ Control Panel


- Use it to set the appliance functions.

#### ⑧ Receiver for remote controller signal (Only for models with remote controller)

### Rear View



**Dual Model**



**Single Model**

#### 1 Smart Diagnosis Panel

- When the product malfunctions or breaks down, the product status can be checked through Smart Diagnosis.

#### 2 PM1.0 (particles with a diameter between 1.0 and 2.5 micrometers) sensor

- It detects the concentration of particles.

#### 3 Odor (Gas) sensor

- It detects a odor (gas).


#### 4 Filter

- It eliminates fine particles, smog causing materials, sickening home syndrome materials, and domestic odor.

### Components



1




2

#### 1 Remote controller/Battery (CR2025, 1EA)

#### 2 Quick Guide

- The remote controller may not be provided depending on the model.

## Filter system



- 'PM1.0&GAS SENSOR SYSTEM' is marked on the rear cover of the product.



### 1 Deodorizing Care filter

- Minimizes smog causing materials (SO<sub>2</sub>, NO<sub>2</sub>), sickening house syndrome materials (toluene, formaldehyde), domestic odor, and sulphur compounds.

### 2 Safe Plus Filter

- Minimizes PM1.0, allergen materials, bacterial and viral from the air.


### 3 Filter handle

- Allows you to separate the filter from the product.


### 4 Ultra-fine filter

- Minimizes large particles floating in the air.

- ### 2
- Remove the packing support(1) from near the filter inlet.



- ### 3
- Disassemble the filter and remove the vinyl.



## ⚠ CAUTION

- Do not disassemble the filter forcefully when it is connected each others.

## Unpacking the Appliance



Unpack the appliance and remove all packing tape and filter vinyl before using the appliance.

- ### 1
- Hold the top of the rear cover of the product and pull it slightly to achieve separation.


- ### 4
- Install the filter in the appliance.

## 14 INSTALLATION

- Install it with the side where the handle (❶) is attached facing up.
- The air inlet needs sufficient space to function properly.



- 5** Insert the fixing part at the bottom of the cover into the fixing grooves at the bottom of the product and close the cover.



### **⚠ CAUTION**

- In case of the dual model, remove the support and the vinyl of the filter at the bottom of the air purifier in the same way.
- Be sure to remove the filter packing support and the vinyl before using the product. Failure to do so may cause product malfunction.
- Pay attention to filter direction when installing it. Failure to do so may cause product malfunction and failure.

## Installation Location Requirements

Install the appliance 1m away from a wall.

- The performance of the appliance may vary depending on the service environment (temperature, humidity, etc.).
- The appliance can provide the guaranteed performance in an environment with humidity ranging between 40% and 70%.

## Transportation Requirements

When you relocate or store the appliance, wind the power cord onto the bottom of the product to prevent it from dragging on the floor.

- Failure to do so may damage the power plug or leave a scratch on the floor.

## When carrying the product

- Do not carry the product by holding the external cover. Doing so may allow the cover to open and the product to drop. Dropping the appliance may cause personal injury or product malfunction.

### **Single Model**

Transport the product safely by holding the bottom of the product with both hands.

### **Dual Model**


Transport the product safely by having two people hold the central part of the product.

# OPERATION

- The exterior or components of the product may vary depending on the model.
- The remote controller may not be provided depending on the model.

## Control Panel

### Control Panel Features



#### ① Start/Stop Button

#### ② Mode Button

Use it to set the mode.

- Pressing it for 3 seconds or more will turn on/off the air quality light.

#### ③ Speed Button

Use it to adjust the fan speed of the air purifier.

##### • Wi-Fi function

- Before appliance connection: Press and hold the button for 3 seconds to activate the Wi-Fi connection mode.
- Wi-Fi function off: Press and hold the **Start/Stop** button and the **Speed** button simultaneously for 3 seconds or more.

#### ④ Booster Speed Button

Use it to adjust the fan speed of the clean booster.

- Press and hold it for 3 seconds or more to turn on or off the ionizer. (See Using the Air Ionizer.)

#### ⑤ Swing Button

Turns the clean booster left or right.

#### ⑥ Indicator Button


Allows you to check the concentration of particles in the air by the size of dust particles.

#### ⑦ Sleep Timer Button

Allows you to use the Sleep Timer function.

- Pressing and holding it for 3 seconds or more locks or unlocks the control panel buttons.

## Status Display Panel



### 1 Display of air quality

- ① Overall air quality (color)
- ② The size of dust particles and the concentration of particles (color)
- ③ The concentration of particles and sleep timer
- ④ The concentration of odor (color)

### 2 Display operating mode

### 3 Display speed and booster speed

Speed : Displays the air purifier's fan speed.

Booster Speed: Displays the clean booster's fan speed.

### 4 Sleep Timer Display


### 5 Icons

Icon	Description
	It turns on when it is time to replace the bottom filter.
	It turns on when the Wi-Fi function is activated.
	It turns on when the Timer is set with the LG ThinQ application.
	It turns on when the control panel is locked.
	It turns on when the ionizer turns on.

Icon	Description
	It turns on when it is time to replace the filter.
	It turns on when it is time to replace the top filter.

# Remote Controller

## Remote Controller Features



### 1 Start/Stop Button

### 2 Speed Button

Use it to adjust the fan speed of the air purifier.

### 3 Sleep Timer Button

Schedules an automatic turn off time for the appliance.

### 4 Booster Speed Button

Use it to adjust the fan speed of the clean booster.

### 5 Light Button

Turns the air quality light on/off.

### 6 Mode Button

Sets the operating mode.

### 7 Swing Button

Allows you to adjust the rotation direction of the clean booster to the left or the right.

- If the battery tray is not fixed firmly, stop using it and put it out of children's reach.

## ⚠ CAUTION

- Do not alter the battery arbitrarily. Doing so may cause fire or a appliance failure.
- Inserting the battery incorrectly may cause explosion.
- Do not charge or disassemble the battery. Doing so may cause explosion.
- Do not discard the battery in a place with flames or heat. Doing so may cause explosion.
- Do not press a number of buttons simultaneously. Doing so may cause the appliance to become inoperable or malfunction.
- Do not use it in a place with wet or moist conditions. Doing so may cause fire or an electric shock.
- Do not use it in a place with flames or heat. Doing so may cause fire or deformation of the appliance.
- If you do not use the remote controller for a long time, store it after separating the battery. Failure to do so may cause the battery fluid to leak, resulting in malfunction.

## NOTE

- If the remote controller does not operate normally, replace the battery or check the polarity of the battery (+, -).
- Position the transmitter for the remote controller facing the receiver for the appliance when using the remote controller.
- If you are away from the product (front) by more than 7 m, the remote control may not work.


## ⚠ WARNING

- This appliance, including the remote controller, is equipped with a button/coin type battery(CR2025).
- Swallowing the battery may cause serious injury or death. If the battery is swallowed, immediately go to a hospital emergency room to see a doctor.
- Make sure to keep the battery out of children's reach.

## Operating the air purifier

### Operation starting

Press the **Start/Stop** button to start the operation.




#### NOTE

- When the operation is started for the first time, the appliance operates in **Booster** mode.
- The most recently used mode is memorized if the power supply is cut off as a result of a power failure.
- When the operation begins, the display of sensor ready will appear for approximately 30 seconds.

### Using the Mode

- Each time you press the **Mode** button, the mode changes in the following order.
  - Single Model : **Smart** → **Booster** → **Normal**
  - Dual Model : **Smart** → **Booster** → **Dual** → **Single**



### Smart Mode

Operating mode and fan speed are adjusted automatically according to overall air quality.

#### NOTE

- When the appliance is operated in **Smart** mode, **Speed**, **Booster Speed**, and **Swing** buttons are not operated.

### Booster Mode

Clean Booster circulates the indoor air by quickly sending purified air over an extended distance.

#### ⚠ CAUTION


- Be careful not to allow your hands to be pinched by the moving parts of the clean booster.

#### NOTE

- When the power cord is unplugged before the clean booster is completely closed, plug the cord in again. The clean booster will rotate and properly close.

### Rotating the Clean Booster

Press the **Swing** button during the **Booster** mode operation.



### Dual Mode : Only for the relevant product

The product operates air purifiers at the top and bottom simultaneously to purify indoor air quickly.

## Single Mode : Only for the relevant product

The air purifier at the bottom purifies indoor air.

- The air purifier at the top operates at a low speed.

## Normal Mode : Only for the relevant product


As a basic operation mode for air purification, air speed can be adjusted.

## Adjusting the Fan Speed

Adjust the fan speed on the air purifier.

Press the **Speed** button during the operation.

- Each time you press the button, the speed changes in the following order:  
Auto → Low → Middle → High → Turbo.



## Fan Speed Display

When you adjust the speed, the speed will be displayed on the status display panel. The Speed increases by 2 columns each time when the level is raised.

- [Example of 'Middle' Display for Speed]



## NOTE


- When the operation is started for the first time, Auto is set as the Speed. In **Auto** mode, the Speed is adjusted automatically according to the contamination level of indoor air.

## Clean Booster Fan Speed

Adjust the fan speed of the clean booster.

Press the **Booster Speed** button during the **Booster** mode operation.

- Each time you press the button, the speed changes in the following order:  
Auto → Low → Middle → High → Turbo.



## Booster Speed Display

When you adjust the Booster Speed, the Booster Speed will be displayed on the status display panel. The Booster Speed increases by 2 columns each time the level is raised.

- [Example of 'Middle' Display for Booster Speed]



## NOTE

- When the **Auto** mode is selected, clean booster speed is automatically adjusted to the same level as Speed.


## Using the Extra Functions

### Using the Air Ionizer

To generate ions to minimize various bacteria from the air.

Press the **Booster Speed** button for more than 3 seconds while operating.

-  (Air ionizer) is displayed on the status display.



### NOTE


- When the operation is stopped, the air ionizer function can not be used.

### Setting the Sleep Timer

Stops the operation automatically after the operation for the set time.

Press the **Sleep Timer** button during operation.

- Each time you press the button, the setting changes in the following order: After 2 hours → After 4 hours → After 8 hours → After 12 hours → Cancel
- When the Sleep Timer is activated, only the sleep timer icon is displayed on the status display panel.



### NOTE


- Speed is changed to the 'Low' level and adjusted automatically at regular intervals according to air quality.
- Fan speed can be adjusted by pressing the **Speed** button while the sleep timer is activated.
- On the sleep timer setting, you can check the set time by pressing the **Sleep Timer** button again.
- The sleep timer setting will be maintained when the appliance is turned off and then on again as the result of a power failure.

### Locking the Control Panel

You can lock the buttons on the control panel to prevent the appliance from operating due to unforeseen reasons, such as a child manipulating the buttons.

Press the **Sleep Timer** button for 3 seconds or longer during operation.

-  (Lock) is displayed on the status display panel.



### NOTE

- You can turn off the lock function in the same way as turning it on.
- You can use the remote controller in locked status. (Only for models with remote controller)
- You can also lock or unlock when the operation has stopped.

## Checking the Air Quality

The overall air quality can be checked through the air quality light and the status display panel.

### Overview the Overall Air Quality

The overall air quality is calculated based on the particles and odor (gas) concentrations and is categorized in 4 levels depending on the contamination of the air.

color	Overall air quality	Concentration of PM ( $\mu\text{g}/\text{m}^3$ )			Concentration of odor	
	State	PM10 (Coarse particles)	PM2.5 (Fine particles)	PM1.0 (Particles with a diameter between 1.0 and 2.5 $\mu\text{m}$ )	State	Level
<b>Red</b>	Poor	255 or more	56 or more	56 or more	Very strong	4
<b>Orange</b>	Unhealthy	155 ~ 254	36 ~ 55	36 ~ 55	Strong	3
<b>Yellow</b>	Moderate	55 ~ 154	13 ~ 35	13 ~ 35	Normal	2
<b>Green</b>	Good	54 or less	12 or less	12 or less	Weak	1


### NOTE

- The color of the overall air quality is based on the worst level detected, whether odors or particulates.
- PM (particulate matter) concentration is displayed in increments of 1 unit, from 8 to 999. PM concentration values are based on the data sheet provided by the sensor manufacturer.
- The PM concentration measurement was tested using LG Electronics' standard test materials.
- Differences in PM concentration values may be the result of different methods of measuring or differences in the actual PM concentration levels.
  - If the PM concentration is high, there may be a larger difference between the displayed concentration and the actual concentration.


### Turning the air quality light On/ Off

1 Check the overall air quality through the air quality light(❶).

- Lower air quality light is only available on dual model.



2 You can turn the air quality light on or off by pressing **Mode** button for 3 seconds or longer during operation.



#### NOTE

- The air quality light turns white during sensor stabilization time (30 seconds). The odor (gas) sensor can be stabilized 2 minutes after its operation.


### Checking the Particles concentration

You can check the concentration of particles in the air by measuring the size of dust particles. Press the **Indicator** button during operation.

- Each time you press the button, the setting changes in the following order:

**PM10 → PM2.5 → PM1.0**


- The concentration of selected dust particles will be displayed for about 10 seconds.



#### NOTE

- The overall air quality level is a result of both PM concentration and the odor level.
- Whether it is a different product or the same product used in the same space, the concentration measurement may vary due to air circulation.
- Unlike odors (gas), dust particles travel slowly. Therefore, the measured concentration may be lower than the actual concentration.
- Air flow near the dust sensor may interrupt normal operation of the particles sensor and indicated concentration may be different from actual particles concentration, accordingly.
- When the product is used in the following environment, the measured concentration of particles may differ from the actual concentration.
  - Near fabric sofas and beds, around hairy carpets, while making beds/folding clothes, while using vacuum cleaners, places with bugs and pets, and places with high humidity
  - Places where outside air is available, such as construction sites, roadsides, and factories, or near outside doors, windows, and vents
  - Places where products generating steam or fine particles (humidifiers, kitchen tools, or sprays) are used
  - The sensor may not detect particles larger than PM10 generated by activities such as dusting off blankets or cleaning, but they are removed by the filter.
- The concentration of odors (gas) may vary due to items emitting odors such as air fresheners, deodorizers, detergents, or cosmetics.

## Checking the Air Status from the Status Display Panel



### ① Overall air quality

You can check the overall air quality through indication color.

### ② Concentration of odor

You can check the concentration of odor through indication color.

### ③ Concentration of particles

You can check the concentration of particles as a specific figure and the color displayed for the size of dust particles. The concentration of particles indicates the concentration of particles contaminated first among the PM10 / PM2.5 / PM1.0.

### ④ PM Size

The size of dust particles is indicated as a color based on the concentration of particles.

# SMART FUNCTIONS

## LG ThinQ Application

The LG ThinQ application allows you to communicate with the appliance using a smartphone.

### LG ThinQ Application Features

#### Smart Diagnosis

If you experience a problem while using the appliance, this smart diagnosis feature will help you diagnose the problem.

#### Settings

Allows you to set various options on the appliance and in the application.

#### NOTE


- If you change your wireless router, internet service provider, or password, delete the connected appliance from the **LG ThinQ** application and connect it again.
- The application is subject to change for appliance improvement purposes without notice to users.
- Functions may vary by model.

## Before using LG ThinQ Application


This feature is only available on models with Wi-Fi function.

- 1 Check the distance between the appliance and the wireless router (Wi-Fi network).
  - If the distance between the appliance and the wireless router is too far, the signal strength becomes weak. It may take a long time to connect or installation may fail.

- 2 Turn off the Mobile data or Cellular Data on your smartphone.



- 3 Connect your smartphone to the wireless router.



#### NOTE

- To verify the Wi-Fi connection, check that the Wi-Fi  icon on the control panel is lit.
- **The appliance supports 2.4 GHz Wi-Fi networks only.** To check your network frequency, contact your Internet service provider or refer to your wireless router manual.
- **LG ThinQ** is not responsible for any network connection problems or any faults, malfunctions, or errors caused by network connection.
- If the appliance is having trouble connecting to the Wi-Fi network, it may be too far from the router. Purchase a Wi-Fi repeater (range extender) to improve the Wi-Fi signal strength.
- The Wi-Fi connection may not connect or may be interrupted because of the home network environment.
- The network connection may not work properly depending on the Internet service provider.
- The surrounding wireless environment can make the wireless network service run slowly.
- If the appliance cannot be connected due to problems with the wireless signal transmission,

unplug the appliance and wait about a minute before trying it again.

- If the firewall on your wireless router is enabled, disable the firewall or add an exception to it.
- The wireless network name (SSID) should be a combination of English letters and numbers. (Do not use special characters.)
- Smartphone user interface (UI) may vary depending on the mobile operating system (OS) and the manufacturer.
- If the security protocol of the router is set to WEP, the network setup may fail. Change the security protocol (WPA2 is recommended) and connect the product again.

## Installing the LG ThinQ Application

Search for the LG ThinQ application from the Google Play Store or Apple App Store on a smartphone. Follow instructions to download and install the application.

## Wireless LAN Module Specifications

Model	LCW-007
Frequency Range	2412 MHz - 2472 MHz
Output power (Max)	IEEE 802.11b: 17.59 dBm IEEE 802.11g: 17.39 dBm IEEE 802.11n(HT20): 16.64 dBm IEEE 802.11n(HT40): 17.05 dBm

Wireless function S/W version : V 1.0

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

## Open Source Software Notice Information

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit <https://opensource.lge.com>. In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to [opensource@lge.com](mailto:opensource@lge.com). This offer is valid for a period of three years after our last shipment of this product. This offer is valid to anyone in receipt of this information.

## Smart Diagnosis

This feature is only available on models with the  or  logo.

Use this feature to help you diagnose and solve problems with your appliance.

### NOTE

- For reasons not attributable to LGE's negligence, the service may not operate due to external factors such as, but not limited to, Wi-Fi unavailability, Wi-Fi disconnection, local app store policy, or app unavailability.
- The feature may be subject to change without prior notice and may have a different form depending on where you are located.

## Using LG ThinQ to Diagnose Issues

If you experience a problem with your Wi-Fi equipped appliance, it can transmit troubleshooting data to a smartphone using the **LG ThinQ** application.


- Launch the **LG ThinQ** application and select the **Smart Diagnosis** feature in the menu. Follow the instructions provided in the **LG ThinQ** application.

### Using Audible Diagnosis to Diagnose Issues


Follow the instructions below to use the audible diagnosis method.

- Launch the **LG ThinQ** application and select the **Smart Diagnosis** feature in the menu. Follow the instructions for audible diagnosis provided in the **LG ThinQ** application.

- 1 Press and hold the **Indicator** button for 5 seconds to execute the **Smart Diagnosis** function.



- 2 Hold the phone near the  or  logo on the back of the appliance.



- 3 After the data transfer is complete, the diagnosis will be displayed in the application.

---

#### NOTE

- For best results, do not move the phone while the tones are being transmitted.
-


# MAINTENANCE

## Maintaining the Product

### Scheduled maintenance

#### **⚠ WARNING**

- Be sure to stop the appliance operation and remove the power plug from the outlet before cleaning and replacing the filter.
- Do not spray water directly on the appliance.

Component	Cleaning frequency	Replacement frequency
 <p>Filter</p>	<p><b>Ultra-fine filter</b> Clean filter as needed</p>	1 year
 <p>PM 1.0 sensor</p>	2 months	-

#### **NOTE**

- The cleaning frequency may vary depending on the operating hours and environment of the appliance.
- If you do not clean the product according to the cleaning frequency, you may experience a bad odor and poor performance.
- The filter must be replaced at the end of its lifespan, and the cost of replacement filters is not covered under the warranty. To purchase new filters, contact an LG Electronics Customer Information Center or visit the website at [www.lg.com](http://www.lg.com)

- If the PM concentration does not change on the display for a long time, clean the PM1.0 sensor even if it is not scheduled for a cleaning.

### Alerts on the Status Display Panel

Model	Alert	Measures
Single		Replace the filter.
Dual		Replace the top purifier filter.
		Replace the bottom filter.

#### **NOTE**

- Filter replacement alerts appear based on the maximum usage time, taking into account the operating hours of the appliance. The replacement frequency is determined by the operating hours and environment.

### Storage

If the appliance is not used for a long period of time, store it at a shaded and dry place.

- 1 Operate the product for one hour or more on a fine day.
  - This removes moisture and prevents molds from building-up inside the product.
- 2 Turn off the power and unplug it from the electrical outlet.
  - Wind the power cord around the bottom of the appliance.

- 3 Package the appliance to prevent the dust or foreign substance from entering the appliance. Store the packaged appliance at a shaded place.

### **⚠ CAUTION**

- Do not store the appliance at a humid place or at a place exposed to the direct sunlight. Otherwise the appliance may be deformed, malfunction or generate odor.
- 

## Cleaning the Appliance

### Cleaning the exterior

- 1 Remove dust from the air inlet and outlet using a vacuum cleaner.
- 2 Wipe the exterior with a soft lint-free cloth.

### **⚠ CAUTION**

- Do not wipe the appliance with an alkaline detergent.
  - Never use sulphuric acid, hydrochloric acid or organic solvent (e.g., thinner, kerosene and acetone) to wipe the appliance exterior, or affix labels on the exterior. Doing so may damage the product surface.
  - Care should be exercised to prevent flowing of water into the product.
- 


### **NOTE**

- If dust on the front and rear covers cannot be removed, disassemble the covers and clean them with water. After cleaning, dry the covers thoroughly in the shade.
- 


## Cleaning the Particles Sensor

PM1.0 (ultra-fine particles) sensor detects fine particles as well as coarse particles. Therefore, you need to clean its lens regularly.

- 1 Separate the rear cover of the product.
- 2 Open the sensor cover.



- 3 Clean the lens with a cotton swab soaked with water and clean it again with a dry cotton swab.



### **NOTE**


- Do not wipe the sensor with any substances other than water. It may cause a appliance to malfunction.
- 

## Maintaining the Filter

### Cleaning the Filters


- 1 Separate the cover of the product.
- 2 Remove particles off of the ultra-fine filter with a vacuum cleaner or a soft brush.

- If contamination cannot be eliminated after cleaning, replace the ultra-fine filter.



**3** Separate the ultra-fine filter from the total filter.

- How to separate the ultra-fine filter: Check the Velcro of the ultra-fine filter and carefully remove the ultra-fine filter in order to avoid it being damaged.



**4** When you assemble the ultra-fine filter, follow the reverse order of the separation procedure.

### ⚠ CAUTION

- Do not clean the filter with water. The service life of the filter may be reduced.
- Be careful not to damage the ultra-fine filter when using a vacuum cleaner.
- Take caution because there is a risk of tearing or loss when separating or assembling the ultra-fine filter.

### NOTE

- In case of the dual model, clean the bottom filter in the same way.


## Replacing the filter

- 1 Separate the cover from the product and replace the filter.
  - To avoid polluting the surroundings when replacing the filter, place a newspaper on the floor before you remove the filter.
- 2 Once you have replaced the filter, disable the filter replacement alert.

## Disabling the Filter Replacement Alert

Press and hold the **Speed** and **Indicator** buttons simultaneously for 3 seconds or more.


- The  (Single Model Filter Replacement Alert) or  (Dual Model Top Filter Replacement Alert) on the Status Display is disabled and the replacement alarm is reset.



## Disabling the Filter Replacement Alert (Only for relevant models)

Press and hold the **Indicator** and **Sleep Timer** buttons simultaneously for 3 seconds or more.

- The  (Bottom Filter Replacement Alert) on the Status Display is disabled and the replacement alarm is reset.



---

### NOTE

- The filter replacement alert will be disabled automatically after 24 hours of the alert being displayed or the power supply to the appliance is cut off.
-

# TROUBLESHOOTING

## Before Calling for Service

Please check the following before calling for service. If the problem persists, contact your local service center.

### Operation

Symptoms	Possible Cause & Solution
The appliance does not operate.	<p><b>The power plug in unplugged from the outlet.</b></p> <ul style="list-style-type: none"> <li>Plug it into the outlet properly.</li> </ul>
There is odor, but the air quality light doesn't change.	<p><b>Is the air quality light red or orange?</b></p> <ul style="list-style-type: none"> <li>The color of the overall air quality light is determined by the worst level sensed, whether that is a PM concentration or odor. The PM concentration level may be worse than the odor level.</li> <li>The odor (gas) sensor is designed to detect harmful gases. Strong food odors may not register as harmful, but the Deodorizing Care filter will minimize them.</li> </ul>
The air quality light stays red.	<p><b>Move the appliance to a different room and see if the color changes.</b></p> <ul style="list-style-type: none"> <li>If the odor level is beyond the capacity of the product to dispel, the light may not change.</li> <li>Clean the sensor area.</li> <li>Remove the power plug from the outlet and reconnect it one minute later.</li> </ul>
	<p><b>A substance was sprayed near the product.</b></p> <ul style="list-style-type: none"> <li>Do not use sprays near the product.</li> </ul>
The buttons on the control panel do not work.	<p><b>The  (Lock) is turned on on the status display panel.</b></p> <ul style="list-style-type: none"> <li>Press and hold the <b>Sleep Timer</b> button for 3 sec. To disable the lock function.</li> </ul>
The PM concentration doesn't change.	<p><b>There is a foreign substance on the sensor.</b></p> <ul style="list-style-type: none"> <li>Clean the PM1.0 sensor.</li> </ul>
	<p><b>The product is used in an enclosed space.</b></p> <ul style="list-style-type: none"> <li>In an enclosed space without frequent air exchange, the air quality may stay the same.</li> </ul>
The PM concentration stays high.	<p><b>The product is located in an area with frequent airflow from the outside.</b></p> <ul style="list-style-type: none"> <li>In an environment where outside air is supplied continuously, the PM concentration may remain high.</li> </ul>

Symptoms	Possible Cause & Solution
<b>The color of the overall air quality light does not match the PM concentration value.</b>	<p><b>The overall air quality light may be reflecting the odor level.</b></p> <ul style="list-style-type: none"> <li>The overall air quality is based on both the PM concentration and the odor level, and its color is determined by which is worse.</li> <li>If the PM concentration is low and the odor level is high, the overall air quality light will reflect the odor level.</li> </ul>
<b>The clean booster is not working.</b>	<p><b>The Booster mode is not selected.</b></p> <ul style="list-style-type: none"> <li>The booster fan speed and booster fan rotation functions work only in the <b>Booster</b> mode.</li> </ul>
<b>The PM concentration levels are different between the appliance and the LG ThinQ app.</b>	<p><b>Make sure you are comparing the levels for the same size particulates.</b></p> <ul style="list-style-type: none"> <li>Make sure that the levels of the PM1.0/PM2.5/PM10 are displayed consistently between the <b>LG ThinQ</b> app and your appliance.</li> <li>The <b>LG ThinQ</b> app may not update the sensor results as quickly as the appliance display.</li> </ul>

## Performance

Symptoms	Possible Cause & Solution
<b>The indoor air is not purified well enough.</b>	<p><b>The indoor air is very dirty.</b></p> <ul style="list-style-type: none"> <li>Ventilate the indoor air before you use the product.</li> </ul>
	<p><b>The ultra-fine filter is clogged with dust.</b></p> <ul style="list-style-type: none"> <li>Clean the ultra-fine filter properly.</li> </ul>
	<p><b>The Safe Plus filter is clogged with dust.</b></p> <ul style="list-style-type: none"> <li>Replace the whole filter.</li> </ul>
	<p><b>The location is too large for the capability of the air purifier.</b></p> <ul style="list-style-type: none"> <li>Use a product that fits the size of the room.</li> <li>Place the appliance away from windows, doors, and other areas with frequent influx of outdoor air.</li> </ul>
	<p><b>The air inlet or outlet is blocked.</b></p> <ul style="list-style-type: none"> <li>Remove the obstacle.</li> </ul>
	<p><b>The appliance is located in a corner or an area where air circulation is blocked.</b></p> <ul style="list-style-type: none"> <li>Move the appliance and install it again.</li> </ul>

## Noise

Symptoms	Possible Cause & Solution
Fan is noisy even on the lowest speed.	<b>The ultra-fine filter is clogged with dust.</b> <ul style="list-style-type: none"> <li>Clean the ultra-fine filter properly.</li> </ul>
	<b>The Safe Plus filter is clogged with dust.</b> <ul style="list-style-type: none"> <li>Replace the whole filter.</li> </ul>
The appliance makes a sudden loud noise while operating.	<b>The operating mode is set to Smart mode or the fan speed is on Auto.</b> <ul style="list-style-type: none"> <li>It may make a sudden noise as it automatically adjusts the air flow depending on indoor air quality.</li> </ul>
A noise is generated when I start or stop the clean booster.	<b>The clean booster is looking for the correct location.</b> <ul style="list-style-type: none"> <li>The clean booster is looking for the correct location.</li> </ul>

## Odor

Symptoms	Possible Cause & Solution
A strange odor comes out from the air outlet as well as the filter.	<b>Appliance is new.</b> <ul style="list-style-type: none"> <li>The odor of activated charcoal is not harmful. This is similar to the odor you may experience in a brand new car. The odor should dissipate after 1-2 weeks of use.</li> </ul>
	<b>The appliance is located in an area with a lot of smoke or odors.</b> <ul style="list-style-type: none"> <li>In areas with a lot of smoke or odors, the lifespan of the filters may be greatly decreased. For best results, ventilate the room first, then use the appliance.</li> </ul>
	<b>The odor is coming from the filter.</b> <ul style="list-style-type: none"> <li>Replace the filter. The filter replacement frequency may differ depending on the usage environment.</li> </ul>
	<b>The appliance is located in an area with a lot of strong odors.</b> <ul style="list-style-type: none"> <li>If the appliance is used near where you cook or broil fish or meat, the lifespan of the filters will be greatly decreased.</li> <li>For best results, ventilate the area first by opening a window or using a vent hood. Use the appliance only to minimize odors left after ventilating the area.</li> </ul>

## Wi-Fi


Symptoms	Possible Cause & Solution
<b>Your home appliance and smartphone is not connected to the Wi-Fi network.</b>	<b>The password for the Wi-Fi that you are trying to connect to is incorrect.</b> <ul style="list-style-type: none"> <li>Find the Wi-Fi network connected to your smartphone and remove it, then connect your appliance in <b>LG ThinQ</b>.</li> </ul>
	<b>Mobile data for your smartphone is turned on.</b> <ul style="list-style-type: none"> <li>Turn off the <b>Mobile data</b> of your smartphone and connect the appliance using the Wi-Fi network.</li> </ul>
	<b>The wireless network name (SSID) is set incorrectly.</b> <ul style="list-style-type: none"> <li>The wireless network name (SSID) should be a combination of English letters and numbers. (Do not use special characters).</li> </ul>
	<b>The router frequency is not 2.4 GHz.</b> <ul style="list-style-type: none"> <li>Only a 2.4 GHz router frequency is supported. Set the wireless router to 2.4 GHz and connect the appliance to the wireless router. To check the router frequency, check with your internet service provider or the router manufacturer.</li> </ul>
	<b>The appliance is too far from the router.</b> <ul style="list-style-type: none"> <li>If the appliance is too far from the router, the signal may be weak and the connection may not be configured correctly. Move the router closer to the appliance.</li> </ul>

# APPENDIX


## Information

### APPLIANCE SPECIFICATIONS

- Appearance and specifications may vary without notice to improve the quality of the appliance.



**Dual Model**



**Single Model**

<b>Name</b>	AS10GD Series, AS65GD Series
<b>Power</b>	AC 220 - 240 V~ 50 Hz
<b>Dual Model Exterior Dimensions</b> (① x ② x ③)	When Clean Booster is stopped: 376mm x 376mm x 1073mm
	When Clean Booster is operating: 376mm x 376mm x 1310mm
<b>Single Model Exterior Dimensions</b> (① x ② x ③)	When Clean Booster is stopped: 343mm x 343mm x 587mm
	When Clean Booster is operating: 343mm x 343mm x 824mm

