



ENGLISH

OWNER'S
MANUAL

OWNER'S MANUAL

WATER PURIFIER

**Read this owner's manual thoroughly before operating the appliance
and keep it handy for reference at all times.**

WCD56US2



MFL69302202

www.lg.com

TABLE OF CONTENTS

This manual is produced for a group of products and may contain images or content different from the model you purchased.


This manual is subject to revision by the manufacturer.


SAFETY INSTRUCTIONS	03
Important Safety Instructions.....	04
INSTALLATION.....	09
Notes for installation.....	09
OPERATION	10
Parts and Functions.....	10
Notes for Operation	11
Using Control Panel.....	12
Notes for Using the Control Panel.....	13
Using the Water Tray.....	13
MAINTENANCE.....	14
Cleaning	14
Using the Smart Function.....	15
SMART DIAGNOSIS™	16
TROUBLESHOOTING.....	17


SAFETY INSTRUCTIONS

The following safety guidelines are intended to prevent unforeseen risks or damage from unsafe or incorrect operation of the product.

The guidelines are separated into 'WARNING' and 'CAUTION' as described below.

 This symbol is displayed to indicate matters and operations that can cause risk. Read the part with this symbol carefully and follow the instructions in order to avoid risk.

 **WARNING** - This indicates that the failure to follow the instructions can cause serious injury or death.

 **CAUTION** - This indicates that the failure to follow the instructions can cause the minor injury or damage to the product.

WARNING

To reduce the risk of explosion, fire, death, electric shock, injury or scalding to persons when using this product, follow basic precautions, including the following:

Children in the Household

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

Important Safety Instructions

WARNING

To reduce the risk of explosion, fire, death, electric shock, injury or scalding to persons when using this product, follow basic precautions, including the following:

Installation

- Ground the appliance for safety. For more details on grounding, inquire at an LG Electronics Customer Information Centre.
- Install the appliance on a firm and level floor.
- Do not install the appliance in a damp and dusty place.
- Do not place the appliance in direct sunlight or expose it to the heat from heating appliances such as stoves or heaters.
- Be careful not to expose the rear of the appliance when installing the appliance.
- Do not install the product near fire or flammable materials (ether, benzene, LP gas, etc).
- When installing the drain hose, attach it deep inside the drain using compressed rubber (applicable to models with the hot water function only).
- Install the appliance in a place where is easy to unplug the power plug of the appliance.

Power

- Do not insert the power plug of the product into a multiple socket outlet with no power cable (attachment type).
- This appliance is equipped with a power cord having an equipment-grounding conductor and a grounding power plug. The power plug must be plugged into an appropriate socket outlet that is installed and grounded in accordance with all local codes and ordinances.
- Use only grounded extension socket outlets.
- Do not plug the appliance into multiple socket outlets or extension power cable.
- Be careful not to point the power plug up or let the appliance lean against the power plug.
- Disconnect the power cord before cleaning the appliance.
- Do not touch the power plug with wet hands.
- Plug the power plug in the socket outlet tightly after removing the moisture and dust completely.
- Never unplug the appliance by pulling on the power cable. Always grip the power plug firmly and pull straight out from the socket outlet.
- If the power cord is damaged or the hole of the socket outlet is loose, do not use the power cord and contact an authorized service centre.
- Unplug the power plug during thunder or lightening or when not in use for a long period of time.
- Do not bend the power cable excessively or place a heavy object on top of it.
- Do not modify or extend the power cord.
- Do not plug and unplug the power plug repeatedly.

Operation

- In case of flood, disconnect the power plug and contact the LG Electronics Customer Information Centre.
- If there is a gas leakage (isobutane, propane, natural gas, etc.), do not touch the appliance or power plug and ventilate the area immediately. This product uses a very eco-friendly gas (isobutane, R600a) as the refrigerant. Although it uses a small amount of the gas, it is still combustible gas. Gas leakage during appliance transport, installation or operation can cause fire, explosion or injury if sparks are caused.
- Do not spray the water inside or outside the appliance to clean it.
- Do not clean the appliance with brushes, cloths or sponges with rough surfaces or which are made of metallic material.
- Immediately unplug the power plug and contact an LG Electronics Customer Information Centre if you detect a strange sound, odour, or smoke coming from the appliance.
- Do not place heavy or fragile objects, liquid filled containers, combustible substances, or flammable objects (such as candles and lamps) on the appliance.
- Only a qualified service personnel from LG Electronics service centre should disassemble, repair, or modify the appliance. Contact an LG Electronics Customer Information Centre if you move and install the appliance in a different location.
- Do not use or store flammable or combustible substances (ether, benzene, alcohol, chemical, LPG, combustible spray, insecticide, air freshener, cosmetics, etc.) near the appliance.
- If water penetrates electrical parts of the appliance, disconnect power plug and contact an LG Electronics Customer Information Centre.
- If water is leaking from the inside of the product or water has collected near the product, close the water supply valve, unplug the power plug, and contact an LG Electronics service centre.
- Do not apply excessive force or impact to the back cover of the appliance.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not move the product while the product is plugged in.
- Do not apply excessive force or impact to the back cover of the product.

Disposal

- When discarding the appliance, remove the door gasket while leaving the shelves and baskets or all parts in place and keep children away from the appliance.
- Dispose of all packaging materials (such as plastic bags and styrofoam) away from children. The packaging materials can suffocate a child.

Technical safety

- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- The refrigerant and insulation blowing gas used in the appliance require special disposal procedures. Consult with service agent or a similarly qualified person before disposing of them.
- This appliance contains a small amount of isobutane refrigerant (R600a), natural gas with high environmental compatibility, but it is also combustible. When transporting and installing the appliance, care should be taken to ensure that no parts of the refrigerating circuit are damaged.
- Refrigerant squirting out of the pipes could ignite or cause an eye injury.
- If a leak is detected, avoid any naked flames or potential sources of ignition and air the room in which the appliance is standing for several minutes. In order to avoid the creation of a flammable gas air mixture if a leak in the refrigerating circuit occurs, the size of the room in which the appliance is used should correspond to the amount of refrigerant used. The room must be 1 m² in size for every 8 g of R600a refrigerant inside the appliance.
- The amount of refrigerant in your particular appliance is shown on the identification plate inside the appliance.
- Never start up an appliance showing any signs of damage. If in doubt, consult your dealer.

CAUTION

To reduce the risk of minor injury to persons, malfunction, or damage to the product or property when using this product, follow basic precautions, including the following:

Installation

- Do not tilt the appliance to pull or push it when transporting.
- This appliance should only be transported by two or more people holding the appliance securely.
- Connect the water pipe of the product to tap water only. Water other than tap water can increase the risk of exposure to disease. Other waters can reduce the product life or cause malfunctions.
- Hot water may splattered, so install the drain hose carefully to the drain.

Operation


- Prevent animals from nibbling on the power cable or water hose.
- Supervise a child or a person with poor cognitive skills to ensure they use the appliance safely.
- Be careful not to damage the refrigerant line.
- Replace the filter with a LG standard filter periodically according to the replacement period. Older filters can multiply bacteria or change the taste of the water. The filter replacement period varies according to the usage, place of usage, season, and water quality.
- When using hot water, use a container with a handle. (Only applicable to a model with hot water function)
- If the drip tray of the product protrudes from a desk or table, do not place any article on top of the drip tray.
- Take care against the possibility of damaging the pipe (inlet, outlet) in order to prevent water leakage.
- When cleaning the product, unplug the power plug.
- Do not allow anyone to hang from or climb on the product.
- Be particularly cautious of children operating the product.

Notes for installation

- Keep a distance of over 10 cm between the back and sides of the product and the wall for smooth ventilation. Not doing so can cause malfunctions.
- When connecting the water hose, do not connect it to the hot water pipe. Doing so may cause malfunctions.
- Check the pipe and hose connection for leaks. Water can leak and cause electric shock or injury.
- When transporting the product, do not tilt the product over 30 degrees. Doing so can cause malfunctions.
- Install the product in an indoor place with a surrounding temperature of over 5 °C and less than 35 °C. Not doing so can cause malfunctions
- Avoid installing the water filtration system in a place with an uneven ground, a large amount of moisture, direct sunlight, dust, and direct water splashing.
- Connect the product to a drinking water pipe with a water pressure of 147-780 kPa (1.5-7.9 kgf/cm²). Not doing so may cause malfunctions.

OPERATION

Parts and Functions



1 Control Panel

This allows you to select the volume of cold water and/or ambient water and indicates the filter replacement period.

2 Turning Water Outlet

This function allows the user to dispense water freely by turning the water outlet.

3 Water tray

This is the area where a water bottle or container can be placed and used.

- The appearance or components of the product may differ from model to model.

Notes for Operation


- Open the water supply valve. The water filtration system operates normally only when water is supplied properly.
- When the hot water and cold water temperature icons are turned off, check if the power supply has been suspended due to power failure or other reasons.
- It is very important to replace the filter periodically in order to drink clean water. When using an expired filter, the performance of water filtration system can deteriorate. Always abide by the filter replacement period.
- It is very important to replace the filter periodically in order to drink clean water. When using an expired filter, the performance of water filtration system can deteriorate. Always abide by the filter replacement period.
- If the product has not been used for a long period of time, discharge cold water, ambient water, and hot water for 10 minutes each, and then use. Old water can multiply bacteria or change the water taste.
- Do not use purified water for replacing water in the humidifier or fishbowl. Leaving purified water as it is for a long period of time can multiply bacteria.
- Use the product only after closing the product cover completely. Otherwise, insects or other foreign substances may get in.
- Do not forcibly operate the turning water outlet (left and right, up and down) or apply impact. Doing so can cause damage to the water outlet.
- When heating or freezing water, white sediment may appear due to minerals in water. These minerals are harmless to humans.
- Water may remain inside the product due to the inspection process carried out while manufacturing the product. This is not a sign of the product having been used previously, so feel free to use the product.
- Do not use a mechanical device other than those recommended for improving the performance of the water purifier. Doing so may cause malfunctions.

Suggestion for Energy Saving

- If the product will not be used for a long period of time, unplug the power plug and drain the water inside the water filtration system completely.
- In case the hot water or cold water function will not be used, turn the hot water or cold water function off.

Using Control Panel

Units and Functions



1 AMBIENT button

This is the function to use ambient water.

1. Press the **AMBIENT** button.
 2. When you press the **Dispense** button, ambient water will come out.
- In case ambient water comes out continuously, press any button to stop.

2 COLD button

This is the function to use cold water.

1. Press the **COLD** button.
 2. When you press the **Dispense** button, cold water will come out.
- If you wish to not use the cold water function in order to save energy, press the **COLD** button more than 3 sec. The cold water function will be cancelled. To use cold water again, press the **COLD** button more than 3 sec. The cold water function will be set.
 - In case cold water comes out continuously, press any button to stop.

3 Cold water temperature icon

The cold water temperature is displayed in 3 levels.

- The icon is divided into 3 levels according to the cold water temperature. As more indication lamps turn on, the cold water becomes colder.
- The temperature cannot be adjusted discretionally.

4 VOLUME button

This function dispenses cold water or ambient water by separating the volume into 3 stages (120 ml, 500 ml, 1000 ml).

- When you press the **AMBIENT** or **COLD** button, select the desired volume and press the **Dispense** button, the selected volume of the selected water type will dispense.
- The dispensed amount of water may vary depending on the installation environment. If an accurate measurement is necessary, use a separate measuring device.

5 CONT. button

This function dispenses cold water or ambient water continuously for up to 3 minutes.

- When another button is pressed while dispensing water continuously, the dispensing will stop.

6 Dispense button + FILTER CHANGE icon

This function is used for dispensing water.

This indicates the filter replacement period.


- The color indicating that the filter is usable is blue. The color indicating that the filter should be replaced is orange.

Notes for Using the Control Panel

- The control panel will turn on in any of the following cases.
 - When the power is turned on
 - When a touch button is pressed
- The control panel will dim automatically for energy saving in any of the following cases.
 - When 1 minute has passed after turning on the power
 - When no touch button operation is carried out for 1 minute after a desired touch button is pressed
- The touch buttons on the control panel operate by responding to an object with static electricity.
- If you press a touch button even after the control panel has dimmed, the relevant function will function.
- If there is contact with a human body while cleaning the control panel, the touch button function may operate.
- If the control panel is smeared with a foreign substance or the touch buttons are operated with clothing or gloves, the operation may be restricted.
- If the control panel is wet, it may not operate or the touch buttons may malfunction. Remove water before using the product.
- The **dispense** button is not a touch button. It operates smoothly only when the center area is pressed.


Using the Water Tray

You can turn the water tray to the left or right to use the product in various directions.



- However, if there is no floor support structure for water tray, do not turn the water tray.
- If the water tray has come off from the floor, do not place a heavy object on top of it.
- Set the direction of the water outlet in the same direction as the tray when using the product.

If the water tray is filled with water, the buoy will come up. If you see the orange color, drain water from the water tray.



- Drain water carefully in order not to spill on the floor.

MAINTENANCE

Cleaning

Notes for Cleaning

Use a soft wet towel to wipe the product exterior. If you have used a neutral detergent, wipe it with a clean towel to make sure it does not stain.

Do not use a rough brush, or detergent (such as toothpaste, alcohol, thinner, bleach, benzene, flammable liquid or polish) to remove adhesive marks or hand prints on the surface of the product.


- This can cause discoloration of product exterior or product damage.

Clean the inside and outside of the water outlet periodically with a cleaning brush.

- If it is not cleaned periodically, lint, lime components (calcium, magnesium), or foreign substances can appear on the outlet.

How to clean water outlet


Clean the water outlet periodically using a soft brush. Fur or foreign substances can accumulate in the water outlet.




- If it is not cleaned periodically, lint, lime components (calcium, magnesium), or foreign substances can appear on the outlet.

How to clean water tray

- 1 Separate the water tray cover by pulling it upwards.




- 2 Separate the water tray by pulling it forward.



- 3 Clean it with water.


- 4 Wipe the surface of the water tray with a soft cloth.

- 5 Place the water tray cover on the water tray, adhere it to the front side of the product closely, and gently push it to install.



- Caution should be taken. If a large amount of water is in the drip tray, water can spill out when separating the drip tray.


Using the Smart Function

This content only applies to models with  logo on the product.

Conveniently use the LG Smart Diagnosis™ to communicate with the appliance right from a smart phone.

Installation of the Application


Search for the LG Smart ThinQ application from the Google Play Store on a smart phone.



Product Registration

- 1 Run the LG Smart ThinQ application on a smart phone.
- 2 Create an account and sign in.
- 3 Select Register.
- 4 Select Water purifier
- 5 Follow the instruction on the smart phone.
 - If you see a pop-up message about NFC, turn on the NFC function in the smart phone.
- 6 Firmly attach the smartphone to the Tag On logo.
 - If you can not make a connection, then move the smart phone up and down slowly.

NOTE

- Press  in the LG Smart ThinQ application for a more detailed guide on how to use the Tag On function.
- To operate the NFC function in this machine requires a smart phone which has at least a certain level of NFC recognition function.
- Because of the characteristics of NFC, if the transmission distance is too far, or if there is a metal sticker or a protective case on the phone, transmission will not be good. In some cases, NFC-equipped phones may be unable to transmit successfully.
- The content found in this manual may differ from the current version of the LG Smart ThinQ application, and the software may be modified without informing customers.
- NFC function would vary depending on smart phones.


Using the Application

Select the appliance of the Dashboard to use desirable functions by touching the LG appliance's Tag On logo with an NFC-equipped smart phones.

Smart Diagnosis


If you use the smart diagnosis function, you will be provided with the useful information such as a correct way of using the product based on the pattern of use.

SMART DIAGNOSIS™

This content only applies to models with  logo on the product.

Use this function if you need an accurate diagnosis by an LG Electronics Customer Information Center when the product malfunctions or fails.

Smart Diagnosis™ cannot be activated unless the appliance is turned on by pressing the **Power** button. If the appliance is unable to turn on, then troubleshooting must be done without using Smart Diagnosis™.



NOTE

- The Smart Diagnosis™ function depends on the local call quality.
- The communication performance will improve, and will receive better service if you use a home phone.
- Smart Diagnosis™ function is used only when contacting a customer service representative.

Using Smart Diagnosis™

Smart Diagnosis™ Using the Smart Phone

- 1 Turn on the power and hold the phone close to the logo of Smart Diagnosis™.
 - Make sure that the mouthpiece of the phone faces the logo of Smart Diagnosis™.
- 2 Press the **AMBIENT** and **CONT.** buttons for 3 seconds to operate the Smart Diagnosis™ function.
- 3 Do not remove the phone from the product while data is being transmitted.
- 4 After data transmission is finished, receive the explanation on the diagnosis result from the customer service representative.
 - All buttons on the control panel will turn on while data is being transmitted. When data transmission is finished, the buttons will return to their initial condition. Receive the explanation on the diagnosis result from the customer service representative and take appropriate measures.

TROUBLESHOOTING

Symptoms	Reason	Solution
Water tastes strange.	Is the power turned off?	<ul style="list-style-type: none"> Press the power button on the control panel to turn it on.
	Have you left the water purifier for a long period of time without using it?	<ul style="list-style-type: none"> The taste of water may change as it ages due to bacterial multiplication. Use the water purifier after discharging cold water, hot water and ambient water for 10 minutes respectively.
	Has it been a long time since you installed and replaced the filter?	<ul style="list-style-type: none"> If an expired filter is used, the purification performance may decline. It is recommended to replace the filter according to the filter replacement period.
The purification amount has reduced suddenly	Is it time to replace the filter?	<ul style="list-style-type: none"> Make a request for a filter replacement.
	Is the water supply valve closed?	<ul style="list-style-type: none"> Open the water supply valve.
Water does not dispense.	Did you miss the filter replacement period?	<ul style="list-style-type: none"> Make a request for a filter replacement.
	Is the water supply valve closed?	<ul style="list-style-type: none"> Open the water supply valve.
	Is the power plug unplugged from the outlet?	<ul style="list-style-type: none"> Plug the power plug in the outlet correctly.
	Does water not dispense when you press the discharge button?	<ul style="list-style-type: none"> Contact an LG Electronics service centre.

Symptoms	Reason	Solution
<p>Cold water, hot water or ambient water does not dispense.</p>	<p>Did you turn off the relevant function?</p>	<ul style="list-style-type: none"> • Turn on the relevant function
	<p>Did you discharge a large amount of cold water?</p>	<ul style="list-style-type: none"> • If you have discharged a lot of cold water so that there is little water in the storage tank, cold water may not dispense. Wait a while until water is filled inside the storage tank and then use. (Only applicable to models with a storage tank.) • If you discharge a large amount of cold water at once, the temperature of cold water inside the cold water tank will rise. Wait a while until water becomes colder and then use. (Only applicable to models with a cooling tank.)
	<p>Did you discharge a lot of hot water?</p>	<ul style="list-style-type: none"> • If you discharge a lot of hot water at once, the temperature of hot water inside the hot water tank drops and tepid water may dispense. Wait a while until hot water becomes hotter and then use. (Only applicable to models with a hot water tank.)
	<p>Did you discharge a lot of ambient water?</p>	<ul style="list-style-type: none"> • If you have discharged a lot of purified water (including ambient water) so that there is little purified water in the storage tank, purified water may not come out. Wait a while until water is filled inside the storage tank and then use. (Only applicable to models with a storage tank.)

Symptoms	Reason	Solution
The product is noisy and generates abnormal sounds.	Is the product installed on a weak floor or not installed on a stable surface?	<ul style="list-style-type: none"> • Install the product in a place with a flat and even surface.
	Does the back of the product touch the wall?	<ul style="list-style-type: none"> • Adjust the installation position to ensure there is enough space around the product. (10 cm)
	Is an object placed on top of the product?	<ul style="list-style-type: none"> • Remove the object placed on top of the product.
No ice forms in the product. (Only applicable to models with ice function)	Is the ice machine cover opened?	<ul style="list-style-type: none"> • Put on the ice machine cover.
	Have 6 hours passed since tap water and power were supplied?	<ul style="list-style-type: none"> • Use the product after 6 hours since tap water and power were supplied first.
Fine particles occur in the purified water.	Did water bubbles form?	<ul style="list-style-type: none"> • Water bubbles may form in the draining process. It is safe for you to drink. • If fine particles still exist after you take water from the water purifier and several minutes have passed, cut off the tap water and power supply and contact an LG Electronics service centre.

WARRANTY CARD

LG WATER PURIFIER

This warranty card is valid only for products sold by LG Electronics in the Market in Thailand.

www.lg.com/th

PURCHASER INFORMATION

PURCHASER'S NAME

ADDRESS

CITY

STATE

PIN CODE

MODEL NO.

SERIAL NO.

DATE OF PURCHASE

INVOICE NO.

DEALER STAMP

STAMP

DEALER INFORMATION

DEALER'S NAME

ADDRESS

CITY

STATE

PIN CODE

THIS WARRANTY IS NOT TRANSFERABLE AND IS APPLICABLE TO THE ORIGINAL PURCHASER ONLY.

FILL OUT THIS RECORD AND KEEP IT TOGETHER WITH YOUR PURCHASE DOCKET IN A SAFE PLACE. SHOULD YOU REQUIRE SERVICE UNDER THE TERMS OF THIS WARRANTY, PLEASE CONTACT US.

LG ELECTRONICS Tai PVT. LTD. UNDERTAKES BY THIS WARRANTY

THE REQUIREMENT OF WARRANTY

Should your LG product fail due to a defect in material or workmanship under normal home use during the warranty period set forth below, the company will repair or replace the product upon receipt of proof of original retail purchase.

This warranty is valid only for the original retail purchaser of the product and applicable only to a product sold in Thailand by the company's authorized dealer.

WARRANTY PERIOD

The LG Water Purifiers comes with a 1 year warranty from the date of purchase. The 1 year warranty covers all functional parts (except consumables-all inside filters, plastic parts), provided the warranty card bears the rubber stamp, date, and signature of our Authorized Dealer.

*Note: If the original date of purchase cannot be verified from the proof of purchase, the warranty will begin 3 months after the manufacturing month, which shall be verified based on the serial no./barcode label on the product.

WHAT THIS WARRANTY COVERS

LG Electronics Thailand Pvt. Ltd. (LGETH/the Company) offers you limited warranty for products sold within the territories of Thailand and guarantees that the product is free from defects in material and workmanship, according to the following terms and conditions:

1. Repairs under warranty shall be carried out by authorized service personnel only. The details of centralized help lines are provided in the overleaf.
2. In case of repairs or replacement of any part of the unit, this warranty will thereafter continue and remain in force only for the unexpired period of the warranty. Replacement of parts will be solely at the discretion of LGETH. In case the replacement of the entire unit is made, (subject to the sole discretion of LGETH), the same model shall be provided as replacement; if such model has been phased out, the equivalent model as determined by LGETH shall be provided as replacement.
3. In case of repair, LGETH shall endeavor to use new parts. If new parts are not available, however, then LGETH will have every right to use refurbished parts. The warranty on replacement model / Refurbished part shall remain in force only for the unexpired period of the warranty based on original purchase.
4. The company or its Authorized Service Center reserves the right to retain any part or component replaced at its discretion in case of a defect discovered in the equipment during the warranty period.
5. The company offers 2 free visits for PM (Preventive Maintenance) in which complete Electrolysis Sterilization will be done at each visits & Pre Carbon composite filter or Sediment filter will be replaced once a year.

6. If any of the colored internal or external components is replaced, LGETH is committed to ensuring that the shades match the original or other components. The replaced shades, patterns, or tints may vary from the customer's unit due to continuous usage of the unit. Any matching component changed at the customer's request other than the component that is actually needed will be charged.
7. This warranty will automatically be terminated upon the expiration of the warranty period specified above, even if the LG product may not be in use at any time during the warranty period for any reason.

WHAT THIS WARRANTY DOES NOT COVER

1. Visiting charges of the service engineer for units installed beyond the municipal limits of the jurisdiction of the company's Authorized Service Center. All expenses incurred in collecting the units or parts thereof from the company's authorized service center as well as expenses incurred from deputizing service personnel/technicians for conveyance and other incidentals, etc., shall be borne by the customer. Local charges for transportation and handling charges may vary by location. Customers are advised to verify in advance. If the customer wishes to bring the unit on his/her own to an authorized service center, such shall be at his/her own risks & consequences.
2. Reinstallation or uninstallation of product based on customer demand. Packing material, if used, will also be charged.
3. Transportation cost in case customer is moving the product to another location.
4. Damage resulting from operating the product in a corrosive atmosphere or contrary to the instructions outlined in the products owner's manual.
5. Replacement of all inside filters (Sediment, Pre carbon, Post Carbon, RO Membrane) are not covered by this warranty.
6. Damage to the product caused by accidents, pests and vermin, lightning, wind, fire floods, or acts of god.
7. Damage resulting from misuse, abuse, improper installation, repair, or maintenance. Improper repair includes use of parts other than those approved or specified by LGETH.
8. Damage or failure caused by unauthorized modification or alteration or use for purposes other than the intended purpose or any water leak in case the unit was not properly installed.
9. Damage or failure caused by incorrect electrical current, voltage, or inadequate electrical services, commercial or industrial use, or use of spurious/fake accessories or components or cleaning products other than those approved by LGETH.
10. Damage caused by transportation and handling, including scratches, dents, chips, and/or other damage to the finish of your product.
11. Damage or missing items of any display, open box, discounted or refurbished product.
12. Free accessories provided external to the product.
13. Damage to the product if the customer has the product repaired by an unauthorized dealer/person.
14. Upon removal, tampering, or alteration of the serial number/identification labels on the machine or any of its components

LG Electronics (Thailand) Co.,Ltd.
75/81 Richmond Building, Class 22,
Sukhumvit Soi.26, Sukhumvit Road,
Klongton, Klong Toey, Bangkok 10110
www.lg.com/th



คู่มือผู้ใช้

เครื่องกรองน้ำ

อ่านคู่มือผู้ใช้ฉบับนี้โดยละเอียดก่อนการใช้งานเครื่องใช้และเก็บรักษาไว้ให้
สะดวกในการนำมาอ้างอิงได้ตลอดเวลา

สารบัญ

คู่มือนี้ถูกจัดทำขึ้นสำหรับกลุ่มของผลิตภัณฑ์และอาจมีภาพหรือเนื้อหาต่างจากรุ่นที่คุณซื้อ
คู่มือนี้อาจมีการเปลี่ยนแปลงแก้ไขโดยผู้ผลิต

คำแนะนำด้านความปลอดภัย	03
คำแนะนำด้านความปลอดภัยที่สำคัญ	04
การติดตั้ง.....	09
หมายเหตุสำหรับการติดตั้ง	09
การใช้งาน	10
ชิ้นส่วนและการทำงาน	10
หมายเหตุสำหรับการใช้งาน	11
การใช้แผงควบคุม.....	12
หมายเหตุสำหรับการใช้แผงควบคุม	13
การใช้ถาดน้ำ.....	13
การบำรุงรักษา.....	14
การทำความสะอาด	14
การใช้ Smart Function	15
SMART DIAGNOSIS™	16
การแก้ปัญหา.....	17

คำแนะนำด้านความปลอดภัย

แนวทางด้านความปลอดภัยต่อไปนี้จะมุ่งหวังที่จะป้องกันความเสี่ยงหรือความเสียหายที่คาดไม่ถึงจากการใช้งานผลิตภัณฑ์ที่ไม่ปลอดภัยหรือไม่ถูกต้อง
แนวทางปฏิบัติได้แยกส่วนเป็น 'คำเตือน' และ 'ข้อควรระวัง' ดังคำอธิบายด้านล่าง

! สัญลักษณ์นี้แสดงไว้เพื่อระบุเนื้อหาและการทำงานที่อาจก่อให้เกิดความเสี่ยงได้อ่านส่วนที่มีสัญลักษณ์นี้อย่างละเอียดและปฏิบัติตามคำแนะนำเพื่อหลีกเลี่ยงความเสี่ยง

! คำเตือน - สัญลักษณ์นี้บ่งชี้ว่าการไม่ปฏิบัติตามคำแนะนำอาจก่อให้เกิดการบาดเจ็บรุนแรงหรือเสียชีวิต

! ข้อควรระวัง - สัญลักษณ์นี้บ่งชี้ว่าการไม่ปฏิบัติตามคำแนะนำอาจก่อให้เกิดการบาดเจ็บเล็กน้อยหรือความเสียหายต่อผลิตภัณฑ์

! คำเตือน

สำหรับการลดความเสี่ยงของการระเบิด ไฟไหม้ การเสียชีวิต ไฟฟ้าช็อต การได้รับบาดเจ็บหรือการถูกไอน้ำลวกต่อบุคคลเมื่อใช้งานผลิตภัณฑ์นี้ กรุณาปฏิบัติตามข้อควรระวังเบื้องต้น รวมไปถึงรายการต่อไปนี้:

เด็กเล็กในบ้าน

เครื่องใช้ไม่ได้ออกแบบมาสำหรับการใช้งานโดยบุคคล (รวมถึงเด็กเล็ก) ที่มีทักษะทางกายภาพ การรับรู้ หรือทางจิตใจที่บกพร่อง หรือขาดความรู้และประสบการณ์ ยกเว้นแต่ได้รับการควบคุมดูแลหรือได้รับคำแนะนำเกี่ยวกับการใช้งานเครื่องใช้นี้โดยบุคคลที่รับผิดชอบความปลอดภัยของพวกเขา เด็กเล็กจะต้องได้รับการควบคุมดูแลเพื่อให้มั่นใจว่าพวกเขาจะไม่เล่นกับเครื่องใช้นี้

คำแนะนำด้านความปลอดภัยที่สำคัญ

คำเตือน

สำหรับการลดความเสี่ยงของการระเบิด ไฟไหม้ การเสียชีวิต ไฟฟ้าช็อต การได้รับบาดเจ็บหรือการถูกไอน้ำลวกต่อบุคคลเมื่อใช้งานผลิตภัณฑ์นี้ กรุณาปฏิบัติตามข้อควรระวังเบื้องต้น รวมไปถึงรายการต่อไปนี้:

การติดตั้ง

- ต่อสายดินเครื่องใช้ไฟฟ้าเพื่อความปลอดภัย สำหรับรายละเอียดเพิ่มเติมเกี่ยวกับการต่อสายดิน สอบถามที่ศูนย์ข้อมูลลูกค้า LG Electronics
- ติดตั้งเครื่องใช้ไฟฟ้าบนพื้นที่แข็งแรงและเสมอกัน
- อย่าติดตั้งเครื่องใช้ไฟฟ้าในสถานที่ชื้นหรือมีฝุ่น
- อย่าวางเครื่องใช้ไฟฟ้าในที่ที่แดดส่องถึงโดยตรงหรือให้สัมผัสกับความร้อนจากเครื่องใช้ที่ทำความร้อน เช่น เตาทำอาหารหรือเครื่องทำความร้อน
- ระวังอย่าสัมผัสกับด้านหลังของเครื่องใช้ไฟฟ้าเมื่อทำการติดตั้งเครื่องใช้ไฟฟ้านั้น
- อย่าติดตั้งผลิตภัณฑ์ใกล้ไฟหรือวัสดุที่ติดไฟได้ (อีเธอร์ เบนซิน แก๊สหุงต้ม ฯลฯ)
- เมื่อทำการติดตั้งท่อระบาย ยึดไว้ด้านในทางระบายให้ลึกโดยใช้ยางอัดตัว (ใช้กับรุ่นที่มีฟังก์ชันทำนําร้อนเท่านั้น)
- ติดตั้งเครื่องใช้ไฟฟ้าในตำแหน่งที่ง่ายต่อการถอดปลั๊กไฟของเครื่องใช้

กำลังไฟ

- อย่าเสียบปลั๊กไฟของผลิตภัณฑ์เข้าไปในเต้ารับแบบหลายชอกเกิดโดยไม่มีสายไฟเคเบิล (ชนิดยึดติด)
- เครื่องใช้ไฟฟ้านี้ได้รับการติดตั้งสายไฟที่มีตัวนำที่ต่อสายดินให้อุปกรณ์และปลั๊กไฟแบบต่อสายดิน สายไฟจะต้องถูกเสียบเข้าไปในเต้ารับชอกเกิดที่เหมาะสมซึ่งถูกติดตั้งและต่อสายดินโดยสอดคล้องกับกฎหมายและข้อบัญญัติท้องถิ่นทั้งหมด
- ใช้งานเฉพาะเต้ารับชอกเกิดต่อขยายที่ต่อสายดินเท่านั้น
- อย่าเสียบปลั๊กเครื่องใช้ไฟฟ้าเข้าไปในเต้ารับแบบหลายชอกเกิดหรือสายไฟเคเบิลต่อขยาย
- ระมัดระวังอย่าช้ปลั๊กไฟชั้นด้านบนหรือปล่อยให้เครื่องใช้ไฟฟ้าเอียงทับสายไฟ
- ถอดสายไฟก่อนทำความสะอาดเครื่องใช้ไฟฟ้า
- อย่าจับปลั๊กไฟด้วยมือที่เปียก
- เสียบปลั๊กไฟในเต้ารับชอกเกิดให้แน่นหนาหลังการขจัดความชื้นและฝุ่นจนหมดแล้ว
- ห้ามถอดปลั๊กเครื่องใช้ไฟฟ้าโดยการดึงที่สายไฟเคเบิล จับที่ปลั๊กไฟให้มั่นและดึงออกตรง ๆ จากเต้ารับชอกเกิดเสมอ
- หากสายไฟได้รับความเสียหายหรือช่องของเต้ารับชอกเกิดหลวม อย่าใช้งานสายไฟและควรติดต่อศูนย์บริการที่ได้รับอนุญาต
- ถอดปลั๊กไฟในระหว่างที่มีฟาร์องหรือฟ้าแลบ หรือเมื่อไม่ใช้งานเป็นระยะเวลานาน
- อย่างอสายไฟมากเกินไปหรือวางของหนักทับบนสายไฟ
- อย่าดัดแปลงหรือต่อสายไฟให้ยาวขึ้น
- อย่าเสียบหรือถอดปลั๊กไฟซ้ำ ๆ หลายครั้ง

การใช้งาน

- ในกรณีที่เกิดน้ำท่วม ให้ทำการถอดปลั๊กไฟและติดต่อศูนย์ข้อมูลลูกค้า LG Electronics
- หากมีการรั่วของแก๊ส (ไอโซบิวเทน โพรเพน แก๊สธรรมชาติ ฯลฯ) อย่าสัมผัสเครื่องใช้ไฟฟ้าหรือปลั๊กไฟ และระบายอากาศในพื้นที่ทันที ผลิตภัณฑ์นี้ใช้แก๊สที่เป็นมิตรต่อสิ่งแวดล้อมอย่างมาก (ไอโซบิวเทน, R600a) เป็นสารทำความเย็น แม้ว่าจะใช้งานแก๊สในปริมาณน้อย แต่ก็เป็นแก๊สที่ลุกไหม้ได้ การรั่วของแก๊สในระหว่างการขนส่ง การติดตั้ง หรือการใช้งานเครื่องใช้ไฟฟ้าอาจก่อให้เกิดไฟ การระเบิด หรือการบาดเจ็บ หากมีประกายไฟเกิดขึ้น
- อย่าพรมน้ำภายในหรือภายนอกเครื่องใช้ไฟฟ้าเพื่อทำความสะอาด
- อย่าทำความสะอาดเครื่องใช้ไฟฟ้าด้วยแปรง ผ้า หรือฟองน้ำที่มีผิวหยาบหรือทำจากวัสดุที่เป็นโลหะ
- ถอดปลั๊กไฟและติดต่อศูนย์ข้อมูลลูกค้า LG Electronics ทันทีหากคุณพบเสียงแปลกปลอม กลิ่น หรือควันออกมาจากเครื่องใช้ไฟฟ้า
- อย่าวางวัตถุที่มีน้ำหนักมากหรือแตกหักง่าย ภาชนะที่บรรจุของเหลว สารที่ลุกไหม้ได้ หรือวัตถุที่ติดไฟได้ (เช่น เทียนหรือตะเกียง) บนเครื่องใช้ไฟฟ้า
- ควรมีเฉพาะบุคลากรที่มีคุณวุฒิจากศูนย์บริการ LG Electronics เท่านั้นที่ถอดชิ้นส่วน ช่อมแซม หรือดัดแปลงเครื่องใช้ไฟฟ้า ติดต่อศูนย์ข้อมูลลูกค้า LG Electronics หากคุณย้ายและติดตั้งเครื่องใช้ไฟฟ้าในตำแหน่งอื่น
- อย่าใช้หรือเก็บรักษาสารที่ติดไฟหรือลุกไหม้ได้ (อีเธอร์ เบนซีน แอลกอฮอล์ สารเคมี แก๊ส หุงต้ม สเปรย์ลุกไหม้ได้ ยาฆ่าแมลง น้ำหอมปรับอากาศ เครื่องสำอาง ฯลฯ) ใกล้เครื่องใช้ไฟฟ้า
- หากน้ำซึมเข้าไปในชิ้นส่วนทางไฟฟ้าของเครื่องใช้ไฟฟ้า ให้ทำการถอดปลั๊กไฟและติดต่อศูนย์ข้อมูลลูกค้า LG Electronics
- หากน้ำรั่วจากภายในของผลิตภัณฑ์หรือน้ำนองใกล้ผลิตภัณฑ์ให้ทำการปิดวาล์วแหล่งจ่ายน้ำ ถอดปลั๊กไฟ และติดต่อศูนย์บริการ LG Electronics
- อย่าใช้แรงที่มากเกินไปหรือกระแทกฝาครอบด้านหลังของเครื่องใช้ไฟฟ้า
- อย่าใช้อุปกรณ์ทางกลหรือวิธีการอื่น ๆ เพื่อเร่งกระบวนการละลายน้ำแข็ง นอกเหนือจากที่ได้ รับการแนะนำโดยผู้ผลิต
- อย่าย้ายผลิตภัณฑ์ในขณะที่ผลิตภัณฑ์ถูกเสียบปลั๊กไว้
- อย่าใช้แรงที่มากเกินไปหรือกระแทกฝาครอบด้านหลังของผลิตภัณฑ์

การกำจัด

- เมื่อทำการทิ้งเครื่องใช้ไฟฟ้า ถอดยางอัดขอบประตูในขณะที่ปล่อยให้เย็นและตะกร้าหรือชิ้นส่วนทั้งหมดไว้ตั้งเต็ม และกันเด็กให้ห่างจากเครื่องใช้ไฟฟ้า
- ทิ้งวัสดุหีบห่อทั้งหมด (เช่น ถุงพลาสติกและสไตโรโฟม) ให้ห่างจากเด็ก วัสดุหีบห่ออาจทำให้เด็กหายใจไม่ออกได้

ความปลอดภัยทางเทคนิค

- ให้ช่องทางการระบายอากาศเปิดไว้ ในพื้นที่ปิดล้อมของเครื่องใช้ไฟฟ้าหรือโครงสร้างภายใน โดยไม่มีการกีดขวาง
- อย่าใช้อุปกรณ์ทางกลหรือวิธีการอื่น ๆ เพื่อเร่งกระบวนการละลายน้ำแข็ง นอกเหนือจากที่ได้รับการแนะนำโดยผู้ผลิต
- อย่าสร้างความเสียหายให้กับวงจรทำความเย็น
- สารทำความเย็นและก๊าซที่แพร่กระจายตัวออกเป็นฉนวนซึ่งใช้ในเครื่องใช้ไฟฟ้านี้จะต้องได้รับการแยกกำจัดด้วยขั้นตอนการกำจัดพิเศษ ปรึกษาตัวแทนการให้บริการหรือบุคลากรที่มีคุณสมบัติที่คล้ายคลึงกันก่อนทำการกำจัด
- เครื่องใช้ไฟฟ้านี้บรรจุสารทำความเย็นไอโซบิวเทน (R600a) ในปริมาณน้อย แก๊สธรรมชาติที่มีความเข้ากันได้กับสภาพแวดล้อมสูง แต่สามารถลุกไหม้ได้ด้วยเช่นกัน เมื่อทำการขนส่งและติดตั้งเครื่องใช้ไฟฟ้า ควรใช้ความระมัดระวังเพื่อให้แน่ใจว่าไม่มีชิ้นส่วนของวงจรทำความเย็นได้รับความเสียหาย
- สารทำความเย็นที่พุ่งออกมาจากท่ออาจลุกไหม้หรือก่อให้เกิดการบาดเจ็บของดวงตาได้
- หากพบการรั่ว ให้หลีกเลี่ยงเปลวไฟหรือแหล่งของการลุกไหม้ที่เป็นไปได้ และระบายอากาศในห้องที่เครื่องใช้ไฟฟ้าตั้งอยู่เป็นเวลาสี่ห้านาที เพื่อหลีกเลี่ยงการเกิดส่วนผสมของอากาศกับแก๊สที่ติดไฟได้ หากเกิดการรั่วไหลในวงจรทำความเย็น ขนาดของห้องที่เครื่องใช้ไฟฟ้าถูกใช้งานควรสอดคล้องกับปริมาณของสารทำความเย็นที่ใช้ ห้องจะต้องมีขนาด 1 ตารางเมตร สำหรับสารทำความเย็น R600a ทุก ๆ 8 กรัมในเครื่องใช้ไฟฟ้า
- ปริมาณของสารทำความเย็นในเครื่องใช้ไฟฟ้าของคุณจะถูกแสดงไว้ในแผ่นลักษณะกำหนดภายในเครื่องใช้ไฟฟ้า
- ห้ามเปิดเครื่องใช้ไฟฟ้าที่มีสัญญาณของความเสียหาย หากมีข้อสงสัย ปรึกษาตัวแทนจำหน่ายของคุณ

⚠️ ข้อควรระวัง

สำหรับการลดความเสี่ยงของการได้รับบาดเจ็บเล็กน้อยต่อบุคคล การทำงานผิดปกติ หรือความเสียหายต่อผลิตภัณฑ์หรือทรัพย์สินเมื่อใช้งานผลิตภัณฑ์นี้ ให้ปฏิบัติตามข้อควรระวังพื้นฐานรวมไปถึงรายการต่อไปนี้:

การติดตั้ง

- อย่าเอียงเครื่องใช้ไฟฟ้าเพื่อตั้งหรือผลักเมื่อทำการขนส่ง
- เครื่องใช้ไฟฟ้านี้ควรถูกขนย้ายโดยคนสองคนหรือมากกว่าที่จับเครื่องใช้ไฟฟ้าอย่างมั่นคง
- ต่อท่อน้ำของผลิตภัณฑ์กับน้ำก๊อกเท่านั้น น้ำอื่นนอกเหนือจากน้ำก๊อกอาจเพิ่มความเสี่ยงต่อการสัมผัสกับโรคได้ น้ำอื่น ๆ อาจลดอายุการใช้งานของผลิตภัณฑ์หรือก่อให้เกิดการทำงานผิดปกติ
- น้ำร้อนอาจกระเซ็นออกมาได้ ดังนั้นติดตั้งท่อระบายน้ำกับทางระบายอย่างความระมัดระวัง

การใช้งาน

- ป้องกันสัตว์จากการแทะสายไฟหรือท่อน้ำ
- ควบคุมเด็กหรือบุคคลที่มีทักษะในการเรียนรู้ไม่ดีเพื่อให้แน่ใจว่าพวกเขาใช้งานเครื่องใช้ไฟฟ้าอย่างปลอดภัย
- ระวังระวังอย่าสร้างความเสียหายให้ท่อส่งสารทำความเย็น
- เปลี่ยนไส้กรองด้วยไส้กรองมาตรฐานของ LG ตามกำหนดเวลาโดยสอดคล้องกับระยะเวลาในการเปลี่ยน ไส้กรองเก่าอาจเพิ่มจำนวนแบคทีเรียหรือเปลี่ยนแปลงรสชาติของน้ำ ระยะเวลาการเปลี่ยนไส้กรองแปรผันไปตามการใช้งาน สถานที่ของการใช้งาน ฤดูกาล และคุณภาพของน้ำ
- เมื่อใช้น้ำร้อน ใช้ภาชนะที่มีหูจับ (ใช้เฉพาะกับรุ่นที่มีฟังก์ชันทำน้ำร้อน)
- หากถาดรองน้ำของผลิตภัณฑ์ยื่นออกมาจากโต๊ะทำงานหรือโต๊ะวางของ อย่าวางสิ่งของใด ๆ ที่ด้านบนของถาดรองน้ำ
- ใช้ความระมัดระวังต่อความเป็นไปได้ของการสร้างความเสียหายให้ท่อ (เข้า ออก) เพื่อป้องกันการรั่วของน้ำ
- เมื่อทำความสะอาดผลิตภัณฑ์ ให้ถอดปลั๊กไฟ
- อย่าปล่อยให้ใครห้อยโหนหรือปีนบนผลิตภัณฑ์
- ระวังระวังโดยเฉพาะอย่างยิ่งกับเด็กที่ใช้งานผลิตภัณฑ์


การติดตั้ง

หมายเหตุสำหรับการติดตั้ง

- เว้นระยะห่างมากกว่า 10 ซม. ระหว่างด้านหลังและด้านข้างของผลิตภัณฑ์และผนังสำหรับการระบายอากาศที่ราบรื่น การไม่ทำตามอาจก่อให้เกิดการทำงานผิดปกติ
- เมื่อทำการต่อท่อ น้ำยาต่อกับท่อน้ำร้อน การกระทำดังกล่าวอาจก่อให้เกิดการทำงานผิดปกติ
- ตรวจสอบการเชื่อมต่อท่อและสายยางเพื่อหาการรั่ว น้ำอาจรั่วและก่อให้เกิดไฟฟ้าช็อตหรือการบาดเจ็บ
- เมื่อทำการขนย้ายผลิตภัณฑ์ อย่าเอียงผลิตภัณฑ์เกินกว่า 30 องศา การกระทำดังกล่าวอาจก่อให้เกิดการทำงานผิดปกติ
- ติดตั้งผลิตภัณฑ์ในพื้นที่ภายในอาคารที่มีอุณหภูมิโดยรอบสูงกว่า 5 °C และต่ำกว่า 35 °C การไม่ทำตามอาจก่อให้เกิดการทำงานผิดปกติ
- หลีกเลี่ยงการติดตั้งระบบกรองน้ำในตำแหน่งที่พื้นไม่เสมอกัน มีความชื้นปริมาณมาก ใต้รับแสงแดดโดยตรง มีฝุ่น และอยู่ในบริเวณที่มีน้ำกระเด็นโดยตรง
- ต่อผลิตภัณฑ์กับท่อน้ำดื่มที่มีแรงดันน้ำ 147-780 kPa (1.5-7.9 kgf/cm²) การไม่ทำตามอาจก่อให้เกิดการทำงานผิดปกติ

การใช้งาน

ชิ้นส่วนและการทำงาน



1 แผงควบคุม

การกระทำนี้ช่วยให้คุณเลือกปริมาณของน้ำเย็นและ/หรือ น้ำที่อุณหภูมิห้อง และระยะเวลาการเปลี่ยนไส้กรองได้

2 หมุนเปิดช่องน้ำออก

ฟังก์ชันนี้ช่วยให้ผู้ใช้จ่ายน้ำได้อย่างอิสระโดยการหมุนเปิดช่องน้ำออก

3 ถาดรองน้ำ

นี่คือพื้นที่ซึ่งขวดน้ำหรือภาชนะสามารถถูกนำมาวางและใช้งานได้

- ลักษณะภายนอกหรือชิ้นส่วนของผลิตภัณฑ์อาจแตกต่างกันไปตามแต่ละรุ่น

หมายเหตุสำหรับการใช้งาน


- เปิดวาล์วแหล่งจ่ายน้ำ ระบบกรองน้ำทำงานตามปกติเมื่อได้รับการจ่ายน้ำอย่างเหมาะสมเท่านั้น
- เมื่อสัญลักษณ์น้ำร้อนและน้ำเย็นดับลง ตรวจสอบว่าแหล่งจ่ายไฟจะจกเนื่องจากไฟดับหรือสาเหตุอื่น ๆ หรือไม่
- เป็นเรื่องสำคัญอย่างมากที่จะเปลี่ยนไส้กรองตามกำหนดเวลาเพื่อให้ได้คือน้ำสะอาด เมื่อใช้งานไส้กรองที่หมดอายุประสิทธิภาพของระบบกรองน้ำอาจเสื่อมลง ปฏิบัติตามระยะเวลาการเปลี่ยนไส้กรองเสมอ
- เป็นเรื่องสำคัญอย่างมากที่จะเปลี่ยนไส้กรองตามกำหนดเวลาเพื่อให้ได้คือน้ำสะอาด เมื่อใช้งานไส้กรองที่หมดอายุประสิทธิภาพของระบบกรองน้ำอาจเสื่อมลง ปฏิบัติตามระยะเวลาการเปลี่ยนไส้กรองเสมอ
- หากผลิตภัณฑ์ไม่ถูกใช้งานเป็นระยะเวลานาน ให้ระบายน้ำเย็น น้ำที่อุณหภูมิห้อง และน้ำร้อนทิ้งเป็นเวลาอย่างละ 10 นาที จากนั้นจึงใช้งาน น้ำเก่าที่ค้างอยู่อาจเพิ่มจำนวนแบคทีเรียหรือเปลี่ยนแปลงรสชาติของน้ำ
- อย่าใช้น้ำกรองแทนที่น้ำในเครื่องทำความชื้นหรืออ่างปลา การปล่อยน้ำกรองทิ้งไว้เป็นระยะเวลานานอาจเพิ่มจำนวนแบคทีเรียได้
- ใช้งานผลิตภัณฑ์หลังจากปิดฝาครอบผลิตภัณฑ์อย่างสมบูรณ์แล้วเท่านั้น มิเช่นนั้น แมลงหรือสิ่งแปลกปลอมอื่น ๆ อาจเข้าสู่ภายใน
- อย่าทำการหมุนเปิดช่องน้ำออกด้วยแรงที่มาก (ซ้ายและขวาขึ้นและลง) หรือใช้แรงกระแทก การกระทำดังกล่าวอาจก่อให้เกิดความเสียหายต่อช่องน้ำออก
- เมื่อทำความร้อนหรือแช่แข็งน้ำ ตะกอนสีขาวอาจปรากฏขึ้นเนื่องจากแร่ธาตุในน้ำ แร่ธาตุเหล่านี้ไม่เป็นอันตรายต่อมนุษย์
- น้ำอาจตกค้างภายในผลิตภัณฑ์เนื่องจากกระบวนการตรวจสอบที่ดำเนินการในระหว่างการผลิตของผลิตภัณฑ์นี้ไม่ใช่สัญญาณที่บ่งชี้ว่าผลิตภัณฑ์เคยถูกใช้งานมาก่อน ดังนั้นใช้งานผลิตภัณฑ์ได้ตามต้องการ
- อย่าใช้อุปกรณ์ทางกลนอกเหนือจากที่ได้รับการแนะนำสำหรับการเพิ่มประสิทธิภาพของเครื่องกรองน้ำ การกระทำดังกล่าวอาจก่อให้เกิดการทำงานผิดปกติ

ข้อแนะนำสำหรับการประหยัดพลังงาน

- หากผลิตภัณฑ์จะไม่ถูกใช้งานเป็นระยะเวลานาน ถอดปลั๊กไฟและระบายน้ำภายในระบบกรองน้ำออกให้หมด
- ในกรณีที่ฟังก์ชันน้ำร้อนหรือน้ำเย็นจะไม่ถูกใช้ ปิดฟังก์ชันการทำงานน้ำร้อนหรือน้ำเย็น

การใช้แผงควบคุม

หน่วยและฟังก์ชัน



1 ปุ่ม AMBIENT

นี่คือฟังก์ชันเพื่อใช้น้ำที่อุณหภูมิห้อง

1. กดปุ่ม AMBIENT

2. เมื่อคุณกดปุ่ม Dispense น้ำที่อุณหภูมิห้อง จะออกมา

- ในกรณีที่น้ำที่อุณหภูมิห้อง ออกมาอย่างต่อเนื่อง ให้กดปุ่มใด ๆ เพื่อหยุด

2 ปุ่ม COLD

นี่คือฟังก์ชันเพื่อใช้น้ำเย็น

1. กดปุ่ม COLD

2. เมื่อคุณกดปุ่ม จ่ายน้ำ น้ำเย็นจะออกมา

- หากคุณไม่ต้องการใช้ฟังก์ชันน้ำเย็นเพื่อประหยัดพลังงาน กดปุ่ม COLD นานกว่า 3 วินาที ฟังก์ชันน้ำเย็นจะถูกล็อก หากต้องการใช้น้ำเย็นอีกครั้ง ให้กดปุ่ม COLD นานกว่า 3 วินาที ฟังก์ชันน้ำเย็นจะถูกตั้งค่า

- ในกรณีที่น้ำเย็นออกมาอย่างต่อเนื่อง กดปุ่มใด ๆ เพื่อหยุด

3 สัญลักษณ์อุณหภูมิน้ำเย็น

อุณหภูมิน้ำเย็นถูกแสดงใน 3 ระดับ

- สัญลักษณ์ถูกแบ่งออกเป็น 3 ระดับตามอุณหภูมิของน้ำเย็น เมื่อไฟระยิบมากขึ้น น้ำเย็นกำลังเย็นมากขึ้น
- อุณหภูมิไม่สามารถปรับตามต้องการได้

4 ปุ่ม VOLUME

ฟังก์ชันนี้จ่ายน้ำเย็นหรือน้ำที่อุณหภูมิห้อง โดยการแยกปริมาณออกเป็น 3 ชั้น (120 มล., 500 มล., 1000 มล.)

- เมื่อคุณกดปุ่ม AMBIENT หรือปุ่ม COLD เลือกปริมาตรที่ต้องการและกดปุ่ม จ่ายน้ำ ปริมาตรที่เลือกของชนิดของน้ำที่เลือกจะจ่ายออกมา
- ปริมาณน้ำที่ถูกจ่ายอาจแปรผันโดยขึ้นกับสภาพแวดล้อมของการติดตั้ง หากจำเป็นต้องทำการรีเซ็ตแบบแมนูเ่ล ให้ใช้อุปกรณ์สำหรับรีเซ็ตที่แยกต่างหาก

5 ปุ่ม CONT.

ฟังก์ชันนี้จ่ายน้ำเย็นหรือน้ำที่อุณหภูมิห้อง อย่างต่อเนื่องสูงสุดถึง 3 นาที

- เมื่อมีปุ่มอื่นถูกกดในขณะที่กำลังจ่ายน้ำอย่างต่อเนื่อง การจ่ายจะหยุดลง

6 ปุ่ม จ่ายน้ำ + สัญลักษณ์ การเปลี่ยนไส้กรอง

ฟังก์ชันนี้ใช้สำหรับการจ่ายน้ำ

นี่เป็นการระบุระยะเวลาการเปลี่ยนไส้กรอง


- สีที่ระบุว่าไส้กรองใช้งานได้คือสีน้ำเงิน สีที่ระบุว่าไส้กรองควรได้รับการเปลี่ยนคือสีส้ม

หมายเหตุสำหรับการใช้แผงควบคุม

- แผงควบคุมจะเปิดทำงานในกรณีต่อไปนี้
 - เมื่อเปิดเครื่อง
 - เมื่อกดปุ่มสัมผัส
- ไฟที่แผงควบคุมจะหรี่ลงโดยอัตโนมัติเพื่อการประหยัดพลังงานในกรณีต่อไปนี้
 - เมื่อผ่านไป 1 นาทีหลังการเปิดเครื่อง
 - เมื่อไม่มีการใช้งานปุ่มสัมผัสเป็นเวลา 1 นาทีหลังการกดปุ่มสัมผัสที่ต้องการ
- ปุ่มสัมผัสบนแผงควบคุมทำงานโดยการตอบสนองต่อวัตถุที่มีไฟฟ้าสถิตย์
- หากคุณกดปุ่มสัมผัสแม้หลังจากไฟที่แผงควบคุมหรี่ลงแล้ว ฟังก์ชันที่สัมพันธ์กันจะทำงาน
- หากมีการสัมผัสกับร่างกายมนุษย์ในขณะที่ทำความสะอาดแผงควบคุม ปุ่มสัมผัสอาจทำงาน
- หากแผงควบคุมเป็นอนาสัมผัสหรือปุ่มสัมผัสทำงานกับผ้าหรือถุงมือ การใช้งานสามารถถูกระงับได้
- หากแผงควบคุมเปียก อาจไม่ทำงานหรือปุ่มสัมผัสอาจทำงานผิดพลาด ชะลอน้ำออกก่อนใช้งานผลิตภัณฑ์
- ปุ่ม **จ่ายน้ำ** ไม่ใช่ปุ่มสัมผัส จะทำงานอย่างราบรื่นเฉพาะเมื่อกดบริเวณพื้นที่ตรงกลางเท่านั้น


การใช้ถาดน้ำ

คุณสามารถหมุนถาดน้ำไปทางซ้ายหรือทางขวาเพื่อใช้ผลิตภัณฑ์ในทิศทางต่าง ๆ ได้



- อย่างไรก็ตาม หากไม่มีโครงสร้างรองรับที่พื้นสำหรับถาดน้ำ อย่าหมุนถาดน้ำ
- หากถาดน้ำหลุดจากพื้น อย่าวางของหนักที่ด้านบน
- กำหนดทิศทางของช่องน้ำออกในทิศทางเดียวกันกับถาดเมื่อใช้งานผลิตภัณฑ์

หากถาดน้ำมีน้ำเต็ม ทุ่นจะลอยขึ้นมา หากคุณเห็นไฟสีส้มให้ระบายน้ำจากถาดน้ำ



- ระบายน้ำด้วยความระมัดระวังเพื่อไม่ให้หกลงพื้น

การบำรุงรักษา

การทำความสะอาด

หมายเหตุสำหรับการทำความสะอาด

ใช้ผ้าขนหนูเปียกนุ่มเพื่อเช็ดภายนอกผลิตภัณฑ์ หากคุณใช้น้ำยาทำความสะอาดที่เป็นกลาง เช็ดด้วยผ้าขนหนูสะอาดเพื่อให้แน่ใจว่าจะไม่เป็นคราบ

อย่าใช้แปรงแข็ง หรือน้ำยาทำความสะอาด (เช่น ยาสีฟัน แอลกอฮอล์ ทินเนอร์ น้ำยาฟอกขาว เบนซิน ของเหลวที่ติดไฟได้ หรือยาขัดเงา) เพื่อขจัดรอยขีดข่วนหรือรอยคราบมีบนพื้นผิวของผลิตภัณฑ์


- การทำเช่นนี้อาจก่อให้เกิดการเปลี่ยนสีของภายนอก ผลิตภัณฑ์หรือความเสียหายของผลิตภัณฑ์ได้

ทำความสะอาดด้านในและด้านนอกของช่องน้ำออกตามกำหนดเวลาด้วยแปรงทำความสะอาด

- หากไม่มีการทำความสะอาดตามกำหนดเวลา อาจมีสาหร่าย ส่วนประกอบของหินปูน (แคลเซียม แมกนีเซียม) หรือสารแปลกปลอมอาจปรากฏในช่องออก

วิธีการทำความสะอาดช่องน้ำออก


ทำความสะอาดช่องน้ำออกตามกำหนดเวลาโดยใช้แปรงอ่อนนุ่ม ขนสัตว์หรือสารแปลกปลอมอาจสะสมในช่องน้ำออก




- หากไม่มีการทำความสะอาดตามกำหนดเวลา อาจมีสาหร่าย ส่วนประกอบของหินปูน (แคลเซียม แมกนีเซียม) หรือสารแปลกปลอมอาจปรากฏในช่องออก

วิธีการทำความสะอาดถาดน้ำ

- 1 แยกฝาครอบถาดน้ำออกโดยการดึงขึ้นด้านบน




- 2 แยกถาดน้ำออกโดยการดึงทางด้านหน้า



- 3 ล้างด้วยน้ำ

- 4 เช็ดพื้นผิวของถาดน้ำด้วยผ้านุ่ม

- 5 วางฝาครอบถาดบนลงบนถาดน้ำ ดัดเข้ากับด้านหน้าของผลิตภัณฑ์ให้ใกล้ และดันอย่างเบามือเพื่อติดตั้ง




- ควรใช้ความระมัดระวัง หากมีน้ำปริมาณมากในถาดรองน้ำ น้ำอาจหกได้เมื่อทำการถอดแยกถาดรองน้ำ

การใช้ Smart Function

เนื้อหาที่ใช้เฉพาะกับรุ่นที่มีโลโก้  บนผลิตภัณฑ์เท่านั้น
ใช้คุณสมบัติ LG Smart Diagnosis™ เพื่อความสะดวกในการ
รื้อสี สารกับเครื่องใช้ไฟฟ้าจากสมาร์ตโฟนของคุณ

การติดตั้งแอปพลิเคชัน


ค้นหาแอปพลิเคชัน LG Smart ThinQ จาก Google Play Store ในสมาร์ตโฟน



การลงทะเบียนผลิตภัณฑ์

- 1 ใช้งานแอปพลิเคชัน LG Smart ThinQ ในสมาร์ตโฟน
- 2 สร้างบัญชีและลงชื่อเข้าใช้
- 3 เลือกทะเบียน
- 4 เลือกเครื่องกรองน้ำ
- 5 ปฏิบัติตามคำแนะนำในสมาร์ตโฟน
 - หากคุณเห็นหน้าต่างข้อความเกี่ยวกับ NFC ให้เปิดใช้งานฟังก์ชัน NFC ในสมาร์ตโฟน
- 6 ยึดสมาร์ตโฟนไว้กับโลโก้ Tag On ให้แน่นหนา
 - หากคุณไม่สามารถทำการเชื่อมต่อได้ ขยับสมาร์ตโฟนขึ้นและลงอย่างช้า ๆ

หมายเหตุ

- กด  ในแอปพลิเคชัน LG Smart ThinQ สำหรับคำแนะนำโดยละเอียดเพิ่มเติมเกี่ยวกับวิธีการใช้ฟังก์ชัน Tag On
- เพื่อใช้งานฟังก์ชัน NFC ในเครื่องนี้จำเป็นต้องใช้สมาร์ตโฟนที่มีฟังก์ชันในการจดจำ NFC อย่างน้อยในระดับหนึ่ง
- หากกระยะการส่งสัญญาณไกลเกินไป หรือมีสติกเกอร์โลหะหรือเคสป้องกันโทรศัพท์ การส่งสัญญาณอาจไม่ติดตามคุณลักษณะของ NFC ในบางกรณี โทรศัพท์ที่ติดตั้ง NFC อาจไม่สามารถส่งสัญญาณได้สมบูรณ์
- เนื้อหาในคู่มือนี้อาจแตกต่างจากเวอร์ชันปัจจุบันของแอปพลิเคชัน LG Smart ThinQ และซอฟต์แวร์อาจได้รับการแก้ไขโดยไม่มีแจ้งลูกค้า
- ฟังก์ชัน NFC อาจแตกต่างกันไปโดยขึ้นกับสมาร์ตโฟน

การใช้งานแอปพลิเคชัน

เลือกเครื่องใช้ไฟฟ้าของแดชบอร์ดเพื่อใช้ฟังก์ชันที่ต้องการ โดยการสัมผัสโลโก้ Tag On ของเครื่องใช้ไฟฟ้า LG เข้ากับสมาร์ตโฟนที่มี NFC


Smart Diagnosis

หากคุณใช้ฟังก์ชัน Smart Diagnosis คุณจะได้รับข้อมูลที่มีประโยชน์ เช่น วิธีการที่ถูกต้องในการใช้งานผลิตภัณฑ์โดยอิงจากรูปแบบการใช้งาน

SMART DIAGNOSIS™

เนื้อหานี้ใช้เฉพาะกับรุ่นที่มีโลโก้  บนผลิตภัณฑ์เท่านั้น
ใช้ฟังก์ชันนี้หากคุณต้องการการวินิจฉัยที่แม่นยำ
โดยศูนย์ข้อมูลลูกค้า LG Electronics เมื่อผลิตภัณฑ์ทำงาน
ผิดปกติหรือล้มเหลว

Smart Diagnosis™ ไม่สามารถเปิดใช้งานได้เว้นแต่เครื่องใช้
ไฟฟ้าจะถูกเปิดโดยการกดปุ่ม **Power** หากเครื่องใช้ไฟฟ้าไม่
สามารถเปิดใช้งานได้ จะต้องทำการแก้ไขปัญหาโดยไม่มี
การใช้ Smart Diagnosis™



หมายเหตุ

- ประสิทธิภาพการทำงานของฟังก์ชัน Smart Diagnosis™ ขึ้นอยู่กับคุณภาพการโทรในพื้นที่
- ประสิทธิภาพในการสื่อสารจะดีขึ้น และจะได้รับการที่ดีขึ้น หากคุณใช้โทรศัพท์บ้าน
- ฟังก์ชัน Smart Diagnosis™ จะใช้เมื่อทำการติดต่อตัวแทนฝ่ายบริการลูกค้าเท่านั้น

การใช้ Smart Diagnosis™

Smart Diagnosis™ ใช้สมาร์โฟน

- 1** เปิดเครื่องและถือโทรศัพท์ไว้ใกล้กับโลโก้ของ Smart Diagnosis™
 - ตรวจสอบให้แน่ใจว่าช่องพูดของโทรศัพท์หันเข้าหาโลโก้ของ Smart Diagnosis™
- 2** กดปุ่ม **AMBIENT** และ **CONT.** เป็นเวลา 3 วินาทีเพื่อใช้งานฟังก์ชัน Smart Diagnosis™
- 3** ย้ายขั้วโทรศัพท์ออกจากผลิตภัณฑ์ในขณะที่กำลังทำการส่งข้อมูล
- 4** หลังการส่งข้อมูลเสร็จสิ้น รับคำอธิบายเกี่ยวกับผลการวินิจฉัยจากตัวแทนฝ่ายบริการลูกค้า
 - ปุ่มทั้งหมดบนแผงควบคุมจะสว่างในขณะที่กำลังทำการส่งข้อมูล เมื่อการส่งข้อมูลเสร็จสิ้น ปุ่มจะกลับสู่สถานะเริ่มต้น รับคำอธิบายเกี่ยวกับผลการวินิจฉัยจากตัวแทนฝ่ายบริการลูกค้าและดำเนินการที่เหมาะสม

การแก้ปัญหา

อาการ	สาเหตุ	การแก้ไข
น้ำมีรสแปลก	ปิดเครื่องอยู่หรือไม่	<ul style="list-style-type: none"> กดปุ่ม Power บนแผงควบคุมเพื่อเปิดเครื่อง
	คุณปล่อยเครื่องกรองน้ำไว้เป็นระยะเวลา เวลานานโดยไม่มีการใช้งานหรือไม่	<ul style="list-style-type: none"> รสชาติของน้ำอาจเปลี่ยนแปลงเมื่อมีอายุมากขึ้นเนื่องจากการเพิ่มจำนวนของแบคทีเรีย ใช้เครื่องกรองน้ำหลังจากทำการจ่ายน้ำเย็น น้ำร้อน และน้ำที่อุณหภูมิห้อง ตามลำดับเป็นเวลา 10 นาที
	เป็นเวลานานแล้วหรือไม่ตั้งแต่คุณติดตั้งและเปลี่ยนไส้กรอง	<ul style="list-style-type: none"> หากใช้งานไส้กรองที่หมดอายุ ประสิทธิภาพการกรองอาจลดลง แนะนำให้เปลี่ยนไส้กรองตามระยะเวลาการเปลี่ยนไส้กรอง
ปริมาณการกรองลดลงอย่างกะทันหัน	นี่เป็นเวลาที่ต้องทำการเปลี่ยนไส้กรองใช่หรือไม่	<ul style="list-style-type: none"> ทำการขอการเปลี่ยนไส้กรอง
	วาล์วแหล่งจ่ายน้ำปิดอยู่หรือไม่	<ul style="list-style-type: none"> เปิดวาล์วแหล่งจ่ายน้ำ
ไม่มีการจ่ายน้ำ	คุณไม่ได้ทำการเปลี่ยนไส้กรองตามระยะเวลาการเปลี่ยนใช่หรือไม่	<ul style="list-style-type: none"> ทำการขอการเปลี่ยนไส้กรอง
	วาล์วแหล่งจ่ายน้ำปิดอยู่หรือไม่	<ul style="list-style-type: none"> เปิดวาล์วแหล่งจ่ายน้ำ
	ปลั๊กไฟถูกถอดออกจากเต้ารับหรือไม่	<ul style="list-style-type: none"> เสียบปลั๊กไฟในเต้ารับอย่างถูกต้อง
	ไม่มีการจ่ายน้ำเมื่อคุณกดปุ่มจ่ายน้ำหรือไม่	<ul style="list-style-type: none"> ติดต่อศูนย์บริการ LG Electronics

อาการ	สาเหตุ	การแก้ไข
<p>ไม่มีการจ่ายน้ำเย็น น้ำร้อน หรือน้ำที่อุณหภูมิห้อง ออกมา</p>	<p>คุณปิดฟังก์ชันที่เกี่ยวข้องหรือไม่</p>	<ul style="list-style-type: none"> เปิดใช้ฟังก์ชันที่เกี่ยวข้อง
	<p>คุณได้จ่ายน้ำเย็นปริมาณมากหรือไม่</p>	<ul style="list-style-type: none"> หากคุณได้จ่ายน้ำเย็นปริมาณมากจะทำให้มีน้ำในถังเก็บน้อย น้ำเย็นอาจไม่ถูกจ่ายออกมา รอสักครู่จนน้ำเต็มภายในถังเก็บแล้วจึงใช้งาน (ใช้กับรุ่นที่มีถังเก็บเท่านั้น) หากคุณจ่ายน้ำเย็นปริมาณมากในทีเดียว อุณหภูมิของน้ำเย็นในถังน้ำเย็นจะสูงขึ้น รอสักครู่จนน้ำเย็นขึ้นแล้วจึงใช้งาน (ใช้กับรุ่นที่มีถังทำความเย็นเท่านั้น)
	<p>คุณจ่ายน้ำร้อนปริมาณมากหรือไม่</p>	<ul style="list-style-type: none"> หากคุณจ่ายน้ำร้อนปริมาณมากในทีเดียว อุณหภูมิของน้ำร้อนในถังน้ำร้อนจะลดลงและน้ำอุ่นอาจถูกจ่ายออกมา รอสักครู่จนน้ำร้อนขึ้นแล้วจึงใช้งาน (ใช้กับรุ่นที่มีถังน้ำร้อนเท่านั้น)
	<p>คุณจ่ายน้ำที่อุณหภูมิห้อง ปริมาณมากหรือไม่</p>	<ul style="list-style-type: none"> หากคุณได้จ่ายน้ำกรองในปริมาณมาก (รวมถึงน้ำที่อุณหภูมิห้อง) จะทำให้มีน้ำกรองในถังเก็บน้อย น้ำกรองอาจไม่ถูกจ่ายออกมา รอสักครู่จนน้ำเต็มภายในถังเก็บแล้วจึงใช้งาน (ใช้กับรุ่นที่มีถังเก็บเท่านั้น)

อาการ	สาเหตุ	การแก้ไข
<p>ผลิตภัณฑ์เสียงดังและมีเสียงผิดปกติ</p>	<p>ผลิตภัณฑ์ได้รับการติดตั้งบนพื้นที่ไม่แข็งแรงหรือบนพื้นที่ไม่มั่นคงหรือไม่</p> <p>ด้านหลังของผลิตภัณฑ์สัมผัสกับผนังหรือไม่</p> <p>มีวัตถุวางอยู่ที่ด้านบนของผลิตภัณฑ์หรือไม่</p>	<ul style="list-style-type: none"> ติดตั้งผลิตภัณฑ์ในตำแหน่งที่มีพื้นราบและเสมอกัน ปรับตำแหน่งการติดตั้งเพื่อให้แน่ใจว่ามีช่องว่างรอบผลิตภัณฑ์เพียงพอ (10 ซม.) นำวัตถุออกจากด้านบนของผลิตภัณฑ์
<p>ไม่มีน้ำแข็งจับตัวในผลิตภัณฑ์ (ใช้กับรุ่นที่มีฟังก์ชันทำน้ำแข็งเท่านั้น)</p>	<p>ฝาครอบเครื่องทำน้ำแข็งเปิดอยู่หรือไม่</p> <p>ผ่านไปแล้ว 6 ชั่วโมงนับตั้งแต่ได้รับการจ่ายน้ำก๊อกและไฟฟ้าหรือไม่</p>	<ul style="list-style-type: none"> ใส่ฝาครอบเครื่องทำน้ำแข็ง ใช้ผลิตภัณฑ์หลังจาก 6 ชั่วโมงนับตั้งแต่จ่ายน้ำก๊อกและไฟฟ้าครั้งแรก
<p>มีเศษฝุ่นละเอียดในน้ำกรอง</p>	<p>มีฟองอากาศเกิดขึ้นหรือไม่</p>	<ul style="list-style-type: none"> ฟองอากาศอาจเกิดขึ้นในกระบวนการระบายแต่น้ำก็ยังคงปลอดภัยสำหรับการดื่มของคุณ หากยังมีเศษฝุ่นละเอียดหลังจากคุณนำน้ำออกจากเครื่องกรองน้ำแล้วเป็นเวลาหลายนาที ให้ตัดการจ่ายน้ำก๊อกและปิดเครื่อง แล้วติดต่อศูนย์บริการ LG Electronics

ใบรับประกัน

เครื่องกรองน้ำแอลจี

ใบรับประกันนี้มีผลเฉพาะผลิตภัณฑ์ที่ขายโดยแอลจี
อิเล็กทรอนิกส์ในตลาดในประเทศไทยเท่านั้น

www.lg.com/th

ข้อมูลผู้ซื้อ

ชื่อของผู้ซื้อ

ที่อยู่

เมือง

รัฐ

รหัสพิน

หมายเลขรุ่น

หมายเลขซีเรียล

วันที่ซื้อ

เลขที่ใบกำกับภาษี

ตราประทับผู้ขาย

ตราประทับ

ข้อมูลผู้ขาย

ชื่อผู้ขาย

ที่อยู่

เมือง

รัฐ

รหัสพิน

ใบรับประกันนี้ไม่สามารถส่งต่อและใช้ได้เฉพาะผู้
ชื่อเท่านั้น

กรอกข้อมูลนี้และเก็บรักษาไว้รวมกันกับใบปะหน้า
สินค้าในที่ปลอดภัย
หากคุณต้องการการบริการภายใต้การรับประกันนี้
กรุณาติดต่อเรา

LG ELECTRONICS Tai PVT. LTD. เป็นผู้รับผิดชอบการรับประกันนี้

ข้อกำหนดของการรับประกัน

หากผลิตภัณฑ์แอลจีของคุณเสียหายเนื่องจากความบกพร่องในวัสดุหรือการผลิตภายใต้การใช้ในครัวเรือนในระหว่างช่วงเวลาการรับประกัน ดังรายการด้านล่าง บริษัทจะซ่อมหรือเปลี่ยนผลิตภัณฑ์โดยพิจารณาจากใบเสร็จหรือหลักฐานของการขายปลีกรั้งเดิม

การรับประกันนี้จะใช้ได้เฉพาะสำหรับการซื้อที่ร้านค้าปลีกของผลิตภัณฑ์และใช้ได้เฉพาะกับสินค้าที่ขายในประเทศไทยโดย บริษัท ตัวแทนจำหน่าย

ช่วงเวลาการรับประกัน

เครื่องกรองน้ำแอลจีมาพร้อมกับการรับประกัน 1 ปีจากวันที่ซื้อ การรับประกัน 1 ปี ครอบคลุมชิ้นส่วนทุกชิ้น (ยกเว้นวัสดุสิ้นเปลือง -- ไส้กรองด้านในทั้งหมด ชิ้นส่วนพลาสติก) พร้อมทั้งไม่รับประกันที่ประตูปรับทราย ลงวันที่ และลายเซ็นของผู้จัดจำหน่ายที่ได้รับอนุญาตของเรา

*ข้อสังเกต: หากวันที่ซื้อดั้งเดิมไม่สามารถพิสูจน์ได้จากหลักฐานในการซื้อ การรับประกันจะเริ่มขึ้น 3 เดือนหลังจากเดือนที่ผลิต ซึ่งอาจจะพิสูจน์ได้จากหมายเลขซีเรียลหรือบาร์โค้ดที่อยู่บนฉลากผลิตภัณฑ์

สิ่งที่การรับประกันครอบคลุม

LG Electronics Thailand Pvt.Ltd. (แอลจีประเทศไทย) ให้ความรับประกันสำหรับสินค้าที่ขายภายในอาณาเขตของประเทศไทยและการรับประกันว่าสินค้าที่เป็นอิสระจากข้อบกพร่องในวัสดุและฝีมือการผลิต, เป็นไปตามข้อกำหนดและเงื่อนไขดังต่อไปนี้

- การซ่อมภายใต้การรับประกันจะเกิดขึ้นโดยผู้ให้บริการที่ได้รับอนุญาตเท่านั้น รายละเอียดของการให้บริการจากศูนย์กลางอยู่ด้านหลัง
- ในกรณีของการซ่อมหรือการเปลี่ยนชิ้นส่วนใดของผลิตภัณฑ์ การรับประกันนี้จะยังดำเนินต่อไปและไม่มีผลเพียงในช่วงเวลาที่ยังไม่สิ้นสุดเวลาการรับประกันเท่านั้น การเปลี่ยนชิ้นส่วนขึ้นอยู่กับดุลพินิจของ แอลจีประเทศไทย ในกรณีของการเปลี่ยนทั้งผลิตภัณฑ์ที่เกิดขึ้น (ขึ้นอยู่กับดุลพินิจของ แอลจีประเทศไทย) การเปลี่ยนจะเกิดขึ้นกับผลิตภัณฑ์รุ่นเดียวกัน หากไม่มี ผลิตภัณฑ์รุ่นที่ใกล้เคียงกันซึ่งกำหนดโดย แอลจีประเทศไทย จะถูกนำมาทดแทน
- ในกรณีการซ่อม แอลจีประเทศไทย จะพยายามใช้ชิ้นส่วนใหม่ หากชิ้นส่วนใหม่ไม่สามารถนำมาใช้ได้ อย่างไรก็ตาม แอลจีประเทศไทย จะมีสิทธิในการใช้ชิ้นส่วนที่ทำขึ้นใหม่ การรับประกันในรุ่นที่เปลี่ยน หรือชิ้นส่วนที่ทำขึ้นใหม่จะมีผลจนถึงช่วงเวลาสิ้นสุดของการรับประกันจากการซื้อดั้งเดิม
- บริษัทหรือศูนย์บริการที่ได้รับอนุญาตมีสิทธิในการเก็บชิ้นส่วนหรือส่วนประกอบใด ๆ ที่เปลี่ยนจากดุลพินิจในกรณีของการค้นพบความเสียหายของอุปกรณ์ในระหว่างช่วงการรับประกัน
- บริษัทมีบริการตรวจสอบสภาพ บำรุงรักษา ใ้ 2 ครั้ง โดยจะมีบริการ อิเล็กทรอนิกส์ สดุดอร์ไลซิง ให้ในแต่ละครั้ง และจะมีการเปลี่ยนตัวกรอง ไส้กรองพรีคาร์บอน หรือ ไส้กรองตะกอน ให้ปีละครั้ง

- หากสีของส่วนประกอบภายนอกหรือภายในเปลี่ยนไป แอลจีประเทศไทย ตัดสินใจจะใช้สีที่เข้ากันกับชิ้นส่วนดั้งเดิมหรือชิ้นส่วนอื่น เจดสี ลาย หรือสีพื้นที่ถูกเปลี่ยนอาจแตกต่างกันไปตามสินค้าของลูกค้าขึ้นอยู่กับวิธีการใช้อย่างต่อเนื่องของสินค้า จะคิดเงินเมื่อมีส่วนประกอบที่ได้รับการเปลี่ยนตามคำขอของลูกค้ามากกว่าชิ้นส่วนที่จำเป็นจริง ๆ
- การรับประกันนี้จะถูกยกเลิกโดยอัตโนมัติตามช่วงเวลาของการสิ้นสุดการรับประกันด้านบน แม้ว่าผลิตภัณฑ์แอลจีอาจจะไม่ได้ถูกใช้งานเลยในระหว่างช่วงเวลาการรับประกันไม่ว่าด้วยเหตุผลใด ๆ ก็ตาม

สิ่งที่การรับประกันไม่ครอบคลุม

- ค่าธรรมเนียมของวิศวกรบริการสำหรับสินค้าที่ติดตั้งอยู่นอกเหนือเขตพื้นที่ของขอบเขตการดูแลจัดการของศูนย์บริการที่ได้รับอนุญาตของบริษัท ค่าใช้จ่ายทั้งหมดที่เกิดขึ้นในการรวบรวมสินค้าหรือชิ้นส่วนที่มาจากการศูนย์บริการที่ได้รับอนุญาตของบริษัท เช่นเดียวกับค่าใช้จ่ายที่เกิดจากบริการของช่างเทคนิคหรือบุคคลผู้ให้บริการแทนสำหรับการขนส่งหรืออุบัติเหตุอื่น ๆ จะเป็นค่าใช้จ่ายที่รับผิดชอบโดยลูกค้า ค่าธรรมเนียมการขนส่งภายในท้องถิ่นและค่าธรรมเนียมการขนย้ายจะแตกต่างกันไปตามสถานที่ ลูกค้าจะได้รับคำแนะนำเพื่อตรวจสอบก่อนล่วงหน้า หากลูกค้าต้องการนำสินค้าไปยังศูนย์บริการที่ได้รับอนุญาตด้วยตนเองจะถือเป็นความเสี่ยงและผลลัพธ์ที่ลูกค้าต้องรับผิดชอบด้วยตนเอง
- การติดตั้งใหม่หรือการถอนการติดตั้งผลิตภัณฑ์ขึ้นอยู่กับความต้องการของลูกค้า จะมีการคิดค่าธรรมเนียมหากใช้วัสดุที่พบ
- ค่าขนส่งในกรณีที่ลูกค้าเคลื่อนย้ายผลิตภัณฑ์ไปยังสถานที่อื่น
- ผลของความเสียหายที่เกิดจากการใช้ผลิตภัณฑ์ในสภาพอากาศที่มีการกัดกร่อนหรือปฏิบัติตรงข้ามกับคำแนะนำที่มีในคู่มือผู้ใช้
- การรับประกันนี้ไม่ครอบคลุมถึงการเปลี่ยนไส้กรองด้านในทั้งหมด (ไส้กรองตะกอน พรี คาร์บอน โพลีคาร์บอน เมมเบรน RO)
- ความเสียหายต่อผลิตภัณฑ์ที่เกิดจากอุบัติเหตุ แมลงและพยาธิ ฟ้าผ่า ลม ไฟ น้ำท่วม หรือภัยพิบัติตามธรรมชาติ
- ความเสียหายที่มาจากการใช้ที่ไม่ถูกต้อง การใช้ในทางที่ผิด การติดตั้ง การซ่อมแซมหรือการดูแลรักษาที่ไม่ถูกต้อง การซ่อมแซมที่ไม่ถูกต้องรวมถึงการใช้ชิ้นส่วนอื่นนอกเหนือไปจากที่รับรองโดย แอลจีประเทศไทย
- ความเสียหายหรือความผิดพลาดที่มีผลมาจากการดัดแปลงหรือเปลี่ยนแปลงแก้ไขโดยไม่ได้รับอนุญาตหรือการใช้เพื่อจุดประสงค์อื่นนอกเหนือจากที่ระบุหรือการรื้อของนำในกรณีที่สินค้าได้รับการติดตั้งที่ไม่ถูกต้อง
- ความเสียหายหรือความผิดพลาดที่มาจากกระแสไฟฟ้า ก่าลังไฟฟ้าที่ไม่ถูกต้องหรือบริการด้านไฟฟ้าที่ไม่เพียงพอ การใช้เชิงพาณิชย์หรืออุตสาหกรรม หรือการใช้อุปกรณ์เสริมหรือส่วนประกอบที่ลอกเลียนแบบหรือผลิตภัณฑ์ที่ทำความสะอาดที่ไม่ได้รับการรับรองจาก แอลจีประเทศไทย
- ความเสียหายที่เกิดขึ้นจากการขนส่งและการเคลื่อนย้าย อาทิ รอยขีดข่วน รอยบุบ รอยบิ่น และหรือความเสียหายอื่นๆ ที่มีต่อผลิตภัณฑ์ชิ้นสุดท้าย
- สินค้าที่เสียหายหรือสูญหายในการจัดส่ง กล่องเปิด ลวดราคา หรือผลิตใหม่
- อุปกรณ์เสริมหรือสำหรับติดตั้งด้านนอกของผลิตภัณฑ์
- ความเสียหายต่อผลิตภัณฑ์หากลูกค้าซ่อมผลิตภัณฑ์โดยผู้ขายหรือบุคคลที่ไม่ได้รับอนุญาต
- การเคลื่อนย้าย ทำลาย หรือเปลี่ยนแปลงแก้ไขจากหมายเลขซีเรียลหรือจลาจลคุณสมบัติบนเครื่องหรือส่วนประกอบใด ๆ

LG Electronics (Thailand) Co., Ltd.
75/81 อาคารชิดมอนด์ ชั้น 22 สุขุมวิท 26 ถ.สุขุมวิท
คลองตัน คลองเตย กรุงเทพฯ 10110
www.lg.com/th



บันทึก

บันทึก

บันทึก

