



SIMPLE MANUAL

# GAMING SPEAKER

---

GP9



MFL71805579

2203\_Rev01

[www.lg.com](http://www.lg.com)

Copyright © 2021-2022 LG Electronics Inc.

All Rights Reserved.




Download Manual

<Android>

<iOS>



Download App




## ENGLISH


# Connecting and Using the Speaker

- 1 Charge the speaker before using it by opening the rear cover and connecting the speaker to the charging adapter.

- 2 Connect the speaker to the PC via a USB cable

\* If there is no audio output when the speaker and device (PS4/PS5/PC, etc.) are connected with a USB cable, turn off the UAC 2.0 option in the XBOOM App or PC App menu. The setting is applied when the speaker is turned off and then on.


- 1 Connect the speaker to the PC via a USB C-type cable.
- 2 Press the **Power**  button on the speaker to turn it on.


- 3 Press the **Function**  button on the speaker repeatedly until the Function LED turns white.

- ! If you are using a voice chat through integrated microphone or headset, press the **Microphone**  button.

- 3 **Connect the speaker to the Game Console via an optical cable**


- 1 Connect the speaker to the Game Console via an optical cable.

- 2 Press the **Power**  button on the speaker to turn it on.


- 3 Press the **Function**  button on the speaker repeatedly until the Function LED turns red.


- 4 **Connect the speaker to a smartphone via Bluetooth**


- 1 Press the **Power**  button on the speaker to turn it on.

- 2 Press the **Function**  button on the speaker repeatedly until the Function LED flashes blue.

- ③ Press the **Settings**  button on the smartphone and select **Bluetooth** . Turn on the Bluetooth function.  
(Off  > On )
  - ④ Find "LG-GP9 (XX)" on the device list on the smartphone and connect to it. Once the smartphone is connected via Bluetooth, the Function LED turns blue.
  - ⑤ On the smartphone, play a music of your choice.
- 5 Connecting the LG XBOOM App**
- ① Find **LG XBOOM** app on the **Google Play** or **App Store** and install it on your smartphone.
  - ② Run the **LG XBOOM** app and use more features (EQ, Voice Chat, Setting etc.)
- ⓘ For EQ of Headset mode, the sound effects button on the top of the product may be different depending on the product S/W version.

- After product S/W update, you can use the DTS Headphone: X or Custom EQ with the EQ button while the **Headset**  button is On. FPS or RTS cannot be selected in Headset mode.

Press and hold the **Headset**  button for 2 seconds to turn the front lighting on or off.

- ✦ For using a headset or earphones connect it to the  terminal.

- Design and specifications are subject to change without notice.
- For more information, download the online owner's manual. <http://www.lg.com>

## ENGLISH

### Specification


#### Power Supply:

- 19 V  2.1 A (AC Adapter)
- Built-in rechargeable battery

#### Power consumption

- Refer to the main label.

#### AC adapter

- Model: ADS-45SN-19-2 19040G
- Manufacturer: SHENZHEN HONOR ELECTRONIC CO.,LTD
- Input: 100 - 240 V ~ 50/60 Hz 1.2 A
- Output: 19 V  2.1 A

#### Dimensions (W x H x D):

Approx. 376 mm x 86 mm x 108 mm

Operating Temperature: 5 °C to 35 °C

Operating Humidity: 5 % to 60 %

#### Attaching the ferrite core (optional)

Wind the headset's wire once around the ferrite core.



### Safety Information

**CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.**



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

**WARNING:**

- TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.
- Do not install this equipment in a confined space such as a book case or similar unit.
- This unit contains magnets which can be harmful to some kind of object (Ex : Magnetic card, Pacemaker etc.).

**CAUTION:**

- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings should never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.
- The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- To avoid fire or electric shock, do not open the unit. contact a qualified personnel only.
- Do not leave the unit in a place near the heating appliances or subject to direct sunlight, moisture, or mechanical shock.
- The Power Plug is the disconnecting device. In case of an emergency, the Power Plug must remain readily accessible.
- To clean the unit, use a soft, dry cloth. If the surfaces are extremely dirty, use a soft cloth lightly moistened with a mild detergent solution. Do not use strong solvents such as alcohol, benzine, or thinner, as these might damage the surface of the unit.
- Do not use volatile liquids such as insecticide spray near the unit. Wiping with strong pressure may damage the surface. Do not leave rubber or plastic products in contact with the unit for a long period of time.
- Do not place the unit over the vehicle's air bag. When the air bag deploys, it may result in injury. Before using in the car, fix the unit.
- Do not use the handsfree function during driving a car.

- Do not leave the unit on an unstable place such as high shelves. It may fall down because of the vibration of the sound.
- Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock.







**CAUTION when using this product in environments of low humidity.**

- It may cause static electricity in environments of low humidity.
- It is recommended to use this product after touching any metal object which conducts electricity.

**NOTICE:** For safety marking information including product identification and supply ratings, please refer to the main label on the bottom or the other surface of the product.

**CAUTION:** Only use the AC adapter supplied with this device. Do not use a power supply from another device or another manufacturer. Using any other power cable or power supply may cause damage to the device and void your warranty.

**Symbols**

	Refers to alternating current (AC).
	Refers to direct current (DC).
	Refers to class II equipment.
	Refers to stand-by.
	Refers to "ON" (power).
	Refers to dangerous voltage.

#### **For models using a built-in battery**

Do not store or transport at pressures lower than 11.6 kPa and at above 15,000 m altitude.

- replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types);
- disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
- leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and
- a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

#### **For models using a battery**

This device is equipped with a portable battery or accumulator.

**CAUTION:** Risk of fire or explosion if the battery is replaced by an incorrect type.

#### **How to Safely remove the batteries or the battery pack from the equipment:**

Remove the old batteries or battery pack, follow the assembly steps in reverse order. To prevent contamination of the environment and bring on possible threat to human and/or animal health, the old batteries or the battery pack must be put in an appropriate container at designated collection points. Do not dispose of batteries or battery pack together with other waste. It is recommended that you use local, free reimbursement systems batteries or battery packs, (may not be available in your area). The batteries or the battery pack should not be exposed to excessive heat such as sunshine, fire or the like.

**POWER:** This unit operates on a mains supply of 100 - 240 V ~ 50/60 Hz.

**Wiring:** This unit is supplied with a BS 1363 approved main plug. When replacing the fuse, always use a fuse of the same rating and approved to BS 1362. Never use this plug with the fuse cover omitted. To obtain a replacement fuse cover contact your dealer. If the type of plug supplied is not suitable for the mains sockets in your home, then the plug should be removed and a suitable type fitted. Please refer to the wiring instructions below:

**Warning:** A mains plug removed from the mains lead of this unit must be destroyed. A mains plug with bared wires is hazardous if inserted in a mains socket. Do not connect either wire to the earth pin, marked with the letter E or with the earth symbol  $\perp$  or coloured green or green and yellow. If any other plug is fitted, use same rating of fuse in the plug.

**Important:** The wires in this mains lead are coloured in accordance with the following codes:

- **BLUE: NEUTRAL, BROWN: LIVE** - As the colours of the wires in the mains lead of this unit may not correspond with the coloured marking identifying the terminals in your plug, proceed as follows: The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black. The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.



